

AIR CONDITIONER

Item		Specification			
		1.6,2.0 Engine (Gasoline)		1.6, 2.0 Engine (Diesel)	
Compressor	Type	VS16M(Variable Displacement Swashplate)			
	Oil type & Capacity	FD46XG (PAG), 150 ± 10cc			
	Pulley type	1.6	2.0	1.6	2.0
		6PK type	4PK type	5PK type	6PK type
	Displacement	160cc/rev			
Condenser	Heat rejection	13,400 - 5% kcal/hr		12,300 -5% kcal/hr	
	Dessicant specification & weight	XH-9 , 50g			
APT(A/C pressure transducer)	The method to measure the pressure	Voltage = 0.00878835 * Pressure + 0.37081095 [PSIA]			
Expansion valve	Type	Block			
Refrigerant	Type	HFC-134a(R-134a)			
	Capacity [oz.(g)]	17.6 ± 0.88 (500 ± 25)			

BLOWER UNIT

Item		Specification
Fresh and recirculation	Operating method	Actuator
Blower	Type	Sirocco
	Speed step	Auto + 8 speed (Automatic), 1-16 speed (Manual)
	Speed control	Power mosfet
Air filter	Type	Particle filter

HEATER AND EVAPORATOR UNIT

Item		Specification
Heater	Type	AL BRAZING TYPE
	Heating capacity	4300 ± 5% kcal/hr
	PTC heater capacity	1000W + 5%/-10%
	Mode operating method	Actuator
	Temperature operating method	Actuator
Evaporator	Temperature control type	Evaporator temperature sensor
	A/C ON/OFF [°C(°F)]	ON : 2.8 (37) OFF: 1.3 (34.3)

TROUBLESHOOTING

Problem Symptoms Table

Before replacing or repairing air conditioning components, first determine if the malfunction is due to the refrigerant charge, air flow or compressor.

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

After correcting the malfunction, check the complete system to ensure that performance is satisfactory.

Standard:

Symptom	Suspect Area	See page
No blower operation	1. Blower fuse	
	2. Blower relay	
	3. Blower motor	
	4. Power mosfet	
	5. Blower speed control switch	
	6. Wire harness	
No air temperature control	1. Engine coolant capacity	
	2. Heater control assembly	
No compressor operation	1. Refrigerant capacity	
	2. A/C Fuse	
	3. Magnetic clutch	
	4. Compressor	
	5. A/C pressure transducer	
	6. A/C switch	
	7. Evaporator temperature sensor	
	8. Wire harness	
No cool comes out	1. Refrigerant capacity	
	2. Refrigerant pressure	
	3. Drive belt	
	4. Magnetic clutch	
	5. Compressor	
	6. A/C pressure transducer	
	7. Evaporator temperature sensor	
	8. A/C switch	
	9. Heater control assembly	
	10. Wire harness	
	1. Refrigerant capacity	
	2. Drive belt	
	3. Magnetic clutch	

Insufficient cooling	4. Compressor	English ▼
	5. Condenser	
	6. Expansion valve	
	7. Evaporator	
	8. Refrigerant lines	
	9. A/C pressure transducer	
	10. Heater control assembly	
No engine idle-up when A/C switch ON	1. Engine ECM	
	2. Wire harness	
No air inlet control	1. Heater control assembly	
No mode control	1. Heater control assembly	
	2. Mode actuator	
No cooling fan operation	1. Cooling fan fuse	
	2. Fan motor	
	3. Engine ECM	
	4. Wire harness	

SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
09977-29000 Disc & hub assembly bolt remover		Removal and installation of the disc & hub assembly bolt

INSTRUCTIONS


When Handling Refrigerant

1. R-134a liquid refrigerant is highly volatile. A drop on the skin of your hand could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
2. It is standard practice to wear goggles or glasses to protect your eyes, and gloves to protect your hands. If the refrigerant splashes into your eyes, wash them with clean water immediately.
3. The R-134a container is highly pressurized. Never leave it in a hot place, and check that the storage temperature is below 52°C (126°F).
4. An electronic leak detector should be used to check the system for refrigerant leakage. Bear in mind that the R-134a, upon coming into contact with flame, produces phosgene, a highly toxic gas.
5. Use only recommended the lubricant for R-134a systems. If lubricants other than the recommended one used, system failure may occur.
6. PAG lubricant absorbs moisture from the atmosphere at a rapid rate, therefore the following precautions must be observed:
 - When removing refrigerant components from a vehicle, cap immediately the components to prevent from the entry of moisture.
 - When installing refrigerant components to a vehicle, do not remove the cap until just before connecting the components.
 - Complete the connection of all refrigerant tubes and hoses without delay to prevent the A/C system from taking on moisture.
 - Use the recommended lubricant from a sealed container only.
7. If an accidental discharge in the system occurs, ventilate the work area before resuming service.



When Replacing Parts On A/c System


1. Never open or loosen a connection before discharging the system.
2. Seal the open fittings of components with a cap or plug immediately to prevent intrusion of moisture or dust.
3. Do not remove the sealing caps from a replacement component until it is ready to be installed.
4. Before connecting an open fitting, always install a new sealing ring. Coat the fitting and seal with refrigerant oil before making the connection.



WHEN INSTALLING CONNECTING PARTS

FLANGE WITH GUIDE PIN

Check the new O-ring for damage (use only the specified) and lubricate it using compressor oil. Tighten the nut to specified torque.



Size	Tightening torque [N.m (kg.m, lbf.ft)]	
	General bolt, nut	
	4T	7T
M6	5 - 6 (0.5 - 0.6, 3.6 - 4.3)	9 - 11 (0.9 - 1.1, 6.5 - 7.9)
M8	12 - 14 (1.2 - 1.4, 8.7 - 10)	20 - 26 (2.0 - 2.6, 14 - 18)
M10	25 - 28 (2.5 - 2.8, 18 - 20)	45 - 55 (4.5 - 5.5, 32 - 39)
Size	Flange bolt, nut	
	4T	7T
	4T	7T
M6	5 - 7 (0.5 - 0.7, 3.6 - 5.0)	8 - 12 (0.8 - 1.2, 5.8 - 8.6)
M8	10 - 15 (1.0 - 1.5, 7 - 10)	19 - 28 (1.9 - 2.8, 14 - 20)
M10	21 - 31 (2.1 - 3.1, 15 - 22)	39 - 60 (3.9 - 6.0, 28 - 43)


Handling Tubing And Fittings

The internal parts of the refrigeration system will remain in a state of chemical stability as long as pure moisture-free refrigerant and refrigerant oil are used. Abnormal amounts of dirt, moisture or air can upset the chemical stability and cause problems or serious damage.


The Following Precautions Must Be Observed



1. When it is necessary to open the refrigeration system, have everything you will need to service the system ready so the system will not be left open any longer than necessary.
2. Cap or plug all lines and fittings as soon as they are opened to prevent the entrance of dirt and moisture.
3. All lines and components in parts stock should be capped or sealed until they are ready to be used.
4. Never attempt to rebind formed lines to fit. Use the correct line for the installation you are servicing.
5. All tools, including the refrigerant dispensing manifold, the gauge set manifold and test hoses, should be kept clean and dry.

REFRIGERATION CYCLE




COMPONENT LOCATION INDEX





Manual heater & A/C controller



Manual heater & A/C controller

REFRIGERANT SYSTEM SERVICE BASICS

Refrigerant Recovery

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

⚠ CAUTION



- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant

Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



2. Measure the amount of refrigerant oil removed from the A/C system after the recovery process is completed. Be sure to install the same amount of new refrigerant oil back into the A/C system before charging.

System Evacuation

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

⚠ CAUTION


- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

English ▼

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using an R-134a refrigerant Recovery/Recycling/Charging System. (If the system has been open for several days, the receiver/dryer should be replaced, and the system should be evacuated for several hours.)
2. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



3. If the low-pressure does not reach more than 93.3 kPa (700 mmHg, 27.6 in.Hg) in 10 minutes, there is probably a leak in the system. Partially charge the system, and check for leaks (see Leak Test.).
4. Remove the low pressure valve from the low-pressure service port.

SYSTEM CHARGING

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.


⚠ CAUTION

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) as shown, following the equipment manufacturer's instructions.



2. Add the same amount of new refrigerant oil to system that was removed during recovery. Use only specified refrigerant oil. Charge the system with 17.6 ± 0.88 (500 $\pm$ 25) of R-134a refrigerant. Do not overcharge the system the compressor will be damaged.

Refrigerant Leak Test


Always conduct a leak test with an electronic leak detector whenever leakage or refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening or connection fittings.

NOTICE


In order to use the leak detector properly, read the manual supplied by the manufacturer.

If a gas leak is detected, proceed as follows:


1. Check the torque on the connection fittings and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector (A).
2. If leakage continues even after the fitting has been tightened, discharge the refrigerant from the system, disconnect the fittings, and check their seating faces for damage. Always replace, even if the damage is slight.
3. Check the compressor oil and add oil if required.
4. Charge the system and recheck for gas leaks. If no leaks are found, evacuate and charge the system again.



COMPONENT LOCATION



COMPONENTS




1. Bolt
2. Disc & hub assembly
3. Shim (Gap washer)
4. Retainer ring (Pulley)
5. Pulley


6. Retainer ring (Field coil)
7. Field coil
8. Screw
9. Connector bracket
10. Compressor assembly

REMOVAL

1. If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
2. Disconnect the negative cable from the battery.
3. Recover the refrigerant with a recovery/charging station.
4. Loosen the drive belt.
5. Remove the bolts, then disconnect the suction line (A) and discharge line (B) from the compressor. Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.




6. Disconnect the compressor clutch connector, and then remove 4 mounting bolts and the compressor (A).



INSTALLATION

1. Make sure of the length of compressor mounting bolts, and then tighten it A→B→C→D order.

Bolt	R,U,D Engine	β Engine
A	100 mm (3.93 in.)	125 mm (4.92in.)
B	100 mm (3.93in.)	109 mm (4.29in.)
C	109 mm (4.29in.)	125 mm (4.92in.)
D	100 mm (3.93in.)	109 mm (4.29in.)




2. Install in the reverse order of removal, and note these items.

- If you're installing a new compressor, drain all the refrigerant oil from the removed compressor, and measure its volume. Subtract the volume of drained oil from 150cc(5.07 oz.) the result is the amount of oil you should drain from the new compressor (through the suction fitting).
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- To avoid contamination, do not return the oil to the container once dispensed, and never mix it with other refrigerant oils.
- Immediately after using the oil, replace the cap on the container and seal it to avoid moisture absorption.
- Do not spill the refrigerant oil on the vehicle; it may damage the paint; if the refrigerant oil contacts the paint, wash it off immediately.
- Adjust the drive belt.
- Charge the system and test its performance.

INSPECTION

1. Check the plated parts of the disc & hub assembly (A) for color changes, peeling or other damage. If there is damage, replace the clutch set.
2. Check the pulley (B) bearing play and drag by rotating the pulley by hand. Replace the clutch set with a new one if it is noisy or has excessive play/drag.




3. Measure the clearance between the pulley (B) and the disc & hub assembly (A) all the way around. If the clearance is not within specified limits, remove the disc & hub assembly and add or remove shim (gap washer) as needed to increase or decrease clearance.

Clearance : $0.45 \pm 0.1\text{mm}$ (0.018 ± 0.004 in.)

NOTICE


The shims (gap washers) are available in seven thicknesses: 0.7mm, 0.8mm, 0.9mm, 1.0mm, 1.1mm, 1.2mm and 1.3mm.



4. Check operation of the magnetic clutch.

Connect the compressor side terminals to the battery (+) terminal and the ground battery (-) terminal to the compressor body.


Check the magnetic clutch operating noise to determine the condition.




DISASSEMBLY

1. Remove the center bolt (A) while holding the disc & hub assembly with a commercially available disc & hub assembly bolt remover; Special tool number 09977-29000.

TORQUE : 10~15N.m (1.02~1.53kgf.m, 7.37~11lb.ft)




2. Remove the disc & hub assembly (A) and shim (gap washer) (B), taking care not to lose the shims. If the clutch needs adjustment, increase or decrease the number and thickness of shims as necessary, then reinstall the disc & hub assembly, and recheck its clearance (Refer to HA-20).




3. If you remove the field coil, remove retainer ring (A) with retainer ring pliers.

NOTICE

- Be careful not to damage the pulley (B) and compressor during removal/installation.
- Once retainer ring (A) is removed, replace it with a new one.



4. Remove the screw (A) from the field coil ground terminal. Remove the retainer ring (B) and then remove the field coil (C) from the shaft with a puller. Be careful not to damage the coil and compressor.



5. Reassemble the compressor clutch in the reverse order of disassembly, and note these items :
- Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
 - Install new retainer rings, and make sure they are fully seated in the groove.
 - Make sure that the pulley turns smoothly after its reassembled.

OIL SPECIFICATION

1. The HFC-134a system requires synthetic (PAG) compressor oil whereas the R-12 system requires mineral compressor oil. The two oils must never be mixed.
2. Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.

Handling of Oil

1. The oil should be free from moisture, dust, metal powder, etc.
2. Do not mix with other oil.
3. The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Compressor Oil absorbs moisture very easily.)
4. The compressor oil must be stored in steel containers, not in plastic containers.

Compressor oil check

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

Oil total volume in system:

150 ± 10cc (5.07 ± 0.34 fl.oz)

Oil Return Operation

There is close affinity between the oil and the refrigerant.

During normal operation, part of the oil recirculates with the refrigerant in the system. When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows:

1. Open all the doors and the engine hood.
2. Start the engine and air conditioning switch to "ON" and set the blower motor control knob at its highest position.
3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
4. Stop the engine.

Replacement of Component Parts

When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

Component parts to be installed	Amount of Oil
Evaporator	50 cc (1.70 fl.oz)
Condenser	30 cc (1.02 fl.oz)
Receiver/dryer	30 cc (1.02 fl.oz)
Refrigerant line (One piece)	10 cc (0.34 fl.oz)


For compressor replacement, subtract the volume of oil drained from the removed compressor from the specified volume, and drain the calculated volume of oil from the new compressor:

The specified volume - volume of removed compressor = volume to drain from the new compressor.

NOTICE

Even if no oil is drained from the removed compressor, don't drain more than 50cc from new compressor.

COMPONENT LOCATION



INSPECTION

1. Check the condenser fins for clogging and damage. If clogged, clean them with water, and blow them with compressed air. If bent, gently bend them using a screwdriver or pliers.
2. Check the condenser connections for leakage, and repair or replace it, if required.


REPLACEMENT

Condenser Assembly

1. Recover the refrigerant with a recovery/ recycling/ charging station.
2. Disconnect the negative (-) battery terminal.
3. Remove 2 nuts (A), and then disconnect the discharge line and liquid line from the condenser.
Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.
TORQUE: 7.8~11.7N.m (0.8~1.2kgf.m, 5.9~8.7lb.ft)



4. Remove the radiator (A).
(Refer to EM group - Radiator)
5. Remove 2 bolts, and then remove the condenser by lifting it up. Be careful not to damage the radiator and condenser fins when removing the condenser (B).



6. Install in the reverse order of removal, and note these items :
 - If you're installing a new condenser, add refrigerant oil ND-OIL8.
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be

sure to use the right O-rings for R-134a to avoid leakage.


English ▼

- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Charge the system, and test its performance.


Desiccant

1. Remove the condenser, and then remove the bottom cap (B) with L wrench (A) from the condenser.

TORQUE: 10~15 N.m (1.0~1.5 kgf.m, 7.23~10.84 lb.ft)



2. Remove the desiccant (A) from condenser using a long nose plier. Check for crumbled desiccant and clogged bottom cap filter.



3. Apply air conditioning compressor oil along the O-rings and threads of the new bottom cap.
4. Insert the new desiccant into the receiver drier tank. The desiccant must be sealed in vacuum before it is exposed to air for use.
5. Install the new bottom cap to the condenser.

NOTICE


- Always replace the desiccant and bottom cap at the same time.
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Charge the system, and test its performance.

COMPONENT LOCATION


[GASOLINE]

[GAMMA]


English ▼



[BATA]



[S]



REPLACEMENT

1. Discharge refrigerant from refrigeration system.
2. Replace faulty tube or hose.

CAUTION

Cap the open fittings immediately to keep moisture or dirt out of the system.

3. Tighten joint of bolt or nut to specified torque.

CAUTION

Connections should not be torque tighter than the specified torque.

Part tightened	N.m	Kgf.m	lbf.ft
Condenser - Discharge hose	8 ~ 12	0.8~1.2	5.8 ~ 8.7
Condenser - Liquid tube			
Compressor - Discharge hose	20~30	2.0~3.0	14.4~21.6
Compressor - Suction hose			
Expansion valve - Evaporator	8 ~ 12	0.8~1.2	5.8 ~ 8.7


4. Evacuate air in refrigeration system and charge system with refrigerant.
Specified amount : 500 ± 25g (17.6 ± 0.88 Oz)
5. Inspect for leakage of refrigerant.
Using a gas leak detector, check for leakage of refrigerant.
6. Inspect A/C operation.

DESCRIPTION

A/C pressure transducer convert the pressure value of high pressure line into voltage value after measure it. By converted voltage value, engine ECM controls cooling fan by operating it high speed or low speed. Engine ECM stop the operation of compressor when the temperature of refrigerant line is so high or so low irregularly to optimize air conditioning system.


COMPONENT LOCATION

A/C PRESSURE TRANSDUCER



INSPECTION


1. Measure the pressure of high pressure line by measuring voltage output between NO.1 and NO.2 terminals.



2. Inspect the voltage value whether it is sufficient to be regular value or not.
Voltage = $0.00878835 \times \text{Pressure} + 0.37081095$ [PSIA]
3. If the measured voltage value is not specification, replace the A/C pressure transducer.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Recover the refrigerant with a recovery/charging station.
3. Disconnect A/C pressure transducer connector (3P) (A).
4. Remove the A/C pressure transducer (B).



⚠ CAUTION

Take care that liquid & suction pipe are not bent.


5. Installation is the reverse order of removal.

DESCRIPTION

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

INSPECTION

1. Ignition "OFF"
2. Disconnect evaporator temperature sensor.
3. Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.




[Specification]

Evaporator core temperature [°C(°F)]	Resistance [kΩ]
-10(14)	43.35
0(32)	27.62
10(50)	18.07
20 (68)	12.11
30(86)	8.30
40(104)	5.81
50(122)	4.15


4. If the measured resistance is not specification, substitute with a known-good evaporator temperature sensor and check for proper operation.
5. If the problem is corrected, replace the evaporator temperature sensor.

REPLACEMENT

1. Remove the crash pad lower panel (A).




2. Remove the evaporator temperature sensor (B), by pulling it after rotating 90° in a counter clock wise direction.



3. Installation is the reverse order of removal

DESCRIPTION

1. In-car air temperature sensor is located at the crash pad.
2. The sensor contains a thermistor which measures the temperature of the inside. The signal decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal the control unit regulates incar temperature to intended value.
3. It perceives the inside temperature, changes the resistance value, and enters the corresponding voltage into the automatic temperature control module.
4. It will used for discharge temperature control, sensor failsafe, temperature door control, blower motor level control, and A/C auto control.



- | | |
|---------------------------|-------------------------------|
| 1. Motor(-) | 4. In-car sensor temp. signal |
| 2. Sensor ground (+) | 5. 5V (Vcc) |
| 3. Humidity sensor signal | 6. Motor (+) |

INSPECTION

1. Ignition "ON"
2. Blow air with changing temperature to the in car sensor air inlet. Measure sensor resistance between 2 and 4 terminals.

[Specification]


Temperature [°C(°F)]	Resistance between terminals 2 and 4 (kΩ)
-30	509.600 ± 4.0%
-15	216.100 ± 3.2%
0	97.710 ± 2.4%
15	47.130 ± 1.7%
25	30.000 ± 1.2%
35	19.590 ± 1.6%
50	10.810 ± 2.2%

NOTICE

In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad. (Refer to BD group-crash pad).
3. Disconnect the connector of in-car sensor (A). Loosen the mounting 2 screws and then remove the in-car sensor.




4. Installation is the reverse order of removal.

DESCRIPTION

1. The photo sensor (A) is located at the center of defrost nozzle.
2. The photo sensor contains a photovoltaic (sensitive to sunlight) diode. The solar radiation received by its light receiving portion, generates an electromotive force in proportion to the amount of radiation received which is transferred to the automatic temperature control module so that the solar radiation compensation will be performed.

INSPECTION


1. Ignition "ON"
2. Using the scan tool.
3. Emit intensive light toward photo sensor using a lamp, and check the output voltage change.
4. The voltage will rise with higher intensive light and reduce with lower intensive light.



- | | |
|-------------|---------------------|
| 1. Ground | 4. - |
| 2. 5V (VCC) | 5. Photo sensor (+) |
| 3. Signal | 6. Photo sensor (-) |

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. With the (-) driver, remove the photo sensor (B) from the center of defrost nozzle (A).




3. Install in the reverse order of removal.

DESCRIPTION

1. Water temperature sensor is located at the heater unit.
2. It detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

INSPECTION

1. Ignition "ON"
2. Using the multi-tester, Measure resistance between terminal "1" and "2" of water temperature sensor.



[Specification]

Coolant temperature [°C(°F)]	Resistance (kΩ)	Voltage (V)
-10(14)	55.85 ± 3%	4.24 ± 3%
0(32)	32.91 ± 3%	3.83 ± 3%
10(50)	19.99 ± 3%	3.33 ± 3%
20(68)	12.51 ± 3%	2.78 ± 3%
30(86)	8.047 ± 3%	2.23 ± 3%
40(104)	5.311 ± 3%	1.73 ± 3%
50(122)	3.588 ± 3%	1.32 ± 3%
60(140)	2.476 ± 3%	0.99 ± 3%
70(158)	1.742 ± 3%	0.74 ± 3%
80(176)	1.246 ± 3%	0.55 ± 3%


3. If the measured resistance is not specification, substitute with a known-good water temperature sensor and check for proper operation.
4. If the problem is corrected, replace the water temperature sensor.

NOTICE


Negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Remove the crashpad lower panel(A).



3. Remove the crashpad lower panel(A).



4. Pull the water temperature sensor (B) out at the heater unit with the clamp (C).



5. Installation is the reverse order of removal.

NOTICE

Apply caulk to the water temperature sensor.
Make sure that there is no air leakage

DESCRIPTION

1. The ambient temperature sensor is located at the front of the condenser and detects ambient air temperature. It is a negative type thermistor; resistance will increase with lower temperature, and decrease with higher temperatures.
2. The sensor output will be used for discharge temperature control, temperature regulation door control, blower motor level control, mix mode control and in-car humidity control.

NOTICE


If the ambient temperature is below 0°C (32°F), the A/C compressor will be stopped.
The compressor will be operated by manual operating.

INSPECTION

1. Ignition "OFF"
2. Disconnect ambient temperature sensor.
3. Check the resistance of ambient temperature sensor between terminals 1 and 2 whether it is changed by changing of the ambient temperature.

[Specification]


Ambient Temperature [°C (°F)]	Resistance between terminals 1 and 2 (kΩ)
-10	158.2± 3%
0 (32)	95.1± 3%
10 (50)	58.8± 3%
20 (68)	37.3± 3%




4. If the measured resistance is not specification, substitute with a known-good ambient temperature sensor and check for proper operation.
5. If the problem is corrected, replace the ambient temperature sensor.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the radiator grill cover(A).



3. Remove the ambient temperature sensor (A).



4. Installation is the reverse order of removal.

DESCRIPTION


1. A.Q.S is located at center support in front of the engine radiator, and detects hazardous elements in ambient air providing output signal to control.
2. It will detect sulfurous acid gas, carbon dioxide, carbon monoxide, hydrocarbon and allergen.

INSPECTION

1. Ignition "ON"
2. Using the scan tool.
3. Check the output voltage of AQS between terminals 2 and 3.

[Specification]

Condition	Output signal	Fresh/recirculation
Heating Condition (IG "ON")	$2.5 \pm 0.5V$	Previous
Normal Condition	$4.3 \pm 0.5V$	Fresh
Hazardous gas detection	$0.9 \pm 0.5V$	Recirculation



1. IG2
2. Ground
3. Output signal


4. AQS diagnosis and fail safe
Detect the signal without choosing the AQS switch.
If 2.5V or more is detected for 3.5 seconds or more among 7 seconds, be judged the open of AQS signal.
Operate as below fail safe function, while choosing AQS.
Fail safe: Release the AQS (AQS cannot be selected), Fresh/recirculation maintains previous situation of AQS selection.

NOTICE


When IG is turned ON, AQS heats for 34 ± 5 seconds, it will output below 2.5 voltage during this time.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the radiator grill cover(A).



3. Remove the AQS (B) after loosening the mounting bolts (A).




4. Installation is the reverse order of removal.

DESCRIPTION

1. Humidity sensor is located at the lower crash pad and detected in-car humidity for in-car humidity control.
2. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity preventing in car fogging.

Air conditioner operation depends on ambient temperature and humidity.



- | | |
|---------------------------|-------------------------------|
| 1. Motor(-) | 4. In-car sensor temp. signal |
| 2. Sensor ground (+) | 5. 5V (Vcc) |
| 3. Humidity sensor signal | 6. Motor (+) |

INSPECTION


1. Ignition "ON"
2. Using the scan tool.
3. Check the frequency of humidity sensor between terminals 2 and 3.

Humidity (%)	Frequency between terminals 2 and 3 (Hz)
30	6976 $\pm$ 5%
50	6728 $\pm$ 5%
60	6600 $\pm$ 5%
70	6468 $\pm$ 5%
80	6330 $\pm$ 5%
90	6186 $\pm$ 5%

4. If the measured resistance is not specification, substitute with a known-good humidity sensor and check for proper operation.
5. If the problem is corrected, replace the Humidity sensor.


REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Remove the center facia lower panel (A). (Refer to BD group - Crash pad)
3. Disconnect the humidity sensor connector
4. Disconnect the connector of humidity sensor. Loosen the mounting 2 screws and then remove the humidity sensor (B).



5. Installation is the reverse order of removal.

COMPONENT LOCATION






- 1. Heater case (L)
- 2. Heater Insulation lower
- 3. Seal duct No.1
- 4. Pad
- 5. Door asy-Def

- 6. Door assy - Vent
- 7. Door assy - Floor
- 8. Door assy - Temp
- 9. Core - PTC heater
- 10. Heater core


- 11. Heater core cover
- 12. Water temp sensor
- 13. Vent actuator
- 14. Floor actuator
- 15. Def actuator

REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Recover the refrigerant with a recovery/ recycling/ charging station.
3. When the engine is cool, drain the engine coolant from the radiator.
4. Remove the expansion valve cover(A).



5. Remove the bolts (A) and the expansion valve (B) from the evaporator core.
Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



6. Disconnect the inlet (C) and outlet (D) heater hoses from the heater unit.




CAUTION

Engine coolant will run out when the hoses are disconnected; drain it into a clean drip pan. Be sure not to let coolant


spill on electrical parts or painted surfaces. If any coolant spills, rinse it off immediately.

English ▼


7. Remove the crash pad.
(Refer to BD group-crash pad)
8. Remove the cowl cross bar assembly.
(Refer to BD group-crash pad)
9. Disconnect the connectors from the temperature control actuator, the mode control actuator and the evaporator temperature sensor.
10. Remove the heater & blower unit after loosening 3 mounting nuts.




11. Remove the blower unit (B) from heater unit after loosening 3 screws.




12. Remove the heater core cover (A).




13. Be careful that the inlet and outlet pipe are not bent during heater core removal, and pull out the heater core (A).



14. Remove the heater unit lower case(A).



15. Remove the evaporator core(B).




16. Install the heater core in the reverse order of removal.

17. Installation is the reverse order of removal, and note these items :

- If you're installing a new evaporator, add refrigerant oil (ND-OIL8).
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Immediately after using the oil, replace the cap on the container, and seal it to avoid moisture absorption.
- Do not spill the refrigerant oil on the vehicle ; it may damage the paint ; if the refrigerant oil contacts the paint, wash it off immediately.
- Apply sealant to the grommets.
- Make sure that there is no air leakage.
- Charge the system and test its performance.
- Do not interchange the inlet and outlet heater hoses and install the hose clamps securely.

- Refill the cooling system with engine coolant.

COMPONENT LOCATION




DESCRIPTION

1. Heater unit includes mode control actuator and temperature control actuator.
2. Temperature control actuator is located at the heater unit. It regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temperature door by operating temperature switch and then temperature will be regulated by the hot/cold air ratio decided by position of temperature door.

INSPECTION

1. Ignition "OFF"
2. Disconnect the connector of temperature control actuator.
3. Verify that the temperature control actuator operates to the hot position when connecting 12V to the terminal 3 and grounding terminal 4.
Verify that the temperature control actuator operates to the cool position when connecting in the reverse.

[Drive]



- 1) -
 - 2) -
 - 3) Cool position
 - 4) 5V (Vcc)
 - 5) Feedback signal
 - 6) Sensor GND
 - 7) Warm position
4. Check the voltage between terminals 5 and 6.


[Specification]

Door position	Voltage (5-6)	Error detecting
Max. cooling	$0.3 \pm 0.15V$	Low voltage : 0.1V or less
Max. heating	$4.7 \pm 0.15V$	High voltage : 4.9V or more

* It will feedback current position of actuator to controls.

5. If the measured voltage is not specification, substitute with a known-good temperature control actuator and check for proper operation.
6. If the problem is corrected, replace the temperature control actuator.

[Passenger]



- 1) -
- 2) -
- 3) Cool position
- 4) 5V (Vcc)
- 5) Feedback signal
- 6) Sensor GND
- 7) Warm position

7. Check the voltage between terminals 5 and 6.

[Specification]


Door position	Voltage (5-6)	Error detecting
Max. cooling	$0.3 \pm 0.15V$	Low voltage :0.1V or less
Max. heating	$4.7 \pm 0.15V$	High voltage :4.9V or more

* It will feedback current position of actuator to controls.

8. If the measured voltage is not specification, substitute with a known-good temperature control actuator and check for proper operation.
9. If the problem is corrected, replace the temperature control actuator.

REPLACEMENT



1. Disconnect the negative (-) battery terminal.
2. Remove the crush pad lower panel (A).




3. Disconnect the damper (B) from the glove box (A).



4. Remove the crash pad lower panel (A).




5. Remove the sower duct (A).




6. Disconnect the temperature control actuator connector (A).


7. Loosen the mounting screw and then remove the temperature control actuator (B).



8. Remove the driver's crash pad lower panel (A).
(Refer to BD group - "Crash pad")




9. After loosening the mounting bolts, then remove the reinforcing panel (A).




10. Disconnect the mode control actuator connector (A) after removing the air duct.

11. Loosen the mounting screws and then remove the mode control actuator (B).



12. Installation is the reverse order of removal.

COMPONENT LOCATION



Mode Control Actuator


DESCRIPTION

The mode control actuator is located at the heater unit.

It adjusts position of mode door by operating mode control actuator based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent → B/L → floor → mix.

INSPECTION


1. Ignition "OFF"
2. Disconnect the connector of mode control actuator.
3. Verify that the mode control actuator operates to the defrost mode when connecting 12V to the terminal 3 and grounding terminal 4.
4. Verify that the mode control actuator operates to the vent mode when connecting in the reverse.




- 1) -
 - 2) -
 - 3) DEF
 - 4) VENT
 - 5) SENSOR GND
 - 6) Feedback signal
 - 7) 5V (Vcc)
5. Check the voltage between terminals 5 and 6.
- | Door position | Voltage (5-6) | Error detecting |
|---------------|-----------------|-----------------------------|
| Vent | $0.3 \pm 0.15V$ | Low voltage : 0.1V or less |
| Defrost | $4.7 \pm 0.15V$ | High voltage : 4.9V or more |
- It will feedback current position of actuator to controls.
6. If the measured voltage is not specification, substitute with a known-good console temp control actuator and check for proper operation.
 7. If the problem is corrected, replace the console temp control actuator.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the driver's crush pad lower panel (A).
(Refer to BD group - "Crash pad")




3. After loosening the mounting bolts, then remove the reinforcing panel (A).



4. Disconnect the mode control actuator connector (A) after removing the air duct.


5. Loosen the mounting screws and then remove the mode control actuator (B).



6. Installation is the reverse order of removal.

DESCRIPTION

PTC (Positive Temperature Coefficient) heater (A) is an electric heater using a PTC element as an auxiliary heating device that supplements deficiency of interior heat source in highly effective diesel engine (U engine).



An electric heater heats up the interior by directly heating the air that passes through the heater.

PTC = positive Temperature Coefficient

The name itself implies that the element has a proportional resistance change sensitive to temperature. PTC heater is installed at the exit or the backside of heater core.



OPERATION PRINCIPLE


ECM outputs a PTC on signal. Operate PTC from 1st setting to 3rd setting with an interval of 15 seconds.

Heat up the air, which passes through a heater core.


OPERATION CONDITION

Judge the condition by ambient temperature is below 5°C, coolant temperature is below 70°C, and battery voltage is above 11V and engine RPM is above 700RPM.

COMPONENT LOCATION



Blower Unit




1. Intake case (R)
2. Intake case (L)
3. Intake door
4. Intake actuator
5. Seal

6. Filter cover
7. Air filter
8. Blower upper case
9. Blower relay
10. Blower lower case

11. Blower motor
12. Power mosfet
13. Blower case

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad.
(Refer to BD group - Crash pad)
3. Disconnect the connectors from the intake actuator, the blower motor and power mosfet.
4. Remove the cowl cross bar assembly.
(Refer to BD group - Crash pad)
5. Remove the blower unit (A) from the heater unit after loosening a mounting bolt and 3 screws.




NOTICE

- Make sure that there is no air leaking out of the blower and duct joints.

6. Installation is the reverse order of removal.

INSPECTION


1. Connect the battery voltage and check the blower motor rotation.




2. If the blower motor voltage is not operated well, substitute with a known-good blower motor and check for proper operation.
3. If the problem is corrected, replace the blower motor.

REPLACEMENT

1. Disconnect the negative (-) battery terminal.
2. Remove the blower motor cover(A).



3. Disconnect the connector (B) of the blower motor and then remove the blower motor (A) after loosening the mounting screws



4. Installation is the reverse order of removal.

English ▼

INSPECTION

Check for continuity between the terminals.


1. There should be continuity between No.1 and No.4 terminals when power and ground are connected to No.2 and No.3 terminals.
2. There should be no continuity between No.1 and No.4 terminals when power is disconnected.

Terminal Position	2	3	1	4
Disconnected	○ — ○			
Connected	⊖ — ⊕		○ — ○	

3. If the blower motor voltage is not operated well, substitute with a known-good blower relay and check for proper operation.
4. If the problem is corrected, replace the blower relay.

REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Disconnect the connector of the blower relay at the below blower unit.
3. Remove the blower relay (A) after loosening the mounting screw.



4. Install in the reverse order of removal.

INSPECTION

1. Ignition "ON"
2. Manually operate the control switch and measure the voltage of blower motor between pin 1 and 2.
3. Select the control switch to raise voltage until high speed.



[Specification]


Fan	Motor voltage	Motor Voltage
	Manual	Auto
First speed	3.80±0.5	3.8±0.5
Second speed	4.29±0.5	4.9±0.5
Third speed	4.77±0.5	6.1±0.5
Forth speed	5.29±0.5	7.2±0.5
Fifth speed	5.74±0.5	8.3±0.5
Sixth speed	6.23±0.5	9.5±0.5
Seventh speed	6.71±0.5	10.6±0.5
Eighth speed	7.20±0.5	Battery (+)
Ninth speed	7.69±0.5	
Tenth speed	8.17±0.5	
Eleventh speed	8.66±0.5	
Twelf speed	9.14±0.5	
Thirteen speed	9.63±0.5	
Fourteen speed	10.11±0.5	
Fifteen speed	10.60±0.5	
Sixteenth speed	Battery (+)	

AUTO COOLING: Auto speed (4.5V~B+)

AUTO HEATING: Auto speed (4.6V~10.6V)

4. If the measured voltage is not specification, substitute with a known-good power mosfet and check for proper operation.
5. If the problem is corrected, replace the power mosfet.

1. Disconnect the negative (-) battery terminal.
2. Disconnect the power mosfet connector at the connecting part between heater and blower unit.
3. Remove the power mosfet (B) after loosening the mounting screws.




4. Installation is the reverse order of removal.

DESCRIPTION


This has particle filter which eliminates foreign materials and odor. The particle filter includes odor filter as well as conventional dust filter to ensure comfortable interior environment.

REPLACEMENT

1. Open the glove box (A). Lower the glove box down completely by removing the glove box stopper (B) to the glove box.



2. Remove the filter cover (A) with pushing the knob (B).



NOTICE

In case of driving in an air-polluted area or rugged terrain, check and replace the air filter as frequently as possible.


Replacement period: 15,000 km (9320 mile)

3. Installation is the reverse order of removal.

DESCRIPTION


1. The intake actuator is located at the blower unit.
2. It regulates the intake door by signal from control unit.
3. Pressing the intake selection switch will shift between recirculation and fresh air modes.

COMPONENT LOCATION



INSPECTION

1. Ignition "OFF"
2. Disconnect the intake actuator connector.
3. Verify that the actuator operates to the recirculation position when connecting 12V to the terminal 3 and grounding terminal 4.
4. Verify that the intake actuator operates to the fresh position when connecting in the reverse.



5. Check the voltage between terminals 5 and 6.

Door position	Voltage (5-6)	Error detecting
Fresh	$0.3 \pm 0.15V$	Low voltage : 0.1V or less
Recirculation	$4.7 \pm 0.15V$	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

6. If the intake actuator is not operated well, substitute with a known-good intake actuator and check for proper operation.
7. If the problem is corrected, replace the intake actuator.

REPLACEMENT




1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad. (Refer to BD group - Crash pad).
3. Disconnect the intake actuator connector.
4. Loosen the mounting screw and then remove the intake actuator (A) from the blower unit.




5. Installation is the reverse order of removal.

CONTROL PANEL

Component



Connector A




Connector B

Connector Pin Function


Connector	Pin	Function	Connector	Pin	Function

REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Put the SST (A) into the space between the center facia (B).



3. Disconnect the connectors (A) from the center facia.




4. Remove the Heater & A/C controller (A) from center facia panel.



5. Installation is the reverse order of removal.

CONTROL PANEL

Component




Connector Pin Function

Connector	Pin	Function	Connector	Pin	Function	English
Connector (A)	1	Tail lamp (+)	Connector (B)	1	Sensor REF (+5V)	
	2	Battery (+)		2	-	
	3	-		3	Ambient sensor (+)	
	4	-		4	-	
	5	-		5	-	
	6	K-line		6	Evaporator temperature sensor (+)	
	7	C_CAN - HIGH		7	-	
	8	C_CNA - LOW		8	-	
	9	HTD		9	FET (G)	
	10	Rear defog S/W		10	FET (D)	
	11	-		11	Blower motor (+)	
	12	-		12	Sensor GND	
	13	Rheostat		13	Temp actuator DR(cool)	
	14	IG2		14	Mode actuator DR(warm)	
	15	-		15	Photo sensor LEFT(-)	
	16	Temp actuator PS(cool)		16	Photo sensor RIGHT(-)	
	17	Temp actuator PS(warm)		17	-	
	18	Temp actuator PS F/B		18	Temp actuator DR F/B	
	19	Mode actuator (vent)		19	-	
	20	Mode actuator (def)		20	PTC on signal	
	21	Mode actuator F/B		21	PTC RLY 2 (diesel only)	
	22	Intake actuator (fre)		22	PTC RLY 3 (diesel only)	
	23	Intake actuator (rec)				
	24	Intake actuator F/B				
	25	GND				
	26	GND				

SELF-DIAGNOSIS

1. Self-diagnosis process



2. How to read self-diagnostic code

After the display panel flickers three times every 0.5 second, the corresponding fault code flickers on the setup temperature display panel every 0.5 second and will show two figures. Codes are displayed in numerical format.


Fault code

Fault code		Fail description
Control unit	DTC	
00	-	Normal
11	B1234	In-car temperature sensor open
12	B1233	In-car temperature sensor short
13	B1238	Ambient temperature sensor open
14	B1237	Ambient temperature sensor short
17	B1242	Evaporator temperature sensor open
18	B1241	Evaporator temperature sensor short
19	B1245	Temperature control actuator feed back open
19	B1246	Temperature control actuator feed back short
20	B2406	Temperature control actuator failure
21	B1249	Mode control actuator open
21	B1250	Mode control actuator short

22	B2409	Mode control actuator failure	English ▼
25	B1208	Intake potentiometer open	
25	B1209	Intake potentiometer short	
26	B2408	Intake potentiometer failure	

3. Fault code display

(1) Continuance operation




(2) Continuance operation : DTC code is more two



(3) Step operation

- Nomal or one fault code is same a continuance operation.
- DTC code is more two.



4. If fault codes are displayed during the check, Inspect malfunction causes by referring to fault codes.


5. Fail safe

- Incar sensor : Control with the value of 23°C(73.4°F)
- Ambient temperature sensor: Control with the value of 20°C(67°F)
- Evaporator temperature sensor: Control with the value of -2°C(28.4°F)
- Temperature control actuator (Air mix potentiometer):
If temperature setting LO-24.5°C, fix at maximum cooling position.
If temperature setting 25°C-HI, fix at maximum heating position
- Mode control actuator (Direction potentiometer):
Fix vent position, while selecting vent mode.
Fix defrost position, while selecting all except vent mode.


- (6) Intake control actuator :
Fix fresh position, while selecting fresh mode.
Fix recirculation position, while selecting recirculation mode.

REPLACEMENT


1. Disconnect the negative (-) battery terminal.
2. Put the SST (A) into the space between the center facia (B).



3. Disconnect the connectors (A) from the center facia.



4. Remove the Heater & A/C controller (A) after loosening 4 screws.



5. Installation is the reverse order of removal.