


POWER WINDOWS

Component Index

- [Dash Fuse Box](#)
- [Left Front Power Window Motor](#)
- [Left Rear Power Window Motor](#)
- [Power Window Relay](#)
- [Right Front Power Window Motor](#)
- [Right Rear Power Window Motor](#)

POWER WINDOWS


Circuit Schematic



POWER WINDOWS

Circuit Schematic

Rodeo



POWER WINDOWS

Component Location Index

(Refer to Section 201 for photographs.)

<u>Component</u>	<u>Photo No.</u>
Dash Fuse Box Left side of I/P, behind panel	58
Left Front Power Window	
Motor Inside front of left front door, behind trim	88
Left Rear Power Window	
Motor Inside front of left rear door, behind trim pad	92
Power Window Relay Left side of I/P, in dash fuse box	59
Right Front Power Window	
Motor Inside front of right front door, behind trim pad	88
Right Rear Power Window	
Motor Inside front of right rear door, behind trim pad	92
<u>Connector</u>	
D-2 (2-WHT) Inside front of left front door, behind trim	88
D-11 (2-WHT) Inside front of right front door	88
D-20 (2-WHT) Inside front of left rear door	92
D-25 (2-WHT) Inside front of right rear door	92
H-24 (10-WHT) Left “B” pillar, behind trim	93
H-28 (22-WHT) Above left kick panel, in door grommet	112
H-29 (10-WHT) Right “B” pillar, behind trim	93
H-32 (16-WHT) Behind left kick panel	62
H-33 (22-WHT) Above right kick panel, in door grommet	112
<u>Ground</u>	
B-8 Below center console	81

POWER WINDOWS

Circuit Operation

The (POWER WINDOW) circuit breaker applies battery voltage at all times to the power window relay contacts. With the starter switch in ON, the CB-15 ELEC. IG. fuse applies battery voltage to the power window relay coil. The relay energizes and allows battery voltage from the circuit breaker to all the door power window switches.

Left Front Window

When the left front door power window switch is moved to UP or DOWN, a signal is sent to the control unit (built-into the switch). The control unit provides power to the left front power window, driving the window in the direction selected. The control unit removes power to the motor when the switch is released or when the window reaches its fully open or closed position.

Auto Down

When the left front door power window switch is moved to AUTO, a signal is sent to the control unit (built-into the switch). The control unit provides power to the left front power window motor, driving the window down. The control unit removes power to the motor when the window reaches the fully open position.

Passenger Windows

The passenger windows can be operated from the left front door power window switch or the respective door power window switch. The passenger door power window switches can only be operated when the lock switch in the left front door power window switch is in the OFF position.

When a passenger power window switch is moved to UP or DOWN, a signal is sent to the control unit (built-into the switch). The control unit then provides power to the window motor, moving the window in the direction selected. The control unit removes power to the motor when the switch is released or when the window reaches its fully open or closed position.

When a passenger window is being controlled by the switch in the left front door, the control unit in the left front door switch sends a multi-plexed signal to the control units in the other power window switches. The signal tells the appropriate control unit to provide power to its power window motor, moving the window in the direction selected. The control unit removes power to the motor when the switch is released or the window reaches its fully open or closed position. Since the signal is multi-plexed, more than one passenger's window can be controlled by the left front door switch simultaneously.