
SERVICE BRAKES

CONTENTS

35109000159

BASIC BRAKE SYSTEM 35A

ANTI-SKID BRAKING SYSTEM (ABS) <2WD> 35B

ANTI-SKID BRAKING SYSTEM (ABS) <4WD>

NOTE

THE GROUPS MARKED BY ■ ARE NOT IN THIS MANUAL

■

BASIC BRAKE SYSTEM

CONTENTS

35109000166

GENERAL INFORMATION	3	Front Disc Brake Rotor Check	12
SERVICE SPECIFICATIONS	4	Brake Lining Thickness Check	14
LUBRICANTS	5	Brake Drum Inside Diameter Check	14
SEALANTS	5	Brake Lining and Brake Drum Connection Check	14
SPECIAL TOOLS	5	BRAKE PEDAL	15
ON-VEHICLE SERVICE	6	MASTER CYLINDER AND BRAKE BOOSTER	17
Brake Pedal Check and Adjustment	6	Master Cylinder	19
Stop Lamp Switch Check	7	FRONT DISC BRAKE	20
Brake Booster Operating Test	7	REAR DRUM BRAKE	25
Check Valve Operation Check	8	Wheel Cylinder	27
Proportioning Valve Function Test	8	PROPORTIONING VALVE	28
Brake Fluid Level Sensor Check	9		
Bleeding	9		
Front Disc Brake Pad Check and Replacement	10		


GENERAL INFORMATION

35100010090

The brake system offers high dependability and durability along with improved braking performance and brake sensitivity.

Items		Specifications
Master cylinder	Type	Tandem type (with level sensor)
	I.D. mm	22.2
Brake booster	Type	Vacuum type, single
	Effective dia. of power cylinder mm	230
	Boosting ratio	5.0
Proportioning valve	Type	Dual type
	Decompression ratio	0.25
Front brakes	Type	Floating caliper, 1-piston, ventilated disc
	Disc effective dia. × thickness mm	184 × 18
	Wheel cylinder I.D. mm	54.0
	Pad thickness mm	10.0
	Clearance adjustment	Automatic
Rear drum brakes	Type	Leading trailing
	Drum I.D. mm	180
	Wheel cylinder I.D. mm	19.0
	Lining thickness mm	4.3
	Clearance adjustment	Automatic
Brake fluid		DOT3 or DOT4

CONSTRUCTION DIAGRAM



A14M0061

SERVICE SPECIFICATIONS

35100030096

Items			Standard value	Limit
Brake pedal height mm	L.H. drive vehicles		163.5–166.5	—
	R.H. drive vehicles		162.5–165.5	—
Brake pedal free play mm			3–8	—
Brake pedal to floor board clearance mm			80 or more	—
Proportioning valve	Split point MPa	Hatchback	2.45 ± 0.25	—
		Sedan	2.94 ± 0.25	—
	Output fluid pressure (Input fluid pressure) MPa	Hatchback	4.30 ± 0.39 (9.81)	—
		Sedan	4.66 ± 0.39 (9.81)	—
	Output fluid pressure difference between left and right MPa		—	0.39
Brake booster push rod to master cylinder piston clearance mm			0.65–0.85	—
Front disc brake	Pad thickness mm		10.0	2.0
	Disc thickness mm		18.0	16.4
	Disc runout mm		—	0.06
	Drag force (tangential force of wheel mounting bolts) N		39 or less	—

Items		Standard value	Limit
Rear drum brake	Lining thickness mm	4.3	1.0
	Drum inside diameter mm	180	182

LUBRICANTS

35100040082

Items	Specified Lubricant
Brake fluid	DOT3 or DOT4
Brake piston seal	Repair kit grease (orange)
Slide pin boot and slide pin bush inner surfaces	
Brake piston boot inner surfaces	
Piston boot mounting grooves	
Rear brake shoe and backing plate contact surfaces	Brake grease SAE J310, NLGI No.1
Shoe assembly and auto adjuster assembly contact surfaces	
Shoe and lever assembly and auto adjuster assembly contact surfaces	



SEALANTS





35100050085

Items	Specified sealant	Remarks
Thread part fitting	3M ATD Part No. 8661 or equivalent	Semi-drying sealant

SPECIAL TOOLS

35100060071

Tool	Number	Name	Use
	MB990964 MB990520 MB990619	Brake tool set	- Pushing-in of the disc brake piston - Installation of drum brake wheel cylinder piston cup
	MB990998	Front hub remover and installer	Provisional holding of the wheel bearing



ON-VEHICLE SERVICE

35100090117

BRAKE PEDAL CHECK AND ADJUSTMENT

1. Turn up the carpet, etc under the brake pedal.
2. Measure the brake pedal height as illustrated. If the brake pedal height is not within the standard value, follow the procedure below.

Standard value:


<L.H. drive vehicles> 163.5–166.5 mm

<R.H. drive vehicles> 162.5–165.5 mm

- (1) Disconnect the stop lamp switch connector.
 - (2) Adjust the brake pedal height by turning the operating rod with pliers (with the operating rod lock nut loosened), until the correct brake pedal height is obtained.
 - (3) Secure by tightening the lock nut of the operating rod.
 - (4) Push the stop lamp switch in the direction of the pedal stroke until it stops. (The switch will slide if it is pushed firmly.)
 - (5) Lift up the pedal until the operating rod is fully extended, and then slide the stop lamp switch back to the required position. Adjust the position of the switch by turning it until the distance shown in the illustration is correct.
 - (6) Connect the connector of the stop lamp switch.
 - (7) Check that the stop lamp is not illuminated with the brake pedal unpressed.
2. With the engine stopped, depress the brake pedal two or three times. After eliminating the vacuum in the power brake booster, press the pedal down by hand, and confirm that the amount of movement before resistance is met (the free play) is within the standard value range.

Standard value: 3–8 mm

If the free play exceeds the standard value, it is probably due to excessive play between the retaining ring bolt and brake pedal arm.
Check for excessive clearance and replace faulty parts as required.




3. Start the engine, depress the brake pedal with approximately 490 N of force, and measure the clearance between the brake pedal and the floorboard.

Standard value: 80 mm or more

If the clearance is outside the standard value, check for air trapped in the brake line, clearance between the lining and the drum and dragging in the parking brake.
Adjust and replace defective parts as required.


4. Turn back the carpet, etc.



STOP LAMP SWITCH CHECK

35100890083

Connect a circuit tester to the stop lamp switch, and check whether or not there is continuity when the plunger of the stop lamp switch is pushed in and when it is released. The stop lamp switch is in good condition if there is no continuity when the plunger is pushed in to a depth of within 4 mm from the outer case edge surface, and if there is continuity when it is released.




BRAKE BOOSTER OPERATING TEST

35100100049

For simple checking of the brake booster operation, carry out the following tests:

1. Run the engine for one or two minutes, and then stop it.

If the pedal depresses fully the first time but gradually becomes higher when depressed succeeding times, the booster is operating properly, if the pedal height remains unchanged, the booster is defective.



2. With the engine stopped, step on the brake pedal several times.

Then step on the brake pedal and start the engine.
If the pedal moves downward slightly, the booster is in good condition. If there is no change, the booster is defective.

3. With the engine running, step on the brake pedal and then stop the engine.
Hold the pedal depressed for 30 seconds. If the pedal height does not change, the booster is in good condition, if the pedal rises, the booster is defective.
If the above three tests are okay, the booster performance can be determined as good.
If one of the above three tests is not okay at last, the check valve, vacuum hose, or booster will be defective.


CHECK VALVE OPERATION CHECK

35100900090

1. Remove the vacuum hose. (Refer to P.35A-17.)

Caution

The check valve should not be removed from the vacuum hose.




2. Check the operation of the check valve by using a vacuum pump.

Vacuum pump connection	Accept/reject criteria
Connection at the brake booster side (A)	A negative pressure (vacuum) is created and held.
Connection at the intake manifold side (B)	A negative pressure (vacuum) is not created.

Caution


If the check valve is defective, replace it as an assembly unit together with the vacuum hose.



PROPORTIONING VALVE FUNCTION TEST

35100110080

1. Connect two pressure gauges, one each to the input side and output side of the proportioning valve, as shown.
2. Bleed the air in the brake line and the pressure gauge.
3. While gradually depressing the brake pedal, make the following measurements and check to be sure that the measured values are within the allowable range.



- (1) Output pressure begins to drop relative to input pressure (split point).

Standard value:

MPa

Hatchback	Sedan
2.45 ± 0.25	2.94 ± 0.25

- (2) Check to be sure that the output fluid pressure is at the standard value when the pedal depression force is increased so that the input fluid pressure is at the values shown in the table below.

Standard value:


MPa

	Hatchback	Sedan
Output fluid pressure (Input fluid pressure)	4.30 ± 0.39 (9.81)	4.66 ± 0.39 (9.81)

- (3) Output pressure difference between left and right brake lines.

Limit: 0.39 MPa

4. If the measured pressures are not within the permissible ranges, replace the proportioning valve.



BRAKE FLUID LEVEL SENSOR CHECK

35100910086

The brake fluid level sensor is in good condition if there is no continuity when the float surface is above "A" and if there is continuity when the float surface is below "A".


BLEEDING

35100140089

Caution

Use the specified brake fluid. Avoid using a mixture of the specified brake fluid and other fluid.


Specified brake fluid: DOT3 or DOT4



MASTER CYLINDER BLEEDING


The master cylinder used has no check valve, so if bleeding is carried out by the following procedure, bleeding of air from the brake pipeline will become easier. (When brake fluid is not contained in the master cylinder.)

- (1) Fill the reserve tank with brake fluid.
- (2) Keep the brake pedal depressed.
- (3) Have another person cover the master cylinder outlet with a finger.
- (4) With the outlet still closed, release the brake pedal.
- (5) Repeat steps (2)–(4) three or four times to fill the inside of the master cylinder with brake fluid.



BRAKE PIPE LINE BLEEDING

Bleed the air in the sequence shown in the figure.




FRONT DISC BRAKE PAD CHECK AND REPLACEMENT

35100150099

NOTE

The left side outer brake pad has a wear indicator. The wear indicator contacts the brake disc when the brake pad thickness becomes 2 mm and emit a squealing sound to warn the driver.



1. Check brake pad thickness through caliper body check port.

Standard value: 10 mm


Limit: 2.0 mm

Caution


1. When the limit is exceeded, replace the pads at both sides, and also the brake pads for the wheels on the opposite side at the same time.
 2. If there is a significant difference in the thickness of the pads on the left and right sides, check the sliding condition of the piston, lock pin and guide pin.
2. Remove the slide pin (M14). Lift caliper assembly and retain with wires.

Caution

Do not wipe off the special grease that is on the slide pin or allow it to contaminate the slide pin.



3. Remove the following parts from caliper support.
 1. Pad and wear indicator assembly <L.H.>, and pad assembly <R.H.>
 2. Pad assembly
 3. Pad liner
 4. Outer shim



4. In order to measure the brake drag force after pad installation, measure the rotary-sliding resistance of the hub with the pads removed. (Refer to P.35A-20.)
5. Install the pads and the caliper assembly, and then check the brake drag force. (Refer to P.35A-20.)

FRONT DISC BRAKE ROTOR CHECK


35100270061

CAUTION

When servicing disc brakes, it is necessary to exercise caution to keep the disc brakes within the allowable service values in order to maintain normal brake operation.

Before re-finishing or re-processing the brake disc surface, the following conditions should be checked.

Inspection items	Remarks
Scratches, rust, saturated lining materials and wear	• If the vehicle is not driven for a certain period, the sections of the discs that are not in contact with lining will become rusty, causing noise and shuddering. • If grooves resulting from excessive disc wear and scratches are not removed prior to installing a new pad assembly, there will momentarily be inappropriate contact between the disc and the lining (pad).
Run-out or drift	Excessive run-out or drift of the discs will increase the pedal depression resistance due to piston knock-back.
Change in thickness (parallelism)	If the thickness of the disc changes, this will cause pedal pulsation, shuddering and surging.
Inset or warping (flatness)	Overheating and improper handling while servicing will cause inset or warping.

**THICKNESS CHECK**

35100160085


1. Using a micrometer, measure disc thickness at eight positions, approximately 45° apart and 10 mm in from the outer edge of the disc.

Brake disc thickness**Standard value: 18.0 mm****Limit: 16.4 mm**

Thickness variation (at least 8 positions)


The difference between any thickness measurements should not be more than 0.015 mm.

2. If the disc is beyond the limits for thickness, remove it and install a new one. If thickness variation exceeds the specification, replace the brake disc or turn rotor with on the car type brake lathe ("MAD; DL-8700PF" or equivalent).

**RUN-OUT CHECK**

35100170088


1. Remove the caliper support; then raise the caliper assembly upward and secure by using wire.
2. Inspect the disc surface for grooves, cracks and rust. Clean the disc thoroughly and remove all rust.



3. Place a dial gauge approximately 5 mm from the outer circumference of the brake disc, and measure the run-out of the disc.


Limit: 0.06 mm or less**NOTE**

Tighten the nuts in order to secure the disc to the hub.

**RUN-OUT CORRECTION**

35100180081


1. If the run-out of the brake disc is equivalent to or exceeds the limit specification, change the phase of the disc and hub, and then measure the run-out again.
 - (1) Before removing the brake disc, chalk both sides of the wheel stud on the side at which run-out is greatest.




- (2) Remove the brake disc, and then place a dial gauge as shown in the illustration; then move the hub in the axial direction and measure the play.

Limit: 0.05 mm

If the play is equivalent to or exceeds the limit, disassemble the hub knuckle and check each part.



- (3) If the play does not exceed the limit specification, install the brake disc at a position 180° away from the chalk mark, and then check the run-out of the brake disc once again.
2. If the run-out cannot be corrected by changing the phase of the brake disc, replace the disc or turn rotor with on the car type brake lathe ("MAD, DL-8700PF" or equivalent).

**BRAKE LINING THICKNESS CHECK**

35100300104


1. Remove the brake drum.
2. Measure the wear of the brake lining at the place worn the most.

Standard value: 4.3 mm**Limit: 1.0 mm**

Replace the shoe and lining assembly if brake lining thickness is less than the limit or if it is not worn evenly. For information concerning the procedures for installation of the shoe and lining assembly, refer to P.35A-25.

Caution

1. Whenever the shoe and lining assembly is replaced, replace both RH and LH assemblies as a set to prevent car from pulling to one side when braking.
2. If there is a significant difference in the thickness of the shoe and lining assemblies on the left and right sides, check the sliding condition of the piston.


**BRAKE DRUM INSIDE DIAMETER CHECK**

35100320094

1. Remove the brake drum.
2. Measure the inside diameter of the brake drum at two or more locations.

Standard value: 180 mm**Limit: 182 mm**

3. Replace brake drums, shoe and lining assembly when wear exceeds the limit value or is badly imbalanced.

**BRAKE LINING AND BRAKE DRUM CONNECTION CHECK**

35100310091

1. Remove the brake drum.
2. Remove the shoe and lining assembly. (Refer to P.35A-25.)
3. Chalk inner surface of brake drum and rub with shoe and lining assembly.
4. Replace shoe and lining assembly or brake drums if there are any irregular contact area.

NOTE

Clean off chalk after check.

BRAKE PEDAL

35100340151


REMOVAL AND INSTALLATION <L.H. drive vehicles>

Pre-removal Operation

- Instrument Under Cover Removal (Refer to GROUP 52A – Instrument Panel.)
- Steering Column Assembly Removal (Refer to GROUP 37A – Steering Wheel and Shaft.)
- Accelerator Pedal Removal (Refer to GROUP 17.)

Post-installation Operation

- Accelerator Pedal Installation (Refer to GROUP 17.)
- Steering Column Assembly Installation (Refer to GROUP 37A – Steering Wheel and Shaft.)
- Instrument Under Cover Installation (Refer to GROUP 52A – Instrument Panel.)
- Brake Pedal Adjustment (Refer to P.35A-6.)

**Removal steps**

1. Stop lamp switch connector
2. Stop lamp switch
3. Snap pin
4. Washer
5. Clevis pin
6. Brake pedal shaft bolt
7. Brake pedal
8. Brake pedal pad

9. Brake pedal return spring
10. Bushing
11. Pipe
12. Pedal support member


REMOVAL AND INSTALLATION <R.H. drive vehicles>

Pre-removal Operation

- Instrument Under Cover Removal (Refer to GROUP 52A – Instrument Panel.)
- Steering Column Assembly Removal (Refer To GROUP 37A – Steering Wheel and Shaft.)
- Accelerator Pedal Removal (Refer to GROUP 17.)

Post-installation Operation

- Accelerator Pedal Installation (Refer to GROUP 17.)
- Steering Column Assembly Installation (Refer to GROUP 37A – Steering Wheel and Shaft.)
- Instrument Under Cover Installation (Refer to GROUP 52 – Instrument Panel.)
- Brake Pedal Adjustment (Refer to P.35A-6.)

**Removal steps**

1. Stop lamp switch connector
2. Stop lamp switch
3. Snap pin
4. Washer
5. Clevis pin
6. Brake pedal shaft bolt
7. Brake pedal

8. Brake pedal pad
9. Brake pedal return spring
10. Bushing
11. Pipe
12. Pedal support member

MASTER CYLINDER AND BRAKE BOOSTER

35100370136


REMOVAL AND INSTALLATION

Pre-removal Operation

- Brake Fluid Draining
- Air Intake Hose Removal <L.H. drive vehicles>


Post-installation Operation

- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P.35A-9.)
- Brake Pedal Adjustment (Refer to P.35A-6.)
- Air Intake Hose Installation <L.H. drive vehicles>




14M0056
00004619


<L.H. drive vehicles>



<R.H. drive vehicles>



14M0057



Sealant: 3M ATD Part No.
8661 or equivalent

Removal steps


1. Brake pipe connection
2. Brake fluid level sensor connector
3. Master cylinder assembly
- ▶B◀ • Clearance adjustment between brake booster push rod and primary piston
- ▶A◀ 4. Vacuum hose (With built-in check valve)
5. Fitting

6. Snap pin
7. Washer
8. Clevis pin
9. Brake booster
10. Sealer

INSTALLATION SERVICE POINTS

►A◄ VACUUM HOSE CONNECTION


Insert securely and completely until the vacuum hose at the engine side contacts the edge of the hexagonal part of the fitting, and then secure by using the hose clip.



►B◄ CLEARANCE ADJUSTMENT BETWEEN BRAKE BOOSTER PUSH ROD AND PRIMARY PISTON

Calculate clearance A from the B, C and D measurements.
 $A = B - C - D$




Standard value: 0.65–0.85 mm



If the clearance is not within the standard value range, adjust by changing the push rod length by turning the screw of the push rod.

35100420091


MASTER CYLINDER DISASSEMBLY AND REASSEMBLY



Disassembly steps

1. Reservoir cap assembly
2. Reservoir cap
3. Diaphragm
4. Brake fluid level sensor
5. Float
6. Reservoir stopper bolt

7. Reservoir tank
8. Reservoir seal
9. Piston stopper ring
10. Primary piston assembly
11. Secondary piston assembly
12. Master cylinder body



DISASSEMBLY SERVICE POINT

◀A▶ PISTON STOPPER RING DISASSEMBLY

Remove the piston stopper ring, while depressing the piston.

FRONT DISC BRAKE

35100600099


REMOVAL AND INSTALLATION

Pre-removal Operation


- Brake Fluid Draining

Post-installation Operation

- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P.35A-9.)


**Removal steps**

1. Brake hose connection
2. Gasket
3. Disc brake assembly
4. Brake disc

**INSTALLATION SERVICE POINT****►A◄ DISC BRAKE ASSEMBLY INSTALLATION**

1. In order to measure the brake drag torque after pad installation, measure the rotary-sliding resistance of the hub by the following procedure with the pads removed.
 - (1) Remove the drive shaft.
(Refer to GROUP 26 – Front Axle.)
 - (2) Attach the special tool to the front hub assembly as shown in the illustration, and tighten it to the specified torque.

Tightening torque: 196 – 255 Nm




- (3) Use a spring balance to measure the rotary-sliding resistance of the hub in the forward direction.

2. After installing the caliper support to the knuckle, install the pad clips and the pads to the caliper support.

Caution


Do not let any oil, grease or other contamination get onto the friction surfaces of the pads and brake discs.



3. Clean piston and insert into cylinder with special tool.
4. Be careful that the piston boot does not become caught when lowering the caliper assembly, and tighten the slide pin (M14) to the specified torque.

Tightening torque: 83 – 93 Nm

5. Start the engine and then depress the brake pedal 2–3 times.
6. Stop engine.
7. Turn brake disc forward 10 times.




8. Use a spring balance to measure the rotation sliding resistance of the hub in the forward direction.
9. Calculate the drag force of the disc brake (difference between of values measured in item 8 and item 1.)

Standard value: 39 N or less

10. If the drag force of the disc brake exceeds the standard value, disassemble piston and clean piston. Check for corrosion or worn piston seal, and check the sliding condition of the slide pins.

DISASSEMBLY AND REASSEMBLY

35100620101



Brake caliper kit	Pad repair kit	Seal and boots repair kit
14S0082	14M0075	14A0557







Caliper assembly disassembly steps

1. Slide pin (M14)
2. Slide pin (M10)
3. Torque member (pad, pad liner, shim)
4. Boot
5. Bush
6. Plug
7. Piston boot
8. Piston
9. Piston seal
10. Caliper body

Pad assembly disassembly steps


1. Slide pin (M14)
2. Slide pin (M10)
3. Torque member (pad, pad liner, shim)
11. Pad and wear indicator assembly <L.H.> or pad assembly <R.H.>
12. Pad assembly
13. Outer shim (coated with rubber)
14. Pad liner

LUBRICATION POINTS



DISASSEMBLY SERVICE POINTS


When disassembling the front disc brakes, disassemble both sides (left and right) as a set.

**◀A▶ PISTON BOOT/PISTON REMOVAL**

Protect caliper body with cloth. Blow compressed air through brake hose to remove piston boot and piston.

Caution

Blow compressed air gently.

**◀B▶ PISTON SEAL REMOVAL**

- (1) Remove piston seal with finger tip.

Caution

Do not use a flat-tipped screwdriver or other tool to prevent damage to inner cylinder.

- (2) Clean piston surface and inner cylinder with trichloroethylene, alcohol or specified brake fluid.

Specified brake fluid: DOT3 or DOT4

INSPECTION

35100630081

- Check cylinder for wear, damage or rust.
- Check piston surface for wear, damage or rust.
- Check caliper body or sleeve for wear.
- Check pad for damage or adhesion of grease, check backing metal for damage.

REAR DRUM BRAKE


REMOVAL AND INSTALLATION

Pre-removal Operation

- Loosening the Parking Brake Cable Adjusting Nut.
- Brake Fluid Draining

Post-Installation Operation

- Brake Line Bleeding (Refer to P.35A-9.)
- Parking Brake Lever Stroke Adjustment (Refer to GROUP 36 – On-vehicle Service.)



A14M0054

Rear drum brake removal steps

1. Brake drum
2. Shoe-to-lever spring
3. Adjuster lever
4. Auto adjuster assembly
5. Retainer spring
6. Shoe hold-down cup
7. Shoe hold-down spring
8. Shoe-to-shoe spring
9. Shoe and lining assembly
10. Shoe, lining and lever assembly
11. Retainer
12. Wave washer
13. Parking lever
14. Shoe and lining assembly
15. Shoe hold-down pin
16. Brake pipe connection
17. Snap ring
18. Hub cap

19. Flange nut
20. Rear hub assembly
21. Wheel cylinder
22. Backing plate



Wheel cylinder removal steps

1. Brake drum
2. Shoe-to-lever spring
8. Shoe-to-shoe spring
16. Brake pipe connection
21. Wheel cylinder

Caution

When removing the rear hub assembly, the wheel bearing inner race may be left at the spindle side. In this case, always replace the rear hub assembly, otherwise the hub will damage the oil seal, causing oil leaks or excessive play.


LUBRICATION POINTS



REMOVAL SERVICE POINT

◀▶ RETAINER REMOVAL


Use a flat-tipped screwdriver or the like to open up the retainer joint, and remove retainer.



INSTALLATION SERVICE POINTS

▶◀ WAVE WASHER INSTALLATION

Install the washer in the direction shown in the illustration.




▶◀ RETAINER INSTALLATION

Use pliers or the like to install the retainer or the pin positively.


35100770066

WHEEL CYLINDER DISASSEMBLY AND REASSEMBLY




14S0152

00003584




14Z0012

Brake fluid: DOT3 or DOT4



14Y554

Grease: Repair kit grease



14Z0014

Wheel cylinder repair kit

Disassembly steps



1. Boots
2. Piston assembly
3. Pistons
4. Piston cups

5. Spring
6. Bleeder
7. Wheel cylinder body

REASSEMBLY SERVICE POINT

▶◀ PISTON CUP/PISTON REASSEMBLY


- (1) Use alcohol or specified brake fluid to clean the wheel cylinder and the piston.
- (2) Apply the specified brake fluid to the piston cups and the special tool.

Specified brake fluid: DOT3 or DOT4

- (3) Set the piston cup on the special tool with the lip of the cup facing up, fit the cup onto the special tool, and then slide it down the outside of the tool into the piston groove.

Caution

In order to keep the piston cup from becoming twisted or slanted, slide the piston cup down the tool slowly and carefully, without stopping.



814U0093

35A-28 BASIC BRAKE SYSTEM – Rear Drum Brake/Proportioning Valve

INSPECTION

35100780038

Check the piston and wheel cylinder walls for rust or damage, and if there is any abnormality, replace the entire wheel cylinder assembly.

PROPORTIONING VALVE

35100570093

REMOVAL AND INSTALLATION


Pre-removal Operation

- Brake Fluid Draining
- Air Intake Hose Removal


Post-installation Operation

- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P.35A-9.)
- Air Intake Hose Installation


Flared brake line nuts



14X0343



14X0214




14X0146

00004624

Removal steps



1. Brake pipe
2. Proportioning valve
3. Bracket



A14L0339

INSTALLATION SERVICE POINT

►A◄ BRAKE PIPE CONNECTION

Connect the pipes to the hydraulic unit as shown in the illustration.

1. Proportioning valve – Rear brake (L.H.)
2. Proportioning valve – Rear brake (R.H.)
3. Proportioning valve – Front brake (R.H.)
4. Proportioning valve – Front brake (L.H.)
5. Proportioning valve – Master cylinder (secondary)
6. Proportioning valve – Master cylinder (primary)

ANTI-SKID BRAKING SYSTEM (ABS) <2WD>

CONTENTS

35209000107

GENERAL INFORMATION	3	ON-VEHICLE SERVICE	23
SERVICE SPECIFICATIONS	4	Brake Pedal Check and Adjustment	 Refer to GROUP 35A
LUBRICANTS	5	Stop Lamp Switch Check	 Refer to GROUP 35A
SPECIAL TOOLS	5	Brake Booster Operating Test	 Refer to GROUP 35A
TROUBLESHOOTING	6		

CONTINUED ON NEXT PAGE

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

The SRS includes the following components: SRS-ECU, SRS warning lamp, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

Proportioning Valve Function Test	Refer to GROUP 35A
Brake Fluid Level Sensor Check	Refer to GROUP 35A
Bleeding	23
Front Disc Brake Pad Check and Replacement	Refer to GROUP 35A
Front Disc Brake Rotor Check	Refer to GROUP 35A
Brake Lining Thickness Check	23
Brake Drum Inside Diameter Check	24
Brake Lining and Brake Drum Connection Check	24
Wheel Speed Sensor Output Voltage Check	24
Hydraulic Unit Check	26
Solenoid Valve Check	27
Motor Operation Check	27
Motor Relay and Valve Relay Continuity Check	28
Remedy for a Flat Battery	29

BRAKE PEDAL Refer to GROUP 35A

MASTER CYLINDER AND BRAKE BOOSTER	30
Master Cylinder	30

FRONT DISC BRAKE	Refer to GROUP 35A
-------------------------------	---------------------------

REAR DRUM BRAKE	32
Wheel Cylinder	34

PROPORTIONING VALVE	35
----------------------------------	-----------

HYDRAULIC UNIT	36
-----------------------------	-----------

WHEEL SPEED SENSOR	38
---------------------------------	-----------

ABS-ECU*	41
-----------------------	-----------

GENERAL INFORMATION

35200010109


The ABS consists of components such as the wheel speed sensors, stop lamp switch, hydraulic unit assembly, ABS control unit (ABS-ECU) and the ABS warning lamp. If a problem occurs in the system, the malfunctioning components can be

identified and the trouble symptoms will be memorized by the diagnosis function. In addition, reading of diagnosis codes and service data and actuator testing are possible by using the MUT-II.

Items		Specifications
Master cylinder	Type	Tandem type (with level sensor)
	I.D. mm	22.2
Brake booster	Type	Vacuum type, single
	Effective dia. of power cylinder mm	230
	Boosting ratio	5.0
Proportioning valve	Type	Dual type
	Decompression ratio	0.25
Front brakes	Type	Floating caliper, 1-piston, ventilated disc
	Disc effective dia. x thickness mm	184 × 18
	Wheel cylinder I.D. mm	54.0
	Pad thickness mm	10.0
	Clearance adjustment	Automatic
Rear drum brakes	Type	Leading trailing
	Drum I.D. mm	203
	Wheel cylinder I.D. mm	17.4
	Lining thickness mm	4.4
	Clearance adjustment	Automatic
Brake fluid		DOT3 or DOT4
ABS type		4-sensor, 4-channel method
Speed sensor		Magnet coil type on 4 wheels
Front rotor teeth		43
Rear rotor teeth		43


CONSTRUCTION DIAGRAM

<L.H. drive vehicles>



14M0060

<R.H. drive vehicles>

14M0039
00004484

- 1. ABS valve relay
- 2. ABS motor relay
- 3. ABS warning lamp
- 4. Stop lamp switch
- 5. Rotor

- 6. Wheel-speed sensor
- 7. ABS-ECU
- 8. Diagnosis connector
- 9. Hydraulic unit

SERVICE SPECIFICATIONS

35200030112

Items		Standard value	Limit
Rear drum brake	Lining thickness mm	4.4	1.0
	Drum inside diameter mm	203	205
Resistance between solenoid valve terminals Ω	IN	8.04 – 9.04	—
	OUT	4.04 – 4.54	—
Wheel speed sensor's internal resistance k Ω		1.4 – 1.8	—
Wheel speed sensor insulation resistance k Ω		100 or more	—


LUBRICANTS

35100040044

Items	Specified lubricant
Brake fluid	DOT3 or DOT4
Wheel cylinder body inner surfaces	Repair kit grease
Rear brake shoe and backing plate contact surfaces	Brake grease SAE J310, NLGI No.1
Shoe assembly and auto adjuster assembly contact surfaces	
Shoe and lever assembly and auto adjuster assembly contact surfaces	

SPECIAL TOOLS

35200060111

Tool	Number	Name	Use
	MB991502	MUT-II sub assembly	For checking of ABS (Diagnosis code display when using the MUT-II)
	MB991529	Diagnosis code check harness	For checking of ABS (Diagnosis code display when using the ABS warning lamp)
	MB991008	Piston cup installer	Installation of drum brake wheel cylinder piston cup

TROUBLESHOOTING

35201110129

STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

NOTES WITH REGARD TO DIAGNOSIS

The phenomena listed in the following table are not abnormal.

Phenomenon	Explanation of phenomenon
System check sound	When starting the engine, a thudding sound can sometimes be heard coming from inside the engine compartment, but this is because the system operation check is being performed, and is not an abnormality.
ABS operation sound	1. Sound of the motor inside the ABS hydraulic unit operation. (whine) 2. Sound is the generated along with vibration of the brake pedal. (scraping) 3. When ABS operates, sound is generated from the vehicle chassis due to repeated brake application and release. (Thump: suspension; squeak: tyres)
ABS operation (Long braking distance)	For road surfaces such as snow-covered roads and gravel roads, the braking distance for vehicles with ABS can sometimes be longer than that for other vehicles. Accordingly, advise the customer to drive safely on such roads by lowering the vehicle speed and not being too overconfident.

Diagnosis detection condition can vary depending on the diagnosis code.

Make sure that checking requirements listed in the "Comment" are satisfied when checking the trouble symptom again.

DIAGNOSIS FUNCTION

35201120108

DIAGNOSIS CODES CHECK

Read a diagnosis code by the MUT-II or ABS warning lamp.
(Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.)

ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

INSPECTION CHART FOR DIAGNOSIS CODES


35201130132

Inspect according to the inspection chart that is appropriate for the malfunction code.


Diagnosis code No.	Inspection item	Diagnosis content	Reference page
11	Front right wheel speed sensor	Open circuit	35B-8
12	Front left wheel speed sensor		
13	Rear right wheel speed sensor		
14	Rear left wheel speed sensor		
15	Wheel speed sensor	Abnormal output signal	35B-9
16	Power supply system		35B-9
21	Front right wheel speed sensor	Short circuit	35B-8
22	Front left wheel speed sensor		
23	Rear right wheel speed sensor		
24	Rear left wheel speed sensor		
33	Stop lamp switch system		35B-10
41	Front right solenoid valve		35B-11
42	Front left solenoid valve		
43	Rear right solenoid valve		
44	Rear left solenoid valve		
51	Valve relay		35B-12
53	Motor relay, motor		35B-13
63	ABS-ECU		35B-41 (Replace the ABS-ECU)

INSPECTION PROCEDURE FOR DIAGNOSIS CODES

Code Nos. 11, 12, 13, 14 Wheel speed sensor open circuit	Probable cause
Code Nos.21, 22, 23, 24 Wheel speed sensor short circuit	
Code Nos.11, 12, 13, 14 are output when the ABS-ECU detects an open circuit in at least one of the four wheel-speed sensors.	• Malfunction of wheel speed sensor • Malfunction of wiring harness or connector • Malfunction of ABS-ECU
Code Nos.21, 22, 23, 24 are output under the following cases: • When an open circuit cannot be found, but more than one wheel-speed sensor does not output any signal during driving at 8 km/h or higher. • When a chipped or plugged-up rotor tooth, etc. is detected during driving at 40 km/h or more.	• Malfunction of wheel-speed sensor • Malfunction of rotor • Malfunction of wheel bearing • Malfunction of wiring harness or connector • Malfunction of ABS-ECU



Code No. 15 Wheel speed sensor (Abnormal output signal)	Probable cause
A wheel speed sensor outputs an abnormal signal (other than an open or short-circuit).	- Improper installation of wheel speed sensor - Malfunction of wheel speed sensor - Malfunction of rotor - Malfunction of wheel bearing - Malfunction of wiring harness or connector - Malfunction of ABS-ECU




Code No. 16 Power supply system	Probable cause
The voltage of the ABS-ECU power supply drops lower or rises higher than the specified value. If the voltage returns to the specified value, this code is no longer output.	- Malfunction of wiring harness or connector. - Malfunction of ABS-ECU


Caution

If battery voltage drops or rises during inspection, this code will be output as well. If the voltage returns to standard value, this code is no longer output.


Before carrying out the following inspection, check the battery level, and refill it if necessary.



Code No. 33 Stop lamp switch system	Probable cause
This code is output when the stop lamp switch is not be turned off (when the stop lamp switch stays on for 15 minutes or more although the ABS is not operating).	• Malfunction of stop lamp switch • Malfunction of harness or connector • Malfunction of ABS-ECU




Code Nos.41, 42, 43, 44 Solenoid valve	Probable cause
The ABS-ECU always monitors the solenoid valve drive circuit. It determines that there is an open or short-circuit in the solenoid coil or in a harness. When no current flows in the solenoid even though the ABS-ECU turns on it, and vice versa.	• Malfunction of wiring harness • Malfunction of hydraulic unit • Malfunction of ABS-ECU



Code No.51 Valve relay	Probable cause
When the ignition switch is turned to ON, the ABS-ECU switches the valve relay off and on during the initial check. In that way, the ABS-ECU compares the signals sent to the valve relay with the voltage in the valve relay monitor line. That is how to check if the valve relay is operating normally. The ABS-ECU always checks if current flows in the valve relay monitor line, too. It determines that there is an open circuit when no current flows in the valve relay monitor line, this diagnosis code is output.	• Malfunction of valve relay • Malfunction of wiring harness or connector • Malfunction of ABS-ECU • Malfunction of hydraulic unit

NOTE

Whenever reading the diagnosis codes using the ABS warning lamp (refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points), this diagnosis code will be output. That is not a malfunction but because the valve relay connector is disconnected. After repairing all other malfunctions, connect the valve relay connector again to check the valve relay. Then check that the ABS warning lamp does not illuminate. If it illuminates, the valve relay may be defective. So carry out the following procedure.




Code No.53 Motor relay, motor	Probable cause
This code is output at the following times: - When the motor relay is on but no signal is input to the motor monitor line (motor is not operating, etc.) - When the motor relay is off but a signal is input to the motor monitor line (motor continues operating, etc.)	- Malfunction of motor relay - Malfunction of wiring harness or connector - Malfunction of hydraulic unit - Malfunction of ABS-ECU

<When the motor does not run>

Caution



Because force-driving of the motor by means of the actuator test will drain the battery, the engine should be started and left to run for a while after testing is completed.



<When the motor keep running>

Caution

If there is a melted contact in the motor relay, the motor will keep running, even if the ignition switch is turned off. In this case, immediately remove the fusible link No.8, or disconnect the hydraulic unit connector A-91 or motor relay connector A-53. Excessive running of the motor will waste battery.

**ABS WARNING LAMP INSPECTION**

35201200055

Check that the ABS warning lamp illuminates as follows.

1. When the ignition key is turned to "ON", the ABS warning lamp illuminates for approximately 3 seconds and then switches off.
2. When the ignition key is turned to "START", the ABS warning lamp remains illuminated.
3. When the ignition key is turned from "START" back to "ON", the ABS warning lamp illuminates for approximately 3 seconds and then switches off.
4. If the illumination is other than the above, check the diagnosis codes.

INSPECTION CHART FOR TROUBLE SYMPTOMS

35201140128

Get an understanding of the trouble symptoms and check according to the inspection procedure chart.

Trouble symptoms		Inspection procedure No.	Reference page
Communication with MUT-II is not possible.	Communication with all systems is not possible.	1	35B-16
	Communication with ABS only is not possible.	2	35B-16
When the ignition key is turned to "ON" (engine stopped), the ABS warning lamp does not illuminate.		3	35B-17
After the engine starts, the ABS warning lamp remains illuminated.		4	35B-17
When the ignition key is turned to "START", the ABS warning lamp does not illuminate.		5	35B-18
After the ignition key is turned to "ON", the ABS warning lamp blinks twice, and when turned to "START", it illuminates. When returned to "ON", the lamp flashes once, and then switches off.		6	35B-18
Faulty ABS operation	Unequal braking power on both sides	7	35B-17
	Insufficient braking power		
	ABS operates under normal braking conditions		
	ABS operates before vehicle stops under normal braking conditions		
	Large brake pedal vibration (Caution 2.)	–	–

Caution

1. If steering movements are made when driving at high speed, or when driving on road surfaces with low frictional resistance, or when passing over bumps, the ABS may operate even though sudden braking is not being applied. Because of this, when getting information from the customer, check if the problem occurred while driving under such conditions as these.
2. During ABS operation, the brake pedal may vibrate or may not be able to be depressed. Such phenomena are due to intermittent changes in hydraulic pressure inside the brake line to prevent the wheels from locking and is not an abnormality.

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


Inspection Procedure 1

Communication with MUT-II is not possible. (Communication with all systems is not possible.)	Probable cause
The reason is probably defect in the power supply system (including earth) for the diagnosis line.	Malfunction of wiring harness or connector

Refer to GROUP 13A – Troubleshooting.


Inspection Procedure 2

Communication with MUT-II is not possible. (Communication with ABS only is not possible.)	Probable cause
When communication with the MUT-II is not possible, the cause is probably an open circuit in the ABS-ECU power circuit or an open circuit in the diagnosis output circuit.	- Blown fuse - Malfunction of wiring harness or connector - Malfunction of ABS-ECU



Inspection Procedure 3

When Ignition key is turned to "ON" (engine stopped), ABS warning lamp does not illuminate.	Probable cause
The cause may be: an open circuit in the lamp power supply circuit, a blown lamp bulb, an open circuit in both the circuit between the ABS warning lamp and the ABS-ECU.	• Blown fuse • Burnt out ABS warning lamp bulb • Malfunction of wiring harness or connector




Inspection Procedure 4

Even after the engine is started, the ABS warning lamp remains illuminated.	Probable cause
The cause is probably a short-circuit in the ABS warning lamp illumination circuit.	• Malfunction of combination meter • Malfunction of ABS-ECU • Malfunction of wiring harness


NOTE

This trouble symptom is limited to cases where communication with the MUT-II is possible (ABS-ECU power supply is normal) and the diagnosis code is a normal diagnosis code.




Inspection Procedure 5

When the ignition key is turned to "START", the ABS warning lamp does not illuminate.	Probable cause
Current does not flow in the ABS-ECU when the ignition switch is turned to "START". Current flows in the ABS warning lamp even when the ignition switch is turned to "START". Therefore, the valve relay, which current is supplied through the ABS-ECU, turns off when the ignition switch is at "START". However, the warning lamp circuit of the valve relay must turn on in turn. So the cause must be a defective circuit on valve relay side.	• Malfunction of wiring harness or connector • Malfunction of ABS-ECU




Inspection Procedure 6

After the ignition key is turned to "ON", the ABS warning lamp blinks twice, and when turned to "START", it illuminates. When returned to "ON", the lamp flashes once, and then switches off.	Probable cause
The ABS-ECU causes the ABS warning lamp to illuminate during the initial check (approx. 3 seconds). During the initial check, the valve relay turns from off to on, off and back to on again. If there is an open circuit in the harness between the ABS-ECU and the ABS warning lamp, the lamp will illuminate only when the valve relay is OFF during valve relay test, etc.	• Malfunction of wiring harness or connector • Malfunction of ABS-ECU



Inspection Procedure 7

Brake operation is abnormal.	Probable cause
This varies depending on the driving conditions and the road surface conditions, so problem diagnosis is difficult. However, if a normal diagnosis code is displayed, carry out the following inspection.	• Improper installation of wheel speed sensor • Incorrect sensor harness contact • Foreign material adhering to wheel speed sensor • Malfunction of wheel speed sensor • Malfunction of rotor • Malfunction of wheel bearing • Malfunction of hydraulic unit • Malfunction of ABS-ECU



DATA LIST REFERENCE TABLE

35201150077

The following items can be read by the MUT-II from the ABS-ECU input data.

1. When the system is normal

Item No.	Check item	Checking requirements	Normal value
11	Front-right wheel speed sensor	Perform a test run	Vehicle speeds displayed on the speedometer and MUT-II are identical.
12	Front-left wheel speed sensor		
13	Rear-right wheel speed sensor		
14	Rear-left wheel speed sensor		
16	ABS-ECU power supply voltage	Ignition switch power supply voltage and valve monitor voltage	9–16 V
33	Stop lamp switch	Depress the brake pedal.	ON
		Release the brake pedal.	OFF

2. When the ABS-ECU shut off ABS operation.

When the diagnosis system stops the ABS-ECU, the MUT-II display data will be unreliable.


ACTUATOR TEST REFERENCE TABLE

35201160025

The MUT-II activates the following actuators for testing.

NOTE

1. If the ABS-ECU runs down, actuator testing cannot be carried out.
2. Actuator testing is only possible when the vehicle is stationary. If the vehicle speed during actuator testing exceeds 10 km/h, forced actuation will be canceled.
3. During the actuator test, the ABS warning lamp will illuminate and the anti-skid control will be cancelled.

**ACTUATOR TEST SPECIFICATIONS**

No.	Item	Solenoid valves and pump motors in the hydraulic unit (simple inspection mode)
01	Solenoid valve for front-left wheel	
02	Solenoid valve for front-right wheel	
03	Solenoid valve for rear-left wheel	
04	Solenoid valve for rear-right wheel	

CHECK AT ABS-ECU

35201180106

TERMINAL VOLTAGE CHECK CHART

1. Measure the voltages between terminals (15), (25) and (42) (earth terminals) and each respective terminal.

NOTE

Do not measure terminal voltage for approx. 3 seconds after the ignition switch is turned on. The ABS-ECU performs the initial check for that period.

2. The terminal layouts are shown in the illustrations below.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----


14Y0076

Con- nector termi- nal No.	Signal	Checking requirements		Normal condition
1	Output to rear-right sole- noid valve (IN)	Ignition switch: ON (When solenoid valve is off)		System voltage
14	Output to front-left sole- noid valve (OUT)			
15	Output to rear-right sole- noid valve (OUT)			
16	Output to front-left sole- noid valve (IN)			
25	Memory power supply	Always		System voltage
26	ABS-ECU power supply	Ignition switch: ON		System voltage
		Ignition switch: START		0 V
33	Input from diagnosis in- dication selection	Connect the MUT-II.		0 V
		Do not connect the MUT-II.		Approx. 12 V
34	Valve relay monitor	Ignition switch: ON		System voltage
35	Motor monitor	Ignition switch: ON	Motor is on.	System voltage
			Motor is off.	0.5V or less
37	Output to rear-left sole- noid valve (OUT)	Ignition switch: ON (When solenoid valve is off)		System voltage
38	Output to front-right sole- noid valve (IN)			
40	Input from stop lamp switch	Ignition switch: ON	Stop lamp switch ON	System voltage
			Stop lamp switch OFF	1 V or less

Con- nector termi- nal No.	Signal	Checking requirements		Normal condition
41	MUT-II	Connect the MUT-II.		Serial com- munication with MUT-II
		Do not connect the MUT-II.		1 V or less
42	Output to valve relay	Ignition switch; ON	The relay is on.	2 V or less
			The relay is off. The system runs down.	System voltage
43	Output to motor relay	Ignition switch: ON	Motor is on.	2 V or less
			Motor is off.	System voltage
44	Output to ABS warning lamp	Ignition switch: ON	The lamp is switched off.	System voltage
			The lamp is illuminated.	3 V or less
45	Output to rear-left sole- noid valve (IN)	Ignition switch: ON (When solenoid valve is off)		System volt- age
46	Output to front-right sole- noid valve (OUT)			


RESISTANCE AND CONTINUITY BETWEEN HARNESS-SIDE CONNECTOR TERMINALS

1. Turn the ignition switch off and disconnect the ABS-ECU connectors before checking resistance and continuity.
2. Check them between the terminals indicated in the table below.
3. The terminal layouts are shown in the illustrations below.



14Y0077

Connector terminal No.	Signal	Normal condition
2 – Body earth	ABS-ECU earth	Continuity
6-19	Front-left wheel speed sensor	1.4 – 1.8 kΩ
7-20	Rear-right wheel speed sensor	1.4 – 1.8 kΩ
8-21	Front-right wheel speed sensor	1.4 – 1.8 kΩ
9-22	Rear-left wheel speed sensor	1.4 – 1.8 kΩ
17 – Body earth	ABS-ECU earth	Continuity
31 – Body earth		
39 – Body earth		



ON-VEHICLE SERVICE

35200150085

BLEEDING

Caution


Use the specified brake fluid. Avoid using a mixture of the specified brake fluid and other fluid.

Specified brake fluid: DOT3 or DOT4

MASTER CYLINDER BLEEDING

The master cylinder used has no check valve, so if bleeding is carried out by the following procedure, bleeding of air from the brake pipeline will become easier. (When brake fluid is not contained in the master cylinder.)

- (1) Fill the reserve tank with brake fluid.
- (2) Keep the brake pedal depressed.
- (3) Have another person cover the master cylinder outlet with a finger.
- (4) With the outlet still closed, release the brake pedal.
- (5) Repeat steps (2) – (4) three or four times to fill the inside of the master cylinder with brake fluid.




BRAKE PIPE LINE BLEEDING

Start the engine and bleed the air in the sequence shown in the figure.

Caution

Be sure to install a filter to the master cylinder reservoir tank when supplying brake fluid.



BRAKE LINING THICKNESS CHECK

35100300050

1. Remove the brake drum.
2. Measure the wear of the brake lining at the place worn the most.


Standard value: 4.4 mm

Limit: 1.0 mm

Replace the shoe and lining assembly if brake lining thickness is less than the limit if it is not worn evenly. For information concerning the procedures for installation of the shoe and lining assembly, refer to P.35B-32.

Caution

1. Whenever the shoe and lining assembly is replaced, replace both RH and LH assemblies as a set to prevent car from pulling to one side when braking.
2. If there is a significant difference in the thickness of the shoe and lining assemblies on the left and right sides, check the sliding condition of the piston.



BRAKE DRUM INSIDE DIAMETER CHECK


35100320049

1. Remove the brake drum.
2. Measure the inside diameter of the brake drum at two or more locations.

Standard value: 203 mm

Limit: 205 mm

3. Replace brake drums, shoe and lining assembly when wear exceeds the limit value or is badly imbalanced.




BRAKE LINING AND BRAKE DRUM CONNECTION CHECK

35100310107

1. Remove the brake drum.
2. Remove the shoe and lining assembly. (Refer to P.35B-32.)
3. Chalk inner surface of brake drum and rub with shoe and lining assembly.
4. Replace shoe and lining assembly or brake drums if there are any irregular contact area.

NOTE

Clean off chalk after check.



WHEEL SPEED SENSOR OUTPUT VOLTAGE CHECK

35200160132

1. Lift up the vehicle and release the parking brake.
2. Disconnect the ABS-ECU connector, and then use the special tool (inspection harness for connector pin contact pressure) to measure the output voltage at the harness-side connector.

3. Rotate the wheel to be measured at approximately 1/2–1 rotation per second, and check the output voltage using a circuit tester or an oscilloscope.


Wheel speed sensor	Front left	Front right	Rear left	Rear right
Terminal No.	6	8	9	7
	19	21	22	20

Output voltage

When measuring with a circuit tester:
50 mV or more

When measuring with an oscilloscope:
120 mV p-p or more

4. If the output voltage is lower than the above values, the reason could be as follow:
 - Faulty wheel speed sensor.
 So replace the wheel speed sensor.



Inspecting Waveforms With An Oscilloscope

Use the following method to observe the output voltage waveform from each wheel sensor with an oscilloscope.

- Start the engine, and rotate the front wheels by engaging 1st gear (vehicles with manual transmission) or D range (vehicles with automatic transmission). Turn the rear wheels manually so that they rotate at a constant speed.

NOTE

- Check the connection of the sensor harness and connector before using the oscilloscope.
- The waveform measurements can also be taken while the vehicle is actually moving.
- The output voltage will be small when the wheel speed is low, and similarly it will be large when the wheel speed is high.

Points In Waveform Measurement

Symptom	Probable causes	Remedy
Too small or zero waveform amplitude	Faulty wheel speed sensor	Replace sensor
Waveform amplitude fluctuates excessively (this is no problem if the minimum amplitude is 100 mV or more)	Axle hub eccentric or with large runout	Replace hub
Noisy or disturbed waveform	Open circuit in sensor	Replace sensor
	Open circuit in harness	Correct harness
	Incorrectly mounted wheel speed sensor	Mount correctly
	Rotor with missing or damaged teeth	Replace rotor

NOTE

The wheel speed sensor cable moves following motion of the front or rear suspension. Therefore, it is likely that it has an open circuit only when driving on rough roads and it functions normally on ordinary roads. It is, therefore, recommended to observe sensor output voltage waveform also under special conditions, such as rough road driving.

HYDRAULIC UNIT (HU) CHECK

35200170142

Caution

Turn the ignition switch off before connecting or disconnecting the MUT-II.

1. Jack up the vehicle and support the vehicle with rigid racks placed at the specified jack-up points or place the wheels which are checked on the rollers of the braking force tester.

Caution


1. The roller of the braking force tester and the tyre should be dry during testing.
2. When testing the front brakes, apply the parking brake, and when testing the rear brakes, stop the front wheels by chocking them.
2. Release the parking brake, and feel the drag force (drag torque) on each road wheel. When using the braking force tester, take a reading of the brake drag force.
3. Turn the ignition key to the OFF position and set the MUT-II.
4. After checking that the shift lever <M/T> or the selector lever <A/T> is in neutral, start the engine.
5. Use the MUT-II to force-drive the actuator.

NOTE

1. During the actuator test, the ABS warning lamp will illuminate and the anti-skid control will be cancelled.
2. When the ABS has been interrupted by the fail-safe function, the MUT-II actuator testing cannot be used.
6. Turn the wheel by hand and check the change in braking force when the brake pedal is depressed. When using the braking force tester, depress the brake pedal until the braking force is at the following values, and check that the braking force decreases when the actuator is force-driven.

Front wheel	785–981 N
Rear wheel	294–490 N


The result should be as shown in the following diagram.



7. If the result of inspection is abnormal, correct according to the "Diagnosis Table" (Refer to P.35B-27).
8. After inspection, disconnect the MUT-II immediately after turning the ignition switch to OFF.

Diagnosis Table

No.	Operation	Judgement – Normal	Judgement – Abnormal	Probable cause	Remedy
01	(1) Depress brake pedal to lock wheel. (2) Using the MUT-II, select the wheel to be checked and force the actuator to operate. (3) Turn the selected wheel manually to check the change of brake force.	Brake force released for 3 seconds after locking.	Wheel does not lock when brake pedal is depressed.	Clogged brake line other than HU	Check and clean brake line
02				Clogged hydraulic circuit in HU	Replace HU assembly
03			Brake force is not released	Incorrect HU brake tube connection	Connect correctly
04				HU solenoid valve not functioning correctly	Replace HU assembly




SOLENOID VALVE CHECK

35201070113

Measure the resistance between terminals.

Standard value:

Solenoid valve	Measurement terminals	Resistance between terminals.
Front IN (right side)	1-11	8.04 – 9.04 Ω
Front IN (left side)	4-11	
Rear IN (right side)	3-11	
Rear IN (left side)	2-11	
Front OUT (right side)	5-11	4.04 – 4.54 Ω
Front OUT (left side)	8-11	
Rear OUT (right side)	7-11	
Rear OUT (left side)	6-11	



MOTOR OPERATION CHECK


35200180114

Connect the battery and check to be sure that the sound of the hydraulic unit motor operating can be heard.

Caution


The battery power should not be applied for more than 1 second.

<L.H. drive vehicles>




16M0297

Motor relay connector



20Z0004

Valve relay connector

20Z0003
00004684**MOTOR RELAY AND VALVE RELAY
CONTINUITY CHECK**

35201090119

<L.H. drive vehicles>


Motor relay

Battery voltage	Terminal No.			
	1	2	3	5
Power is not supplied	○		○	
Power is supplied	⊕	○	⊖	○

Valve relay


Battery voltage	Terminal No.				
	1	2	3	4	5
Power is not supplied	○		○		○
Power is supplied	⊕		⊖	○	○

<R.H. drive vehicles>




16M0037

Motor relay connector



14X0104

Valve relay connector

14W0039
00004683


<R.H. drive vehicles>

Motor relay

Battery voltage	Terminal No.			
	1	3	4	5
Power is not supplied	○	○		
Power is supplied	⊕	⊖	○	○

Valve relay

Battery voltage	Terminal No.				
	1	2	3	5	6
Power is not supplied	○	○	○	○	
Power is supplied		⊕	○	⊖	○



REMEDY FOR A FLAT BATTERY

35200350102

When booster cables are used to start the engine when the battery is completely flat and then the vehicle is immediately driven without waiting for the battery to recharge itself to some extent, the engine may misfire, and driving might not be possible.

This happens because ABS consumes a great amount of current for its self-check function; the remedy is to either allow the battery to recharge sufficiently, or to remove the fusible link for ABS circuit, thus disabling the anti-skid brake system. The ABS warning lamp will illuminate when the fusible link (for ABS) is removed.

After the battery has sufficiently recharged, install the fusible link (for ABS) and restart the engine; then check to be sure the ABS warning lamp is not illuminated.

MASTER CYLINDER AND BRAKE BOOSTER




35200400142

REMOVAL AND INSTALLATION

Refer to GROUP 35A.

MASTER CYLINDER**DISASSEMBLY AND REASSEMBLY**


35200450062

**Disassembly steps**


1. Reservoir cap assembly
2. Reservoir cap
3. Diaphragm
4. Filter
5. Brake fluid level sensor
6. Float
7. Reservoir stopper bolt



8. Reservoir tank
9. Reservoir seal
10. Piston stopper bolt
11. Gasket
12. Piston stopper ring
13. Primary piston assembly
14. Secondary piston assembly
15. Master cylinder body

**DISASSEMBLY SERVICE POINTS****◀A▶ PISTON STOPPER BOLT DISASSEMBLY**

Remove the piston stopper bolt, while depressing the piston.

**◀B▶ PISTON STOPPER RING DISASSEMBLY**

Remove the piston stopper ring, while depressing the piston.


INSPECTION

35200460027

- Check the inner surface of master cylinder body for rust or pitting.
- Check the primary and secondary pistons for rust, scoring, wear, damage or wear.
- Check the diaphragm for cracks and wear.

- Loosening the Parking Brake Cable Adjusting Nut.
- Brake Fluid Draining

- Brake Line Bleeding (Refer to P.35B-23.)
- Parking Brake Lever Stroke Adjustment (Refer to GROUP 36 – On-vehicle Service.)





1. Brake drum
2. Shoe-to-lever spring
3. Adjuster lever
4. Auto adjuster assembly
5. Retainer spring
6. Shoe hold-down cup
7. Shoe hold-down spring
8. Shoe-to-shoe spring
9. Shoe and lining assembly
10. Shoe, lining and lever assembly
11. Retainer
12. Wave washer
13. Parking lever
14. Shoe and lining assembly
15. Shoe hold-down pin
16. Brake pipe connection
17. Snap ring
18. Hub cap
19. Flange nut
20. Rear hub and rotor assembly
21. Wheel cylinder
22. Speed sensor
23. Backing plate

1. Brake drum
2. Shoe-to-lever spring
8. Shoe-to-shoe spring
16. Brake pipe connection
21. Wheel cylinder

1. Be careful when handling the pole piece at the tip of the speed sensor and the toothed edge of the rotor so as not to damage them by striking against other parts.
2. When removing the rear hub assembly, the wheel bearing inner race may be left at the spindle side. In this case, always replace the rear hub assembly, otherwise the hub will damage the oil seal, causing oil leaks or excessive play.


LUBRICATION POINTS



REMOVAL SERVICE POINT

◀A▶ RETAINER REMOVAL


Use a flat-tipped screwdriver or the like to open up the retainer joint, and remove retainer.



INSTALLATION SERVICE POINTS

▶A◀ WAVE WASHER INSTALLATION

Install the washer in the direction shown in the illustration.




▶B◀ RETAINER INSTALLATION




Use pliers or the like to install the retainer or the pin positively.

WHEEL CYLINDER DISASSEMBLY AND REASSEMBLY

35200720019




1450152



Disassembly steps

1. Boots
2. Piston assembly
3. Pistons
4. Piston cups

5. Spring
6. Bleeder
7. Wheel cylinder body



REASSEMBLY SERVICE POINT

▶A◀ PISTON CUP/PISTON REASSEMBLY

- (1) Use alcohol or specified brake fluid to clean the wheel cylinder and the piston.
- (2) Apply the specified brake fluid to the piston cups and the special tool.

Specified brake fluid: DOT3 or DOT4

- (3) Set the piston cup on the special tool with the lip of the cup facing up, fit the cup onto the special tool, and then slide it down the outside of the tool into the piston groove.

Caution

In order to keep the piston cup from becoming twisted or slanted, slide the piston cup down the tool slowly and carefully, without stopping.

INSPECTION

35100780038

Check the piston and wheel cylinder walls for rust or damage, and if there is any abnormality, replace the entire wheel cylinder assembly.

PROPORTIONING VALVE

35200570089

REMOVAL AND INSTALLATION**Pre-removal Operation**

- Brake Fluid Draining
- Air Intake Hose Removal

Post-Installation Operation


- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P.35B-23.)
- Air Intake Hose Installation

Flared brake line nuts


15 Nm



14X0343

14X0146
00004486**Removal steps**

1. Brake pipe
2. Proportioning valve
3. Bracket

**INSTALLATION SERVICE POINT****▶A◀ BRAKE PIPE CONNECTION**

Connect the pipes to the hydraulic unit as shown in the illustration.

1. Proportioning valve – Rear brake (L.H.)
2. Proportioning valve – Rear brake (R.H.)
3. Proportioning valve – Hydraulic unit
4. Proportioning valve – Hydraulic unit

HYDRAULIC UNIT

35200860155

REMOVAL AND INSTALLATION


Pre-removal Operation

- Brake Fluid Draining
- Windshield Wiper Motor Removal <L.H. drive vehicles> (Refer to GROUP 51)


Post-installation Operation

- Windshield Wiper Motor Installation <L.H. drive vehicles> (Refer to GROUP 51)
- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P35B-23.)
- Brake Pedal Adjustment (Refer to GROUP 35A – On-vehicle Service.)


<L.H. drive vehicles>



14M0049



<R.H. drive vehicles>


14M0003
00004485**Removal steps**

- ▶A◀ 1. Brake pipe connection
2. Connector bracket <R.H. drive vehicles>
3. Hydraulic unit assembly
4. Hydraulic unit bracket

◀A▶

REMOVAL SERVICE POINT**◀A▶ HYDRAULIC UNIT ASSEMBLY REMOVAL****Caution**

1. The hydraulic unit assembly is heavy, and so care should be taken when removing it.
2. The hydraulic unit assembly is not to be disassembled; its nuts and bolts should absolutely not be loosened.
3. The hydraulic unit assembly must not be dropped or otherwise subjected to impact shocks.
4. The hydraulic unit assembly must not be turned upside down or laid on its side.

**INSTALLATION SERVICE POINT****▶A◀ BRAKE PIPE CONNECTION**

Connect the pipes to the hydraulic unit assembly as shown in the illustration.


1. To the proportioning valve (RH)
2. To the proportioning valve (LH)
3. From the master cylinder (Primary)
4. From the master cylinder (Secondary)
5. To the front brake (RH)
6. To the front brake (LH)

WHEEL SPEED SENSOR

REMOVAL AND INSTALLATION

Post-Installation Operation

- Wheel Speed Sensor Output Voltage Check
(Refer to P.35B-24.)

**Front speed sensor removal steps**

1. Front speed sensor
2. Front rotor
(Refer to GROUP 26 – Drive shaft.)

NOTE


The front rotor is integrated with the drive shaft and is not disassembled.


Rear speed sensor removal steps

3. Rear rotor
(Refer to GROUP 27 – Rear Axle Hub.)
4. Rear speed sensor

REMOVAL SERVICE POINT**◀A▶ FRONT SPEED SENSOR/REAR SPEED SENSOR REMOVAL****Caution**

Be careful when handling the pole piece at the tip of the speed sensor and the toothed edge of the rotor so as not to damage them by striking against other parts.



**INSTALLATION SERVICE POINT****►A◄ REAR SPEED SENSOR INSTALLATION****Caution**

Be careful that the pole piece at the end of the speed sensor and the rotor teeth do not become damaged by striking them against the metal parts.

Insert a thickness gauge into the space between the speed sensor's pole piece and the rotor's toothed surface, and then tighten the speed sensor bracket at the position where the clearance is the standard value all around.

Standard value: 0.1 – 2.0 mm

INSPECTION

35200840111


SPEED SENSOR

- (1) Check whether any metallic foreign material has adhered to the pole piece at the speed sensor tip, and if so, remove it.

Also check whether the pole piece is damaged, and if so, replace it with a new one.

NOTE

The pole piece can become magnetized because of the magnet but into the speed sensor, with the result that metallic foreign material easily adheres to it. Moreover, the pole piece may not be able to function to correctly sense the wheel rotation speed if it is damaged.



- (2) Measure the resistance between the speed sensor terminals.


Standard value: 1.4 – 1.8 kΩ

If the internal resistance of the speed sensor is not within the standard value, replace with a new speed sensor.

- (3) Check the speed sensor cable for breakage, damage or disconnection; replace with a new one if a problem is found.

NOTE

When checking for cable damage, remove the cable clamp part from the body and then bend and pull the cable near the clamp to check whether or not temporary disconnection occurs.

**SPEED SENSOR INSULATION INSPECTION**

- (1) Remove all connections from the speed sensor, and then measure the resistance between terminals (1) and (2) and the body of the speed sensor.

Standard value: 100 k Ω or more

- (2) If the speed sensor insulation resistance is outside the standard value range, replace with a new speed sensor.

TOOTHED ROTOR

Check whether rotor teeth are broken or deformed, and, if so, replace the rotor.

ABS-ECU


35200980127

REMOVAL AND INSTALLATION**CAUTION: SRS**

When removing and installing the ABS-ECU from vehicles equipped with SRS, do not let it bump against the SRS diagnosis unit or other components.

Pre-removal and Post-installation Operation

- Floor Console Removal and Installation (Refer to GROUP 52A.)

**Removal steps**

1. ABS-ECU bracket
2. ABS-ECU

INSPECTION

Refer to P.35B-21.

35200990083

NOTES