





Workshop Manual

electrical wiring

SUPPLEMENT

PAJERO 2002



Pub. No. PHJE0001-B

PAJERO

ELECTRICAL WIRING SUPPLEMENT

FOREWORD

This publication contains information on major changes which have occurred as a result of a model change for the PAJERO.

It contains only additions and changes to the original issue. For detailed information on inspection of the electrical system components, you should refer to the following publications as well as this manual if necessary.

Note that some wiring harness configuration diagrams and circuit diagrams are compilation diagrams containing information for different vehicle specifications, and actual diagrams may not be identical to those shown in the manual.

TECHNICAL INFORMATION MANUAL
PYJE0001

WORKSHOP MANUAL
ENGINE GROUP

PWEE□□□□
(Looseleaf edition)
CHASSIS GROUP

PWJE0001
PWJE0001-A
PWJE0001-B
PWJT0008R-B
(CD-ROM)

ELECTRICAL WIRING
PHJE0001
PHJE0001-A

BODY REPAIR MANUAL
PBJE0001

PARTS CATALOGUE
B603H602A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.



MITSUBISHI MOTORS CORPORATION

“GDI” is a registered mark of Mitsubishi Motors Corporation.

© Mitsubishi Motors Corporation

April 2001

GROUP INDEX

GENERAL	0
WIRING HARNESS CONFIGURATION DIAGRAMS	1
SINGLE PART INSTALLATION POSITION	2
CIRCUIT DIAGRAMS	3

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLE

WARNING!

- (1) Improper service or maintenance of any component of the SRS or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) SRS components should not be subjected to heat over 93 °C, so remove the SRS-ECU, air bag module (driver's side and front passenger's side) and clock spring before drying or baking the vehicle after painting.
- (3) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (4) MITSUBISHI dealer personal must thoroughly review the Workshop Manual (chassis), and especially its GROUP 52B—Supplemental Restraint System (SRS), before beginning any service or maintenance of any component of the SRS or any SRS-related component.

HOW TO USE THIS MANUAL

CONTENTS

The preceding page contains GROUP INDEX that lists the group title and group number.

PAGE NUMBERS

All page numbers consist of two sets of digits separated by a dash. The digits preceding the dash identify the number of the group. The digits following the dash represent the consecutive page number within the group. The page number can be found on the top left or right of each page.