

TIRES AND WHEELS

CONTENTS

	page		page
TIRES	1	WHEELS	9

TIRES

INDEX

	page		page
DESCRIPTION AND OPERATION		TIRE NOISE OR VIBRATION	4
RADIAL-PLY TIRES	2	TIRE WEAR PATTERNS	3
REPLACEMENT TIRES	3	TREAD WEAR INDICATORS	3
SPARE TIRE (TEMPORARY)	2	SERVICE PROCEDURES	
TIRE INFLATION PRESSURES	2	REPAIRING TIRE LEAKS	6
TIRE INFORMATION	1	TIRE AND WHEEL MATCH MOUNTING	6
TIRE PRESSURE FOR HIGH—SPEED OPERATION	3	TIRE AND WHEEL ROTATION	6
DIAGNOSIS AND TESTING		CLEANING AND INSPECTION	
LEAD CORRECTION CHART	4	CLEANING OF TIRES	7
PRESSURE GAUGES	3	SPECIFICATIONS	
		TIRE SPECIFICATIONS	8

DESCRIPTION AND OPERATION

TIRE INFORMATION

Tires are designed and engineered for each specific vehicle. They provide the best overall performance for normal operation. The ride and handling characteristics match the vehicle's requirements. With proper care they will give excellent reliability, traction, skid resistance, and tread life.

Driving habits have more effect on tire life than any other factor. Careful drivers will obtain, in most cases, much greater mileage than severe use or careless drivers. A few of the driving habits which will shorten the life of any tire are:

- Rapid acceleration
- Severe application of brakes
- High-speed driving
- Taking turns at excessive speeds
- Striking curbs and other obstacles

Radial ply tires are more prone to irregular tread wear. It is important to follow the tire rotation interval shown in the section on Tire Rotation. This will help to achieve a greater tread-life potential.

TIRE IDENTIFICATION

Tire type, size, aspect ratio and speed rating are encoded in the letters and numbers imprinted on the side wall of the tire. Refer to the chart to decipher the tire identification code (Fig. 1).

Performance tires will have a speed rating letter after the aspect ratio number. The speed rating is not always printed on the tire sidewall. The letter **S** indicates that the tire is speed rated up to 112 mph.


- **Q** up to 100 mph
- **T** up to 118 mph
- **U** up to 124 mph
- **H** up to 130 mph
- **V** up to 149 mph
- **Z** more than 149 mph (consult the tire manufacturer for the specific speed rating)

An All Season type tire will have either **M + S**, **M & S** or **M-S** (indicating mud and snow traction) imprinted on the side wall.

TIRE CHAINS

This vehicle was not designed to allow the use of snow chains on the tires. If snow chains are installed on the tires, there may not be sufficient clearance under all driving conditions. This may cause damage

DESCRIPTION AND OPERATION (Continued)

**Fig. 1 Tire Identification**

to the body and/or suspension components of the vehicle.

RADIAL-PLY TIRES

Radial-ply tires improve handling, tread life, ride quality and decrease rolling resistance.

Radial-ply tires must always be used in sets of four and under no circumstances should they be used on the front only. They may be mixed with temporary spare tires when necessary. A maximum speed of 50 MPH is recommended while a temporary spare is in use.

Radial-ply tires have the same load-carrying capacity as other types of tires of the same size. They also use the same recommended inflation pressures.

The use of oversized tires, either in the front or rear of the vehicle, can cause vehicle drive train failure. This could also cause inaccurate wheel speed signals when the vehicle is equipped with Anti-Lock Brakes.


It is recommended that tires from different manufacturers NOT be mixed. The proper tire pressure should be maintained on all four tires. For proper tire pressure refer to the Tire Inflation Pressure Chart provided with the vehicle.

SPARE TIRE (TEMPORARY)


The temporary spare tire is designed for emergency use only. The original tire should be repaired and reinstalled at the first opportunity, or a new tire purchased. Do not exceed speeds of 50 MPH. Refer to Owner's Manual for complete details.

TIRE INFLATION PRESSURES

Under inflation causes rapid shoulder wear, tire flexing, and can result in tire failure (Fig. 2).

**Fig. 2 Under Inflation Wear**

Over inflation causes rapid center wear and loss of the tire's ability to cushion shocks (Fig. 3).

**Fig. 3 Over Inflation Wear**

Improper inflation can cause:

- Uneven wear patterns
- Reduced tread life
- Reduced fuel economy
- Unsatisfactory ride
- The vehicle to drift.

For proper tire pressure specification refer to the Tire Inflation Pressure Chart Placard provided with the vehicle.

DESCRIPTION AND OPERATION (Continued)

Tire pressures have been chosen to provide safe operation, vehicle stability, and a smooth ride. Tire pressure should be checked cold once per month. Check tire pressure more frequently when the weather temperature varies widely. Tire pressure will decrease when the outdoor temperature drops.

Inflation pressures specified on the placard are always the cold inflation pressure of the tire. Cold inflation pressure is obtained after the vehicle has not been operated for at least 3 hours, or the vehicle is driven less than one mile after being inoperative for 3 hours. Tire inflation pressures may increase from 2 to 6 pounds per square inch (psi) during operation. Do not reduce this normal pressure build-up.

WARNING: OVER OR UNDER INFLATED TIRES CAN AFFECT VEHICLE HANDLING. THE TIRE CAN FAIL SUDDENLY, RESULTING IN LOSS OF VEHICLE CONTROL.

TIRE PRESSURE FOR HIGH—SPEED OPERATION

Chrysler Corporation advocates driving at safe speeds within posted speed limits. Where speed limits allow the vehicle to be driven at high speeds, correct tire inflation pressure is very important. For speeds up to and including 75 mph (120 km/h), tires must be inflated to the pressures shown on the tire placard. For continuous speeds in excess of 75 mph (120 km/h), tires must be inflated to the maximum pressure specified on the tire sidewall.

Vehicles loaded to the maximum capacity should not be driven at continuous speeds above 75 mph (120 km/h).

For emergency vehicles that are driven at speeds over 90 mph (144 km/h), special high-speed tires must be used. Consult tire manufacturer for correct inflation pressure recommendations.

REPLACEMENT TIRES

The original equipment tires provide a proper balance of many characteristics such as:

- Ride
- Noise
- Handling
- Durability
- Tread life
- Traction
- Rolling resistance
- Speed capability

It is recommend that tires equivalent to the original equipment tires be used when replacement is needed.

Failure to use equivalent replacement tires may adversely affect the safety and handling of the vehicle.

The use of oversize tires not listed in the specification charts may cause interference with vehicle components. Under extremes of suspension and steering travel, interference with vehicle components may cause tire damage.

WARNING: FAILURE TO EQUIP THE VEHICLE WITH TIRES HAVING ADEQUATE SPEED CAPABILITY CAN RESULT IN SUDDEN TIRE FAILURE.

DIAGNOSIS AND TESTING


PRESSURE GAUGES

A high-quality air-pressure gauge is recommended to check tire pressure. After checking with the gauge, replace valve caps and finger tighten.

TREAD WEAR INDICATORS

Tread wear indicators are molded into the bottom of the tread grooves. When tread depth is 1.6 mm (1/16 in.), the tread wear indicators will appear as a 13 mm (1/2 in.) band.

Tire replacement is necessary when indicators appear in two or more grooves or if localized balding occurs (Fig. 4).













J8922-5

Fig. 4 Tread Wear Indicators

TIRE WEAR PATTERNS

Under inflation results in faster wear on shoulders of tire. Over inflation causes faster wear at center of tread.

DIAGNOSIS AND TESTING (Continued)

CONDITION	RAPID WEAR AT SHOULDERS	RAPID WEAR AT CENTER	CRACKED TREADS	WEAR ON ONE SIDE	FEATHERED EDGE	BALD SPOTS	SCALLOPED WEAR
EFFECT	1.  2. 						
CAUSE	UNDER-INFLATION OR LACK OF ROTATION 	OVER-INFLATION OR LACK OF ROTATION 	UNDER-INFLATION OR EXCESSIVE SPEED*	EXCESSIVE CAMBER 	INCORRECT TOE 	UNBALANCED WHEEL OR TIRE DEFECT* 	LACK OF ROTATION OF TIRES OR WORN OR OUT-OF-ALIGNMENT SUSPENSION.
CORRECTION	ADJUST PRESSURE TO SPECIFICATIONS WHEN TIRES ARE COOL ROTATE TIRES			ADJUST CAMBER TO SPECIFICATIONS	ADJUST TOE-IN TO SPECIFICATIONS	DYNAMIC OR STATIC BALANCE WHEELS	ROTATE TIRES AND INSPECT SUSPENSION SEE GROUP 2

*HAVE TIRE INSPECTED FOR FURTHER USE.

RN797

Fig. 5 Tire Wear Patterns

Excessive camber causes the tire to run at an angle to the road. One side of tread is worn more than the other.

Excessive toe-in or toe-out causes wear on the tread edges of the tire, from dragging of tire. There is a feathered effect across the tread (Fig. 5).

TIRE NOISE OR VIBRATION

Radial-ply tires are sensitive to force impulses caused by improper mounting, vibration, wheel defects, or possibly tire imbalance.


To find out if tires are causing the noise or vibration, drive the vehicle over a smooth road at varying

speeds. Note the effect of acceleration and deceleration on noise level. Differential and exhaust noises will change in intensity as speed varies, while tire noise will usually remain constant.


LEAD CORRECTION CHART

Use the following chart to diagnose a vehicle that has a complaint of a drift or lead condition. The use of the chart will help to determine if the lead condition is the result of a bad tire or is caused by the front wheel alignment.

VEHICLE LEAD DIAGNOSIS TIRE LEAD DIAGNOSIS AND CORRECTION PROCEDURE



ALIGNMENT LEAD DIAGNOSIS AND CORRECTION PROCEDURE



* VERIFY LEAD/PULL IS NOT INCLUDED BY ROAD CROWN OR CROSS WINDS

SERVICE PROCEDURES

TIRE AND WHEEL ROTATION

NON-DIRECTIONAL TREAD PATTERN TIRES

Tires on the front and rear axles operate at different loads and perform different functions. For these reasons, they wear at unequal rates, and tend to develop irregular wear patterns. These effects can be reduced by timely rotation of tires. The benefits of rotation are especially worthwhile. Rotation will increase tread life, help to maintain mud, snow, and wet traction levels, and contribute to a smooth, quiet ride.

The suggested rotation method is the forward-cross tire rotation method (Fig. 6). This method takes advantage of current tire industry practice which allows rotation of radial-ply tires. Other rotation methods may be used, but may not have all the benefits of the recommended method.

NOTE: Only the 4 tire rotation method may be used if the vehicle is equipped with a low mileage or temporary spare tire.




Fig. 6 Forward-Cross Tire Rotation Method

DIRECTIONAL TREAD PATTERN TIRES

Some vehicles are fitted with special high-performance tires having a directional tread pattern. These tires are designed to improve traction on wet pavement. To obtain the full benefits of this design, the tires must be installed so that they rotate in the correct direction. This is indicated by arrows on the tire sidewalls.

When wheels and tires are being installed, extra care is needed to ensure that this direction of rotation is maintained.

Refer to Owner's Manual for rotation schedule.

REPAIRING TIRE LEAKS

For proper repairing, a radial tire must be removed from the wheel. Repairs should only be made if the defect, or puncture, is in the tread area (Fig. 7). The tire should be replaced if the puncture is located in the sidewall.

Deflate tire completely before dismounting tire from the wheel. Use lubrication such as a mild soap solution when dismounting or mounting tire. Use tools free of burrs or sharp edges which could damage the tire or wheel rim.

Before mounting tire on wheel, make sure all rust is removed from the rim bead and repaint if necessary.

Install wheel on vehicle, and progressively tighten the 5 wheel nuts to a torque of 135 N·m (100 ft. lbs.).




Fig. 7 Tire Repair Area

TIRE AND WHEEL MATCH MOUNTING


Wheels and tires are match mounted at the factory. This means that the high spot of the tire is matched to the low spot on the wheel rim. This technique is used to reduce run-out in the wheel/tire assembly. The high spot on the tire is marked with a paint mark or a bright colored adhesive label on the outboard sidewall. The low spot on the rim is identified with a label on the outside of the rim and a dot or line on the inside of the rim. If the outside label has been removed the tire will have to be removed to locate the dot or line on the inside of the rim.

Before dismounting a tire from its wheel, a reference mark should be placed on the tire at the valve

SERVICE PROCEDURES (Continued)

stem location. This reference will ensure that it is remounted in the original position on the wheel.


(1) Measure the total indicator runout on the center of the tire tread rib. Record the indicator reading. Mark the tire to indicate the high spot. Place a mark on the tire at the valve stem location (Fig. 8).



J9322-3

Fig. 8 First Measurement On Tire

(2) Break down the tire and remount it 180 degrees on the rim (Fig. 9).




J9322-4

Fig. 9 Remount Tire 180 Degrees

(3) Measure the total indicator runout again. Mark the tire to indicate the high spot.

(4) If runout is still excessive, the following procedures must be done.

- If the high spot is within 102 mm (4.0 in.) of the first spot and is still excessive, replace the tire.
- If the high spot is within 102 mm (4.0 in.) of the first spot on the wheel, the wheel may be out of specifications. Refer to Wheel and Tire Runout.
- If the high spot is NOT within 102 mm (4.0 in.) of either high spot, draw an arrow on the tread from second high spot to first. Break down the tire and remount it 90 degrees on rim in that direction (Fig. 10). This procedure will normally reduce the runout to an acceptable amount.



J9322-5

Fig. 10 Remount Tire 90 Degrees In Direction of Arrow

CLEANING AND INSPECTION

CLEANING OF TIRES

Remove protective coating on tires before delivery of vehicle. The coating could cause deterioration of tires.

Remove protective coating by:

- Applying warm water
- Letting it soak one minute
- Scrubbing the coating away with a soft bristle brush.
- Steam cleaning may also be used for cleaning.
- DO NOT use gasoline or wire brush for cleaning.
- DO NOT use mineral oil or an oil-based solvent.

SPECIFICATIONS

TIRE SPECIFICATIONS

The following guide should help you understand the tire designations:

P	Passenger car tire (or "T" for temporary-use tire).
185	Nominal width of tire in millimeters,
70	Tire height-to-width ratio.
R	Radial-ply tire (or "D" for bias-ply tire).
14	Nominal rim diameter in inches.

Do not install smaller than minimum size tires shown on the tire inflation placard on the vehicle.

WHEELS

INDEX

	page		page
DESCRIPTION AND OPERATION			
WHEEL COVER (LOCK-ON)	9	REMOVAL AND INSTALLATION	
WHEEL INFORMATION	9	WHEEL AND TIRE	13
DIAGNOSIS AND TESTING			
TIRE AND WHEEL RUNOUT	10	WHEEL COVER (LOCK-ON)	13
WHEEL INSPECTION	10	SPECIFICATIONS	
SERVICE PROCEDURES			
TIRE AND WHEEL BALANCE	12	WHEEL SPECIFICATIONS	15

DESCRIPTION AND OPERATION

WHEEL INFORMATION

Original equipment wheels are designed for proper operation at all loads up to the specified maximum vehicle capacity.

All models use steel or cast aluminum drop center wheels. Every wheel has raised sections between the rim flanges and rim drop well called safety humps (Fig. 1).




Fig. 1 Safety Rim

Initial inflation of the tires forces the bead over these raised sections. In case of air loss the raised sections help hold the tire in position on the wheel until the vehicle can be brought to a safe stop.

Cast aluminum wheels require special balance weights to fit on the thicker flange of the rim and special wheel clamps for the alignment equipment.

The wheel studs and nuts are designed for specific wheel applications and must be replaced with equivalent parts. Do not use replacement parts of lesser quality or of a substitute design. All aluminum and some steel wheels have wheel stud nuts with an enlarged nose. This enlarged nose is necessary to ensure proper retention of the wheels.

Before installing a wheel, remove any buildup of corrosion on the wheel mounting surface.

WARNING: INSTALLING WHEELS WITHOUT GOOD METAL-TO-METAL CONTACT COULD CAUSE LOOSENING OF WHEEL LUG NUTS. THIS COULD ADVERSELY AFFECT THE SAFETY AND HANDLING OF YOUR VEHICLE.

WHEEL COVER (LOCK-ON)

For the 1997 model year, this vehicle uses a lock-on type wheel cover (Fig. 2).




Fig. 2 Lock-On Wheel Cover

DESCRIPTION AND OPERATION (Continued)

(1) The wheel cover is locked to the wheel using three of the five wheel nuts (Fig. 3).




Fig. 3 Lock-On Wheel Cover Retention To Wheel

This lock-on wheel cover can not be removed from the wheel until the three wheel nuts (Fig. 3) are removed. Then the lock-on wheel cover can be removed with the remaining two wheel nuts remaining tightened.

DIAGNOSIS AND TESTING

WHEEL INSPECTION

WARNING: FAILURE TO USE EQUIVALENT REPLACEMENT WHEELS MAY ADVERSELY AFFECT THE SAFETY AND HANDLING OF THE VEHICLE.

WARNING: REPLACEMENT WITH USED WHEELS IS NOT RECOMMENDED. THE SERVICE HISTORY OF THE RIM MAY HAVE INCLUDED SEVERE TREATMENT OR VERY HIGH MILEAGE. THE RIM COULD FAIL WITHOUT WARNING.

Wheels must be replaced if they:

- Have excessive run out
- Are bent or dented
- Leak air from any area or surface of the rim
- Have damaged wheel lug/ nut holes

Wheel repairs employing hammering, heating, welding or repairing leaks are not allowed.

Original equipment replacement wheels should be used. When obtaining replacement wheels, they should be equivalent in load carrying capacity. The physical dimensions (diameter, width, offset, pilot hole and bolt circle) of the wheel should be the same as the original wheel.

TIRE AND WHEEL RUNOUT

Radial run out is the vertical distance between the high and low points on the tire or wheel edge.

Lateral run out is the horizontal movement of the tire or wheel.

Radial run out of more than .762 mm (.030 inch) measured at the center line of the tread may cause the vehicle to shake.

Lateral run out of more than .762 mm (.030 inch) measured near the shoulder of the tire may cause the vehicle to shake.

Runout should always be measured off the vehicle and on a suitable balance machine.

Usually radial run out can be reduced by relocating the wheel and tire on the wheel studs (See Method 1). If this does not reduce run out to an acceptable level, the tire can be rotated on the wheel. (See Method 2).

METHOD 1 (RELOCATE WHEEL ON HUB)

Check accuracy of the wheel mounting surface; adjust wheel bearings.

Drive vehicle a short distance to eliminate tire flat spotting from a parked position.

Verify all wheel nuts are properly torqued (Fig. 4).




Fig. 4 Tightening Wheel Nuts

Use run out gauge D-128-TR to determine run out (Fig. 5).




Fig. 5 Run Out Gauge

DIAGNOSIS AND TESTING (Continued)

Relocate wheel on the mounting, two studs over from the original position.

Retighten wheel nuts until all are properly torqued. This will prevent brake distortion.

Check the radial run out of the wheel. If still excessive, mark tire sidewall, wheel, and stud at point of maximum run out (Fig. 6) and proceed to Method 2.




Fig. 6 Chalk Marking On Wheel, Tire And Stud

METHOD 2 (RELOCATE TIRE ON WHEEL)

Rotating tire on wheel is particularly effective when there is run out in both tire and wheel.

Remove tire from wheel and remount wheel on hub in former position.

Check the radial run out of the wheel (Fig. 7). The radial run out of the wheel should be no more than 0.762 mm (.030 inch)




Fig. 7 Checking Radial Run Out Of Wheel

Check the lateral run out of the wheel (Fig. 8). The lateral run out of the wheel should be no more than .762 mm (.030 inch).




Fig. 8 Checking Lateral Run Out Of Wheel

If point of the most wheel radial run out is near original chalk mark, remount tire 45 degrees from its original spot. Recheck run out.

SERVICE PROCEDURES


TIRE AND WHEEL BALANCE

Balancing need is indicated by vibration of seats, floor pan, or steering wheel. The vibration will be noticed mostly when driving over 95 km/h (60 mph) on a smooth road.

It is recommended that a two plane dynamic balancer be used when a wheel and tire assembly require balancing. Static should be used only when a two plane balancer is not available.


For static imbalance, find location of heavy spot causing imbalance. Counter balance wheel directly opposite the heavy spot. Determine weight required to counterbalance the area of imbalance. Place half of this weight on the **inner** rim flange and the other half on the **outer** rim flange (Fig. 9) (Fig. 10). Off-vehicle balancing is necessary.

Wheel balancing can be accomplished with either on or off vehicle equipment. When using on-vehicle balancing equipment, remove the opposite wheel/tire.



J8922-8

Fig. 9 Static Unbalance & Balance



J8922-9

Fig. 10 Dynamic Unbalance & Balance

REMOVAL AND INSTALLATION

WHEEL COVER (LOCK-ON)

REMOVE

(1) Remove the three wheel nuts, (Fig. 11) used to lock the wheel cover to the wheel.




Fig. 11 Wheel Cover Locking Nuts

CAUTION: When removing the wheel cover, do not pry the wheel cover from the wheel. This can result in damage to the wheel cover. The wheel cover is removed by pulling it off the wheel by hand.

(2) Grasp the center of the wheel cover and pull straight outward from the wheel. This will pop the wheel cover retaining tabs (Fig. 12) over the two remaining wheel nuts, removing the wheel cover from the wheel.




Fig. 12 Wheel Cover Retaining Tabs

INSTALL

(1) Align the valve notch in the wheel cover with the valve stem on the wheel (Fig. 13). Align the two holes in the wheel cover having the retaining tabs,

with the two installed and properly tightened wheel nuts (Fig. 13).




Fig. 13 Wheel Cover Installation Position

(2) Press in on center of wheel cover until retaining tabs on wheel cover engage with wheel nuts. This will hold the wheel cover to the wheel.

(3) Install the three remaining wheel nuts.

(4) Tighten all 5 wheel nuts to a torque of 135 N·m (100 ft. lbs.).

WHEEL AND TIRE

CAST WHEEL

To install the wheel, first position it properly on the hub mounting surface using the hub pilot as a guide. Loosely install all 5 wheel nuts. All wheel nuts should then be tightened just snug. Progressively tighten them in the proper sequence (Fig. 14). Tighten wheel nuts to 129 N·m (95 ft. lbs.). Never use oil or grease on studs or nuts.




Fig. 14 Tightening Wheel Nuts

REMOVAL AND INSTALLATION (Continued)

STEEL WHEEL

REMOVE

(1) Remove the three wheel nuts, (Fig. 15) used to lock the wheel cover to the wheel.




Fig. 15 Wheel Cover Locking Nuts

CAUTION: When removing the wheel cover, do not pry the wheel cover from the wheel. This can result in damage to the wheel cover. The wheel cover is removed by pulling it off the wheel by hand.

(2) Grasp the center of the wheel cover and pull straight outward from the wheel. This will pop the wheel cover retaining tabs (Fig. 16) over the two remaining wheel nuts, removing the wheel cover from the wheel.




Fig. 16 Wheel Cover Retaining Tabs

(3) Remove the two remaining wheel nuts from the studs.

(4) Remove the wheel and tire from the hub.

INSTALL

NOTE: The wheel nuts must be installed on the studs shown in (Fig. 17) to allow the installation of the wheel cover.

(1) To install the wheel, first position it properly on the hub mounting surface using the hub pilot as a guide. Then install and **lightly tighten** the 2 wheel nuts on the studs as shown in (Fig. 17) holding the wheel to the hub.




Fig. 17 Wheel Installation

(2) Align the valve notch in the wheel cover with the valve stem on the wheel (Fig. 18). Align the two holes in the wheel cover having the retaining tabs, with the two installed wheel nuts (Fig. 18).




Fig. 18 Wheel Cover Installation Position

(3) Press in on center of wheel cover until retaining tabs on wheel cover engage with wheel nuts. This will hold the wheel cover to the wheel.

(4) Install the three remaining wheel nuts (Fig. 15).

REMOVAL AND INSTALLATION (Continued)


(5) Progressively tighten the 5 wheel nuts in the proper sequence (Fig. 19). Tighten wheel nuts to 135 N·m (100 ft. lbs.). Never use oil or grease on studs or nuts.

SPECIFICATIONS**WHEEL SPECIFICATIONS****Wheel:**

Mounting Stud Size M12 x 1.5mm

Mounting Stud Lug Nut Hex Size 19mm

Mounting Lug Nut Tightening Torque (4 and 5 Stud
Wheels) 135 N·m (100 ft. lbs.)



80a72375

Fig. 19 Wheel Nut Tightening Sequence

