



Owner's Manual

2015 Audi R8 Spyder



Foreword

Thank you for choosing an Audi - we value your trust in us.

Your new Audi will allow you to experience the best in groundbreaking technology and premium quality equipment a vehicle has to offer. We recommend that you read your Owner's Manual thoroughly so that you quickly become acquainted with your Audi and make use of all of its features.

In addition to explaining how the different features work, we provide many useful tips and information concerning your safety, how to care for your vehicle and how to maintain your vehicle's value. We also give you useful tips and information on how to drive your vehicle more efficiently and in an environmentally friendly manner.

In the Owner's Manual packet, you will also find an Owner's Manual for your Infotainment system and the vehicle maintenance schedule.

We hope you enjoy driving your Audi and we wish you safe and pleasant motor-ing.

AUDI AG

Table of contents

Vehicle literature	4	Cigarette lighter/socket	59
About this Owner's Manual	5	Storage	59
Controls and equipment	6	Warm and cold	61
Cockpit	6	Climate controls	61
General illustration	6	On the road	66
Instruments and warning/ indicator lights	8	Steering	66
Instruments	8	Ignition lock/Ignition switch	66
Warning/indicator lights	11	Starting and stopping the engine	67
Driver information system	20	Parking brake	68
Introduction	20	Speed warning system	69
Trip computer	21	Cruise control	71
Menu display	22	Audi magnetic ride	72
Service interval display	24	Sporty driving	73
Lap timer	25	Transmission	74
On-Board Diagnostic system (OBD)	26	Manual transmission	74
Opening and closing	27	S tronic	75
Keys	27	Parking system	80
Power locking system	29	Parking system advanced	80
Front lid	32	Safety first	86
Anti-theft alarm system	33	Driving Safely	86
Power windows	34	General notes	86
Garage door opener (HomeLink)	35	Proper occupant seating positions	87
Convertible top	38	Driver and passenger side footwell	90
Convertible top	38	Pedal area	90
Wind deflector	40	Stowing luggage	91
Rear window	40	Reporting Safety Defects	92
Convertible top emergency operation	41	Active rollover protection system	93
Clear vision	46	Safety belts	95
Lights	46	General notes	95
Interior lights	48	Why safety belts?	96
Vision	49	Safety belts	98
Wiper and washer system	51	Safety belt pretensioners	100
Digital compass	54	Airbag system	102
Seats and storage	56	Important things to know	102
General recommendations	56	Front airbags	106
Power seats	57	Monitoring the Advanced Airbag System .	112
Head restraints	58		
Cup holder	58		
Ashtray	59		

Knee airbags	116	Battery	164
Side airbags	118	Windshield washer container	168
Child Safety	122	Tires and wheels	169
Important things to know	122	Tires	169
Child safety seats	127	Tire pressure monitoring system	196
Installing a child safety seat	130	Do-it-yourself service	199
Additional Information	132	What do I do now?	199
Vehicle operation	134	Trunk escape handle	199
Intelligent technology	134	Vehicle tool kit	199
Notice about data recorded by vehicle		Tire repair	199
control modules	134	What should I be aware of when changing	
Electronic Stabilization Control (ESC)	134	a tire?	203
Braking	136	Jump-starting	206
Rear spoiler	138	Emergency towing with commercial tow	
Power steering	139	truck	208
Dry sump lubrication	139	Fuses and bulbs	210
Driving with your quattro	139	Electrical fuses	210
Energy management	140	Bulbs	211
Driving and environment	142	Technical data	212
Break-in period	142	Technical Data	212
Avoid damaging the vehicle	142	Vehicle identification	212
Driving through water on roads	142	Weights	212
Catalytic converter	142	Dimensions	213
Shutting down vehicle	143	Capacities	213
Operation and maintenance	143	Gasoline engines	214
Trailer towing	144	Consumer Information	215
Vehicle care	145	Warranty coverages	215
Vehicle care and cleaning	145	Operating your vehicle outside the U.S.A.	
General information	145	or Canada	215
Car washes	145	Audi Service Repair Manuals and	
Cleaning and care information	146	Literature	215
Fuel supply and filling your fuel		Maintenance	215
tank	151	Additional accessories, modifications and	
Gasoline	151	parts replacement	217
Fuel tank	152	Index	219
Checking and filling	155		
Engine compartment lid	155		
Engine oil	158		
Engine cooling system	161		
Brake fluid	164		

In addition to this Owner's Manual, your Audi comes with a Warranty & Maintenance booklet.

Moreover, depending on the model and the equipment, there may be additional instruction booklets delivered with your vehicle (for example, Operating Instructions for your Sound System, Navigation System, etc.).

If you are missing one of these publications, or if you believe that the information is not complete, contact your authorized Audi dealer for assistance.

The Warranty & Maintenance booklet

explains how you can keep your Audi in top driving condition by having it serviced regularly and contains detailed information about the warranties covering your Audi. Always have the booklet with you when you take your vehicle to an authorized Audi dealer for service. Your Audi Service Advisor will record each scheduled service and can answer any questions you may have regarding how to maintain your vehicle.

In Canada,

the vehicle literature is also available in French. To obtain a copy, contact your dealer or write to:

Au Canada, on peut se procurer un exemplaire en français de ce document auprès du concessionnaire ou de:

Audi Canada, Inc.
Client Assistance
Assistance à la Clientèle
777 Bayly Street, West,
Ajax, Ontario L1S 7G7

If you sell your Audi

all literature should be left in the vehicle to make the Warranty terms as well as all operating, safety and maintenance information available to the next owner.

If you change your address or if you bought this Audi used

be sure to send in a "Notice of Address Change" / "Notice of Used Car Purchase" post card. This card can be found in the Warranty & Maintenance

booklet or obtained from your authorized Audi dealer.

It is in your own interest that we are able to contact you should the need arise.

This owner's manual contains important information, tips, suggestions, and warnings for the use of your vehicle.

Make sure that this owner's manual is always located in the vehicle. This is especially important if you allow other people to drive the vehicle, or if you sell it.

This owner's manual describes the **equipment range** specified for this model at the editorial deadline date. Some of the equipment described here will only be available at a later date, or only in specific markets.

Some sections in this owner's manual do not apply to all vehicles. In that case, the **range of applicability** is given at the beginning of the section, e. g. "Applies to vehicles: with Audi Parking System". In addition, optional or vehicle-specific equipment is indicated by an asterisk "*".

The details in the **illustrations** may be different from those in your vehicle, and are intended to be viewed as a basic guide.

You will find a **table of contents** at the beginning of this book, which displays all topics described in this manual in order of appearance. You will find an alphabetical **index** at the end of this book.

All **directions**, such as "left", "right", "front", "back", are relative to the direction of travel.

- * Optional or vehicle-specific equipment
- This section continues on the next page.
- ⇒ ⚠ Cross-reference to a "WARNING!" within a section. For indication with a page number, the corresponding "WARNING!" can be found outside of the section.

**WARNING**

Text with this symbol contains important information on safety and how to reduce the risk of personal injury or death.

**Note**

Text with this symbol draws your attention to potential sources of damage to your vehicle.

**For the sake of the environment**

Text with this symbol contains information about the environment and how you can help protect it.

**Tips**

Text with this symbol contains special tips and other information about getting the most out of your vehicle and its features.

Cockpit

General illustration




Fig. 1 Cockpit: left section




Fig. 2 Cockpit: right section

① Adjuster control for outside mirrors	49	⑩ Switches for:	
② Door handle		– Windshield wiper/washer	51
③ Power locking switch	31	– Trip computer	21
④ Switches for:		– Menu display	22
– Front lid release	32	– Lap Timer	25
– Fuel filler flap release	153	– Speed warning system	69
⑤ Air outlets	63	⑪ Steering lock/ignition/starter switch (in the steering wheel column)	66
⑥ Light switch	46	⑫ Adjustable steering column	66
⑦ Turn signal and high beam	47	⑬ Cruise control	71
⑧ Multifunction steering wheel with:		⑭ Instrument lighting	49
– Horn		⑮ Data Link Connector (DLC) for On Board Diagnostics (OBD II)	26
– Driver's airbag	106	⑯ Power window switches	34
– Audio, telephone and voice control system operating buttons		⑰ Navigation system	
⑨ Instrument cluster	8	⑱ Glove compartment (lockable)	60
		⑲ Front passenger's airbag	106
		⑳ Rear window defogger switch	64
		㉑ Climate controls	61
		㉒ Gear shift lever or selector lever (S tronic):	
		– Manual transmission	
		– S tronic	75
		㉓ Switches for:	
		– Audi magnetic ride	72
		– Electronic Stabilization Control	134
		– Emergency flasher	48
		– Retractable rear spoiler	138
		– Parking system	80
		㉔ Convertible top switch	38
		㉕ Rear window switch	40
		㉖ Parking brake lever	68

Tips

- Some of the equipment or features shown in the general illustration may be standard equipment on your vehicle or may be optional equipment depending on your model.
- A separate brochure is provided for your factory-installed audio system and/or the Audi Navigation System.

Instruments and warning/indicator lights

Instruments

Instrument cluster and controls

The instrument cluster is your central source of information.




Fig. 3 Overview of the instrument cluster

- 1

Engine oil temperature

8
- 2

Tachometer with time and date display

9, 9
- 3

Coolant temperature gauge

9
- 4

Fuel gauge

10
- 5

Speedometer with odometer

10
- 6

Voltmeter

11
- 7

Set/Check button

9
- 8

Driver information display

20
- 9

RESET button for trip odometer .

10

The illumination for the instrument cluster lights up whenever you switch on the ignition with the **vehicle headlights off**. The gauges are also illuminated when the lights are turned on.

Engine oil temperature display

The engine oil temperature display ⇒ *page 8, fig. 3* only operates with the ignition on. To prevent engine damage, please observe the following important points concerning the temperature ranges.

Cold range

If the needle is at the bottom of the gauge, the engine oil has not reached operating temperature yet. Avoid high engine speeds, full throttle applications and heavy engine loads.

Normal range

The engine has reached operating temperature when the needle moves into the center of the gauge under normal driving conditions. The needle may move higher on the gauge with heavier engine load at high outside temperatures. This is not a cause for concern as long as the  indicator light in the display does not flash.

Warning light

If the symbol  in the display flashes, either the engine oil temperature is too high or the engine oil level is too low ⇒ *page 159*.

If the needle is well in the upper area of the gauge, the engine oil temperature is too high. **Stop the vehicle, switch the engine off and allow it to cool.** If the warning light comes on again after driving a short distance, contact an authorized Audi dealer.

Tachometer (engine rev counter)

The tachometer indicates the engine RPM (revolutions per minutes).

If engine RPM drops below 1,500, you should downshift to the next lower gear. The red area at the end of the scale indicates maximum permissible engine RPM after the break-in period. Before reaching this area, move the selector lever to position "A (Automatic operation)" or ease your foot off the accelerator pedal.

! Note

The tachometer needle should only briefly be in the red zone: you could damage your engine! The beginning of the red zone varies depending on the engine.



For the sake of the environment

Upshifting early saves fuel and reduces engine noise.

Digital clock with date display

Your vehicle is equipped with a quartz controlled digital clock.



Fig. 4 Instrument cluster with the digital clock

To set the hour

- Pull the knob (hour display flashes) and turn it to the left or right.

To set the minutes

- Pull the knob as many times as necessary until the minute display flashes.
- Turn the knob to the left or right.

To set the date

- Pull the knob as many times as necessary until the day, month or year display flashes.
- Turn the knob to the left or right.

To hide or display the date

- Pull the knob as many times as necessary until the date display flashes.
- Turn the knob to the left or right.

When the date display stops blinking, this means the time and date have been successfully stored.

With the ignition off, pushing or pulling the Set/Check button ⇒ page 8, fig. 3 ⑦ can turn on the display field lighting for a few seconds.

Engine coolant temperature gauge

The engine coolant gauge ⇒ page 8, fig. 3 ③ only works when the ignition is on. To prevent damage to your engine, please note the following important points.

Engine cold

As long as the needle remains at the bottom of the gauge, the engine still has not reached its operating temperature. Avoid high engine speeds, heavy engine loads and heavy throttle.

Normal temperature

When the engine has reached its operating temperature, the needle will move into the middle of the gauge and remain there. If the engine is working hard at high outside temperatures, the needle may turn further to the right. This is no cause for concern as long as the  warning light in the instrument cluster does not illuminate.

When the  warning light starts to flash, this can mean one of two things: either the coolant temperature is too high, or the coolant level is too low ⇒ page 14.



WARNING

- Always observe the warning in ⇒ page 155, *Working in the engine compartment* before opening the engine compartment lid and checking the engine coolant level.

- Never open the engine compartment lid if you see or hear steam, or if you see engine coolant dripping from the engine compartment. You could burn yourself. Let the engine cool off first until you can no longer see or hear steam or coolant escaping.

Note

- Mounting additional lights or accessories in front of the air inlets reduces the cooling effect of the radiator. At high outside temperatures or high engine load, the engine could overheat.
- The front spoiler has been designed to properly distribute the cooling air when the vehicle is moving. If the spoiler is damaged, this could reduce the cooling effect and the engine could then overheat. Ask your authorized Audi dealer for assistance.

Fuel gauge

The fuel gauge works only when the ignition is on. When the needle reaches the red area, the warning light in the instrument cluster will illuminate ⇒ [page 17](#) . **Time to refuel!**

Note

Never run the tank completely dry! An irregular supply of fuel can cause engine misfiring and fuel could enter into the exhaust system. The catalytic converter could then overheat and be damaged.

Speedometer with odometer

The speedometer shows you the vehicle speed, and the odometer shows you how many miles (kilometers) you have driven.



Fig. 5 Speedometer close-up: odometer display

The distance driven is shown in miles (USA models) or in kilometers (Canada models).

Lower odometer

The lower odometer shows the total number of miles (kilometers) driven.

Upper odometer (trip odometer)

The upper odometer shows the total number of miles (kilometers) driven since you last reset the odometer back to zero. You can use this odometer when you want to keep track of how many miles (kilometers) you have driven for a single trip or errand. The last digit indicates 1/10 of a mile (100 meters). You can set the trip odometer back to zero by pressing the reset button ⇒ [fig. 5](#).

With the ignition off, pushing of the Set/Check button ⇒ [page 8](#), [fig. 3](#)  can turn on the display field lighting for a few seconds.

Malfunction message

If there is a malfunction somewhere in the instrument cluster, **DEF** will appear in the trip odometer and will stay on. Contact your authorized Audi dealer to have the problem corrected.

Immobilizer

When the ignition is switched on, the data on the ignition key are scanned automatically.

If an unauthorized key was used, **SAFE** is displayed continuously in the odometer display

field. The vehicle cannot be operated
⇒ *page 28*.

Voltmeter display

The voltmeter shows the voltage in the vehicle electrical system. If the reading drops below 12 volts with the engine running, you should have the power supply (battery and generator) inspected by an authorized Audi dealer.

Tips

Voltage can drop below 8 volts when you start the engine.

Warning/indicator lights

Description

The indicator lights in the instrument cluster blink or turn on. They indicate functions or malfunctions ⇒ .

Messages may appear with some indicator lights. The messages turn off after a short time. To display a message again, press the Set/Check button ⇒ *page 8, fig. 3* . If there is more than one malfunction, the indicator lights will turn on one after the other for approximately two seconds each.

Some indicators lights in the display can turn on in several colors.

WARNING

- Failure to heed warning lights and other important vehicle information may result in serious personal injury or vehicle damage.
- Whenever stalled or stopped for repair, move the vehicle a safe distance off the road, stop the engine, and turn on the emergency flasher ⇒ *page 48*.
- The engine compartment of any motor vehicle is a potentially hazardous area. Before you check anything in the engine compartment, stop the engine and let it cool down. Always exercise extreme caution when working under the hood ⇒ *page 155, Working in the engine compartment*

Overview

Some indicator lights turn on briefly to check the function of that system when you switch the ignition on. These systems are marked with a ✓ in the following tables. If one of these indicator lights does not turn on, there is a malfunction in that system.

Red indicator lights

BRAKE	USA models: Malfunction in the brake system ⇒ <i>page 12</i>
	Canada models: Malfunction in the brake system ⇒ <i>page 12</i>
AIR BAG	USA models: Airbag system ✓ ⇒ <i>page 13</i>
	Canada models: Airbag system ✓ ⇒ <i>page 13</i>
	Safety belt ⇒ <i>page 14</i>
	Battery ✓ ⇒ <i>page 14</i>
	Engine oil pressure too low ⇒ <i>page 14</i>
	Engine coolant level too low/ engine coolant temperature too high ⇒ <i>page 14</i>
	Gearbox malfunction* ⇒ <i>page 78</i>

Yellow indicator lights

	Convertible top operation ✓ ⇒ <i>page 15</i>
	Electronic Stabilization Control (ESC) ✓ ⇒ <i>page 15</i>
	Electronic Stabilization Control (ESC) ✓ ⇒ <i>page 15</i>
ABS	USA models: anti-lock brake system (ABS) ✓ defective ⇒ <i>page 15</i>
	Canada models: anti-lock brake system (ABS) ✓ defective ⇒ <i>page 15</i>
	Worn brake pads ⇒ <i>page 16</i>
	Tire pressure too low ⇒ <i>page 197</i>

TPMS	Tire pressure monitoring system ⇒ page 196
EPC	Electronic power control ✓ ⇒ page 16
	USA models: Malfunction Indicator Lamp (MIL) ⇒ page 17
	Canada models: Malfunction Indicator Lamp (MIL) ⇒ page 17
	Engine speed limitation* ⇒ page 17
	Check engine oil level ⇒ page 17
	Engine oil sensor malfunction ⇒ page 17
	Battery ✓ ⇒ page 14
	Low fuel level ⇒ page 17
	Windshield washer fluid level low ⇒ page 17
	Defective light bulb ⇒ page 17
BRAKE LIGHT	USA models: Defective brake light ⇒ page 17
	Canada models: Defective brake light ⇒ page 17
	Light/rain sensor defective (automatic headlights)* defective ⇒ page 18
	Audi magnetic ride ⇒ page 18
	Rear spoiler ✓ ⇒ page 18
	USA models: Speed warning 1 ⇒ page 69
	Canada models: Speed warning 1 ⇒ page 69
	USA models: Speed warning 2 ⇒ page 69
	Canada models: Speed warning 2 ⇒ page 69
	Gearbox malfunction* ⇒ page 78

Other indicator lights

	Turn signals ⇒ page 18
CRUISE	USA models: Cruise control activated ⇒ page 19
	Canada models: Cruise control activated ⇒ page 19
	High beam ⇒ page 47

BRAKE/ (ⓘ) Brake system

This warning/indicator light illuminates when the brake fluid level is too low or when there is a malfunction in the ABS, or when the parking brake is set.

If the  (USA models)/ (Canada models) symbol flashes in the display with the parking brake released, there is a malfunction in the brake system. In addition to the symbol, one of two messages appears in the display:

Stop vehicle and check brake fluid level

Stabilization program and ABS fault! See Owner's manual

- Pull off the road and stop the vehicle.
- Obtain professional assistance.

USA models: if there is a malfunction in the ABS system, the  warning/indicator light illuminates along with the  system malfunction warning/indicator light ⇒ .

Canada models: if there is a malfunction in the ABS system, the  warning/indicator light illuminates together with the  brake system malfunction warning/indicator light ⇒ .

The light  (USA)/ (Canada) illuminates when the ignition is turned on. It goes out after the engine has been started and the parking brake is fully released. This indicates that the brake warning light is functioning properly.

If the brake warning light does not light up when the engine is cranking or the parking brake is applied, there may be a malfunction in ►

the electrical system. In this case, contact your Audi dealer.

If the ABS fails, the ABS warning/indicator light  (USA models)/ (Canada models) flashes together with the brake system warning/indicator light .

(USA models): If the warning light **BRAKE** and the warning light  illuminate together, immediately contact your authorized Audi dealer or qualified workshop to have all brake pads inspected $\Rightarrow$ page 16.

When the light comes on, an audible warning signal is also given.

Parking brake set

The parking brake warning light /  (Canada models) illuminates when the parking brake is set. In addition, a warning tone will sound after you have driven for longer than 3 seconds and faster than 3 mph (5 km/h).

Parking brake set

The **BRAKE** warning/indicator light illuminates when the parking brake is set $\Rightarrow$ .

WARNING

- Always observe the warnings in $\Rightarrow$ page 155, *Working in the engine compartment*, before opening the engine hood and checking the brake fluid.
- Driving with low brake fluid is a safety hazard! Stop the car and get professional assistance.
- *USA models*: If both, the **BRAKE** warning light and the  warning light come on at the same time, the rear wheels could lock up first under hard braking. Lock-up of the rear wheel brakes can cause loss of vehicle control and an accident. Have your vehicle repaired immediately by your authorized Audi dealer or a qualified workshop. Drive slowly and avoid sudden, hard brake application.
- *Canada models*: If both, the brake warning light  and the ABS warning light  come on at the same time, the rear wheels could lock up first under hard braking. Lock-up of

the rear wheel brakes can cause loss of vehicle control and an accident. Have your vehicle repaired immediately by your authorized Audi dealer or a qualified workshop. Drive slowly and avoid sudden, hard brake application.

- If the brake warning/indicator light does not go out after a few seconds and the parking brake is released, or lights up while you are driving, the fluid level in the brake fluid reservoir is too low. If you believe that it is safe to do so, proceed immediately at low speed to the nearest authorized Audi dealer or qualified workshop and have the brake system inspected.
- Always keep in mind that after several brake applications, you will need greater pressure on the brake pedal to stop your vehicle. Do not rely on strained brakes to respond with maximum stopping power in critical situations. You must allow for increased braking distances. The extra distance used up by fading brakes could lead to an accident.

Safety systems

The  (USA models) /  (Canada models) indicator light monitors the safety systems e.g. air-bags, pretensioners and illuminates for a few seconds each time you switch the ignition on.

If the  (USA models) /  (Canada models) indicator light does not go out, or if it illuminates while you are driving, or if it starts to blink, then there is a malfunction somewhere in the system. If the light does not illuminate when you switch on the ignition, this also means there is a malfunction.

WARNING

If you have a malfunction in the safety systems, contact your authorized Audi dealer immediately. Otherwise the safety systems may not work properly in an accident.

Safety belt warning light

Applies to vehicles: with safety belt warning light

The warning light is a reminder to fasten safety belts.

The warning light  comes on for a few seconds after the ignition is switched on as a reminder to fasten your safety belt.

Additional information on safety belts
⇒ *page 95*.

Battery

This warning/indicator light detects a malfunction in the generator or in the vehicle's electrical system.

The  warning/indicator light illuminates when you switch on the ignition and must go out after the engine has started.

Alternator fault: Battery is not being charged

If the indicator light turns on and the message appears, there is a malfunction in the generator or vehicle electrical system.

Drive to your authorized Audi dealer or qualified workshop immediately. Because the vehicle battery is discharging, turn off all unnecessary electrical equipment such as the radio. Seek professional assistance if the battery charge level is too low.

Low battery: battery will be charged while driving

If the indicator light turns on and the message appears, there may be limited starting ability.

If this message turns off after a little while, the battery charged enough while driving.

If the message does not turn off, have your authorized Audi dealer or qualified workshop correct the malfunction.

Engine oil pressure

The red engine oil pressure warning symbol requires immediate service or repair.

If the  symbol appears in the display and flashes, the oil pressure is too low. In addition to the symbol, the following message also appears in the display:

Switch off engine! Oil pressure is too low

- ▶ Pull off the road and stop the vehicle.
- ▶ Shut the engine down.
- ▶ Check the engine oil level ⇒ *page 159*.
- ▶ Contact your authorized Audi dealer for assistance if necessary.

Engine oil level too low

If the engine oil level is too low, top off oil to the proper level ⇒ *page 160*.

Engine oil level OK

If the  symbol starts flashing again even though the engine oil level checks OK on the dipstick, **do not start driving again and do not let the engine run at idle**. Instead, contact your authorized Audi dealer for assistance.

Tips

- The engine oil pressure symbol  is not an indicator for a low engine oil level. Do not rely on it. Instead, check the oil level in your engine at regular intervals, preferably each time you refuel, and always before going on a long trip.
- The yellow oil level warning indication  requires oil refill or workshop service without delay. Do not wait until the red oil pressure warning symbol  starts to flash before you respond to the low oil level warning . By then, your engine may already have suffered serious damage.

Engine cooling system

A malfunction in the engine cooling system must be repaired as soon as possible.

When the  symbol in the display flashes, then either the engine coolant *temperature* is too

high, or the coolant *level* is too low. In addition to the symbol, the following message also appears in the display:

Switch off engine and check coolant level

- ▶ Pull off the road and stop the vehicle.
- ▶ Turn off the engine.
- ▶ Check coolant level ⇒ *page 162*.
- ▶ Add coolant if necessary ⇒ *page 163*.
- ▶ Continue driving only after the engine coolant warning/indicator light goes out.
- ▶ Contact your authorized Audi dealer for assistance if necessary.

If the engine coolant level is correct, then the radiator fan may be the cause of the malfunction.

If the generator warning/indicator light should also illuminate ⇒ *page 14*, then the fan belt may be damaged.

WARNING

- If your vehicle should break down for mechanical or other reasons, park at a safe distance from moving traffic, turn off the engine and turn on the hazard warning lights ⇒ *page 48, Emergency flasher*.
- Never open the engine compartment lid if you see or hear steam or coolant escaping from the engine compartment - you risk being scalded. Wait until you can no longer see or hear steam or coolant escaping.
- The engine compartment of any vehicle is a dangerous area. Before you perform any work in the engine compartment, turn off the engine and allow it to cool. Follow the warning stickers ⇒ *page 155, Working in the engine compartment*.

Note

Do not continue driving if the  symbol illuminates. There is a malfunction in the engine cooling system – you could damage your engine.

Convertible top operation

The indicator light turns on 

- When the convertible top opens or closes or

- If the convertible top did not open or close completely.

The indicator light blinks if the convertible top cannot open or close ⇒ *page 39*.

Electronic Stabilization Control (ESC)

If the  indicator lamp blinks while driving, the ESC or ASR (Anti-Slip Regulation) is actively regulating.

If the  indicator lamp illuminates, the system has switched the ESC off. In this case, you can switch the ignition off and then on to switch the ESC on again. The system is functioning completely when the indicator lamp switches off.

If the  indicator lamp illuminates, the ESC was switched off with the  button.

Stabilization program and ABS fault! See owner's manual

If the  indicator lamp and the  ABS indicator lamp illuminate and the driver message appears, the ABS or electronic differential lock is malfunctioning. This also interrupts the ESC. The brakes still function with their normal power, but ABS is not active.

Drive to your authorized Audi dealer immediately to have the malfunction corrected.

For more information about the ESC ⇒ *page 134*.

Anti-lock brake system

This warning/indicator light monitors the ABS and the electronic differential lock (EDL).

The warning/indicator light  (USA models) /  (Canada models) will come on for a few seconds when the ignition is switched on. The light will go out after an automatic check sequence is completed.

There is a malfunction in the ABS when:

- The warning/indicator light does not illuminate when you switch the ignition on.
- The warning/indicator light does not go out after a few seconds.

- The warning/indicator light illuminates while driving.

The ESC indicator light also illuminates if there is a malfunction in the ABS. The message **Stabilization program and ABS: fault! See owner's manual** also appears in the instrument cluster display and a warning tone sounds.

The brake system will still respond even without the assistance of the ABS system. See your authorized Audi dealer as soon as possible to restore full braking performance. For more information regarding the ABS ⇒ *page 134*.

Malfunction in the brake system

If the brake warning light ⇒ *page 12* and the ABS warning illuminate *together* there may be a malfunction in the ABS, and there may also be a malfunction in the brake system itself ⇒ . **The ABS will not work and you will notice a change in braking response and performance.**

In the event of a **malfunction in the brake system** the warning/indicator light **BRAKE** (USA models)/ (Canada models) in the instrument cluster flashes ⇒ *page 12*.

Malfunction in the electronic differential lock (EDL)

The EDL works together with the ABS. The ABS warning light will come on if there is a malfunction in the EDL system ⇒ *page 134*. See your authorized Audi dealer as soon as possible.

WARNING

- If the **ABS** (USA models)/ (Canada models) warning light does not go out, or if it comes on while driving, the ABS system is not working properly. The vehicle can then be stopped only with the standard brakes (without ABS). You will not have the protection ABS provides. Contact your Audi dealer as soon as possible.
- *USA models:* If the **BRAKE** warning light, the  warning light and the **ABS** warning light come on together, the rear wheels could

lock up first under hard braking. Rear wheel lock-up can cause loss of vehicle control and an accident. Have your vehicle repaired immediately by your authorized Audi dealer or a qualified workshop. Drive slowly and avoid sudden, hard brake applications.

- *Canada models:* If the brake warning light , the  warning light and the ABS warning light  come on together, the rear wheels could lock up first under hard braking. Rear wheel lock-up can cause loss of vehicle control and an accident. Have your vehicle repaired immediately by your authorized Audi dealer or a qualified workshop. Drive slowly and avoid sudden, hard brake applications.

Worn brake pads

Check brake pads!

If the warning light illuminates, immediately contact your authorized Audi dealer or qualified workshop to have all brake pads inspected. On USA models the warning light  comes on together with the warning light **BRAKE**. Both sets of brake pads on an axle must always be replaced at the same time.

WARNING

- Driving with bad brakes can cause a collision and serious personal injury.
- If the warning light  and the warning light **BRAKE**¹⁾ with the message **Brake pads!** comes on in the instrument cluster display, immediately contact your authorized Audi dealer or qualified workshop to have all brake pads checked or replaced if necessary.

EPC Electronic power control

This warning/indicator light monitors the electronic power control.

The **EPC** warning/indicator light (Electronic Power Control) illuminates when you switch on the ignition as a function check.

1) **BRAKE**: USA models only

 Tips

If this warning/indicator light illuminates while you are driving, then there is a malfunction in the engine electronics. Have the malfunction corrected as soon as possible by your authorized Audi dealer or qualified workshop.

 Malfunction Indicator Lamp (MIL)

The Malfunction Indicator Lamp (MIL) is part of the On-Board Diagnostic (OBD II) system. The symbol  lights up when the ignition is turned on and will turn off after the engine has started and has settled at constant idle speed. This indicates that the MIL is working properly.

The warning light illuminates when there is a malfunction in the engine electronic system. Contact your authorized Audi dealer and have the malfunction corrected.

An improperly closed fuel filler cap may also cause the MIL light to illuminate ⇒ *page 153*.

For more information ⇒ *page 26*.

 Engine speed limitation**Maximum 6000 RPM**

The engine speed is automatically limited to 6000 RPM. This protects the engine from overheating.

The engine speed limitation  deactivates once the engine is no longer in the critical temperature range and you have released the accelerator pedal once.

 Tips

When cold, the engine speed is limited to 6000 RPM (with the V10 engine) or 7000 RPM (with the V8 engine) to protect the engine. The limit is deactivated once the oil temperature rises above 140 °F (60 °C) and the engine is at operating temperature.

 Checking the engine oil level

 **Please add max. 1 qt of engine oil!**

If the  symbol comes on, add 1 quart (1 liter) of oil at the next opportunity ⇒ *page 160*.

 Engine oil sensor defective

If the  symbol illuminates, contact your authorized Audi dealer and have the oil sensor inspected.

 Fuel supply too low

When the  symbol illuminates, this means there are about 2.6 gallons (10 liters) of fuel left in the fuel tank. Time to refuel! ⇒ *page 152*.

If the symbol lights up, even when there is ample fuel in the tank, and the text **Tank system malfunction! Please contact workshop** appears in the display, there is a fault in the system. Contact a qualified workshop to have the fault rectified.

 Windshield washer fluid level too low

If the  symbol illuminates, add windshield washer fluid to the washer system ⇒ *page 168*.

 Defective light bulb warning

If a defective bulb has been detected by the system or a light bulb burns out, the  symbol with a message appears in the display to tell you which bulb is burnt out and where it is located. For example:

Rear left turn signal

After 5 seconds, the message disappears. If you want to recall the message into the display, press the CHECK button ⇒ *page 8, fig. 3* .

There are three reasons why the defective bulb message would appear in the display:

- The light bulb has burnt out ⇒ *page 211*.
- The fuse is “blown” ⇒ *page 210, Replacing fuses*.
- The wire connection to the light bulb is defective.

Have the bulb replaced or the connection repaired by your authorized Audi Service department.

WARNING

- Light bulbs are pressurized and could explode while they are being changed causing serious personal injury.
- Work with due care when handling the high-voltage section of gas discharge (xenon) lamps. Failing to do so could result in death or serious injury!

Brake light / **Brake light defective**

In case of a malfunction or component failure, the symbol **Brake light** (USA models) /  (Canada models) can appear. The following electrical components should be checked, repaired or replaced, as necessary:

- Brake light bulbs
- All wiring connections
- Brake light switch

Contact your authorized Audi dealer for assistance if necessary.

Tips

The brake light switch is only inspected as part of the functional check after the engine is started.

Light/rain sensor defective

Applies to vehicles: with automatic headlights

If the symbol illuminates, the light sensor has failed. For safety reasons, the low beams are turned on permanently with the switch in **AUTO**. However, you can continue to turn the lights on and off using the light switch. In the case of a defect in the rain sensor, the windshield wiper lever functions are still available. Have the light/rain sensor checked as soon as possible at an authorized Audi dealer.

Audi magnetic ride

The indicator light monitors vehicle damping.

The indicator light  illuminates when the ignition is switched on as a function check.

Tips

If the indicator lamp illuminates while you are driving, there is a malfunction in the vehicle damping. The chassis should be inspected immediately by an authorized Audi dealer.

Rear spoiler

The warning/indicator light monitors the electrically retractable rear spoiler.

The warning/indicator light  has the following functions:

- It comes on for about 3 seconds as a function check when the ignition is switched on.
- It comes on if there is a malfunction in the electrically retractable rear spoiler.

Additional information about the electrically retractable rear spoiler ⇒ *page 138*.

Tire pressure monitoring system

Applies to vehicles: with tire pressure monitoring system

Tire pressure that is too low must be corrected as soon as possible.

The warning/indicator light  illuminates for a few seconds after the ignition is turned on as a function check. If the  warning light comes on, pressure in at least one tire is too low.

- ▶ Stop driving as soon as possible without endangering yourself and other drivers on the road.
- ▶ Inspect all tires.
- ▶ Correct the tire pressure ⇒ *page 179*.

Additional information about the **tire pressure monitoring system** can be found ⇒ *page 197*.

Turn signals

The indicator light blinks when you use either turn signal.

Whenever you use the left  or the right  turn signal, the indicator light blinks. When you use the emergency flasher, both indicator lights flash.

If one of the turn signal light bulbs burn out, the turn signal will blink twice as fast as normal.

Additional information on the turn signals
⇒ *page 47*.

CRUISE/ Cruise control

The **CRUISE** (USA models)/  (Canada models) warning/indicator light illuminates when the cruise control is activated.

Driver information system

Introduction

The Driver information display inside the instrument cluster provides you, the driver, with important information.



Fig. 6 Instrument cluster: center display



Fig. 7 Wiper lever: controls for the menu display

Center display

With the ignition on, the display in the Driver Information System shows the following information:

- CD inserted or Radio station set
- Outside temperature: At temperatures below 41 °F (+5 °C), a snowflake symbol appears in front of the temperature display ⇒ ⚠.
- Warning when a door, the engine compartment lid or the trunk lid is not closed.

Additional functions

You can open the following functions in the Driver Information System display by pressing the **RESET** button ⇒ fig. 7 one or more times:

Digital speedometer*
Tire pressure monitoring ⇒ page 196

Trip computer ⇒ page 21
Menu display ⇒ page 22
Service interval display ⇒ page 24
Lap timer* ⇒ page 25
Speed warning ⇒ page 69

Auto Check Control

Some functions and vehicle components are scanned for their operating status when you switch the ignition on and while you are driving. Malfunctions or required service procedures are signaled audibly and indicated by red and yellow illuminated symbols and reminders in the display.

 **WARNING**

- Never rely exclusively on the outside temperature display to determine if a road surface is icy or not. Keep in mind that road surfaces, especially bridges and overpasses, could be ice covered and slippery even at an outside temperature above 41 °F (+5 °C).
- Always remember, even if the “snowflake” symbol (ice warning) does not appear in the display, black ice could be on the road.
- Always reduce your speed and drive with special care in cold weather conditions when the chance of encountering icy road surfaces increases.

 **Tips**

On vehicles with Audi Navigation system, the displays may differ from their normal appearance during navigation.

Trip computer

Introduction

The trip computer gives you information on current and average fuel mileage, average speed, fuel range and driving time.



Fig. 8 Trip computer 1

The following information is continuously evaluated by the trip computer and can be displayed sequentially in the instrument cluster display:

Fuel range

The estimated cruising range in miles (km) appears in the display. The display changes in increments of 5 miles (10 km).

Average fuel mileage

The average fuel economy in MPG (l/100 km) since you last cleared the memory appears in this display.

Current fuel mileage

The instantaneous fuel consumption in miles per gallon (l/100 km) is shown in this display. When the vehicle is stationary, the most recent fuel consumption is displayed.

Average speed

The average speed in mph (km/h) since the last time the display was reset appears in the display.

Elapsed time

The length of time that you have been driving since you last reset the memory appears in this display. The maximum time period that can be recorded is 999 hours and 59 minutes.

Distance

The elapsed distance since the last time the memory was cleared appears in the display. The maximum distance that can be recorded is 9,999.9 miles (9,999.9 kilometers).

Tips

- Fuel consumptions (average and current), range and speed are displayed in metric units on Canadian models.
- All stored values will be lost if the vehicle battery is disconnected.

Memories

The trip computer is equipped with two fully automatic memories.




Fig. 9 Trip computer display: memory level 1

You can switch between the trip computer 1 and 2 by pressing the **RESET** button  ⇒ page 22, fig. 10.

You can tell which memory level is currently active by the number or the sign in the display ⇒ fig. 9. The data from the single-trip memory (memory level 1) is being displayed if a **1** appears in the display. If a **2** is shown, then the data from the total-trip memory is being displayed (memory level 2).

Single-trip memory (Trip computer 1)

The single-trip memory stores the trip information from the time the ignition is turned on until it is turned off. If the trip is continued **within 2 hours** from the time the ignition was turned off, the new data will be included in the calculation of ►

the current trip information. If the trip is interrupted for **more than 2 hours** the memory is reset automatically.

Total-trip memory (Trip computer 2)

Unlike the single-trip memory, the total-trip memory is not reset automatically. This permits you to evaluate your driving data for the entire period between manual resets.

Operation

The trip computer is controlled by two switches on the windshield wiper lever.



Fig. 10 Wiper arm/wiper lever: controls for the trip computer

Selecting the trip computer

- ▶ Tap the **Reset** button **(B)** until the trip computer (memory level 1 or 2) appears in the display
⇒ page 21, fig. 8.

Selecting the functions

- ▶ Push in the upper (lower) protrusion on the function selector switch **(A)** ⇒ fig. 10. The functions for the trip computer are displayed in succession on the respective memory levels.

Resetting the function to zero

- ▶ Push the **RESET** button **(B)** for at least two seconds.

You can reset the following values to zero:

- driving time
- distance
- average fuel mileage
- average speed

The trip computer only operates when the ignition is on. When you turn on the ignition, the function that was in use when you last turned the ignition off will be displayed.

i Tips

- You can also set the values for the functions to zero in the menu display (**Reset**)
⇒ page 22.
- All stored values will be lost if the vehicle battery is disconnected.

Menu display

Introduction



Fig. 11 Display: Start menu

Some functions in your vehicle can be set, activated, and controlled by **Menus** (e.g. parking system*). With these menus you can also select the information shown in the Driver Information System, which operates only with the ignition switched on. Operation is controlled by the **RESET** button and the rocker switch on the wiper lever ⇒ page 23, fig. 12.

The **Start menu** shows you the different display types ⇒ fig. 11. Each display type in the Start menu contains a submenu with additional options.

Set	Clock ⇒ page 23
	Tire pressure ⇒ page 196
	Computer ⇒ page 23
	Speed warning ⇒ page 70
	Language ⇒ page 23
	Units (distance, fuel consumption, temperature) ⇒ page 23
	Lap timer ⇒ page 25
	Lights ⇒ page 46
	Wiper (service position) ⇒ page 53
Check	Doors (unlocking and locking mode, for example Auto-lock) ⇒ page 29, ⇒ page 29
	Service ⇒ page 24
	Chassis number ⇒ page 212
Menu off	Keys
	The menu display is hidden and the lap timer appears.

Navigating the menu

Use the rocker switch on the windshield wiper lever and the **RESET** button to operate the menu and carry out inquiries and selections.



Fig. 12 Wiper lever: Controls for the menu display




Fig. 13 Display: Start menu

Reset button (B) and **rocker switch** (A) ⇒ fig. 12 functions:

To open the menu

- Press the **Reset** button (B) until the menu display ⇒ fig. 13 appears

Selections and settings

- Press the rocker switch (A) to reach a menu display. The switch is operated the same as the display (up/down).

Entering and confirming

- Press the **RESET** button (B).

Returning to the Start menu

- Press the **RESET** button longer than 2 seconds to return from any menu level to the Start menu.

Using the rocker switch, you can select the menus in the display or change settings. A cursor appears on the left in front of the selected values.

By pressing the **RESET** button, you activate the selection you made or confirm the values you set. **Selected** functions are identified with a check mark or are carried out directly.

Selecting settings

The Driver Information System settings are menu-guided.



Fig. 14 Display: Menu Settings, computer selected (page 1)

- Press the **RESET** button. The Start menu appears ⇒ fig. 14.
- Press the rocker switch until **Set** is displayed.
- Press the **RESET** button. All the menus appear. ►

- ▶ Press the rocker switch until the desired line is highlighted (cursor) ⇒ *fig. 14*.
- ▶ Press the **RESET** button.
- ▶ If necessary, scroll by selecting and activating the symbol for “Next page” or “Previous page”.

When you have selected the Computer menu and activated it by pressing the **RESET** button, two computer levels appear (computer 1 and computer 2). Now you have to select the level you want using the rocker switch and activate it with the **RESET** button.

Service interval display

The service interval display reminds you when your next service is due.




Fig. 15 Section of instrument cluster: Service interval display

The schedule for the next oil change or inspection is calculated automatically and displayed accordingly. The display works in two stages:

Service reminder

30 days before the next service is due, a service reminder appears in the display when you turn on the ignition.

After about 5 seconds the display switches back to normal. The distance and time remaining are updated each time the ignition is turned on until the date due for service is reached.

Service due

When the due date for service is reached, the message **Service due!** appears in the instrument cluster immediately after you turn on the ignition. Additionally, a warning tone sounds. After

about 5 seconds the display switches back to normal.

Calling up the service schedules

If or when an oil change or inspection is due, can be shown in the instrument cluster by selecting the service interval display. Select **Check > Service > Oil change** or **Service** by using the **RESET** button and the rocker switch ⇒ *page 23, fig. 12*.

Resetting the service interval display

Your authorized Audi dealer will reset the corresponding service schedule after performing the appropriate service on your vehicle. You also have the possibility to reset the oil change schedule after having performed an oil change according to Audi specifications.

- Switch the ignition on.
- Pull the knob ⇒ *fig. 15*. The message. **Service due!** appears.
- Pull the knob until the display **Oil change in ----- mi (km)--- days** appears. If the **RESET** button is not pulled within 5 seconds, the display reset mode closes.

! Note

- Only reset the oil change display when you have completed an oil change.
- If you disconnect the battery terminals, no calculations can be made for the service interval display during this time and no service reminder will appear. Remember that observing the proper service intervals is vitally important to extending the life of your vehicle, particularly the engine, and maintaining its value. Even if the mileage driven is low, the maximum period of one year from one service to the next must not be exceeded.

i Tips

The information in the Service Reminder remains stored even when the vehicle battery is disconnected.

Lap timer

Introduction

You can record and evaluate lap times with the lap timer in the display ⇒ *page 25, fig. 17*. The time is measured in minutes, seconds and 1/10 seconds. The hours are also shown when the lap time exceeds 60 minutes. The maximum individual measurement is 99 hours.

WARNING

Please devote your full attention to driving. As the driver, you have complete responsibility for safety in traffic. Only use the functions in such a way that you always maintain complete control over your vehicle in all traffic situations.

Tips

When the lap timer stopwatch is running, you can call up the trip computer information with the **RESET** button.

Calling up the lap timer and timing

Applies to vehicles: with lap timer



Fig. 16 Controls




Fig. 17 Display: Lap timer

Calling up the lap timer

- Press the **RESET** ⇒ *fig. 16 B* button until the lap timer ⇒ *fig. 17* appears.

Timing laps

- To start timing, press the upper section of the wiper switch **A**. The time measurement is shown in line **1** ⇒ *fig. 17*.
- To stop timing, press the upper section of the wiper switch **A** again. This also starts timing the next round. The previous time moves one line up, first to line **2** and then to line **3**. Line **4** shows the current lap number, for example LAP 5.

Displaying intermediate time and pausing timing

- To display an intermediate time, press the lower section of the wiper switch **A**. The intermediate time appears in line **1** and is marked with *.
- To pause timing, press the lower section of the wiper switch **A** again.
- To continue timing, press the upper section of the wiper switch **A**.

If timing is paused, you can continue it later even if you switch the ignition off.

Evaluating times and continuing or resetting timing

You can evaluate the fastest, slowest and average lap times.



Fig. 18 Display: lap time evaluation

- To evaluate lap times, press and hold the **RESET** ⇒ *page 25, fig. 16 B* button for approximately 2 seconds. The display shows the

fastest lap "+", the slowest lap "-" and the average lap time "Ø".

- ▶ To continue timing for additional laps, press the wiper switch **A**.
- ▶ To reset the timer to zero, press and hold the **RESET** button again for approximately 2 seconds.
- ▶ To switch the lap timer off completely, press the **RESET** button briefly.

i Tips

- Saved lap times cannot be individually deleted from the total results.
- The saved lap timer values will not be lost after turning the ignition off.

On-Board Diagnostic system (OBD)

Malfunction Indicator Lamp (MIL)

The Malfunction Indicator Lamp (MIL)  is part of the On-Board Diagnostic (OBD II) system.

The warning light illuminates when there is a malfunction in the engine electronic system. A malfunction may have various causes:

- The fuel filler cap may be improperly closed
⇒ *page 153*.
- There is a leak in the fuel vapor recovery system.
- The engine control receives faulty vehicle road-speed signals.

Contact your nearest authorized Audi dealer for assistance.

If the light illuminates, the catalytic converter could be damaged. Continue driving **with reduced power** (avoiding sustained high speeds and/or rapid accelerations) and have the condition corrected.

An improperly closed fuel filler cap may also cause the MIL light to illuminate ⇒ *page 153*.

On-Board Diagnostics



Fig. 19 Location of Data Link Connector (DLC)

On-Board Diagnostics monitors the components of your emission control system. Each monitored component in your engine system has been assigned a code. In case of a malfunction, the component will be identified and the fault stored as a code in the control module memory.

In order to make an accurate diagnosis, the stored data can only be displayed using special diagnostic equipment (generic scan tool for OBD).

In order to connect the special diagnostic equipment, push the plug into the Data Link Connector (DLC) ⇒ *fig. 19*.

Your authorized Audi dealer or a qualified service station can interpret the code and perform the necessary repair.



WARNING

Do not use the diagnostic connector for personal use. Incorrect usage can cause malfunctions, which can increase the risk of a collision!

Opening and closing

Keys

Key set




Fig. 20 Key set



Fig. 21 Remote master key: Indicator light

A Master key with remote control

You can centrally lock and unlock your vehicle and start the engine with the master key with remote control. To fold the key out and back in place, press the release button ⇒ *fig. 20* (arrow).

B Valet key

The valet key only fits the lock in the driver's door and the ignition lock. If you have to leave the key with somebody else, you are well-advised to turn over the valet key only.

Be aware that the front lid and glove compartment can be opened from inside the vehicle using the release buttons.

C Emergency key

The emergency key is only for temporary use if the vehicle key should be lost or misplaced.

Key replacement

If you lose a key, contact your authorized Audi dealer immediately to have the *lost* key disabled. Be sure to bring all your keys with you.

If a key is lost, you should report it to your insurance company.

Registered keys

You can inquire about the number of remote master keys registered to your vehicle ⇒ *page 22*. In this way, you can be certain of obtaining all the remote master keys if you purchase a used vehicle.

State of master key battery

When a button is pressed, the check light flashes ⇒ *fig. 21*. If the check light does not come on or flash, the battery is dead and has to be replaced.

Battery replacement ⇒ *page 28*.



WARNING

- Do not leave your vehicle unattended with the key in the ignition lock. Entry by unauthorized persons could endanger you or result in theft or damage the vehicle. Always lock all doors and take the key.
- Do not leave children unattended in the vehicle, especially with access to vehicle keys. Unguarded access to the keys provides children the opportunity to start the engine and/or activate vehicle systems such as the power windows etc. Unsupervised operation of any vehicle system by children can result in serious injury.



Tips

- If you open the driver's door with the key left in the ignition lock, a chime will sound. This is your reminder to remove the key and lock the door.
- For security reasons, replacement keys are only available from Audi dealers.

Master key with remote control

The remote control allows you to lock or unlock the vehicle electronically.

The transmitter and battery are located in the head of the remote control. The receiver is located inside the vehicle. The maximum effective range depends on several things. Remember, if the battery is weak, the effective range decreases.

If you need to replace the remote control, or if you need to have it repaired, you must see your authorized Audi dealer. Only then can you use the key again.

Tips

- If the ignition is switched on, the remote control system is deactivated.
- The remote control system can be affected by other systems operating in the same frequency range close to the vehicle, such as mobile telephones, television broadcasting stations, etc.
- For Declaration of Compliance to United States FCC and Industry Canada regulations
⇒ page 218.

Master key battery replacement

Each master key contains a battery housed under the cover.




Fig. 22 Remote master key: opening the cover

- Pry apart the base ⇒ fig. 22 **A** and the cover **B** carefully with a coin.
- Remove the cover (arrow).
- Remove the dead battery from the cover.

- Install the new battery. Please make certain that the “+” sign on the battery faces down in the cover. Correct polarity is shown on the cover.
- Place the cover with the new battery on the key base and press both parts together.



For the sake of the environment

Dispose of dead batteries properly so as not to pollute the environment.



Tips

The replacement battery must be the same specification as the original.

Electronic immobilizer

The immobilizer helps to prevent unauthorized use of your vehicle.

A computer chip inside your key automatically deactivates the electronic immobilizer when you insert the key in the ignition lock. When you remove the key from the ignition lock, the electronic immobilizer is automatically activated once again.



WARNING

Always take the key with you when you leave the vehicle. The key can disarm the electronic engine immobilizer and permit an unauthorized person to start the engine and enable operation of the vehicle systems such as power window leading to serious personal injury.



Tips

- The vehicle cannot be started if an unauthorized key is used. The vehicle may not start if another radio device such as a key for another vehicle or a transponder is located on the key ring.
- For Declaration of Compliance to United States FCC and Industry Canada regulations
⇒ page 218.

Power locking system

General description

The power locking system locks or unlocks all doors simultaneously.

The power locking system in your vehicle incorporates the following functions:

- Central locking function
- Remote control feature ⇒ *page 28*.
- Anti-Theft Alarm System ⇒ *page 33*.

All the doors and the front lid are locked by the central locking system when you lock the vehicle.

The unlocking and locking mode* can be changed in the driver information system ⇒ *page 22*.

Unlocking the vehicle

You can unlock the vehicle from outside either by using the remote control **or** by inserting and turning the key in the driver's door lock. When you **unlock** your vehicle:

- The anti-theft alarm system is deactivated briefly.
- The vehicle interior lights illuminate for approximately 30 seconds.
- All turn signal lights will flash twice when the car is unlocked.
- After unlocking the vehicle, you have 30 seconds to open a door or the front lid. After 30 seconds, the vehicle automatically locks and the anti-theft alarm system activates again.

The front lid can be locked or unlocked either by using the remote control **or** by inserting and turning the key in the driver's door lock. Unlocking the vehicle with the remote control  will only *unlock* the front lid, to *open* it, the lid handle needs to be pressed.

Locking the vehicle

You can lock the vehicle from outside either by using the remote control **or** by inserting and turning the key in the driver's door lock. When you **lock** the vehicle:

- All doors and the front lid are locked.
- All turn signal lights will flash once when the car is locked.

- The anti-theft alarm system is activated. The horn of the anti-theft alarm system will sound and the anti-theft alarm system readiness light, located in the center of the instrument panel below the windshield on the right side of the air vent, will start to blink.
- The vehicle interior lights turn off.

Automatic locking*

The automatic locking feature locks all the vehicle doors and the front lid when you drive faster than 9 mph (15 km/h).

You can unlock the vehicle from the inside by:

- removing the key from the ignition switch (the vehicle will automatically unlock itself) or
- pressing the unlock part of the power lock switch  or

pulling the door handle (to open the door).

If you wish, you can have an authorized Audi dealer convert your power door lock system to automatic locking.

Unintentionally locking yourself out

The vehicle does not lock with the central locking switch ⇒ *page 31* if the driver's door is open.

Do not lock your vehicle with the **remote master key** until all doors and the front lid are closed. In this way you avoid locking yourself out accidentally.



WARNING

- When you lock your vehicle from outside, nobody - especially children - should remain inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.
- When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in one of the doors.
- Do not leave children inside the vehicle unsupervised. In an emergency it would be impossible to open the doors from the outside without the key.

Tips

- The driver's door can be locked and unlocked with the key if the power locking system fails. The passenger's door can be locked manually ⇒ *page 32*.
- In the event of a crash with airbag deployment all locked doors will be automatically unlocked to give access to the vehicle occupants from the outside.
- The anti-theft alarm system cannot be activated if the power locking system is not activated.
- You are well advised not to keep valuables inside an unattended vehicle, visible or not. Even a properly locked vehicle cannot provide the security of a safe!

Unlocking and locking the vehicle with the remote control

How the remote control works.



Fig. 23 Remote control: function buttons

Whether only the driver's door or the entire vehicle is unlocked when the opening button **A** is pressed once, depends on the settings in the Driver information system **Central locking** menu ⇒ *page 22*.

To unlock the vehicle

- ▶ Press button **A**.
- ▶ Press button **A** *two times* within two seconds **to unlock all doors and the front lid**.

To lock the vehicle

- ▶ Press button **B** ⇒  in *General description on page 29*.
- ▶ Watch that all turn signal lights flash once.

To unlock front lid only

- ▶ Press button **C** for approximately one second.

PANIC Button

- ▶ Push the red button **D** to activate the panic function. The horn sounds and the turn signals flash.
- ▶ Push the button **D** again to deactivate the panic function.

The remote controls allows you to:

- lock or unlock the vehicle
- selectively unlock the front lid.

The turn signals will flash briefly whenever you lock or unlock the vehicle. Also, the interior light will come on or go off whenever you open or close the driver's door.

The transmitter and battery are located in the head of the remote control. The receiver is located inside the vehicle. The maximum effective range depends on several things. Remember, if the battery is weak, the effective range decreases.

The remote-control key contains a fold-out key that you can use to manually lock or unlock the vehicle and to start the engine.

If you need to replace the remote control, or if you need to have it repaired, you must see your authorized Audi dealer. Only then can you use the key again.

WARNING

Read and follow all WARNINGS ⇒  in *General description on page 29*.

Tips

- The remote control key is automatically deactivated when the ignition is switched on.
- The operation of the remote control key can be temporarily disrupted by interference from transmitters in the vicinity of the vehicle working in the same frequency range (e.g. a cell phone, radio equipment).
- In order to make sure the locking function is working, you should always keep your eye

on the vehicle to make sure it is properly locked.

- Do not use the remote control if you are inside the car, otherwise you may unintentionally lock the vehicle, and then you would set off the anti-theft alarm when you try to start the engine or open a door. In case this happens anyhow, push the unlock button .
- Use the panic function only if you are in an emergency situation.

Resetting the remote control

The remote control must be reset if the vehicle does not unlock.

- ▶ Press the unlock button  on the remote control.
- ▶ Manually unlock the driver's door lock with the mechanical key within 30 seconds.
- ▶ Press either the lock-  or the unlock  button to complete the reset sequence.

Operating locks with the key

To lock and unlock the vehicle from the outside, turn the key in the lock of the driver's door.




Fig. 24 Key turns for opening and closing

- ▶ To unlock the vehicle, turn the key to the opening position **A** ⇒ *fig. 24*.
- ▶ To lock the vehicle, turn the key in the lock of the driver's door to the lock position **B** ⇒ .

WARNING

Always read and heed WARNING ⇒  in General description on page 29.

Locking and unlocking the vehicle from inside

The vehicle can be locked or unlocked from the inside using the power locking switch.




Fig. 25 Section from driver's door: Power locking switch

- ▶ Press the upper part of the power locking switch  to lock the vehicle ⇒ .
- ▶ Press lower part of the switch  to unlock the vehicle.

If you lock the vehicle using the power locking switch, please note the following:

- You cannot open the doors from the *outside* (increased security, for example when you are stopped at a red light).
- The LED in the switch  lights up when all the doors and the front lid are closed and locked.
- You can unlock and open the doors from the *inside* by pulling on the door handle.
- You cannot lock the vehicle with the central locking switch when the driver's door is open.
- If you have a crash and the airbag is activated, the doors automatically unlock.

WARNING

- If you use the power locking switch with the doors closed, remember that all the vehicle doors will lock.
- Locked doors make it more difficult for emergency workers to get into the vehicle, which puts lives at risk. Do not leave anyone behind in the vehicle, especially children.

Emergency locking

If the power locking system fails (power failure), you will need to lock the passenger door separately.




Fig. 26 Passenger's door: emergency release

For this purpose, a mechanical locking device is provided on the end panel of the passenger door (only visible when the door is open).

- ▶ Remove the cap ⇒ fig. 26.
- ▶ Insert the key into the inner slot and turn it to the right as far as it can go.

After you close the door you will no longer be able to open it from the outside. You can open it from the inside, however, by pulling on the door latch twice.

Front lid

Opening/closing the front lid



Fig. 27 Drivers door: remote front lid release



Fig. 28 Release lever under the front lid

When opening the front lid, the windshield wipers must be switched off and the wiper arms must be folded against the windshield. Otherwise the paint could be damaged.

Opening the front lid

- ▶ Press the center button on the master key or
- ▶ Pull the release button in the driver's door ⇒ fig. 27.
- ▶ Pull up on the release under the front lid ⇒ fig. 28 (arrow). This releases the catch.
- ▶ Open the front lid all the way.

Closing the front lid

- ▶ Pull the front lid down until the pressure from the struts is reduced.
- ▶ Close the front lid.
- ▶ Press the front lid closed carefully using both hands until it latches audibly ⇒ ⚠.

⚠ WARNING

A front lid that is not completely latched could fly up and block your view while driving.

- When you close the front lid, check it to make sure the safety catch has properly engaged. The lid should be flush with the surrounding vehicle body parts.
- If you notice while driving that the lid is not secured properly, stop at once and close it.
- Never leave your vehicle unattended especially with the front lid left open. A child could crawl into the luggage compartment and pull the lid shut, becoming trapped and unable to get out. To reduce the risk of personal injury, never let children play in or around your vehicle. Always keep the front

lid as well as the vehicle doors closed when not in use.

! Note

Make sure no objects are protruding above the edge of the luggage compartment. Otherwise, the front lid could be damaged.

i Tips

If the front lid is open or not properly locked when the ignition is turned on, the door and front lid warning appears in the instrument cluster display.

Emergency release for front lid

If the front lid cannot be opened, an emergency release is provided.



Fig. 29 Section: Emergency release

- Reach under the closed glove compartment. There is a red plastic cord under the glove compartment.
- Pull the red plastic cord towards you.

Anti-theft alarm system

The anti-theft alarm triggers an alarm if anyone attempts to break into the vehicle.



Fig. 30 Diode position in the instrument panel

The anti-theft alarm system triggers an audible alarm and turns on the emergency flasher if an unauthorized interference with the vehicle is sensed by the system.

How is the anti-theft alarm system switched on?

The anti-theft alarm system is switched on when you lock the driver's door manually using the fold-out key, or when you use the remote control. The system is activated approximately 30 seconds after the vehicle is locked. The indicator light  *fig. 30* starts flashing rapidly for 2 seconds and then blinks slowly.

How is the anti-theft alarm system switched off?

The anti-theft alarm system is switched off only when you unlock your vehicle. If you do not open a door within 30 seconds after you have unlocked with the remote control, the vehicle will lock itself again automatically.

When will the anti theft alarm system be triggered?

When the vehicle is locked, the alarm system monitors and protects the following parts of the vehicle:

- engine compartment
- luggage compartment
- doors
- ignition

When the system is activated, the alarm will be triggered if one of the doors, the engine compartment lid or the front lid are opened.

The anti-theft alarm system will also go off when the battery is disconnected.

You can also trigger the alarm by pressing the **PANIC** button on your remote-control key. This will alert other people in case of emergency. Press the **PANIC** button again to turn off the alarm.

How is the anti-theft alarm switched off when triggered?

The alarm system is switched off when you unlock the vehicle using the remote-control key or when the ignition is switched on. The alarm will also switch itself off when it comes to the end of its cycle.

Emergency flasher

The emergency flasher will blink briefly when the doors, engine compartment lid and front lid are properly closed.

If the emergency flashers do not blink, check the doors, engine compartment lid and front lid to make sure they are properly closed. If you close a door, the engine compartment lid or the front lid with the anti-theft alarm switched on, the emergency flashers will blink only after you have closed the door or lid.

Tips

For the anti-theft alarm system to function properly, make sure all vehicle doors and windows are closed before leaving the vehicle.

Power windows

Controls

The driver can operate all windows.



Fig. 31 Driver's door: power window switches

The power window switches have a **two-position function**:

Opening the windows

- ▶ Press the switch and **hold it down** until the window has reached the desired position.
- ▶ Press the switch **briefly** to open the window automatically.
- ▶ By briefly pressing/pulling the switch again, the downward travel of the window can be stopped in any position ⇒ ⚠.

Closing the windows

- ▶ Pull the switch and **hold it** until the window has reached the desired position.
- ▶ Pull the switch **briefly** to close the window automatically.
- ▶ By briefly pressing/pulling the switch again, the upward travel of the window can be stopped in any position ⇒ ⚠.

WARNING

- Do not leave children unattended in the vehicle, especially with access to vehicle keys. Unsupervised use of the keys can result in starting of the engine and use of vehicle systems such as power windows, etc. which could result in serious injury.
- Remember – you can still open or close the power windows for about ten minutes after

the ignition is switched off. Only when either of the front doors are opened are the power windows switched off.

- Be careful when closing the windows. Check to see that no one is in the way, or serious injury could result!
- Always remove the ignition key whenever you leave your vehicle.
- If you lock your vehicle from the outside, no one, especially children, should remain in the vehicle.
- Do not stick anything on the windows or the windshield that may interfere with the driver's field of vision.

Tips

- When the doors are opened, the windows are automatically lowered 0.4 in (10 mm).

Reactivating the system after battery disconnection

If the vehicle battery is disconnected and then reconnected, the automatic closing and opening function will not work until it is reactivated.

- ▶ Pull and hold the power window switch until the window is completely closed.
- ▶ Release the switch and pull it again for one second.

Garage door opener (HomeLink)

Description



Fig. 32 Garage door opener: examples of using with different systems

You can activate various systems such as garage doors, security systems and home lighting from inside your vehicle using the garage door opener (HomeLink). There are three buttons for this in the vehicle headliner that can be in used in place of up to three hand-held transmitters.

To operate systems using the garage door opener, the three buttons in the headliner must be programmed first.

WARNING

Make sure no people or objects are in the immediate vicinity of the equipment when using or programming the garage door opener. People can be injured and objects can be damaged if they are caught in the equipment.

Tips

- For security reasons, we recommend that you clear the programmed buttons before selling the vehicle.
- For additional information about HomeLink, visit www.homelink.com.
- For Declaration of Compliance to United States FCC and Industry Canada regulations ⇒ *page 218*.

Programming the HomeLink transmitter




Fig. 33 Overhead console: HomeLink keypad




Fig. 34 Front bumper: location of transmitter unit

The transmitter is programmed in two phases. For rolling code transmitters, a third phase is also necessary.

Phase 1: programming the overhead keypad

1. Make sure your vehicle is within operating range of the remote controlled garage door opener.
 2. Set the parking brake ⇒ ⚠ in Description on page 35.
 3. Turn the ignition on. Do not start the engine!
 4. Press and hold the two outside HomeLink buttons **I** and **III** for approximately 20 seconds until indicator light **A** ⇒ fig. 33 begins to flash. Then release both buttons. Do not hold the buttons for longer than 30 seconds.
- This procedure only needs to be performed **once**. It erases the factory-set default codes and does not have to be repeated to program additional remote controls.
5. Press and hold the HomeLink button **I**, **II** or **III** until the indicator light **A** starts flashing *slowly*. Release the button.

- The system will remain in programming mode for 5 minutes. Go to the front of the vehicle and proceed with phase 2.

Phase 2:

programming the bumper mounted transmitter

6. Hold the *original remote control* at a distance between 0–6 in. (0–15 cm) from the bumper below the appropriate headlight for your vehicle ⇒ fig. 34 (use the shortest distance possible).
 7. Aim the remote control just below the **driver side** headlight.
 8. Press and hold the activation button on the remote control.
- May be different in Canada. If so, press and repress (cycle) the activation button on your remote control every two seconds.
9. The emergency flashers will flash **three times** (after about 15–60 seconds) when the programming is successful. Release the button on the remote control.
- To program more devices, repeat steps 4 to 9.
10. Press and hold the trained HomeLink button and observe the indicator light **A** ⇒ fig. 33.
- If the indicator light is solid/continuous, programming is complete and your device should activate when you press and release the trained HomeLink button.
- If the indicator light blinks rapidly for 2 seconds and is then a solid/continuous light, proceed with phase 3 to program a rolling code device.

Phase 3: rolling code programming

- A second person on a ladder who can safely reach the garage door opener motor is recommended.
11. Locate the “learn” button on the garage door opener motor (refer to the operating instructions for the opener, as the location of this button may vary by manufacturer).
 12. Press and release the learn button on the garage door opener motor.
- **Note:** once the button is pressed, there are **30 seconds** in which to initiate the next step.
13. On the HomeLink keypad inside the vehicle, firmly press and hold the HomeLink button

previously programmed in phases 1 and 2 for two seconds and release. Repeat this sequence **twice**.

- ▶ Some vehicles may require the press/hold/release sequence up to three times to complete the training process.
- ▶ *HomeLink should now activate your rolling code equipped device.*

If the 5 minute time limit is exceeded, the **emergency flashers will flash one time** to indicate that the process has been terminated. In this case, repeat steps 4 through 9.

If the emergency flashers do not flash *three* times (after about 15–60 seconds), programming was not successful. In this case, repeat steps 4 through 9.

Remote control units for garage door openers in Canada are set to stop transmitting radio frequency signals after two seconds. This time may not be sufficient for the HomeLink system to learn the radio frequency signal. Perform all other steps as described above.

Operating the HomeLink transmitter

The HomeLink transmitter works in the same manner as the original handheld remote control that came with the system.

- ▶ Press the appropriate programmed button **I**, **II** or **III** ⇒ *page 36, fig. 33* to activate the desired remote control function ⇒  in *Description on page 35*.

Reprogramming a single button

A HomeLink button can be reprogrammed individually without affecting the other button allocations.

Programming the overhead keypad

- ▶ Press the appropriate HomeLink button until the indicator light begins flashing slowly.

Programming the bumper mounted transmitter

1. Hold the *original remote control* at a distance between 0–5 in. (0–13 cm) from the

bumper below the appropriate headlight for your vehicle (use the shortest distance possible).

2. Aim the remote control just below the **driver side** headlight.
 3. Press and hold the activation button on the remote control.
 4. The emergency flashers will flash **three times** (after about 15–60 seconds) when the programming is successful. Now release the button on the remote control.
- ▶ If the device utilizes a rolling code, please follow phase 3 of ⇒ *page 36, Programming the HomeLink transmitter* for rolling code programming.

This procedure will cause the existing programming on the HomeLink button to be erased!

Erasing the programming of the HomeLink transmitter

When you erase the programming, the programming on all three of the transmitter channels will be lost!

- ▶ Perform steps 1 to 4 as described on ⇒ *page 36, Phase 1: programming the overhead keypad*.

When completed, the HomeLink system will be in the programming mode and is then ready to learn the codes for remote controlled devices.

Tips

- Programmed buttons cannot be erased individually.
- For security reasons you are advised to erase the programming of the HomeLink system before you sell your vehicle.

Convertible top

Convertible top

General information

The fabric convertible top opens and closes automatically. When it is open, it is stored in the convertible top storage bay. The convertible top may be opened or closed at speeds up to 31 mph (50 km/h).

The convertible top is wind- and waterproof under normal conditions. Some moisture may collect in the vehicle interior, but only under extremely adverse weather conditions such as torrential rain. That is normal and no cause for concern.

Follow the cleaning and maintenance instructions ⇒ *page 145* to ensure the convertible top remains wind- and waterproof. Also note the following points:

- Only stow the convertible top when it is clean and dry. Grains of sand or coarse dirt particles can cause abrasions on the convertible top when stowed that can lead to damage to the fabric over time. Stowing the convertible top when it is damp can cause marks or permanent mildew spots to form.
- Do not leave the convertible top open for several weeks or the creases in it may become discolored. This is especially true if the top was stowed when damp.
- Remove ice and snow before opening the convertible top. Do not use any sharp edged objects to remove ice and snow or the convertible top could be scratched or damaged. The rear window may be cleared with a standard ice scraper.
- The fabric in the convertible top loses elasticity in sub-zero temperatures. We recommend not opening or closing the convertible top when the temperature is below 32 °F (0 °C). The convertible top will not open when the temperature is 5 °F (-15 °C) or below.

Opening/closing the convertible top



Fig. 35 Center console: convertible top switch

Requirement: the front lid must be closed and the ignition must be switched on.

Opening the convertible top

- Pull and hold the convertible top switch until the top is stowed in the bay and the cover on the bay has closed completely.

Opening the convertible top using the one-touch function

- Pull the switch briefly to open the convertible top completely. It is not necessary to hold the switch. The one-touch function is only available at speeds between 4 and 31 mph (6 and 50 km/h).

Closing the convertible top

- Press and hold the switch until the convertible top is closed and the latch is locked.

The indicator light  in the instrument cluster goes out when the top is completely open or closed.

The side windows automatically lower slightly during the opening/closing process.

WARNING

- Never drive when the convertible top is not locked correctly. The wind generated by driving could cause it to open, which could injure vehicle occupants or damage the vehicle.

- Make sure no one will be injured by the convertible top supports and other moving objects on the vehicle when opening and closing the top.

Note

To prevent damage to the convertible top:

- do not store any objects in the convertible top storage bay.
- make sure there is enough space above the vehicle when opening or closing the convertible top.

Tips

- When the indicator lamp  blinks, there is a system malfunction ⇒ *page 15*.
- The one-touch opening function is not available when the vehicle is traveling below 4 mph (6 km/h) or above 31 mph (50 km/h). If this is the case, a warning tone will sound and a message will appear in the instrument cluster ⇒ *page 39*.

Error message in the instrument cluster display

An error message appears if the convertible top cannot open or close.

Several conditions must be met for the convertible top to open or close automatically.

An error message in the instrument cluster display indicates if one of the conditions is not met or there is a malfunction.

Soft top: Please close engine lid!

The engine compartment lid must be closed when opening or closing the convertible top. This message appears in the instrument cluster display if the engine compartment lid is not closed.

Soft top: Cannot be used!

This error message appears if the convertible top cannot open or close because of safety reasons or if there is a malfunction. The following causes are possible:

- **The vehicle is traveling too fast:** Convertible top operation is deactivated for safety reasons

if the vehicle is traveling too fast. A message will appear. Reduce the vehicle speed and pull or press the switch again to open or close the convertible top.

- **The battery voltage is too low:** The convertible top cannot open or close if the battery voltage is too low. This ensures there will be enough battery voltage left to start the vehicle. The convertible top can be operated again after the engine is started.
- **Overload protection is active:** Operating the convertible top continuously for a long period of time places stress on the hydraulic unit. Overload protection is activated to prevent damage to the system. This protective function prevents the convertible top from opening or close for approximately 15 to 30 minutes. It will function again after that ⇒ .
- **Malfunction:** Failure of system components is one possible cause for malfunction. If this happens, you can also operate the convertible top by hand ⇒ *page 41*.
- **The exterior temperature is too low:** The convertible top will not open in temperatures below (5 °F) (-15 °C).

Soft top not secure

If the convertible top is not **completely** open or closed and the vehicle is traveling too fast, the error message above appears and a warning tone sounds. Reduce the vehicle speed and pull or press the switch again to open or close the convertible top.

WARNING

Never drive when the convertible top is not locked correctly. The wind from driving could cause the convertible top to open. This can result in injuries and damage to the vehicle.

Wind deflector

The wind deflector reduces turbulence in the passenger compartment and makes driving more comfortable.




Fig. 36 Installing the wind deflector




Fig. 37 Luggage compartment: storing the wind deflector

The wind deflector is located in the luggage compartment. Installing it from the side of the vehicle that is farthest from traffic is recommended for safety reasons. Follow the installation instructions provided in the storage bag.

Installing/removing the wind deflector

- ▶ To install the wind deflector, slide the retaining pin **A** into the mount **B** ⇒ fig. 36. The wind deflector is secure when it clicks into place and the red marks on both buttons are no longer visible.
- ▶ To remove the wind deflector, press both buttons **C** and pull the deflector upward.

Storing the wind deflector

- ▶ Slide the wind deflector into the storage bag with the retaining pins facing downward.
- ▶ Hang the storage bag on the retainers **D** in the luggage compartment ⇒ fig. 37.

! WARNING

- Do not use the wind deflector to secure cargo or other objects. This could result in injury.
- Be careful of traffic when installing the wind deflector.

! Note

To prevent damage to the vehicle paint, do not lean on the vehicle when installing the wind deflector. Objects such as belt buckles could scratch the surface of the paint.

i Tips

- Keeping both side windows raised provides the best wind protection.
- To prevent mildew, do not store the wind deflector when it is damp.

Rear window




Fig. 38 Rear window in wind deflector position



Fig. 39 Section of the center console: convertible top switch

The rear window can be extended slightly when the convertible top is open to reduce air movement inside the vehicle and increase comfort. ▶

This is called the wind deflector position

⇒ *fig. 38.*

The rear window can be extended completely for cleaning. This is called the cleaning position.

Extending the rear window into the wind deflector position

- ▶ Pull and hold the rear window switch ⇒ *fig. 39.*
- ▶ Release the switch once the rear window has reached the wind deflector position.

Extending the rear window into the cleaning position

- ▶ Pull and hold the rear window switch ⇒ *fig. 39.*
- ▶ Release the switch once the rear window has reached the wind deflector position.
- ▶ Pull and hold the rear window switch again.
- ▶ Pull and hold the convertible top switch within one second ⇒ *page 38, fig. 35.*

Retracting the rear window

- ▶ Press and hold the rear window switch until the window has been retracted.

Retracting the rear window using the one-touch function

- ▶ Press the rear window switch briefly. There is no need to hold the switch.

The rear window can only be operated when the ignition is switched on.

The rear window can also be extended or retracted when the convertible top is closed.

WARNING

- Do not use the rear window to secure cargo or other objects. This could result in injury.
- Always pay attention and be careful when extending or retracting the rear window. It could cause injury by pinching.

Tips

- Keeping all of the windows raised provides the best wind protection.
- The vehicle must be stationary to bring the rear window into the cleaning position. The rear window will retract once you begin driving.

Convertible top emergency operation

General information

The convertible top can be closed by hand if there is a malfunction.

First check if overload protection is active ⇒ *page 39.* If this is the case, the convertible top will operate again after a short delay. Otherwise the following steps must be completed before closing the convertible top:

- ▶ Activate the parking brake.
- ▶ Open the side windows, if necessary.
- ▶ Remove the key from the ignition.
- ▶ Pull or press the convertible top switch ⇒ *page 38, fig. 35* for approximately 10 seconds.

Emergency locking is not intended for long-term use or long drives. The convertible top will not be completely waterproof after using the emergency locking procedure because the seals will not be seated correctly. Only close the convertible top manually in an emergency. Please see an authorized Audi R8 dealer to have the cause of the malfunction corrected.

WARNING

- The ignition must be switched off during the entire closing procedure.
- When positioning the convertible top, avoid contact with the supports or other moving parts. Otherwise you could pinch your hands.
- If convertible top operation fails when opening or closing the top, do not hold or touch the supports or other moving parts when releasing the pressure. The convertible top will sink down and could pinch your hands.
- Never drive when the convertible top is not locked correctly. The wind from driving could cause the convertible top to open. This can result in injuries and damage to the vehicle.

Tips

Have a second person assist when closing the convertible top. Opening the storage bay lid and positioning the convertible top is easier when a second person is assisting.

Step 1: Retract the rear window



Fig. 40 Upper storage compartment: removing the cover



Fig. 41 Upper storage compartment: using the Allen wrench as a crank to lower the rear window

The rear window must be retracted in order to close the convertible top. If the rear window switch is not functioning ⇒ *page 40*, the rear window can be cranked.

- ▶ Open the upper storage compartment between the seat backrests ⇒ *page 60*.
- ▶ Remove the cover using the screwdriver from the vehicle tool kit ⇒ *fig. 40*.
- ▶ Press the Allen wrench from the vehicle tool kit firmly into the opening until it clicks into place ⇒ *fig. 41*.
- ▶ Turn the bolt clockwise until the rear window is lowered.

Step 2: Open the convertible top storage bay lid




Fig. 42 Engine compartment: installing the emergency operation bolts



Fig. 43 Raising the storage bay lid and pulling it back

The engine compartment lid must be released using the emergency procedure in order to release the storage bay lid ⇒ *page 155*.

Releasing the convertible top storage bay lid

- ▶ Turn the emergency operation bolts on the left and right sides of the engine compartment ⇒ *fig. 42* clockwise using the open end wrench from the vehicle tool kit until the bolts are installed completely. The convertible top storage bay lid will raise approximately 0.4 in (1 cm) from the vehicle when the bolts are installed completely.
- ▶ Close the engine compartment lid ⇒ *page 156*.

Opening the convertible top storage bay lid

- ▶ From the rear of the vehicle, reach into the center ventilation slot in the storage bay lid with both hands and raise the lid approximately 12 in (30 cm).
- ▶ Hold the storage bay lid in this position and pull it toward you until it stops ⇒ *fig. 43*.

⚠ WARNING

When working in the engine compartment:

- Turn the engine off.
- Activate the parking brake.
- In vehicles with a manual transmission, move the shifter lever into idle. In vehicles with the R tronic transmission, move the selector lever into the N position.
- Remove the ignition key.
- Let the engine cool down.
- Keep children away from the engine compartment.

! Note

To prevent damage to the vehicle, only open the convertible top storage bay lid when the engine compartment lid is closed.

Step 3: Remove the covers




Fig. 44 Convertible top: covers marked



Fig. 45 Convertible top storage bay lid: removing the cover

The following steps must be performed on both sides of the vehicle.

- Remove the bolt in the cover on the bottom side of the storage bay lid using the open end wrench from the vehicle tool kit ① ⇒ fig. 45.

- Move the cover up and down carefully until it can be pulled downward from the teeth ②.

Step 4: Lift the convertible top out




Fig. 46 Convertible top storage bay: lifting the convertible top out



Fig. 47 Windshield frame: pressing the convertible top forward

- Hold the convertible top at the ① point (arrow) ⇒ fig. 46 and raise it carefully ⇒ ⚠.
- Pull the convertible top all the way out in the direction indicated ②. Position the fins upward at the same time.
- Press the convertible top as far forward toward the windshield frame as possible ⇒ fig. 47.

Have a second person assist when positioning the convertible top. That person should stand on the opposite side of the vehicle and perform the same steps.

⚠ WARNING

- When positioning the convertible top, avoid contact with the supports or other moving parts. Otherwise you could pinch your hands.
- When pressing the convertible top down onto the windshield frame, make sure that you do not pinch yourself or anyone else.

Step 5: Secure the convertible top




Fig. 48 Convertible top storage bay: installing the driver




Fig. 49 Securing the convertible top

The convertible top must be under tension to secure it to the windshield frame. The wheel wrench, driver and bolts from the vehicle tool kit are required for this.

Have a second person assist with this step. That person should stand on the opposite side of the vehicle and perform the same steps.

- ▶ Position the driver (A) on the bolt (B) in the front section of the convertible top storage bay and rotate clockwise to install in the threads ⇒ *fig. 48*.
- ▶ Position the wheel wrench (C) with the long end on the driver (1).
- ▶ Press the convertible top as far forward as possible toward the windshield frame (2) with one hand ⇒ *fig. 49*. At the same time, pull the fins upward (3) for support with the other hand.
- ▶ Now, grasp the fins with the hand that you used to move the convertible top forward and hold the fins in this position. With the other hand, turn the wheel wrench upward until it stops (4).

i Tips

- When pressing the convertible top forward, make sure the locking pins are seated in the latch on the windshield frame and not on the frame itself.
- When pressing the convertible top forward, make sure the locking pins are seated exactly in the latch on the windshield frame and not on the frame itself. This is the only way that the convertible top can be latched correctly.

Step 6: Lock the convertible top




Fig. 50 Inner side of the convertible top: removing the cap



Fig. 51 Inner side of the convertible top: positioning the Allen wrench

- ▶ Remove the cap in the center of the convertible top using the screwdriver from the vehicle tool kit ⇒ *fig. 50*. The emergency locking mechanism is located behind it.
- ▶ Insert the Allen wrench (1) and turn the bolt to the left (2) until it is tight and the convertible top is locked securely ⇒ *fig. 51*.
- ▶ Remove the Allen wrench from the opening and cover the opening with the cap.
- ▶ Remove the wheel wrench from the convertible top storage bay.
- ▶ Close the convertible top storage bay lid.

WARNING

Make sure the convertible top is locked correctly. Otherwise the wind from driving could cause the convertible top to open. This can result in injuries and damage to the vehicle.

Step 7: Secure the fins on the body




Fig. 52 Convertible top: pressing the fins downward




Fig. 53 Interior: tightening the bolt

The following steps must be performed on both sides of the vehicle.

- ▶ Press the fin downward firmly ⇒ *fig. 52*.
- ▶ Hold the fin in this position and tighten the bolt above the seat belt -arrow- using the Allen wrench from the vehicle tool kit at the same time ⇒ *fig. 53*.

A second person should assist when securing the fins to the body. Tightening the bolts is much easier if a second person presses the fins down.

WARNING

Make sure the fins lie on the body. Otherwise the convertible top will not lock securely and it could open while driving. This can result in injuries and damage to the vehicle.

Step 8: Extend the rear window



Fig. 54 Upper storage compartment between the seat backrests: extending the rear window

- ▶ Press the Allen wrench from the vehicle tool kit firmly into the opening until it clicks into place ⇒ *fig. 54*.
- ▶ Turn the bolt counterclockwise until the rear window is extended. Press the rear window back lightly while doing this.

Note

To prevent damage to the vehicle, make sure the rear window is in the guide in the convertible top when extending the window and the fins are secured on the body.

Clear vision

Lights

Switching the headlights on/off




Fig. 55 Instrument panel: light switch (automatic head- and taillight control)

Switching on the side marker lights

- Turn the light switch to .

Switching on the headlights and high beam

- Turn the light switch to .
- Push the high beam lever forward towards the instrument panel $\Rightarrow$ page 47.

Switching off the lights

- Turn the light switch to **O**.

Switching on automatic head- and taillight control

- Turn the light switch to **AUTO** $\Rightarrow$ fig. 55.

The headlights and taillights will come on automatically when the ignition is switched on and the light switch is in the position **AUTO** (only in nighttime conditions). When switching off the ignition, the headlights will go off and only the side marker lights will remain lit.

Daytime running lights

USA models: The daytime running lights will come on automatically when the ignition is switched on and the light switch is in the position **AUTO** (only in daylight conditions).

Canada models: The daytime running lights will come on automatically when the ignition is switched on and the light switch is in the position **O**, **AUTO** (only in daylight conditions) or .

Automatic head- and taillight control

In the switch position **AUTO** the automatic head- and taillight control is activated. Light sensors are located in the inside mirror housing and constantly check the light conditions surrounding the vehicle. If ambient brightness falls below a factory set value (e.g. when driving into a tunnel), the head- and taillights including the license plate illumination are automatically turned on. When ambient brightness increases again, the external lights are turned off again $\Rightarrow$ . In the switch position **AUTO**, the low beams are turned off when the ignition is switched off. The remaining lights are turned off when the key is taken out of the ignition lock.

With automatic head- and taillight control, the high-beam function is also available, but with one restriction: If you have not switched the high beams back to low beams during automatic headlight operation (for example, after driving through a tunnel), only the low beams come on the next time automatic headlights are switched on. To use the high beams, you first have to pull the high beam lever back and then push the lever forward again.

The side marker lights and headlights can be switched on manually by turning the light switch to the desired position.

Light sensor malfunction

If there is a light sensor malfunction, the symbol  comes on in the display. For safety reasons, the low beams are turned on permanently with the switch in **AUTO**. However, you can continue to turn the lights on and off using the light switch. Have the light sensor checked as soon as possible at an authorized Audi dealer.

Coming home/leaving home function

The function is switched on when the switch is in the **AUTO** position and the function is shown as active in the driver information system.

The **coming home** function illuminates the area around the vehicle when the ignition is switched off and the driver's door is opened. The length of time the lights remain on can be set in the menu display (**Lights** > **Exterior lights** > **coming home**). ►

The **leaving home** function illuminates the area around the vehicle when unlocking it.

WARNING

- Never use daytime running lights to see where you are going. They are not bright enough and will not let you see far enough ahead for safety, especially at dusk or when it is dark. Be aware of changes in outside light conditions when you are driving and respond by switching on your low beams.
- Automatic head- and taillight control is only intended to assist the driver. This feature does not relieve the driver of his responsibility to check the headlights and to turn them on manually according to the current light and visibility conditions. For example, fog and rain cannot be detected by the light sensors. Consequently, always switch the headlights on under these weather conditions and when driving in the dark.
- Crashes can happen when you cannot see the road ahead and when you cannot be seen by other motorists.
- Always turn on the headlights so that you can see ahead and so that others can see your car from the back.
- Please observe legal regulations when using the lighting systems described.

Tips

- Always observe the specific local regulations for your area when to use your lights.
- Turn on low beams as evening approaches or in conditions of poor visibility.
- Do not attach stickers to the windshield in front of the sensors as this can disable the automatic head- and taillight control and the automatic glare-dimming of the rear-view mirror(s)*.
- If you remove the ignition from the ignition lock while the headlights are still on, a buzzer will sound as long as the driver's door is open to remind you to turn off the lights.
- In the AUTO mode, the low beams are turned off when the ignition is turned off. The remaining lights are turned off when the key is taken out of the ignition.

- In cool or damp weather conditions the headlights may fog over temporarily on the inside.
- The critical factor is the temperature difference between the interior and the exterior of the headlight lens.
- With the main beams switched on, the light-emitting area will be free of condensation after a short time, however the edges of the glass may still be fogged.
- This physical phenomenon has no effect on the life of your vehicle's lighting system.

Turn signals and high beam lever

The lever on the left side of the steering column is used to operate the turn signals and the high beam as well as the headlight flasher.



Fig. 56 Turn signal and high beam lever

The turn signal and high beam lever has the following functions:

Turn signals ① ②

- Push the lever up as far as it can go to turn on the right turn signal or down to turn on the left turn signal ⇒ fig. 56.
- Move the lever briefly until you meet resistance and release it to flash three times.
- Move the lever (up or down) until you meet resistance and hold it there to determine the flashing time for the turn signals.

High beam ③

- Push the lever forward to switch on the high beam.
- Pull the lever back towards you to switch off the high beam.

Headlight flasher ④

- Pull the lever toward the steering wheel to use the headlight flasher.

Notes on these features

- The *turn signals* only work with the ignition switched on. The indicator lights  or  in the instrument cluster $\Rightarrow$ *page 11* also blink.
- After you have turned a corner, the turn signal switches off automatically.
- The *high beam* works only when the headlights are on. The indicator light  in the instrument cluster illuminates when the high beams are on.
- The *headlight flasher* works only as long as you hold the lever - even if there are no lights turned on. The indicator light  in the instrument cluster illuminates when you use the headlight flasher.

WARNING

Do not use the high beam or headlight flasher if you know that these could blind oncoming traffic.

Emergency flasher

The emergency flasher makes other motorists aware that you or your vehicle are in an emergency situation.



Fig. 57 Center console: emergency flasher switch

- Press the switch  $\Rightarrow$ *fig. 57* to switch the emergency flasher on or off.

When the emergency flasher is on, all four turn signals blink at the same time. The turn signal indicator lights   in the instrument cluster, as well as the light in the emergency flasher switch

 blink likewise. The emergency flashers also work when the ignition is turned off.

The emergency flasher will automatically switch on if you are in an accident where the airbag has deployed.

Tips

You should switch on the emergency flasher when:

- you are the last vehicle standing in a traffic jam so that any other vehicles coming can see you, or when
- your vehicle has broken down or you are in an emergency situation, or when
- your vehicle is being towed by a tow truck or if you are towing another vehicle behind you.

Interior lights

Interior lights

The interior lights include the reading lights for the driver and the front passenger.




Fig. 58 Section from headliner: Interior lights

Activating door contact circuit

- Press the button . The LED in the button illuminates.

Deactivating door contact circuit

- Press the button . The LED in the button goes out.

Front reading lights

- Press one of the switches  to turn the right or left reading light on/off.

With the door contact circuit, the interior lights turn on as soon as you unlock the vehicle or open the doors. The interior lights are also turned on when the ignition key is removed. The lights turn off about 30 seconds after the doors are closed. When the vehicle is locked or when the ignition is turned on, the interior lights are turned off.

When a door is open, the interior lights are turned off after about 10 minutes to prevent battery draining.

The brightness of the lights is controlled automatically by a dimmer when they are switched on/off.

Instrument panel illumination

The illumination of the instruments, displays and the center console can be adjusted.



Fig. 59 Instrument panel illumination

You regulate the brightness of the instruments with the left thumbwheel  ⇒ *fig. 59*.

Ignition ON, light switch at

With the ignition switched ON, the glow of *instrument needles* can be adjusted to appear brighter or dimmer.

Ignition ON, light switch at or .

With the lights switched on, the brightness of instrument cluster (i.e. needles, gauges and displays) and center console illumination can be adjusted.

Note

The instrument cluster and center console illumination (gauges and needles) comes on when you switch on the ignition and the **vehi-**

cle headlights are off. Be aware of the following difference between models built to US or Canadian specifications:

- USA models: illumination of the instrument cluster (gauges and needles), dash and center console around the gearshift lever is controlled by a light sensor located in the instrument panel. The instrument panel illumination will automatically become dimmer as the daylight fades away and eventually will go out completely when outside light is very low. This is to remind you, the driver, to switch on the headlights before it gets too dark.
- Canada models: instrument panel illumination will stay bright regardless of the intensity of ambient light. Always be aware of changes in outside light conditions while you are driving. Respond in time to fading daylight by turning the light switch to position  (or “AUTO” if your car is equipped with this feature) to turn on your headlights.

Luggage compartment light

The light is located on the right side of the luggage compartment.

These lights come on automatically when the front lid is opened. The lights turn off automatically if the lid is left open for more than 10 minutes.

Vision

Adjusting the exterior mirrors



Fig. 60 Forward section of driver's armrest: power mirror controls

Turn the knob to the desired position:

↔ - In this position, you can adjust the driver's and front passenger's exterior mirrors by turning the knob in the desired direction.

☀ - The mirrors are heated depending on the outside temperature.

↔ - The exterior mirrors fold in*

You are well-advised to fold the exterior mirrors in when maneuvering in tight spaces or when leaving the car parked close to other vehicles.

WARNING

- Curved (i. e. convex) mirror surfaces increase your field of view. Remember that vehicles or other objects will appear smaller and farther away than when seen in a flat mirror. If you use this mirror to estimate distances of following vehicles when changing lanes, you could estimate incorrectly and cause an accident.

Note

- If the mirror housing is moved unintentionally (for example, while parking your vehicle), then you must first fold the mirror electrically. Do not readjust the mirror housing manually. You could damage the motor which controls the mirror.
- If you wash the vehicle in an automatic car wash, you must fold the exterior mirrors in to reduce the risk of damage to the mirrors. Never fold power folding exterior mirrors* by hand. Only fold them in and out using the power controls.

Tips

If there should be a malfunction in the electrical system, you can still adjust the exterior mirrors by pressing the edge of the mirror.

Dimming the mirrors




Fig. 61 Automatic dimming rearview mirror*

Manual anti-glare adjustment

- Move the small lever (located on the bottom edge of the mirror) to the rear.

Automatically dimming mirrors*

- To dim the rearview mirror and both exterior mirrors, press the **A** button. The diode **B** turns on. The rearview and exterior mirrors dim automatically when light shines on them, for example from headlights on a vehicle to the rear.

WARNING

Electrolyte fluid can leak from automatic dimming mirrors if the glass is broken. Electrolyte fluid can irritate skin, eyes and respiratory system.

- Repeated or prolonged exposure to electrolyte can cause irritation to the respiratory system, especially among people with asthma or other respiratory conditions. Get fresh air immediately by leaving the vehicle or, if that is not possible, open windows and doors all the way.
- If electrolyte gets into the eyes, flush them thoroughly with large amounts of clean water for at least 15 minutes; medical attention is recommended.
- If electrolyte contacts skin, flush affected area with clean water for at least 15 minutes and then wash affected area with soap and water; medical attention is recommended. Thoroughly wash affected clothing and shoes before reuse.

- If swallowed and person is conscious, rinse mouth with water for at least 15 minutes. Do not induce vomiting unless instructed to do so by medical professional. Get medical attention immediately.

! Note

Liquid electrolyte leaking from broken mirror glass will damage any plastic surfaces it comes in contact with. Clean up spilled electrolyte immediately with clean water and a sponge.

i Tips

- Switching off the dimming function of the inside rear view mirror also deactivates the automatic dimming function of the exterior mirrors.
- The automatic dimming mirrors do not dim when the interior lighting is turned on or the reverse gear is selected.
- Automatic dimming for the mirror only operates properly if the light striking the inside mirror is not hindered in any way.

Sun visors




Fig. 62 Sun visor

The vanity mirrors in the sun visors are equipped with covers.

Wiper and washer system

Windshield wiper

The windshield wiper lever controls both the windshield wipers and the washer system.




Fig. 63 Wiper lever: windshield wiper lever positions

The windshield wiper lever ⇒ fig. 63 has the following positions:

Intermittent wiping (activating rain sensor)*

- Move the lever up to position ①.
- Move the interval set switch **A**, to change the intervals.

Low wiper speed

- Move the lever up to position ②.

High wiper speed

- Move the lever up to position ③.

One-touch wiping

- Move the lever to position ④, when you want to wipe the windshield *briefly*.

Automatic wiper/washer

- Pull the lever to position ⑤ (toward the steering wheel) and hold.
- Release the lever. The washer stops and the wipers keep going for about four seconds.

Turning off the wipers

- Move the lever back to position ①.

The windshield wipers and washer only work when the ignition is turned on. If you switch off the ignition with the windshield wiper lever still ►

in the interval wipe position and then come back a while later and drive off, the rain sensor will re-activate itself after the vehicle speed has exceeded 4 mph (6 km/h).

The rain sensor* is only activated with the wiper lever set to position ①. When it starts to rain, the rain sensor will automatically activate the intermittent wiping mode.

To reduce the sensitivity of the sensor, move switch Ⓐ down. To increase the sensitivity, move the switch up. The higher you adjust the sensitivity, the faster the sensor will react when it senses moisture on the windshield. The pauses between wiper turns depend not only on the sensitivity setting, but on the vehicle speed as well.

During brief stops, e.g. at a red light, wiper motion will automatically be reduced to the next lower speed. Wipers already turning at low speed change to intermittent wiping.

When the ignition is turned on, the washer jets are heated.

WARNING

- Wiper blades are crucial for safe driving! Only when they are in good condition are they able to clear the windows properly to provide uncompromising visibility. Worn or damaged wiper blades are a safety hazard ⇒ *page 53, Replacing windshield wiper blades!*
- The light/rain sensor* is only designed to assist and support the driver. It remains entirely the driver's responsibility to monitor outside weather conditions and to manually activate the wipers as soon as rain or drizzle reduces visibility through the windshield.
- The windshield must not be treated with water-repellent materials. They can increase glare under poor visibility conditions such as wetness, darkness, or when the sun is low on the horizon. In addition, they can cause the windshield wipers to chatter.

Note

In freezing or near freezing conditions:

- Always check that the wiper blades are not frozen to the glass before you turn the wipers on. Loosen a wiper blade which is frozen in place before operating the wipers to prevent damage to the wiper blade or the wiper motor.
- Do not use the wipers to clear a frosted window. Using the wipers as a convenient ice scraper will destroy the wiper blades.
- Before you take your vehicle to an automatic car wash, make sure you have the windshield wiper system switched off (lever in position 0), otherwise the windshield wiper system could get damaged in the car wash if it should suddenly come on.

Tips

- The windshield wipers are switched off when the ignition is turned off. Activate the windshield wipers after the ignition is switched back on by moving the windshield wiper lever to any position.
- Worn or dirty windshield wiper blades cause smearing, which can affect the operation of the light/rain sensor*. Check the condition of your windshield wiper blades regularly.
- The rain sensor is part of the interval wiping system. Turning off the ignition will also deactivate the rain sensor. To reactivate the sensor, switch off the interval wiping function, then switch it back on again.
- Applies to vehicles with light/rain sensor: When the wipers are switched on manually and in rain conditions, the automatic headlights* turn on ⇒ *page 46, Lights* or off during the day when the wipers are no longer operating. The automatic headlights* function is available in this case only when the light switch is in the "AUTO" position ⇒ *page 46, fig. 55*.
- Make sure the washer fluid reservoir in the engine compartment is topped off before going on a long trip. Look up ⇒ *page 168* for checking and filling the washer container.
- The wipers only operate with the hood completely closed.

Service position

It is only possible to change wiper blades if you move the wiper arms to the service position.

In order to use the windshield wipers, the front lid must be completely closed.

Moving wiper blades to the service position

- ▶ When there is a risk of frost, make sure that the wiper blades are not frozen to the windshield.
- ▶ Switch the ignition on.
- ▶ Move the wiper lever to position **0** ⇒ *page 51, fig. 63*.
- ▶ Press the **RESET** button until the **Display type** menu appears in the Driver Information System display.
- ▶ Using the rocker switch and the **RESET** button, select the **Set > Wipers > Front > Service position on** function. The windshield wiper arms move to the service position.

Moving wiper blades to park position

- ▶ Make certain that the wiper arms are lying against the windshield.
- ▶ Switch the ignition on and move the wiper lever from position **0** to **4** ⇒ *page 51, fig. 63*. The wiper arms will move back to the park position.

! Note

Never drive your vehicle when the windshield wiper arms are in the service position and pulled away from the windshield. When you drive faster than 4 mph (6 km/h), the wiper arms automatically return to the park position and could cause paint damage to the front lid!

i Tips

- You can also turn on the service position, for example, if you want to protect the windshield from icing by using a cover.
- The service position moves to **off** automatically when you operate the windshield wiper lever, or speed exceeds 4 mph (6 km/h).

Cleaning windshield wiper blades

Clean the windshield wiper blades when they begin to leave streaks. Use a soft cloth and glass cleaner to clean the windshield wiper blades.

- ▶ Place the windshield wiper arms in the service position. Refer to ⇒ *page 53*.
- ▶ Lift the wiper arm away from the front window.



WARNING

Dirty windshield wiper blades can impair your view. This can lead to accidents.

Replacing windshield wiper blades

Wiper blades in good condition help keep the windshield clear.




Fig. 64 Unlatching wiper blades




Fig. 65 Removing wiper blades

Removing the wiper blade

- ▶ Move the wipers to the service position ⇒ *page 53*.
- ▶ Fold the windshield wiper arm away from the glass.
- ▶ On the upper end of the wiper arm at the corrugation, squeeze the plastic retainer together on both sides in the direction of the arrow ⇒ *fig. 64*.

- ▶ Rotate the wiper blade in the direction of the arrow **(A)** ⇒ *fig. 65* away from the wiper arm.
- ▶ Lift the wiper blade off in the direction of the arrow **(B)**.

Installing the wiper blade

- ▶ Place the rounded end of the wiper onto the end of the wiper arm in the **opposite** direction to the arrow **(B)** ⇒ *fig. 65*.
- ▶ Squeeze the corrugation on the wiper until you hear it click in the wiper arm.
- ▶ Fold the wiper arm back onto the windshield.
- ▶ Switch the ignition on and move the wiper lever down briefly ⇒ *page 51, fig. 63*. The wiper will move back to the park position.

WARNING

For your safety, you should replace the wiper blades once or twice a year. See your authorized Audi dealer for replacement blades.

Note

- The wiper blades may only be changed ⇒ *page 53* in the service position! Otherwise, you risk damaging the paint on the front lid or the windshield wiper motor.
- To help prevent damage to the wiper system, always loosen blades which are frozen to the windshield before operating wipers.
- To help prevent damage to wiper blades, do not use gasoline, kerosene, paint thinner, or other solvents on or near the wiper blades.
- To help prevent damage to the wiper arms or other components, do not attempt to move the wipers by hand.

Tips

- Commercial hot waxes applied by automatic car washes affect the cleanability of the glass surface.
- The front wiper blades are different lengths; the blade on the driver's side is longer.

Digital compass

Activating or deactivating the compass

Applies to vehicles: with digital compass




Fig. 66 Inside rearview mirror: digital compass activated

- ▶ To activate or deactivate, hold the **(A)** button down until the red display appears or disappears.

The digital compass only works with the ignition turned on. The directions are displayed as initials: **N** (North), **NE** (Northeast), **E** (East), **SE** (Southeast), **S** (South), **SW** (Southwest), **W** (West), **NW** (Northwest).

The compass has to be recalibrated if the display is wrong or inaccurate ⇒ *page 55*.

Tips

- To avoid inaccurate directions, do not allow any remote controls, electrical systems, or metal parts close to the mirror.
- The correct magnetic deflection zone must be set in order to display the directions correctly.

Setting the magnetic deflection zone

Applies to vehicles: with digital compass




Fig. 67 Magnetic deflection zone boundaries

- Hold the **(A)** button ⇒ *page 54, fig. 66* down until the number of the set magnetic deflection zone appears on the interior rear view mirror.
- Adjust the magnetic deflection zone by repeatedly pressing on the **(A)** button. The set mode automatically deactivates after a few seconds.

Calibrating the compass

Applies to vehicles: with digital compass

- Hold the **(A)** button down until the letter **C** is displayed on the interior rearview mirror.
- Drive in a circle at a speed of about 5 mph (10 km/h) until a direction is shown on the interior rearview mirror.



WARNING

The digital compass is to be used as a directional aid only. Even though you may want to look at it while you are driving, you must still pay attention to traffic, road and weather conditions as well as other possible hazards.

Seats and storage

General recommendations

Why is your seat adjustment so important?

The safety belts and the airbag system can only provide maximum protection if the front seats are correctly adjusted.

There are various ways of adjusting the front seats to provide safe and comfortable support for the driver and the front passenger. Adjust your seat properly so that:

- you can easily and quickly reach all the switches and controls in the instrument panel
- your body is properly supported thus reducing physical stress and fatigue
- the safety belts and airbag system can offer maximum protection ⇒ *page 102*.

In the following sections, you will see exactly how you can best adjust your seats.

There are special regulations and instructions for installing a child safety seat on the front passenger's seat. Always heed the information regarding child safety provided in ⇒ *page 122, Child Safety*.

WARNING

Incorrect seating position of the driver and all other passengers can result in serious personal injury.

- Always keep your feet on the floor when the vehicle is in motion — never put your feet on top of the instrument panel, out of the window or on top of the seat cushion! This applies especially to the passengers. If your seating position is incorrect you increase the risk of injury in the case of sudden braking or an accident. If the airbag inflates and the seating position is incorrect this could result in personal injury or even death.
- It is important for both the driver and front passenger to keep a distance of at least 10 inches (25 cm) between themselves and the steering wheel and/or instrument panel. If you're sitting any closer than this, the air-

bag system cannot protect you properly. In addition to this, the front seats and head restraints must be adjusted to your body height so that they can give you maximum protection.

- Always try to keep as much distance as possible between yourself and the steering wheel or instrument panel.
- Do not adjust the driver's or front passenger's seat while the vehicle is moving. Your seat may move unexpectedly, causing sudden loss of vehicle control and personal injury. If you adjust your seat while the vehicle is moving, you are out of position.

Driver's seat

The correct seat position is important for safe and relaxed driving.

We recommend that you adjust the driver's seat in the following manner:

- ▶ Adjust the seat in fore and aft direction so that you can easily push the pedals to the floor while keeping your knee slightly bent ⇒  in *Why is your seat adjustment so important? on page 56*.
- ▶ Adjust the seatback so that when you sit with your back against the seatback, you can still grasp the top of the steering wheel.
- ▶ Position the head restraint according to the occupant's height ⇒ *page 58*. For maximum protection, the top of the head restraint should be at least at eye level, preferably higher and ideally level with the top of the head ⇒ *page 89, fig. 101*.

WARNING

Never place any objects in the driver's footwell. An object could get into the pedal area and interfere with pedal function. In case of sudden braking or an accident, you would not be able to brake or accelerate!

Front passenger's seat

Always move the front passenger seat into the rearmost position.

To avoid contact with the airbag while it is deploying, do not sit any closer to the instrument panel than necessary and always wear the three-point safety belt provided adjusted correctly. We recommend that you adjust the passenger's seat in the following manner:

- ▶ Bring the backrest up to an (almost) upright position. **Do not** ride with the seat reclined.
- ▶ The ideal position for the head restraint is with the upper edge of the restraint level with the top of your head ⇒ page 58. You should *not* lower the top of the restraint below the level of your eyes.
- ▶ Place your feet on the floor in front of the passenger's seat.

Power seats

Adjustment switches

The operating logic for the switches corresponds to the construction and function of the seat.




Fig. 68 Adjustment switches: locations on driver seat

The operating logic for the switches corresponds to the construction, the design and the function of the seat. Push or pull either switch in exactly the same direction you want the corresponding part of the seat to move.

Adjustment switches

- ① Adjusting the lumbar support
- ② Adjusting seat height and fore-and-aft position
- ③ Adjusting the angle of the seatback

Power seat adjustment

The switches can be moved in various directions to allow precise adjustment.

Read and heed all warnings before you adjust your seat. ⇒ ⚠.

Adjusting the curvature of the lumbar support

- ▶ Push the forward or rear depression on the switch shell ① ⇒ page 57, fig. 68 to increase or decrease the backrest curvature.

Adjusting the height of the lumbar support

- ▶ Push the top or bottom depression on the switch shell ① to raise or lower the support in the backrest.

Moving the front seats forward or backward

- ▶ Press the switch ② forward or backward horizontally.

Adjusting the seat height

- ▶ Pull or push the switch ② evenly at both ends to raise or lower the seat.

Angling the seat cushion up and down (front)

- ▶ Pull or push the switch ② at the front only to raise or lower the seat.

Angling the seat cushion up and down (rear)

- ▶ Pull or push the switch ② at the rear only to raise or lower the seat.

Adjusting the seatback

- ▶ Push or pull the switch ③ in the same direction you want the seatback to tilt.



WARNING

- Never adjust the driver's or front passenger seat while the vehicle is moving. If you do this while the vehicle is moving, you will be out of position. Always adjust the driver's or front passenger seat when the vehicle is not moving.

- Be careful when adjusting the seat height. Check to see that no one is in the way, or serious injury could result!
- Because the seats can be electrically adjusted with the ignition key removed, never leave children unattended in the vehicle. Unsupervised use of the electric seat adjustments may cause serious injury.
- To reduce the risk of injury in the case of sudden braking or accident, front passengers must never ride in a moving vehicle with the seatback reclined. Safety belts and the airbag system offer maximum protection only when the seatback is upright and the safety belts are properly positioned on the body. The more the seatback is reclined, the greater the risk of personal injury from an incorrect seating position and improperly positioned safety belts!
- Always make sure the front seatbacks are in the upright position and securely locked in place when driving.

Head restraints

Adjusting head restraints

The head restraints must be adjusted properly to provide protection.




Fig. 69 Driver's seat head restraint: adjusting the height

The head restraints on the *front* seats can be adjusted to provide safe support to head and neck at the optimum height. When optimally adjusted, the top of the restraint should be level with the top of the head ⇒ *page 89*.

- Grasp the sides of the head restraint with both hands and slide it upward/downward until you feel it click into place ⇒ *fig. 69*.

WARNING

- Driving without head restraints or with head restraints that are not properly adjusted increases the risk of serious or fatal neck injury dramatically.
- Read and heed all WARNINGS ⇒ *page 89*, *Proper adjustment of head restraints*.

Tips

Correctly adjusted head restraints and safety belts are an extremely effective combination of safety features.

Cup holder



Fig. 70 Cup holder

WARNING

Spilled hot liquid can cause an accident and personal injury.

- Never carry any beverage containers with hot liquids, such as hot coffee or hot tea, in the vehicle while it is moving. In case of an accident, sudden braking or other vehicle movement, hot liquid could spill, causing scalding burns. Spilled hot liquid can also cause an accident and personal injury.
- Use only soft cups in the cupholder. Hard cups and glasses can cause injury in an accident.
- Never use the cupholder or adapter as an ashtray - risk of fire.

Note

Only drink containers with lids should be carried in the cupholder. Liquid could spill out

and damage your vehicle's electronic equipment or stain the upholstery, etc.

Ashtray




Fig. 71 Center console: ashtray

The ashtray is inserted in the cupholder.

Opening the ashtray

- ▶ Fold the cover upward.

Emptying the ashtray

- ▶ Lift the closed ashtray up out of the cupholder.

WARNING

Never put waste paper in the ashtray. Hot ashes or other hot objects in the ashtray could set waste paper on fire.

Cigarette lighter/socket

The cigarette lighter or socket only work with the ignition on.

Using the cigarette lighter

- ▶ Press the cigarette lighter in.
- ▶ Remove the cigarette lighter when it pops out.

Connecting an appliance

- ▶ Slide the cover open to reach the cigarette lighter.
- ▶ Remove cigarette lighter.
- ▶ Plug in appliance to be used.

The socket of the cigarette lighter may be used for 12-volt appliances with maximum consumption of up to 100 watts, such as a flash light, small vacuum cleaner, etc.

WARNING

Improper use of the cigarette lighter can cause serious injury or start a fire.

- Be careful when using the cigarette lighter. If you do not pay attention to what you are doing when you are using the cigarette lighter you can burn yourself.

Note

- To avoid damaging the socket, only use plugs that fit properly.
- Only use the cigarette lighter socket as a power source for electrical accessories for short durations. Use the sockets in the vehicle when a power source is needed for longer durations.

Tips

- When the engine is off and accessories are still plugged in and are on, the vehicle battery can still be drained.
- The vehicle battery must not be charged with a standard small charger that plugs into the cigarette lighter or outlet.

Storage

General

WARNING

- Always remove objects from the instrument panel. Any items not put away could slide around inside the vehicle while driving or when accelerating or when applying the brakes or when driving around a corner.
- When you are driving make sure that anything you may have placed in the center console or other storage locations cannot fall out into the footwells. In case of sudden braking you would not be able to brake, depress the clutch or accelerate.
- Any articles of clothing that you have hung up must not interfere with the driver's view. The coat hooks are designed only for lightweight clothing. Never hang any clothing with hard, pointed or heavy objects in the pockets on the coat hooks. During sudden

braking or in an accident - especially if the airbag is deployed - these objects could injure any passengers inside the vehicle.

Glove compartment

The glove compartment is illuminated and can be locked.



Fig. 72 Glove compartment

- ▶ To open the glove compartment, pull the handle in the direction of the arrow ⇒ *fig. 72* and swing the cover down to open.
- ▶ To close the glove compartment, push the glove compartment lid upward until the lock engages.

The glove compartment light comes on as the parking or driving lights are switched on and the compartment is opened. You will find a glasses case in the lid.

The glove compartment has a standard 12-volt socket for connecting electrical accessories. The power consumption at the outlet must not exceed 100 watts. The socket works only with the ignition switched on.

WARNING

To reduce the risk of personal injury in an accident or sudden stop, always keep the glove compartment closed while driving.

Storage compartment in the front seats

Applies to vehicles: with storage compartment in the front seats

There is a fold-out storage compartment in the front of the seats.

- ▶ To open the storage compartment, lift the handle and pull the drawer out.
- ▶ To close the storage compartment, push the drawer in completely until it latches.

Tips

The maximum carrying capacity 2.2 lbs. (1 kg).

Storage compartments between the seat backrests

The storage compartments are illuminated and can be locked with the vehicle key.



Fig. 73 Storage compartments between the seat backrests

The CD changer* or the Audi Music Interface* are located in the lower storage compartment.

- ▶ To open the upper storage compartment, fold the lid upward in the direction of the arrow ① ⇒ *fig. 73*.
- ▶ To open the lower storage compartment, fold the lid downward in the direction of the arrow ②.

WARNING

Always keep the storage compartments closed when driving to help reduce the risk of injury.

Tips

Both lids must be closed in order to lock the compartments.

Warm and cold

Climate controls

Controls

The climate controls automatically maintain the selected temperature in the vehicle interior throughout each season.



Fig. 74 Climate controls

We recommend the following setting:

- ▶ Rotate the knob ⇒ *fig. 74* ② to the right to switch on the air conditioning.
- ▶ Set the temperature to 72 °F (22 °C).
- ▶ Press the **AUTO** ⇒ *fig. 74* button.

Using the previously recommended setting is the quickest way to achieve a comfortable climate in the vehicle. This setting should therefore only be changed when personal comfort levels or certain circumstances require it.

The climate controls are a combination of automatic heating and ventilation systems and a cooling system which dehumidifies and cools the air inside the vehicle.

The climate controls automatically maintain a temperature once it has been set. The temperature of the air from the vents, fan speed (air volume) and air distribution are also automatically adjusted. The system also takes into account strong sunshine so that manual adjustment is not necessary. So in almost all cases, **automatic mode** offers the best conditions for the comfort

of the occupants at all times of the year
⇒ *page 64*.

Please note:

In cooling mode, relative humidity in the interior is reduced. This prevents the windows from fogging up.

When relative humidity and temperatures outside are high, **condensation** can drip from the air conditioning evaporator and form a pool of water under the vehicle. This is normal and not an indication of a leak!

When outside temperatures are low, the fan does not switch to a higher speed until the coolant has reached an adequate temperature, with the exception of the defrost setting.

When accelerating at wide-open throttle, the air conditioning compressor is temporarily switched off to maintain full engine power.

In order to ensure engine cooling under extreme engine loads, the compressor is switched off if coolant temperatures climb too high. ►

Functions are set by turning the rotary knob or switched on and off by tapping the buttons. The LED in the buttons illuminates when the function is active.

Button(s)	Meaning
Rotary knob ①	Temperature selection ⇒ page 62
Rotary knob ② 	Switch air conditioning on/off (Fan) ⇒ page 62
Rotary knob ③	Air distribution ⇒ page 63
	Defrost ⇒ page 63
	Rear window defogger ⇒ page 64
	Heated seat* driver/passenger side ⇒ page 64
	Recirculation ⇒ page 64
	Switch on cooling system ⇒ page 65

Pollutant filter

The pollutant filter (particle filter) ensures that contaminants in the outside air (such as dust or pollen) are greatly reduced or stopped. The air is also filtered in recirculation mode.

The pollutant filter element must be changed according to the intervals specified in the maintenance schedule so that the air conditioning system's performance is not adversely affected.

If the filter's effectiveness is weakened by driving the vehicle in areas with heavily polluted outside air, the filter element should also be changed between the listed services.

 **WARNING**

For safety reasons, it is important that all windows are free of ice, snow, and condensation. Only then is good visibility ensured. Please familiarize yourself with the correct operation of the air conditioning and how to dehumidify/defrost the windows.

 **Note**

– If you suspect that the climate controls have been damaged, switch the system off

- to avoid damaging it, and have it inspected by an authorized Audi dealer.
- Audi climate control system repairs require special expertise and the proper tools. You should contact an authorized Audi dealer in the event of malfunctions.

 **Tips**

- To avoid adversely affecting heating and cooling performance and to prevent condensation on the windows, the air intake in front of the windshield must be free of ice, snow, and leaves.
- Climate control works most effectively if the windows are closed. However, if the interior of a parked vehicle is extremely hot from the sun's rays, briefly opening the windows can speed up the cooling process.

Setting temperature

- Turn the rotary knob ① ⇒ page 61, fig. 74 to the desired temperature setting.

To set a lower temperature, turn the rotary knob to the left. To set a higher temperature, turn the rotary knob to the right. There are additional intermediate settings available to adjust the temperature as needed.

Switching climate control on/off

Switching the climate control system on/off

- Turn the knob ② ⇒ page 61, fig. 74 to the right to switch climate control on. The LED next to the word OFF goes out.
- Turn the knob ② ⇒ page 61, fig. 74 to the left to switch the climate control system off. The LED next to the word OFF comes on.

Setting fan speed

- Turn the knob ② ⇒ page 61, fig. 74 to the setting you want to adjust fan speed (air quantity).

If the difference between the desired temperature set by you and the vehicle's interior temperature is too great, the fan speed will change automatically. This is done so that the desired temperature setting is reached as quickly as possible. ►

i Tips

If the difference between the desired temperature you have set and the vehicle's interior

temperature is too high, the fan speed will change automatically. This is done so that the desired temperature setting is reached as quickly as possible.


Air distribution

Fig. 75 Instrument panel: Location of air vents

- ▶ Turn the rotary knob ③ ⇒ page 61, fig. 74 to the desired setting.
- ▶ To open and close the outlets, turn the adjusting ring.
- ▶ To adjust the direction of the airflow from the outlet, move the tab in the center of the outlet in the desired direction. The direction of the air delivered from the vents can be adjusted horizontally and vertically.

Air distribution:

- In setting , air flows only to the windows, vents ① and ② are open. To defrost the driver and front passenger side windows most effectively, the vents ② should be directed toward the side windows.
- In setting , air flows only to the driver/passenger, vents ② and ③ are open.
- In setting , air flows only to the footwell, vents ④ are open.
- In setting , air flows only to the windows and the footwell, vents ①, ② and ④ are open.

There are additional combinations (through intermediate settings) available to adjust air distribution as needed.

i Tips

If the climate controls are running in cooling mode, air should flow mainly from vents ② and ③. To achieve sufficient cooling, you should never close these vents completely.

Defrost

The windshield and side windows are defrosted or cleared of condensation as quickly as possible.

- ▶ To turn on the defogger/defroster, press the  button ⇒ page 61, fig. 74.
- ▶ To turn the defogger/defroster off, press the  button again, or the **AUTO** button.

Temperature is controlled automatically. The maximum amount of air flows mainly from vents 1 ⇒ page 63.

A small amount of air flows from vents 2 - if they are open ⇒ page 63.

Pressing the  button switches off recirculation mode.

Rear window defogger

The rear window defogger clears the rear window of condensation.

- Press the  button ⇒ *page 61, fig. 74* to turn the rear window defogger on and off.

The rear window defogger works only when the engine is running. The indicator light in the button illuminates when the rear window defogger is turned on.

The window between the cockpit and engine compartment is also cleared with the rear window.

The rear window defogger is switched off automatically after approx. 10 minutes.



For the sake of the environment

As soon as the rear window is clear, you should switch the rear window defogger off. The reduced power consumption has a beneficial effect on fuel consumption.

Heated seats

Applies to vehicles: with heated seats

The seat cushion and the seatback of the front seats can be heated electrically.

- Press the heated seats button  ⇒ *page 61, fig. 74* to set the level of heating desired.

The range of controls goes from 1 to 3. The heat setting selected is shown by LEDs above the button.



WARNING

Individuals with reduced sensitivity to pain or temperature could develop burns when using the seat heating function. To reduce the risk of injury, these individuals should not use seat heating.



Note

To avoid damage to the heating elements in the seats, do not kneel on the seats or place heavy loads on a small area of the seat.

Automatic operation

Standard operating mode at all times of the year.

Turning on automatic operation

- Set the temperature you want.
- Press the  button ⇒ *page 61, fig. 74*.

Automatic operation ensures constant temperatures in the interior and dehumidifies the air inside the vehicle. Air temperature, volume, and distribution are controlled automatically to reach or maintain the desired interior temperature as quickly as possible. Fluctuations in exterior temperature and the effects of temperature from the position of the sun are compensated for automatically.

Manual air recirculation mode

The recirculation mode prevents polluted outside air from entering the vehicle interior.

Switching on air recirculation

- Press the button  ⇒ *page 61, fig. 74*, ⇒ .

Switching off air recirculation

- Press the button  again, or
- Press the  button, or
- Press the .

In recirculation mode, air is drawn from the vehicle interior, filtered, and recirculated. We recommend that you select recirculation mode *briefly* ⇒  under the following conditions:

When driving through a tunnel or in a traffic jam so that exhaust fumes and odors cannot enter the vehicle interior.



WARNING

You should not use the recirculation mode for an extended period since no fresh air is drawn in, and with the air conditioning switched off the windows can fog up - this increases the risk of an accident!

A/C operation **Switching on A/C**

- ▶ Press the  button ⇒ *page 61, fig. 74.*

Switching A/C off

- ▶ Press the  button again.

The cooling system is switched on during A/C operation - the heating and ventilation system is controlled automatically.

 Tips

If the LED in the switch stays on after A/C operation has been switched off (= switching the A/C off), there is a fault in an air conditioning component. Please consult an authorized Audi dealer when there is an operating problem.

Using the climate controls economically

Economical use of the climate controls helps to save fuel.

When climate control is working in cooling mode, engine performance is reduced and fuel consumption is affected. To keep the time the air conditioning is on as short as possible, you should do the following:

- ▶ If you would like to save fuel, switch the air conditioning off.
- ▶ If you open the windows while driving, switch the air conditioning off.
- ▶ If the vehicle is extremely hot due to the heat of the sun, briefly open doors and windows.

**For the sake of the environment**

When you save fuel, you reduce emissions from the vehicle.

On the road

Steering

Adjusting the steering wheel column

The steering wheel position can be continuously adjusted in height and distance.




Fig. 76 Lever under the steering column

- ▶ Push the lever ⇒ *fig. 76* down ⇒ ⚠.
- ▶ Move the steering wheel to the desired position.
- ▶ Push the lever against the steering column until it locks.

There must be at least 10 inches (25 cm) between your chest and the center of the steering wheel. If you cannot sit more than 10 inches (25 cm) from the steering wheel, see if adaptive equipment is available to help you reach the pedals and increase the distance from the steering wheel.

For detailed information on how to adjust the driver's seat, see ⇒ *page 57*.

⚠ WARNING

Improper use of steering wheel adjustment and improper seating position can cause serious personal injury.

- Adjust the steering wheel column only when the vehicle is not moving to prevent loss of vehicle control.
- Adjust the driver's seat or steering wheel so that there is a minimum of 10 inches (25 cm) between your chest and the steering wheel ⇒ *page 87, fig. 100*. If you cannot maintain this minimum distance, the airbag system cannot protect you properly.

- If physical limitations prevent you from sitting 10 inches (25 cm) or more from the steering wheel, check with your authorized Audi dealer to see if adaptive equipment is available.
- If the steering wheel is aligned with your face, the supplemental driver's airbag cannot provide as much protection in an accident. Always make sure that the steering wheel is aligned with your chest.
- Always hold the steering wheel with your hands at the 9 o'clock and 3 o'clock positions to reduce the risk of personal injury if the driver's airbag deploys.
- Never hold the steering wheel at the 12 o'clock position or with your hands inside the steering wheel rim or on the steering wheel hub. Holding the steering wheel the wrong way can cause serious injuries to the hands, arms and head if the driver's airbag deploys.

Ignition lock/Ignition switch

Ignition lock

The ignition key starts or stops the engine.




Fig. 77 Ignition lock positions

Ignition off ①

In position ⇒ *fig. 77* ① both the ignition and engine are off, and the steering is locked.

To **lock the steering** after you have removed the ignition key, turn the steering wheel in either direction until you hear it lock into place. You should always lock the steering whenever you

leave your vehicle. This makes vehicle theft even more difficult ⇒ ⚠.

Ignition on ②

After switching the ignition on, the needles move all the way up and then down.

If it is difficult to turn the key after you have inserted it into the ignition lock, turn the steering wheel back and forth. This will take the load off the steering lock mechanism and you will be able to turn the key freely and start the engine.

Starting the engine ③

In this position the engine starts. While the engine is starting, the power supply to the headlights and other electrical consumers is temporarily interrupted to conserve battery power. After the engine has started, release the key and it will return to position ②.

Before the starter can be operated again the key must be turned back to position ①. The **non-repeat lock** prevents you from damaging the starter when the engine is running.

⚠ WARNING

- Never remove the key from the ignition lock while the vehicle is moving. The steering wheel will lock causing loss of control.
- If you have to leave your vehicle - even for just a minute - always remove the ignition key and take it with you. This is especially important if you are going to leave children behind in the vehicle. The children could start the engine or use other vehicle controls. Unsupervised use of vehicle controls (for example, power windows) can cause serious personal injuries.

i Tips

If the vehicle battery has been disconnected and then reconnected, then you must leave the key in position ② for about 5 seconds before you can start the engine.

Starting and stopping the engine

Starting the engine

The engine can only be started with your original Audi key.

On vehicles with S tronic*, the engine can be started in the neutral position N and in each gear (1 - 7 and R).

- ▶ Set the parking brake ⇒ ⚠.
- ▶ On vehicles with manual transmission*, fully depress the clutch pedal.
- ▶ Press and hold the brake pedal.
- ▶ Turn the ignition key to position ③ ⇒ page 66, fig. 77 - do not depress the gas pedal when starting the engine.
- ▶ Let go of the key as soon as the engine starts - the starter must not continue to run. On vehicles with S tronic, select gear position N.

A cold engine may at first be loud after it has been started. This is due to the hydraulic valves building up the oil pressure. This is normal and no need for concern.

If the engine does not start immediately, stop trying after 10 seconds and then try to restart the engine about 30 seconds later.

⚠ WARNING

- Never start or let the engine run in a confined or enclosed area. Exhaust fumes from the engine contain carbon monoxide, a colorless and odorless gas. Carbon monoxide can be fatal if inhaled.
- Never leave the engine idling unattended. An unattended vehicle with a running engine poses a danger of personal injury or theft.
- With the engine running and a gear engaged, you have to hold the vehicle with the foot brake.

! Note

- Avoid high engine speeds, fast acceleration or heavy engine loads while the engine is still cold. This could damage the engine.

- The engine cannot be started by pushing or towing the vehicle.



For the sake of the environment

To avoid unnecessary engine wear and to reduce exhaust emissions, do not let your vehicle stand and warm up. Be ready to drive off immediately after starting your vehicle.

Stopping the engine

On vehicles with S tronic*, the engine can be turned off in the neutral position N and in each gear (1 - 7 and R).

- Turn the ignition key to position ① ⇒ *page 66, fig. 77.*



WARNING

- Never turn off the engine until the vehicle has come to a complete stop.
- The brake booster and servotronic only work when the engine is running. With the ignition turned off, you have to apply more force when steering or braking. Since you cannot steer and stop normally, this can lead to accidents and serious injuries.



Note

- If the engine has been under heavy load for an extended period of time, heat builds up in the engine compartment after the engine is switched off - there is a risk of damaging the engine. Allow the engine to continue to run at idle for a short time or drive until it has cooled down before you turn it off ⇒ *page 73.*
- If the engine has been under heavy load for an extended period of time, it can become extremely hot. You should not park your vehicle over easily combustible objects or areas (e.g. grass or leaves). There is a risk of starting a fire.



Tips

After the engine has been switched off, the radiator fan can continue to run for up to 10 minutes - even with the ignition switched off. It

can also switch on again after some time if the coolant temperature rises as the result of heat buildup or if the engine compartment is heated by the sun's rays and the engine is hot.

Parking brake

Parking brake

When the parking brake is set, it prevents the vehicle from rolling away unintentionally.




Fig. 78 Center console: Parking brake set

Setting the parking brake

- Pull the parking brake lever all the way up.

Releasing the parking brake

- Pull the parking brake lever up slightly *and* press the release button at the same time ⇒ *fig. 78 - arrow -*.
- Keep the release button pressed and lower the parking brake ⇒

If you should drive off with the parking brake still set, a warning tone will sound and the following message will appear in the instrument cluster to remind you to release the parking brake:

Handbrake is applied

The parking brake warning comes on only after you have driven for longer than 3 seconds and faster than 3 mph (5 km/h).

The parking brake warning light  (USA) /  (CDN) illuminates when the parking brake is set and you switch on the ignition.

 WARNING

Always release the parking brake completely. A partially engaged brake will overheat the rear brakes, reduce their effectiveness and cause excessive wear. This could lead to brake failure and an accident.

 Note

Only after the vehicle has come to complete stop, should you firmly set the parking brake and move the gearshift lever into a gear.

Parking**Parking**

- ▶ Stop the vehicle using the brake pedal.
- ▶ Set the parking brake firmly.
- ▶ Switch off the engine.
- ▶ Move the selector lever into the P position (**automatic transmission**) or move the gearshift lever into 1st. gear (**manual transmission**)
⇒ .
- ▶ When on inclines or declines, turn the steering wheel so that the vehicle will roll into the curb if it begins to move.

 WARNING

This is how you can reduce the risk of injury when leaving your vehicle.

- Never park the vehicle where it can come in contact with dry grass, spilled fuel or any other flammable materials.
- Never allow anyone - especially small children - to remain in the vehicle when it is locked. Locked doors make it more difficult for rescuers to access the passenger compartment in the event of an emergency. Danger to life!
- Never leave children unsupervised in the vehicle. Children could release the parking brake or move the gearshift lever out of gear. The vehicle could start to roll away and cause an accident.
- No matter what the season is, the temperature in a parked vehicle can reach dangerous levels.

Starting on hills

Applies to vehicles: with hill hold assist

Hill hold assist makes it easier to start on hills.

The system is activated when the brake pedal is depressed **for a few seconds**.

After releasing the brake pedal, the brake power is held for a *brief moment* to prevent the vehicle from rolling back when starting. At this time, you can easily begin to move your vehicle.

 WARNING

- If you did not begin moving immediately after releasing the brake pedal, under certain circumstances, the vehicle would begin to roll backward. Depress the brake pedal immediately or engage the hand brake.
- Should the engine stall, depress the brake pedal immediately or engage the hand brake.
- In order to prevent the vehicle from rolling back unintentionally when starting in stop-and-go traffic, keep the brake pedal depressed for a few seconds before driving off.

 Tips

You can find out if your vehicle is equipped with “Hill hold assist” at an authorized Audi dealership.

Speed warning system**Speed warning system**

The speed warning system helps you to keep your driving speed below a set speed limit.

The speed warning system warns the driver if he exceeds a previously stored maximum speed. A warning tone will sound as soon as the vehicle speed exceeds the set speed by about 3 mph (3 km/h). At the same time, a warning symbol appears in the display.

The speed warning system has **two warning thresholds** that function independently of each other and that have somewhat different purposes:

Speed warning 1 (Canada models)

You can use speed warning 1 to set the maximum speed while you are driving. This setting will remain in effect until you turn off the ignition, assuming that you have not changed or reset the setting.

The speed warning symbol   (Canada models) in the warning 1 display appears when you exceed the maximum speed. It goes out when the speed falls below the stored maximum speed.

The speed warning symbol will also go out if the speed *exceeds* the stored maximum speed by more than about 25 mph (40 km/h) for at least 10 seconds. The stored maximum speed is deleted.

Setting speed warning 1 ⇒ *page 70*.

Speed warning 2 (Canada models)

Storing warning 2 is recommended if you *always* want to be reminded of a certain speed, for example when you are traveling in a country that has a general maximum speed limit, or if you do not want to exceed a specified speed for winter tires.

The speed warning 2 symbol,   (Canada models) appears in the display when you exceed the stored speed limit. Unlike warning 1, it will not go out until the vehicle speed drops below the stored speed limit.

Setting speed warning 2 ⇒ *page 70*.

Tips

Even though your vehicle is equipped with a speed warning system, you should still watch the speedometer to make sure you are not driving faster than the speed limit.

Speed warning 1: setting a speed limit

Warning threshold 1 is set by the button.



Fig. 79 Section of instrument cluster: Set/Check button

Storing the maximum speed

- ▶ Drive at the desired maximum speed.
- ▶ Press the knob button ⇒ *fig. 79* until the symbol appears.

Resetting the maximum speed

- ▶ Drive the vehicle at a speed of at least 3 mph (5 km/h)
- ▶ Press the knob for more than 2 seconds.

The speed warning symbol  (USA models) /  (Canada models) will appear briefly in the display when you release the button to indicate that the maximum speed has been stored successfully. The maximum speed remains stored until it is changed by pressing the button again briefly or until it is deleted by a lengthy push on the button.

Speed warning 2: setting a speed limit

Switches in the wiper arm are used to operate warning threshold 2.



Fig. 80 Controls

To store maximum speed

- ▶ Turn off the ignition.
- ▶ Briefly press the button in the instrument cluster ⇒ *page 70, fig. 79*. The odometer and the digital clock are now illuminated.
- ▶ Press the button for at least 2 seconds. The currently stored maximum speed appears in the display **or** the crossed out symbol for warning threshold 2, if no maximum speed was set previously.
- ▶ Press the function selector switch in the wiper lever **(A)** ⇒ *fig. 80* up or down to change the set value. Values run up or down in steps of 6 mph (10 km/h).

To delete maximum speed

- ▶ Turn off the ignition.
- ▶ Briefly press the button in the instrument cluster ⇒ *page 70, fig. 79*. The odometer and the digital clock are now illuminated.
- ▶ Press the button for at least 2 seconds. The currently stored maximum speed appears in the display.
- ▶ Press the **RESET** button in the wiper lever **(B)** ⇒ *fig. 80* until the crossed out speed warning symbol for warning threshold 2 appears in the display.

A few seconds after the adjustment is completed, the illumination for the odometer and the digital clock will go out.

i Tips

This warning threshold can also be controlled through the trip computer ⇒ *page 23, Navigating the menu*.

Cruise control

Switching the system on

The cruise control system makes it possible to drive at a constant speed starting at 20 mph (30 km/h).




Fig. 81 Control lever with set button

- ▶ Pull the lever to position **(1)** ⇒ *fig. 81* to switch the system on.
- ▶ Drive at the speed you wish to set.
- ▶ Press button **(A)** to set that speed.

The display may vary depending on the type of display in your vehicle. The indicator light **CRUISE** (US model) /  (Canadian model) will also light up in the instrument cluster.



WARNING

- Always pay attention to traffic even when the cruise control is switched on. You are always responsible for your speed and the distance between your vehicle and other vehicles.
- For safety reasons, the cruise control should not be used in the city, in stop-and-go traffic, on twisting roads and when road conditions are poor (such as ice, fog, gravel, heavy rain and hydroplaning) - risk of accident.
- Turn off the cruise control temporarily when entering turn lanes, highway exit lanes or in construction zones.
- Please note that inadvertently “resting” your foot on the accelerator pedal causes the cruise control not to brake. This is because the cruise control is overridden by the driver's acceleration.

Tips

- Vehicles with manual transmission: You can attain the set speed only if the currently engaged gear allows it and the engine is not stressed. Shifting to a higher or lower gear promptly will allow the engine to run smoothly.
- The cruise control cannot maintain a constant speed when driving downhill. The vehicle will accelerate under its own weight. Downshift to a lower gear or use the brakes to slow down.

Changing speed

- ▶ Press lever in the  or  direction ⇒ *page 71, fig. 81* to increase or decrease your speed.
- ▶ Release the lever to save that speed.

You can also press the accelerator pedal down to increase your speed, e.g. if you want to pass someone. The speed you saved earlier will resume as soon as you release the accelerator pedal.

If, however, you exceed your saved speed by 5 mph (10 km/h) for longer than 5 minutes, the cruise control will turn off temporarily. The symbol will go out but the saved speed will be retained.

Presetting your speed

You can preset your desired speed while the vehicle is not moving.

- ▶ Turn on the ignition.
- ▶ Pull lever into position  ⇒ *page 71, fig. 81*.
- ▶ Press the lever in the  or  direction to increase or decrease your speed.
- ▶ Release the lever to save that speed.

This function makes it possible, for example, to save the speed you want before driving on the highway. Once on the highway, activate the cruise control by pulling the lever toward .

Switching the system off

Temporary deactivation

- ▶ Press the brake pedal, or
- ▶ Keep the clutch pedal pressed down longer, or
- ▶ Press the lever into position  (not clicked into place) ⇒ *page 71, fig. 81*, or
- ▶ Drive for longer than 5 minutes at more than 5 mph (10 km/h) above the stored speed.

Switching off completely

- ▶ Press lever into position  (clicked into place), or
- ▶ Switch the ignition off.

The system retains the saved speed if you deactivate the cruise control temporarily. To resume the saved speed, release the brake or clutch pedal and pull the lever to position .

Switching the ignition off erases the saved speed.

WARNING

You should only return to the saved speed if it is not too fast for the current traffic conditions - risk of an accident!

Audi magnetic ride

Damping can be adjusted to the driver's preference and it adapts automatically to the current driving situation.



Fig. 82 Center console: Switch for Audi magnetic ride

- ▶ To turn sport setting on/off, press the switch ⇒ *fig. 82*.

Audi magnetic ride is an electronically controlled damping system. This chassis system assists the driver by adapting to the particular situation

through imperceptible control processes. The damping provides individual modulation of damping forces. For example, with damping characteristics set to provide greater comfort, damping is set somewhat harder for a brief period only as required, when rounding a curve and when braking.

Standard setting

Select the standard setting if you prefer a suspension setting emphasizing comfort.

Sport setting

Select the sport setting if you prefer a sporty suspension setting. The LED in the button  comes on to indicate sport setting.

Tips

The warning/indicator light  in the instrument cluster comes on in the event of a malfunction. Drive to the closest authorized Audi dealer as soon as possible and have the malfunction repaired.

Sporty driving

Warming up and cooling down

By carefully warming up and cooling down your vehicle, you can help ensure that it is not overstressed unnecessarily during sporty driving.

When warming up, the vehicle is driven at a maximum engine speed of 6000 RPM (V10 engine) or 7000 RPM (V8 engine) in order to raise the engine oil temperature to a minimum of 140 °F (60 °C). The tires also only reach their full road holding capability once they have warmed up.

The cooling fan can continue to run in your vehicle after the engine is switched off. However, driving the vehicle to cool it down is particularly important. During sporty driving, the engine and brakes, the exhaust system, and the transmission all become extremely hot. Before you park the vehicle, you should drive it for a few miles/kilometers at light load in the low rpm range to allow it to cool down.

Driving on a track

Before you take your vehicle out on a track, ensure that it is in perfect condition. For example, you should check the tire tread and the brake pads. It is best to increase tire pressure by about 0.3 bar.

When driving on a track, oil consumption may be somewhat higher than in “normal” operation
⇒ *page 159*.

You should definitely inspect your vehicle after subjecting it to severe conditions. Are the brake pads OK? Is there anything unusual about the tires, including the inner and outer sidewalls (e.g. tread, blistering)? Are the air intakes free of leaves and tire dust? Is the oil level OK?

Your authorized Audi dealer or qualified workshop will be happy to undertake an inspection before and after use on the race track.



WARNING

Some race tracks (e.g. steeply banked turns) may affect the response of the ESC.



Tips

- Review the track requirements and conditions before you start driving.
- When driven on a race track, all vehicle parts are severely stressed. This can result in increased wear.

Transmission

Manual transmission

Gearshift lever

Applies to vehicles: with manual transmission

The clutch pedal must be depressed all the way before you can start the engine.

The manual transmission in your Audi is equipped with an *interlock-feature*.

- ▶ Depress the clutch pedal all the way.
- ▶ Start the engine with the gearshift lever in Neutral and the clutch pedal depressed.

! Note

Always depress the clutch pedal fully when changing gears. Do not hold the vehicle on a hill with the clutch pedal partially depressed. This may cause premature clutch wear or damage.

i Tips

- Resting your hand on the gearshift lever knob while driving will cause premature wear in the transmission.
- The back-up lights go on when you shift into Reverse with the ignition on.

Gearshift pattern (6-speed manual transmission)

Applies to vehicles: with 6-speed manual transmission



Fig. 83 Gearshift pattern: 6-speed manual transmission

Drive in 6th gear for optimum fuel economy when cruising. However, if more acceleration is required (when passing, for example), shift down.

Engaging reverse gear (R)

- ▶ Move the shift lever all the way to the left, press it down, then push it backward.

Especially after driving forward, stop the vehicle completely, shift into *Neutral* and rest the shift lever briefly in Neutral before shifting into *Reverse*.

Launch Control Program

Applies to vehicles: with V10 engine and manual transmission

The Launch Control Program enables maximum acceleration.

Requirement: The engine must be at operating temperature and the steering wheel must not be turned.

- ▶ With the engine running, press the button  one time. The ESC indicator light  in the Driver Information System display illuminates and the message **ESC sport - Warning! Restricted stability** appears.
- ▶ Press the clutch and hold it down.
- ▶ Engage the first gear.
- ▶ Press the accelerator pedal all the way down until the engine speed remains steady at 6500 RPM.
- ▶ Release the clutch carefully ⇒ .

! WARNING

- Always adapt your driving to the traffic flow.
- Only use Launch Control when road and traffic conditions allow it and other drivers will not be endangered or annoyed by your driving and the vehicle's acceleration.
- Please note that the driving wheels can spin and the vehicle can break away when ESC is switched off, especially when the road is slippery.
- Once you have accelerated, you should switch the ESC back on by pressing the button .

i Tips

- When accelerating using the Launch Control program, all vehicle parts are subject to

heavy loads. This can result in increased wear.

- The Launch Control Program only functions when the parking brake is released and the vehicle speed is less than 3 mph (5 km/h).

S tronic

Description

Applies to vehicles: with S tronic




Fig. 84 Shift pattern



Fig. 85 Display: selected gears

Your vehicle is equipped with an electronically-controlled manual transmission called S tronic. Two independent clutches transfer the power between the engine and transmission. They replace the torque converter used in conventional automatic transmissions and allow the vehicle to accelerate without a noticeable interruption in traction.

The selected mode of operation, the gear engaged and the sport function are shown in the Driver Information System display ⇒ fig. 85.

M - Manual operation

In this operating mode, you shift the forward gears using the selector lever ⇒ page 76 or the

shift paddles on the multifunction steering wheel ⇒ page 78.

A - Automatic operation

In this operating mode, the forward gears are shifted up or down depending on engine load and vehicle speed ⇒ page 77.

R - Reverse

Only shift into reverse gear when the vehicle is *stationary* and the engine is running at idle speed ⇒ ⚠.

To engage reverse gear, you have to press the brake pedal, move the selector lever to the right and tip it towards R. In reverse gear, the backup lights illuminate when the ignition is on.

N - Neutral

To engage neutral, you have to move the selector lever to the left or to the right. If reverse gear is engaged, move the selector lever to the left. If a forward gear is engaged, move the selector lever to the right.

Sport function

The sport function is switched on by pressing the **SPORT** button on the selector lever cover. Upshifting at a higher RPM makes full use of the engine's power. Shift time is decreased and accelerator pedal response is improved. In addition, in manual operation the engine does **not** shift automatically into the next gear before it has reached the maximum permissible engine speed. In automatic operation, upshifting continues automatically.

P - Automatic parking lock

The automatic parking lock is engaged immediately after you remove the key. The automatic parking lock is also engaged if you turn off the engine while in the A, R, or manual mode positions.

If you turn off the engine while in the N position and leave the vehicle key in the ignition, the transmission remains in the N position for approximately 20 minutes and then activates the automatic parking lock. If vehicle movement is detected within that 20 minutes based on

rotation of the wheels, then the time will increase accordingly.

WARNING

- If a gear is engaged when the vehicle is stationary, the accelerator must not be pressed inadvertently under any circumstances. Otherwise the vehicle will immediately start to move - sometimes even if the parking brake is firmly applied.
- Before you or other persons open the engine compartment lid and work on a running engine, select neutral position N and firmly apply the handbrake. Always read and follow the applicable warnings ⇒ *page 155, Working in the engine compartment.*

Tips

- If you accidentally shifted into N while driving, you can engage a gear in the normal way using the selector lever.
- An indicator light is displayed if a malfunction occurs while in S tronic. Refer to ⇒ *page 78.*

Manual mode

Applies to vehicles: with S tronic

S tronic allows the driver to shift gears manually.

Starting from a stop

- ▶ Press and hold the brake pedal.
- ▶ Move the selector lever to the left.
- ▶ Tap the selector lever forward .
- ▶ Release the brake pedal and press the accelerator pedal ⇒ .

Shifting

- ▶ To shift up, tap the selector lever forward .
- ▶ To shift down, tap the selector lever to the rear .

Stopping temporarily

- ▶ Press the brake pedal to prevent the vehicle from moving, for example at traffic lights.

Parking

- ▶ Press and hold the brake pedal ⇒ .

- ▶ Activate the parking brake.
- ▶ Turn off the ignition and remove the key.

Stopping on an incline

- ▶ *Always* keep the vehicle stationary using the foot brake to prevent it from “rolling back” ⇒ . Do **not** try to prevent the vehicle from “rolling back” when a gear is engaged by increasing engine speed.
- ▶ Activate the parking brake.

Starting on a hill

- ▶ With a gear engaged, remove your foot from the brake, accelerate and slowly release the parking brake.

When accelerating, S tronic shifts into the next gear in gears 1, 2, 3, 4, 5 and 6 shortly before the maximum permissible engine speed is reached.

If you have selected a lower gear than the current one, S tronic will shift down only when the engine will not be over-revved.

You can switch to automatic operation at any time ⇒ *page 77.*

WARNING

- Never leave your vehicle with the engine running while in gear. If you must leave your vehicle with the engine running, set the parking brake firmly and engage neutral N.
- With the engine running and a gear engaged, you have to hold the vehicle with the foot brake.
- Do not accelerate when you shift gears with the vehicle stationary and the engine running.
- Before driving down a steep slope, reduce your speed and shift into a lower gear with S tronic.
- Do not ride the brakes or press the brake pedal too often or too long. Constant braking causes the brakes to overheat and substantially reduces braking performance, increases braking distance or causes complete failure of the brake system.

Note

If you must stop on an incline, always hold the vehicle in place with the foot brake to prevent it from rolling back. Do not try to prevent the vehicle from rolling back when the gear is engaged by increasing speed, as this may damage the clutch.

Automatic mode

Applies to vehicles: with S tronic

Starting from a stop

- ▶ Press and hold the brake pedal.
- ▶ Tap the selector lever towards A.
- ▶ Release the brake pedal and press the accelerator pedal ⇒  in *Manual mode on page 76*.

Under certain circumstances (driving in the mountains for example), it can be beneficial to switch temporarily to the manual shift program ⇒ *page 76* in order to adjust the gear ratios to driving conditions *manually*.

Kick-down

Applies to vehicles: with S tronic

When you depress the accelerator pedal beyond the resistance point, S tronic downshifts into a lower gear, depending on vehicle speed and engine rpm. It shifts up into the next higher gear once the maximum specified engine RPM is reached. Exception: you have activated the sport function.

WARNING

Please note that the wheels could spin on slick or slippery roads when kick-down is active.

Launch control program

Applies to vehicles: with S tronic

The Launch Control Program enables maximum acceleration.

Requirement: The engine must be at operating temperature and the steering wheel must not be turned.

- ▶ With the engine running, press the / **ESC OFF**¹⁾ button one time. The  indicator light and the message **ESC Sport - Caution! Limited stability!** appears in the driver information system display.
- ▶ Press the brake pedal with your left foot and hold it down.
- ▶ Engage a gear.
- ▶ Press the **SPORT** button on the selector lever cover.
- ▶ Press the accelerator pedal at the same time with your right foot until the engine has reached a constant speed.
- ▶ Remove your left foot from the brake ⇒ .

WARNING

- Always adapt your driving to the traffic flow.
- Only use the Launch control program when road and traffic conditions allow it and other drivers will not be endangered or bothered by your driving and the vehicle's acceleration.
- Please note that the driving wheels can spin and the vehicle can break away when ESC is switched off, especially when the road is slippery.
- Once you have accelerated, you should switch the ESC back on by pressing the  button.

Tips

- The transmission temperature may increase significantly after using the Launch Control Program. If that happens, the program may not be available for a few minutes. It will be available again after a cool-down period.

¹⁾ Market-specific

- When accelerating using the Launch Control program, all vehicle parts are subject to heavy loads. This can result in increased wear.

Steering wheel with shift paddles

Applies to vehicles: with S tronic

The shift paddles allow you to select gears manually on the steering wheel.



Fig. 86 Steering wheel: shift paddles

- To downshift, press the paddle on the left (-).
- To upshift, press the paddle on the right (+).

You can continue to use the manual shift program with the selector lever in the center console.

Transmission malfunction

Applies to vehicles: with S tronic

Transmission: please press the brake pedal and select the position again

Press the brake pedal and select the desired selector lever position again. You can then continue driving.

Transmission too hot: please modify driving style

The transmission temperature has increased significantly due to the sporty driving manner. Drive in a less sporty manner until the temperature returns to the normal range and the indicator light switches off.

Transmission: System malfunction! You may continue driving

There is a system malfunction in the transmission. You may continue driving. Drive to your au-

thorized Audi dealer or qualified repair facility soon to have the malfunction corrected.

Transmission: System malfunction ! You may continue driving in A until you turn the engine off.

There is a system malfunction in the transmission. The transmission is switching to emergency mode. Drive to your authorized Audi dealer or qualified repair facility immediately to have the malfunction corrected.

Transmission: System malfunction ! Driving ability is restricted

There is a system malfunction in the transmission. The transmission is switching to emergency mode. This mode only shifts into certain gears or will no longer shift at all. The engine may stall. Drive to your authorized Audi dealer or qualified repair facility immediately to have the malfunction corrected.

Transmission: System malfunction ! Driving ability is restricted. No reverse gear

There is a system malfunction in the transmission. The transmission is switching to emergency mode. This mode only shifts into certain gears or will no longer shift at all. The engine may stall. You cannot engage the reverse gear. Drive to your authorized Audi dealer or qualified repair facility immediately to have the malfunction corrected.

Risk of rolling! P not possible. Please set the parking brake

- The parking lock was released using the emergency release ⇒ *page 79*. Or
- The parking lock can no longer be engaged. Drive to your authorized Audi dealer or qualified repair facility immediately to have the malfunction corrected.

Transmission: System malfunction ! Stop the vehicle

Do not continue driving. Turn off the ignition and contact your nearest authorized Audi dealer for assistance.

There is a serious system malfunction. Continuing to drive could result in subsequent damage. ►

Note

If S tronic has switched to emergency operation mode, you should have the malfunction corrected as soon as possible.

Parking lock emergency release

Applies to vehicles: with S tronic

The parking lock must be released using the emergency release before towing the vehicle.




Fig. 87 Engine compartment: emergency release




Fig. 88 Engine compartment: parking lock emergency release

The emergency release is located in the engine compartment.

Releasing the parking lock using the emergency release

- ▶ Turn the engine off.
- ▶ Set the parking brake to prevent the vehicle from rolling unintentionally.
- ▶ Remove the removable plastic key from the luggage compartment and extend the key to its full length.
- ▶ Remove the cover over the emergency release mechanism.

- ▶ Insert the plastic key into the emergency release mechanism and turn it all the way to the right ⇒ *fig. 88*.

Resetting the parking lock

- ▶ Turn the key all the way to the left.
- ▶ Install the cover.

The  indicator light appears in the instrument cluster if the parking lock was released from P using the emergency release. The message **Risk of rolling! P not possible. Please set the parking brake** also appears.

WARNING

- Only activate the emergency release while on a level surface or a slight slope.
- If you release the parking lock using the emergency release, secure your vehicle with the parking brake. The vehicle can roll away if it is not secured and cause a crash.

Tips

The transmission cannot detect if the parking lock was released with the emergency release. An error message appears in the instrument cluster as soon as the transmission requires the P position but this position is not engaged.

Parking system

Parking system advanced

Introduction

Applies to vehicles: with parking system advanced




Fig. 89 Parking mode 1: Reverse parking




Fig. 90 Parking mode 2: Parallel parking

Vehicles with the parking system are equipped with a **rear view camera** in addition to the acoustic and visual parking system.

You can choose between two modes to help you when parking your vehicle. Use “parking mode 1” when parking in a parking space or garage ⇒ *fig. 89*. If you are going to be parallel parking, use “parking mode 2” ⇒ *fig. 90*.

General Information

Applies to vehicles: with parking system advanced




Fig. 91 View from top: Rearview camera coverage area




Fig. 92 Side view: Rearview camera coverage area

Sensors in the bumper

Sensors are located in the front and rear bumpers. If these detect an obstacle, audible and visual signals warn you. The range at which the sensors begin to measure is approximately:

front	side	3 ft (0.90 m)
	center	4 ft (1.20 m)
rear	side	2 ft (0.60 m)
	center	5.2 ft (1.60 m)

The closer you get to the obstacle, the shorter the interval between the audible signals. A continuous tone sounds when the obstacle is less than approximately 1 foot (0.30 meters) away. Do not continue driving farther.

If the distance to an obstacle remains constant, the volume of the distance warning gradually drops after about four seconds (this does not apply in the continuous tone range).

Rear view camera coverage area

The rearview camera shows you the area behind your vehicle in the navigation system display. This ►

area roughly corresponds to the area in $\Rightarrow$ *fig. 91* and ① $\Rightarrow$ *fig. 92*. Orientation lines and colored surfaces are projected in the area shown, which can help you with parking and maneuvering. Objects that are located in an area that is not captured by the camera ② $\Rightarrow$ *fig. 92* and that are closer to the bumper will not appear on the navigation system display.

We recommend that you practice parking with the rearview camera in a traffic-free location or parking lot to become familiar with the system, the orientation lines, and their function. There should be sufficient light and good weather conditions when doing so.

In the navigation system display, objects or vehicles appear closer or further away if:

Objects or vehicles appear closer or farther away in the navigation system if:

- you are driving in reverse gear from a level surface onto an incline, or a downward slope,
- you are driving in reverse gear toward protruding objects.

The accuracy of the orientation lines and blue surfaces diminishes if:

- the rearview camera does not provide a reliable image, for example, in poor visibility conditions or if the lens is dirty,
- the image on the screen is not visible due to sun glare and reflection.

Caring for the rearview camera lens

The rearview camera is located in the center of the vehicle above the rear license plate bracket. In order for the rearview camera to function properly, the camera lens must be kept clean and free of snow and ice.

- Dampen the lens with a household alcohol-based glass cleaner, and clean the lens with a dry cloth.
- Remove snow with a hand brush and ice preferably with a de-icing spray $\Rightarrow$!.

ble for parking and similar driving maneuvers.

- Sensors have blind spots in which objects cannot be detected. Pay special attention to small children and animals because the sensors cannot always detect them.
- Always keep your eyes on the vehicle's surroundings, using the rearview mirror as well.
- Do not allow yourself to be distracted from traffic by the rearview camera pictures in the navigation system display.
- If the position and the installation angle of the camera has changed, for example, after a rear end collision, do not continue to use the system for safety reasons. Have it checked by an authorized Audi dealer or other qualified workshop.

! Note

- Low obstacles already signaled by a warning can disappear from the system's detection range as they are approached and will not continue to be signaled. Objects such as barrier chains, trailer draw bars, narrow painted vertical poles or fences may not be detected by the system, posing risk of damage.
- Never use warm or hot water to remove snow or ice from the rearview camera lens because the lens could crack.
- Never use products that are abrasive when cleaning the lens.

! WARNING

- The parking system cannot replace the driver's attention. The driver alone is responsi-

Switching on/off

Applies to vehicles: with parking system advanced



Fig. 93 Section of the center console: Park assist switch



Fig. 94 Navigation system display: visual distance display

Switching on

- ▶ Switch the navigation system and the navigation system display on.
- ▶ Engage the reverse gear, or
- ▶ Press the  switch in the center console ⇒ *fig. 93*. A short confirmation tone sounds and the indicator light in the switch lights up.

Switching between the rear view camera and visual display

- ▶ Press the **Graphic** control button ⇒ *page 83*, *fig. 95* to see the visual display.
- ▶ Press the **Rear view** control button to see the rear view camera image ⇒ *fig. 94*.

Switching off

- ▶ Drive faster than 6 mph (10 km/h), or
- ▶ Press the  switch, or
- ▶ Switch off the ignition.

Segments in the visual display

The red segments in front of and behind the vehicle ⇒ *fig. 94* help you to determine the distance between you and an obstacle. As your vehicle

comes closer to the obstacle, the segments move closer to the vehicle. The collision area has been reached when the next to last segment is displayed. Do not continue driving farther ⇒  in *General Information on page 81!*



WARNING

- The navigation system display cannot show, or cannot adequately show, certain objects (such as small posts or grating), recesses in the ground and protruding parts on another car.
- Only use the rearview camera to assist you if it shows a good, clear picture. For example, the image may be affected by the sun shining into the lens, dirt on the lens or if there is a defect.



Tips

- The sensors must be kept clean and free of snow and ice for the park assist to operate.
- You can change the volume and pitch of the signals ⇒ *page 85*.
- What appears in the display is time-delayed.

Reverse parking

Applies to vehicles: with parking system advanced

Parking mode 1 can be used when parking in a garage or into a parking space.




Fig. 95 Navigation system display: Aiming at a parking spot




Fig. 96 Navigation system display: Aligning the vehicle

- ▶ Switch the navigation system and the display of the navigation system on.
- ▶ Select the reverse gear.
- ▶ Turn the steering wheel until the orange orientation lines (1) appear in the parking spot ⇒ *fig. 95*. Use the markings (2) to help you estimate the distance from an obstacle. Each marking represents 3 ft. (1 m). The blue area represents an extension of the vehicle's outline by approximately 16 ft. (5 m) to the rear.
- ▶ While driving in reverse gear, adjust the steering wheel angle to fit the parking spot with the aid of the orange orientation lines ⇒ (1), (2). (3) marks the rear bumper. Stop the vehicle once the red orientation line (4) touches an object ⇒ (4).

WARNING

- The rearview camera does not show the entire area behind the vehicle ⇒ *page 80*,

fig. 92. Watch out especially for small children and animals. The rear view camera cannot always detect them, posing risk of an accident!

- Please note that objects not touching the ground can appear to be farther away than they really are (for example, the bumper of a vehicle or the rear of a truck). In this case, you should not use the orientation lines to help with parking, which poses danger of an accident!

Note

In the navigation system display, the direction of travel of the vehicle rear is represented depending on the steering wheel angle. The vehicle front swings out more than the vehicle rear. Maintain plenty of distance so that your outside mirror or a corner of your vehicle does not collide with any obstacles. This can damage to your vehicle.

Parallel parking

Applies to vehicles: with parking system advanced

Use parking mode 2 to help you parallel park along the side of a street.




Fig. 97 Navigation system display: Blue surface aligned with parking spot




Fig. 98 Navigation system display: The blue curved line contacting the curb

The following steps apply only when there is no obstacle such as a wall near the parking spot. Otherwise, please read the information provided in the "Parking Next to Obstacles" section.

- ▶ Activate the turn signal.
- ▶ Position your vehicle parallel to the edge of the street, approximately 3 ft. (1 m) from a parked vehicle.
- ▶ Switch the navigation system and the navigation system display on.
- ▶ Select reverse gear. The parking aid turns on and parking mode 1 appears on the display.
- ▶ Press the control button 1 on the navigation system ⇒ fig. 97. Parking mode 2 appears.
- ▶ Back up and align your vehicle so the blue area (2) borders on the rear end of the vehicle or on the parking spot line. The blue area represents an extension of the vehicle's outline by approximately 16 ft (5 meters) to the rear. The long

side of the blue area should be on the curb. The entire blue area must fit into the parking spot.

- ▶ With the vehicle stopped, turn the steering wheel to the right as far as it will go.
- ▶ Back into the parking spot until the blue curve touches the curb ⇒ fig. 98. Stop the vehicle.
- ▶ With the vehicle stopped, turn the steering wheel to the left as far as it will go.
- ▶ Continue to back into the parking spot until the vehicle is parked parallel to the curb. (3) marks the rear bumper. Stop the vehicle when the red orientation line (4) borders an object ⇒ ⚠. Keep an eye on the front of your vehicle while doing this ⇒ ⚠.

Parking next to obstacles

When there is an obstacle (such as a wall) next to the parking spot, choose a spot with more space on the sides. Position the long side of the blue area so that there is sufficient space from the curb. The area must not be on the curb. You will also need to start turning the steering wheel much earlier. There should be a sufficient amount of space between the curb and the blue curve, and the blue curve ⇒ fig. 98 must **not** touch the curb.

⚠ WARNING

- The rearview camera does not show the entire area behind the vehicle ⇒ page 80, fig. 92. Watch out especially for small children and animals. The rear view camera cannot always detect them, posing risk of an accident!
- Please note that objects not touching the ground can appear to be farther away than they really are (for example, the bumper of a vehicle or the rear of a truck). In this case, you should not use the orientation lines to help with parking, which poses danger of an accident!

⚠ Note

In the navigation system display, the direction of travel of the vehicle rear is represented depending on the steering wheel angle. The vehicle front swings out more than the vehicle rear. Maintain plenty of distance so that your

outside mirror or a corner of your vehicle does not collide with any obstacles. This can damage to your vehicle.

Tips

The left or right orientation lines and surfaces will be displayed, depending on the turn signal being used.

Tips

If an error has occurred before the ignition is turned off, the LED in the  switch will blink the next time the ignition is switched on, reverse gear selected, and the acoustic parking system is activated.

Adjusting the warning tones

Applies to vehicles: with parking system advanced



Fig. 99 Navigation system display: adjusting the parking system

Requirement: The parking system must be switched on.

- Press the Settings control button.
- **Front volume** - front sensor volume
- **Front frequency** - front sensor frequency
- **Rear volume** - rear sensor volume
- **Rear frequency** - rear sensor frequency

The newly adjusted value is briefly heard from the signal generator.

Tips

Changed settings are activated when parking system is switched on again.

Error messages

Applies to vehicles: with parking system advanced

There is an error in the system if the LED on the  switch is blinking and you hear a continuous alarm for a few seconds after switching on the parking system or when the parking system is already activated. Have your authorized Audi dealer correct the error.

Driving Safely

General notes

Safe driving habits

Please remember - safety first!

This chapter contains important information, tips, instructions and warnings that you need to read and observe for your own safety, the safety of your passengers and others. We have summarized here what you need to know about safety belts, airbags, child restraints as well as child safety. Your safety is for us *priority number 1*. Always observe the information and warnings in this section - for your own safety as well as for that of your passengers.

The information in this section applies to all model versions of your vehicle. Some of the features described in this section may be standard equipment on some models, or may be optional equipment on others. If you are not sure, ask your authorized Audi dealer.

WARNING

- Make certain that you follow the instructions and heed the WARNINGS in this Manual. It is in your interest and in the interest of your passengers.
- Always keep the complete owner's literature in your Audi when you lend or sell your vehicle so that this important information will always be available to the driver and passengers.
- Always keep the owner's literature handy so that you can find it easily if you have questions.

Safety equipment

The safety features are part of the occupant restraint system and work together to help reduce the risk of injury in a wide variety of accident situations.

Your safety and the safety of your passengers should not be left to chance. Advances in technology have made a variety of features available to help reduce the risk of injury in an accident.

The following is a listing of just a few of the safety features in your Audi:

- sophisticated safety belts for driver and all passenger seating positions,
- safety belt pretensioners,
- front airbags,
- knee airbags,
- side airbags in the seats
- adjustable head restraints,
- adjustable steering column.

These individual safety features can work together as a system to help protect you and your passengers in a wide range of accidents. These features cannot work as a system if they are not always properly adjusted and properly used!

Safety is everybody's responsibility!

Important things to do before driving

Safety is everybody's job! Vehicle and occupant safety always depends on the informed and careful driver.

For your safety and the safety of your passengers, **before driving always:**

- ▶ Make sure that all lights and signals are operating correctly.
- ▶ Make sure that the tire pressure is correct.
- ▶ Make sure that all windows are clean and afford good visibility to the outside.
- ▶ Secure all luggage and other items carefully
⇒ *page 59*.
- ▶ Make sure that nothing can interfere with the pedals.
- ▶ Adjust front seat, head restraint and mirrors correctly for your height.
- ▶ Instruct passengers to adjust the head restraints according to their height.
- ▶ Make sure to use the right child restraint correctly to protect children ⇒ *page 122, Child Safety*.
- ▶ Sit properly in your seat and make sure that your passengers do the same ⇒ *page 56, General recommendations*.
- ▶ Fasten your safety belt and wear it properly. Also instruct your passengers to fasten their safety belts properly ⇒ *page 95*.

What impairs driving safety?

Safe driving is directly related to the condition of the vehicle, the driver as well as the driver's ability to concentrate on the road without being distracted.

The driver is responsible for the safety of the vehicle and all of its occupants. If your ability to drive is impaired, safety risks for everybody in the vehicle increase and you also become a hazard to everyone else on the road ⇒ ⚠. Therefore:

- ▶ Do not let yourself be distracted by passengers or by using a cellular telephone.
- ▶ NEVER drive when your driving ability is impaired (by medications, alcohol, drugs, etc.).
- ▶ Observe all traffic laws, rules of the road and speed limits and plain common sense.
- ▶ ALWAYS adjust your speed to road, traffic and weather conditions.
- ▶ Take frequent breaks on long trips. Do not drive for more than two hours at a stretch.
- ▶ Do NOT drive when you are tired, under pressure or when you are stressed.

⚠ WARNING

Impaired driving safety increases the risk of serious personal injury and death whenever a vehicle is being used.

Proper occupant seating positions

Proper seating position for the driver

The proper driver seating position is important for safe, relaxed driving.




Fig. 100 Correct seating position

For your own safety and to reduce the risk of injury in the event of an accident, we recommend that you adjust the driver's seat to the following position:

- ▶ Adjust the steering wheel so that there is a distance of at least 10 inches (25 cm) between the steering wheel and your breast bone ⇒ fig. 100.
- ▶ Adjust the driver's seat so that you can easily push the pedals all the way to the floor while keeping your knee(s) slightly bent ⇒ ⚠.
- ▶ Grasp the top of the steering wheel with your elbow(s) slightly bent.
- ▶ Adjust the head restraint so the upper edge is as even as possible with the top of your head. If that is not possible, try to adjust the head restraint so that it is as close to this position as possible.
- ▶ Adjust the steering wheel so that the steering wheel and airbag cover points at your chest and not at your face.
- ▶ Adjust the angle of the seatback so that it is in an upright position so that your back comes in full contact with it when you drive.
- ▶ Fasten and wear safety belts correctly ⇒ page 95.
- ▶ Always keep both feet in the footwell so that you are in control of the vehicle at all times.

For detailed information on how to adjust the driver's seat, see ⇒ page 56, *General recommendations*.

⚠ WARNING

Drivers who are unbelted, out of position or too close to the airbag can be seriously injured by an airbag as it deploys. To help reduce the risk of serious personal injury:

- Always adjust the driver's seat and the steering wheel so that there are at least 10 inches (25 cm) between your breastbone and the steering wheel.
- Always adjust the driver's seat and the steering wheel so that there are at least 4 inches (10 cm) between the knees and the lower part of the instrument panel.
- Always hold the steering wheel on the outside of the steering wheel rim with your hands at the 9 o'clock and 3 o'clock

positions to help reduce the risk of personal injury if the driver's airbag inflates.

- Never hold the steering wheel at the 12 o'clock position or with your hands at other positions inside the steering wheel rim or on the steering wheel hub. Holding the steering wheel the wrong way can cause serious injuries to the hands, arms and head if the driver's airbag inflates
- Pointing the steering wheel toward your face decreases the ability of the supplemental driver's airbag to protect you in a collision.
- Always sit in an upright position and never lean against or place any part of your body too close to the area where the airbags are located.
- Before driving, always adjust the front seats and head restraints properly and make sure that all passengers are properly restrained.
- Never adjust the seats while the vehicle is moving. Your seat may move unexpectedly and you could lose control of the vehicle.
- Never drive with the backrest reclined or tilted far back! The farther the backrests are tilted back, the greater the risk of injury due to incorrect positioning of the safety belt and improper seating position.
- Children must always ride in child seats ⇒ *page 122*. Special precautions apply when installing a child seat on the front passenger seat ⇒ *page 102*.

Proper seating position for the front passenger

The proper front passenger seating position is important for safe, relaxed driving.

For your own safety and to reduce the risk of injury in the event of an accident, we recommend that you adjust the seat for the front passenger to the following position:

- ▶ Adjust the angle of the seatback so that it is in an upright position and your back comes in full contact with it whenever the vehicle is moving.
- ▶ Adjust the head restraint so the upper edge is as even as possible with the top of your head. If

that is not possible, try to adjust the head restraint so that it is as close to this position as possible ⇒ *page 89*.

- ▶ Keep both feet flat on the floor in front of the front passenger seat.
- ▶ Fasten and wear safety belts correctly .

For detailed information on how to adjust the front passenger's seat, see ⇒ *page 56, General recommendations*.



WARNING

Front seat passengers who are unbelted, out of position or too close to the airbag can be seriously injured or killed by the airbag as it deploys. To help reduce the risk of serious personal injury:

- Passengers must always sit in an upright position and never lean against or place any part of their body too close to the area where the airbags are located.
- Passengers who are unbelted, out of position or too close to the airbag can be seriously injured by an airbag as it deploys with great force in the blink of an eye.
- Always make sure that there are at least 10 inches (25 cm) between the front passenger's breastbone and the instrument panel.
- Always make sure that there are at least 4 inches (10 cm) between the front passenger's knees and the lower part of the instrument panel.
- Each passenger must always sit on a seat of their own and properly fasten and wear the safety belt belonging to that seat.
- Before driving, always adjust the front passenger seat and head restraint properly.
- Always keep your feet on the floor in front of the seat. Never rest them on the seat, instrument panel, out of the window, etc. The airbag system and safety belt will not be able to protect you properly and can even increase the risk of injury in a crash.
- Never drive with the backrest reclined or tilted far back! The farther the backrests are tilted back, the greater the risk of injury due

to incorrect positioning of the safety belt and improper seating position.

- Children must always ride in child seats ⇒ *page 122*. Special precautions apply when installing a child seat on the front passenger seat ⇒ *page 102*.

Proper adjustment of head restraints




Fig. 101 Head restraint: viewed from the front

The head restraints must be correctly adjusted to achieve the best protection.

- For adjustable head restraints: adjust the head restraint so the upper edge is as even as possible with the top of your head. If that is not possible, try to adjust the head restraint so that it is as close to this position as possible ⇒ *fig. 101*.

Adjusting head restraints ⇒ *page 58*.

WARNING

All seats are equipped with head restraints. Driving without head restraints or with head restraints that are not properly adjusted increases the risk of serious or fatal neck injury dramatically. To help reduce the risk of injury:

- Always drive with the head restraints in place and properly adjusted.
- Every person in the vehicle must have a properly adjusted head restraint.
- Always make sure each person in the vehicle properly adjusts their head restraint. Adjust the head restraints so the upper edge is as even as possible with the top of your head. If that is not possible, try to adjust the head restraint so that it is as close to this position as possible,

- Never attempt to adjust head restraint while driving. If you have driven off and must adjust the driver headrest for any reason, first stop the vehicle safely before attempting to adjust the head restraint.
- Children must always be properly restrained in a child restraint that is appropriate for their age and size ⇒ *page 122*.

Examples of improper seating positions

The occupant restraint system can only reduce the risk of injury if vehicle occupants are properly seated.

Improper seating positions can cause serious injury or death. Safety belts can only work when they are properly positioned on the body. Improper seating positions reduce the effectiveness of safety belts and will even increase the risk of injury and death by moving the safety belt to critical areas of the body. Improper seating positions also increase the risk of serious injury and death when an airbag deploys and strikes an occupant who is not in the proper seating position. A driver is responsible for the safety of all vehicle occupants and especially for children. Therefore:

- Never allow anyone to assume an incorrect seating position when the vehicle is being used ⇒ .

The following bullets list only some sample positions that will increase the risk of serious injury and death. Our hope is that these examples will make you more aware of seating positions that are dangerous.

Therefore, whenever the vehicle is moving:

- never stand up in the vehicle
- never stand on the seats
- never kneel on the seats
- never ride with the seatback reclined
- never lean up against the instrument panel
- never sit on the edge of the seat
- never sit sideways
- never lean out the window
- never put your feet out the window
- never put your feet on the instrument panel

- never rest your feet on the seat cushion or back of the seat
- never ride in the footwell
- never ride in the cargo area

WARNING

Improper seating positions increase the risk of serious personal injury and death whenever a vehicle is being used.

- Sitting incorrectly places occupants at risk of being critically injured if the airbags deploy and strike them.
- Before you start driving, seat yourself properly and always maintain this seating position during the trip. Before each trip, instruct your passengers to seat themselves properly and to maintain this seating position during the trip ⇒ *page 56, General recommendations.*

Driver and passenger side footwell

Important safety instructions

WARNING

Always make sure that the knee airbag can inflate without interference. Objects between yourself and the airbag can increase the risk of injury in an accident by interfering with the way the airbag deploys or by being pushed into you as the airbag deploys.

- No persons (children) or animals should ride in the footwell in front of the passenger seat. If the airbag deploys, this can result in serious or fatal injuries.
- No objects of any kind should be carried in the footwell area in front of the driver's or passenger's seat. Bulky objects (shopping bags, for example) can hamper or prevent proper deployment of the airbag. Small objects can be thrown through the vehicle if the airbag deploys and injure you or your passengers.

Pedal area

Pedals

The pedals must always be free to move and must never be interfered with by a floor mat or any other object.

Make sure that all pedals move freely without interference and that nothing prevents them from returning to their original positions.

Only use floor mats that leave the pedal area free and can be secured with floor mat fasteners.

If a brake circuit fails, increased brake pedal travel is required to bring the vehicle to a full stop.

WARNING

Pedals that cannot move freely can cause loss of vehicle control and increase the risk of serious injury.

- Never place any objects in the driver's footwell. An object could get into the pedal area and interfere with pedal function. In case of sudden braking or an accident, you would not be able to brake or accelerate!
- Always make sure that nothing can fall or move into the driver's footwell.

Floor mats on the driver side

Always use floor mats that can be securely attached to the floor mat fasteners and do not interfere with the free movement of the pedals.

- Make sure that the floor mats are properly secured and cannot move and interfere with the pedals ⇒ .

Use only floor mats that leave the pedal area unobstructed and that are firmly secured so that they cannot slip out of position. You can obtain suitable floor mats from your authorized Audi Dealer.

Floor mat fasteners are installed in your Audi.

Floor mats used in your vehicle must be attached to these fasteners. Properly securing the floor

mats will prevent them from sliding into positions that could interfere with the pedals or impair safe operation of your vehicle in other ways.

WARNING

Pedals that cannot move freely can result in a loss of vehicle control and increase the risk of serious personal injury.

- Always make sure that floor mats are properly secured.
- Never place or install floor mats or other floor coverings in the vehicle that cannot be properly secured in place to prevent them from slipping and interfering with the pedals or the ability to control the vehicle.
- Never place or install floor mats or other floor coverings on top of already installed floor mats. Additional floor mats and other coverings will reduce the size of the pedal area and interfere with the pedals.
- Always properly reinstall and secure floor mats that have been taken out for cleaning.
- Always make sure that objects cannot fall into the driver footwell while the vehicle is moving. Objects can become trapped under the brake pedal and accelerator pedal causing a loss of vehicle control.

Stowing luggage

Loading the luggage compartment

All luggage and other objects must be properly stowed and secured in the luggage compartment.

Loose items in the luggage compartment can shift suddenly, changing vehicle handling characteristics. Loose items can also increase the risk of serious personal injury in a sudden vehicle maneuver or in a collision.

In a collision, the laws of physics mean that even smaller items that are loose in the vehicle will become heavy missiles that can cause serious injury. Items in the vehicle possess energy which vary with vehicle speed and the weight of the item. Vehicle speed is the most significant factor.

For example, in a frontal collision at a speed of 30 mph (48 km/h), the forces acting on a 10-lb (4.5 kg) object are about 20 times the normal weight of the item. This means that the weight of the item would suddenly be about 200 lbs. (90 kg). You can imagine the injuries that a 200 lbs. (90 kg) item flying freely through the passenger compartment could cause in a collision like this.

WARNING

Improperly stored luggage or other items can fly through the vehicle causing serious personal injury in the event of hard braking or an accident. To help reduce the risk of serious personal injury:

- Always put objects, for example, luggage or other heavy items in the luggage compartment.

WARNING

Heavy loads will influence the way your vehicle handles. To help reduce the risk of a loss of control leading to serious personal injury:

- Always keep in mind when transporting heavy objects, that a change in the center of gravity can also cause changes in vehicle handling.
- Never exceed the Gross Axle Weight Rating or the Gross Vehicle Weight Rating specified on the safety compliance sticker on the left door jamb. Exceeding permissible weight standards can cause the vehicle to slide and handle differently.
- Please observe information on safe driving ⇒ page 86.

WARNING

Always make sure that the doors, all windows and the front lid are securely closed and locked to reduce the risk of injury when the vehicle is not being used.

- After closing the front lid, always make sure that it is properly closed and locked.
- Never leave your vehicle unattended especially with the front lid left open. A child

could crawl into the luggage compartment and close the front lid becoming trapped and unable to get out. Being trapped in a vehicle can lead to serious personal injury.

- Never let children play in or around the vehicle.
- Never let passengers ride in the luggage compartment. Vehicle occupants must always be properly restrained in one of the vehicle's seating positions.

Tips

The tire pressure must correspond to the load. The tire pressure is shown on the tire pressure label. The tire pressure label is located on the driver's side B-pillar. The tire pressure label lists the recommended cold tire inflation pressures for the vehicle at its maximum capacity weight and the tires that were on your vehicle at the time it was manufactured. For recommended tire pressures for normal load conditions, please see chapter *⇒ page 176*.

Reporting Safety Defects Applicable to U.S.A.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Audi of America, Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However,

NHTSA cannot become involved in individual problems between you, your dealer, or Audi of America, Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at:

Tel.: 1-888-327-4236 (TTY:
1-800-424-9153) or
1-800-424-9393

or you may write to:

Administrator
NHTSA
1200 New Jersey Avenue, SE
Washington, D.C. 20590

You can also obtain other information about motor vehicle safety from:

<http://www.safercar.gov>

Applicable to Canada

If you live in Canada and you believe that your vehicle has a defect that could cause a crash, injury or death, you should immediately inform Transport Canada, Defect Investigations and Recalls. You should also notify Audi Canada, Inc.

Canadian customers who wish to report a safety-related defect to ►

Transport Canada, Defect Investigations and Recalls, may either call Transport Canada toll-free at:

Tel.: 1-800-333-0510 or

Tel.: 1-819-994-3328 (Ottawa region and from other countries)

TTY for hearing impaired: Tel.: 1-888-675-6863

or contact Transport Canada by mail at:

Transport Canada

Motor Vehicle Safety Investigations Laboratory

80 Noel Street

Gatineau, QC

J8Z 0A1

For additional road safety information, please visit the Road Safety website at:

<http://www.tc.gc.ca/eng/roadsafety/menu.htm>

Active rollover protection system

Function

The active rollover protection system helps protect vehicle occupants in the event of a rollover.




Fig. 102 Rollbar deployment range



Fig. 103 Rollbar deployed

The active rollover protection system consists of:

- two rollbars
- the safety belts with belt tensioners
- the windshield frame
- the rollover sensors.

The active rollover protection system provides additional safety in the event of a rollover. Within milliseconds, sensors deploy two rollbars located behind the headrests ⇒ *fig. 103*.

The rollbars, reinforced windshield frame and belt tensioners help protect vehicle occupants in the event of a rollover.

The rollover protection system functions when the convertible top is both open and closed. ►

WARNING

Do not use the area behind the headrests ⇒ *fig. 102* as a storage area. This is the area where the rollbars deploy. If the rollover protection system is triggered, objects placed there can be propelled through the vehicle and make it more difficult for the rollbars to deploy. This increases the risk for serious or life-threatening injuries.

When is rollover protection deployed?

Rollover protection deploys in a collision or rollover.

Depending on the collision, sensors throughout the vehicle and the control module trigger the rollover system to deploy.

For safety reasons, rollover protection also deploys during front, side and rear collisions above a certain level of severity.

Retracting rollover protection



Fig. 104 Deployed rollbar with release loop




Fig. 105 Deployed rollbar with convertible top frame facing upward

If the rollbars deployed but the vehicle was not involved in a collision or rollover, you can retract

them without special tools. The system is ready for use again once they are retracted.

- ▶ Remove the wind deflector, if necessary ⇒ *page 40*.
- ▶ Lower the rear window, if necessary ⇒ *page 41*.
- ▶ Pull the loop upward in the direction of the arrow and hold it in place ① ⇒ *fig. 104*.
- ▶ Slide the rollbar down ② ⇒ .
- ▶ Release the loop just before the rollbar reaches its end position 1-2 in. (3-5 cm).
- ▶ Press the rollbar down firmly until it stops.
- ▶ Make sure the rollbar is secure before releasing it.
- ▶ Close the cover A ⇒ *fig. 105*.
- ▶ Repeat the procedure on the other rollbar.

WARNING

- Make sure your head or other parts of your body are not located in the area above the rollbar when pressing the rollbar down. If the rollbar is not secured correctly, it could deploy again as soon as you release it and cause injuries.
- Have the rollover protection system checked by your authorized Audi dealer if it malfunctions. Otherwise the system may not deploy correctly in a collision.
- Modifying the rollover protection system or individual components is not permitted.
- Work on the rollover protection system should only be performed by your authorized Audi dealer. Otherwise the system may not function correctly in a collision or it could deploy unexpectedly.
- Have the system inspected at service intervals. This ensures the system will always be ready for use. Have your authorized Audi dealer check the rollover protection system every two years at the latest.

Note

If the rollbars deploy when the convertible top is closed, do not open the top. Doing so could result in damage to the vehicle. Please see your authorized Audi dealer for assistance.

Safety belts

General notes

Always wear safety belts!

Wearing safety belts correctly saves lives!

This chapter explains why safety belts are necessary, how they work and how to adjust and wear them correctly.

- Read all the information that follows and heed all of the instructions and WARNINGS.

WARNING

Not wearing safety belts or wearing them improperly increases the risk of serious personal injury and death.

- Safety belts are the single most effective means available to reduce the risk of serious injury and death in automobile accidents. For your protection and that of your passengers, always correctly wear safety belts when the vehicle is moving.
- Pregnant women, injured, or physically impaired persons must also use safety belts. Like all vehicle occupants, they are more likely to be seriously injured if they do not wear safety belts. The best way to protect a fetus is to protect the mother - throughout the entire pregnancy.

Number of seats

Your Audi R8 has two seating positions in the front. Each seating position has a safety belt.

WARNING

Not wearing safety belts or wearing them improperly increases the risk of serious personal injury and death.

- Never strap more than one person, including small children, into any belt. It is especially dangerous to place a safety belt over a child sitting on your lap.
- Never let more people ride in the vehicle than there are safety belts available.

- Be sure everyone riding in the vehicle is properly restrained with a separate safety belt or child restraint.

Safety belt warning light

Your vehicle has a warning system for the driver and front seat passenger to remind you about the importance of buckling up.



Fig. 106 Safety belt warning light in the instrument cluster - enlarged

Before driving off, always:

- Fasten your safety belt and make sure you wear it properly.
- Make sure that your passengers also buckle up and wear their safety belts properly.
- Protect children with a child restraint system appropriate for the size and age.

The warning light  in the instrument cluster lights up when the ignition is switched on as a reminder to fasten the safety belts. In addition, you will hear a warning tone for a certain period of time.

Fasten your safety belt and make sure that your passengers also put on their safety belts properly.

WARNING

- Safety belts are the single most effective means available to reduce the risk of serious injury and death in automobile accidents. For your protection and that of your passengers, always wear safety belts correctly when the vehicle is moving.
- Failure to pay attention to the warning light that comes on could lead to personal injury.

Why safety belts?

Frontal collisions and the law of physics

Frontal crashes create very strong forces for people riding in vehicles.




Fig. 107 Unbelted occupants in a vehicle heading for a wall



Fig. 108 The vehicle crashes into the wall.

The physical principles are simple. Both the vehicle and the passengers possess energy which varies with vehicle speed and body weight. Engineers call this energy “kinetic energy.”

The higher the speed of the vehicle and the greater the vehicle's weight, the more energy that has to be “absorbed” in the crash.

Vehicle speed is the most significant factor. If the speed doubles from 15 to 30 mph (25 to 50 km/h), the energy increases 4 times!

Because the occupants in this vehicle are not using safety belts ⇒ *fig. 107*, they will keep moving at the same speed the vehicle was moving just before the crash, until something stops them - here, the wall ⇒ *fig. 108*.

The same principles apply to people sitting in a vehicle that is involved in a frontal collision. Even at city speeds of 20 to 30 mph (30 to 50 km/h), the forces acting on the body can reach one ton

(2,000 lbs, or 1,000 kg) or more. At higher speeds, these forces are even greater.

People who do not use safety belts are also not attached to their vehicle. In a frontal collision they will also keep moving forward at the speed their vehicle was travelling just before the crash. Of course, the laws of physics don't just apply to frontal collisions, they determine what happens in all kinds of accidents and collisions.

What happens to occupants not wearing safety belts?

In crashes unbelted occupants cannot stop themselves from flying forward and being injured or killed. Always wear your safety belts!



Fig. 109 A driver not wearing a safety belt is violently thrown forward

Unbelted occupants are not able to resist the tremendous forces of impact by holding tight or bracing themselves. Without the benefit of safety restraint systems, the unrestrained occupant will slam violently into the steering wheel, instrument panel, windshield, or whatever else is in the way ⇒ *fig. 109*. This impact with the vehicle interior has all the energy they had just before the crash.

Never rely on airbags alone for protection. Even when they deploy, airbags provide only additional protection. Airbags are not supposed to deploy in all kinds of accidents. Although your Audi is equipped with airbags, all vehicle occupants, including the driver, must wear safety belts correctly in order to minimize the risk of severe injury or death in a crash. ►

Remember too, that airbags will deploy only once and that your safety belts are always there to offer protection in those accidents in which airbags are not supposed to deploy or when they have already deployed. Unbelted occupants can also be thrown out of the vehicle where even more severe or fatal injuries can occur.

Safety belts protect

People think it's possible to use the hands to brace the body in a minor collision. It's simply not true!



Fig. 110 Driver is properly restrained in a sudden braking maneuver.

Safety belts used properly can make a big difference. Safety belts help to keep passengers in their seats, gradually reduce energy levels applied to the body in an accident, and help prevent the uncontrolled movement that can cause serious injuries. In addition, safety belts reduce the danger of being thrown out of the vehicle.

Safety belts attach passengers to the car and give them the benefit of being slowed down more gently or “softly” through the “give” in the safety belts, crush zones and other safety features engineered into today's vehicles. By “absorbing” the kinetic energy over a longer period of time, the safety belts make the forces on the body more “tolerable” and less likely to cause injury.

Although these examples are based on a frontal collision, safety belts can also substantially reduce the risk of injury in other kinds of crashes. So, whether you're on a long trip or just going to the corner store, always buckle up and make sure others do, too. Accident statistics show that vehicle occupants properly wearing safety belts have

a lower risk of being injured and a much better chance of surviving an accident. Properly using safety belts also greatly increases the ability of the supplemental airbags to do their job in a collision. For this reason, wearing a safety belt is legally required in most countries including much of the United States and Canada.

Although your Audi is equipped with airbags, you still have to wear the safety belts provided. Front airbags, for example, are activated only in some frontal collisions. The front airbags are not activated in all frontal collisions, in side and rear collisions, in roll overs or in cases where there is not enough deceleration through impact to the front of the vehicle. The same goes for the other airbag systems in your Audi. So, always wear your safety belt and make sure everybody in your vehicle is properly restrained!

Important safety instructions about safety belts

Safety belts must always be properly positioned across the strongest bones of your body.

- ▶ Always wear safety belts as illustrated and described in this chapter.
- ▶ Make sure that your safety belts are always ready for use and are not damaged.



WARNING

Not wearing safety belts or wearing them improperly increases the risk of serious personal injury and death. Safety belts can work only when used correctly.

- Always fasten your safety belts correctly before driving off and make sure all passengers are properly restrained.
- For maximum protection, safety belts must always be positioned correctly on the body.
- Never strap more than one person, including small children, into any single safety belt.
- Never place a safety belt over a child sitting on your lap.
- Always keep feet in the footwell in front of the seat while the vehicle is being driven.

- Never let any person ride with feet on the instrument panel or sticking out the window or on the seat.
- Never remove a safety belt while the vehicle is moving. Doing so will increase your risk of being injured or killed.
- Never wear belts twisted.
- Never wear belts over rigid or breakable objects in or on your clothing, such as eye glasses, pens, keys, etc., as these may cause injury.
- Never wear the shoulder part of the belt under your arm or otherwise out of position.
- Several layers of heavy clothing may interfere with correct positioning of belts and reduce their effectiveness.
- Always keep belt buckles free of anything that may prevent the buckle from latching securely.
- Never use comfort clips or devices that create slack in the shoulder belt. However, special clips may be required for the correct use of some child restraint systems.
- Never allow safety belts to become damaged by being caught in door or seat hardware.
- Torn or frayed safety belts can tear and damaged belt hardware can break in an accident. Inspect belts regularly. If webbing, bindings, buckles, or retractors are damaged, have belts replaced by an authorized Audi dealer or qualified workshop.
- Safety belts that have been worn and loaded in an accident must be replaced with the correct replacement safety belt by an authorized Audi dealer or qualified workshop. Replacement may be necessary even if damage cannot be clearly seen. Anchorages that were loaded must also be inspected.
- Never remove, modify, disassemble, or try to repair the safety belts yourself.
- Always keep the belts clean. Dirty belts may not work properly and can impair the function of the inertia reel ⇒ *table Cleaning interior on page 147.*

Safety belts

Fastening safety belts

Seat first - everybody buckle up!



Fig. 111 Belt buckle and tongue on the driver's seat

To provide maximum protection, safety belts must always be positioned correctly on the wearer's body.

- ▶ Adjust the front seat and head restraint properly ⇒ *page 56, General recommendations.*
- ▶ Hold the belt by the tongue and pull it evenly across the chest and pelvis ⇒ .
- ▶ Insert the tongue into the correct buckle of your seat until you hear it latch securely ⇒ *fig. 111.*
- ▶ Pull on the belt to make sure that it is securely latched in the buckle.

Automatic safety belt retractors

Every safety belt is equipped with an automatic belt retractor on the shoulder belt. This feature locks the belt when the belt is pulled out fast, during hard braking and in an accident. The belt may also lock when you drive up or down a steep hill or through a sharp curve. During normal driving the belt lets you move freely.

Safety belt pretensioners

The safety belts are equipped with a belt pretensioner that helps to tighten the safety belt and remove slack when the pretensioner is activated. The function of the pretensioner is monitored by a warning light ⇒ *page 13.*

Convertible locking retractor

Every safety belt except the one on the driver seat is equipped with a convertible locking retractor that **must** be used when the safety belt is used to attach a child seat. Be sure to read the important information about this feature ⇒ *page 130*.

WARNING

Improperly positioned safety belts can cause serious injury in an accident ⇒ *page 99*, *Safety belt position*.

- Safety belts offer optimum protection only when the seatback is upright and belts are properly positioned on the body.
- Never attach the safety belt to the buckle for another seat. Attaching the belt to the wrong buckle will reduce safety belt effectiveness and can cause serious personal injury.
- A passenger who is not properly restrained can be seriously injured by the safety belt itself when it moves from the stronger parts of the body into critical areas like the abdomen.
- Always lock the convertible locking retractor when you are securing a child seat in the vehicle ⇒ *page 131*.

Safety belt position

Correct belt position is the key to getting maximum protection from safety belts.




Fig. 112 Safety belt position

Standard features on your vehicle help you adjust the position of the safety belt to match your body size.

– height-adjustable front seats.

WARNING

Improperly positioned safety belts can cause serious personal injury in an accident.

- The shoulder belt should lie as close to the center of the collar bone as possible and should fit well on the body. Hold the belt above the latch tongue and pull it evenly across the chest so that it sits as low as possible on the pelvis and there is no pressure on the abdomen. The belt should always fit snugly ⇒ *fig. 112*. Pull on the belt to tighten if necessary.
- The lap belt portion of the safety belt must be positioned as low as possible across pelvis and never over the abdomen. Make sure the belt lies flat and snug ⇒ *fig. 112*. Pull on the belt to tighten if necessary.
- A loose-fitting safety belt can cause serious injuries by shifting its position on your body from the strong bones to more vulnerable, soft tissue and cause serious injury.
- Always read and heed all WARNINGS and other important information ⇒ *page 97*.

Pregnant women must also be properly restrained

The best way to protect the fetus is to make sure that expectant mothers always wear safety belts correctly - throughout the pregnancy.



Fig. 113 Safety belt position during pregnancy

To provide maximum protection, safety belts must always be positioned correctly on the wearer's body ⇒ *page 99*.

- ▶ Adjust the front seat and head restraint correctly ⇒ *page 56, General recommendations.*
- ▶ Make sure the seatback of the rear seat bench is in upright position and securely latched in place before using the belt.
- ▶ Hold the belt by the tongue and pull it evenly across the chest and pelvis ⇒ *fig. 113*, ⇒ ⚠.
- ▶ Insert the tongue into the correct buckle of your seat until you hear it latch securely ⇒ *page 98, fig. 111.*
- ▶ Pull on the belt to make sure that it is securely latched in the buckle.

⚠ WARNING

Improperly positioned safety belts can cause serious personal injury in an accident.

- Expectant mothers must always wear the lap portion of the safety belt as low as possible across the pelvis and below the rounding of the abdomen.
- Always read and heed all WARNINGS and other important information ⇒ ⚠ in *Fastening safety belts on page 99.*

Unfastening safety belts

Unbuckle the safety belt with the red release button only after the vehicle has stopped.



Fig. 114 Releasing the tongue from the buckle

- ▶ Push the red release button on the buckle ⇒ *fig. 114*. The belt tongue will spring out of the buckle ⇒ ⚠.
- ▶ Let the belt wind up on the retractor as you guide the belt tongue to its stowed position.

⚠ WARNING

Never unfasten safety belt while the vehicle is moving. Doing so will increase your risk of being injured or killed.

Improperly worn safety belts

Incorrectly positioned safety belts can cause severe injuries.

Wearing safety belts improperly can cause serious injury or death. Safety belts can only work when they are correctly positioned on the body. Improper seating positions reduce the effectiveness of safety belts and will even increase the risk of injury and death by moving the safety belt to critical areas of the body. Improper seating positions also increase the risk of serious injury and death when an airbag deploys and strikes an occupant who is not in the correct seating position. A driver is responsible for the safety of all vehicle occupants and especially for children. Therefore:

- ▶ Never permit anyone to assume an incorrect sitting position in the vehicle while traveling ⇒ ⚠.

⚠ WARNING

Improperly worn safety belts increase the risk of serious personal injury and death whenever a vehicle is being used.

- Always make sure that all vehicle occupants are correctly restrained and stay in a correct seating position whenever the vehicle is being used.
- Always read and heed all WARNINGS and other important information ⇒ *page 97.*

Safety belt pretensioners

How safety belt pretensioners work

In front, side and rear end collisions and in a rollover above a particular severity, safety belts in use are tensioned automatically.

The safety belts for the front seating positions are equipped with safety belt pretensioners. The ▶

system is activated by sensors in front, side and rear-end collisions and in a rollover of great severity. This tightens the belt and takes up belt slack ⇒  *in Service and disposal of safety belt pretensioner on page 101*. Taking up the slack helps to reduce forward occupant movement during a collision.

Tips

The safety belt pretensioner can only be activated once.

- In minor frontal and side collisions, in rear-end collisions and in accidents involving very little impact force, the safety belt pretensioners are not activated.
- When the safety belt pretensioner is activated, a fine dust is released. This is normal and is not caused by a fire in the vehicle.
- The relevant safety requirements must be observed when the vehicle or components of the system are scrapped. An authorized Audi dealer is familiar with these regulations and will be pleased to pass on the information to you.
- Be sure to observe all safety, environmental and other regulations if the vehicle or individual parts of the system, particularly the safety belt or airbag, are to be disposed. We recommend you have your authorized Audi dealer perform this service for you.

Service and disposal of safety belt pretensioner

The safety belt pretensioners are parts of the safety belts on your Audi. Installing, removing, servicing or repairing of belt pretensioners can damage the safety belt system and prevent it from working correctly in a collision.

There are some important things you have to know to make sure that the effectiveness of the system will not be impaired and that discarded components do not cause injury or pollute the environment.



WARNING

Improper care, servicing and repair procedures can increase the risk of personal injury and death by preventing a safety belt pretensioner from activating when needed or activating it unexpectedly:

- The belt pretensioner system can be activated only once. If belt pretensioners have been activated, the system must be replaced.
- Never repair, adjust, or change any parts of the safety belt system.
- Safety belt systems including safety belt pretensioners cannot be repaired. Special procedures are required for removal, installation and disposal of this system.
- For any work on the safety belt system, we strongly recommend that you see your authorized Audi dealer or qualified technician who has an Audi approved repair manual, training and special equipment necessary.



For the sake of the environment

Undeployed airbag modules and pretensioners might be classified as Perchlorate Material -special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate. When the vehicle or parts of the restraint system including airbag modules, safety belts with pretensioners are scrapped, all applicable laws and regulations must be observed. Your authorized Audi dealer is familiar with these requirements and we recommend that you have your dealer perform this service for you.

Airbag system

Important things to know

Importance of wearing safety belts and sitting properly

Airbags are only supplemental restraints. For airbags to do their job, occupants must always properly wear their safety belts and be in a proper seating position.

For your safety and the safety of your passengers, before driving off, always:

- ▶ Adjust the driver's seat and steering wheel properly ⇒ *page 87*,
- ▶ Adjust the front passenger's seat properly ⇒ *page 88*,
- ▶ Wear safety belts properly ⇒ *page 97*,
- ▶ Always properly use the proper child restraint to protect children ⇒ *page 122*.

In a collision airbags must inflate within the blink of an eye and with considerable force. The supplemental airbags can cause injuries if the driver or the front seat passenger are not seated properly. Therefore in order to help the airbag to do its job, it is important, both as a driver and as a passenger to sit properly at all times.

By keeping room between your body and the steering wheel and the front of the passenger compartment, the airbag can inflate fully and completely and provide supplemental protection in certain frontal collisions ⇒ *page 87*, *Proper occupant seating positions*. For details on the operation of the seat adjustment controls ⇒ *page 57*.

It's especially important that children are properly restrained ⇒ *page 122*.

There is a lot that the driver and the passenger can and must do to help the individual safety features installed in your Audi work together as a system.

Proper seating position is important so that the front airbag on the driver side can do its job. If you have a physical impairment or condition that prevents you from sitting properly on the driver seat with the safety belt properly fastened and

reaching the pedals, or if you have concerns with regard to the function or operation of the Advanced Airbag System, please contact your authorized Audi dealer or qualified workshop, or call Audi Customer Relations at 1-800-822-2834 for possible modifications to your vehicle.

When the airbag system deploys, a gas generator will fill the airbags, break open the padded covers, and inflate between the steering wheel and the driver and between the instrument panel and the front passenger. The airbags will deflate immediately after deployment so that the front occupants can see through the windshield again without interruption.

All of this takes place in the blink of an eye, so fast that many people don't even realize that the airbags have deployed. The airbags also inflate with a great deal of force and nothing should be in their way when they deploy. Front airbags in combination with properly worn safety belts slow down and limit the occupant's forward movement. Together they help to prevent the driver and passenger from hitting parts of the inside the vehicle while reducing the forces acting on the occupant during the crash. In this way they help to reduce the risk of injury to the head and upper body in the crash. Airbags do not protect the arms or the lower parts of the body.

Both front airbags will not inflate in all frontal collisions. The triggering of the airbag system depends on the vehicle deceleration rate caused by the collision and registered by the electronic control unit. If this rate is below the reference value programmed into the control unit, the airbags will not be triggered, even though the car may be badly damaged as a result of the collision. Vehicle damage, repair costs or even the lack of vehicle damage is not necessarily an indication of whether an airbag should inflate or not.

It is not possible to define a range of vehicle speeds that will cover every possible kind and angle of impact that will always trigger the airbags, since the circumstances will vary considerably between one collision and another. Important factors include, for example, the nature (hard or soft) of the object which the car hits, the angle of impact, vehicle speed, etc. The front airbags will ►

also not inflate in side or rear collisions, or in roll-overs.

Always remember: Airbags will deploy only once, and only in certain kinds of collisions. Your safety belts are always there to offer protection in those situations in which airbags are not supposed to deploy, or when they have already deployed; for example, when your vehicle strikes or is struck by another after the first collision.

This is just one of the reasons why an airbag is a supplementary restraint and is not a substitute for a safety belt. The airbag system works most effectively when used with the safety belts. Therefore, always properly wear your safety belts
⇒ *page 95*.

WARNING

Sitting too close to the steering wheel or instrument panel will decrease the effectiveness of the airbags and will increase the risk of personal injury in a collision.

- Never sit closer than 10 inches (25 cm) to the steering wheel or instrument panel.
- If you cannot sit more than 10 inches (25 cm) from the steering wheel, investigate whether adaptive equipment may be available to help you reach the pedals and increase your seating distance from the steering wheel.
- If you are unrestrained, leaning forward, sitting sideways or out of position in any way, your risk of injury is much higher.
- You will also receive serious injuries and could even be killed if you are up against the airbag or too close to it when it inflates - even with an Advanced Airbag.
- To reduce the risk of injury when an airbag inflates, always wear safety belts properly
⇒ *page 98, Safety belts*.
- Never let children ride unrestrained or improperly restrained in the vehicle. Adjust the front seats properly. If children are not properly restrained, they may be severely injured or killed when an airbag inflates.
- Never ride with the backrest reclined.
- Always sit as far as possible from the steering wheel or the instrument panel

⇒ *page 87, Proper occupant seating positions*.

- Always sit upright with your back against the backrest of your seat.
- Never place your feet on the instrument panel or on the seat. Always keep both feet on the floor in front of the seat to help prevent serious injuries to the legs and hips if the airbag inflates.
- Never recline the front passenger's seat to transport objects. Items can also move into the area of the side airbag or the front airbag during braking or in a sudden maneuver. Objects near the airbags can become projectiles and cause injury when an airbag inflates.

WARNING

Airbags that have deployed in a crash must be replaced.

- Use only original equipment airbags approved by Audi and installed by a trained technician who has the necessary tools and diagnostic equipment to properly replace any airbag in your vehicle and assure system effectiveness in a crash.
- Never permit salvaged or recycled airbags to be installed in your vehicle.

Child restraints on the front seat – some important things to know

- Be sure to read the important information and heed the WARNINGS for important details about children and Advanced Airbags
⇒ *page 122*.

The airbag on the passenger side makes the front seat a potentially dangerous place for a child to ride. The front seat is not the safest place for a child in a forward-facing child safety seat. It can be a very dangerous place for an infant or a child in a rearward-facing seat.

The Advanced Airbag System in your vehicle has been certified to comply with the Requirements of United States Federal Motor Vehicle Safety Standard 208 as applicable at the time your vehicle was manufactured.

The Standard requires the front airbag on the passenger side to be turned off (“suppressed”) if a child up to about one year of age restrained in one of the rear-facing or forward-facing infant restraints listed in Federal Motor Vehicle Safety Standard 208 with which the Advanced Airbag System in your vehicle was certified has been installed on the front passenger seat. For a listing of the child restraints that were used to certify compliance with the US Safety Standard ⇒ *page 124*.

The **PASSENGER AIR BAG OFF** light in the instrument panel tells you when the front Advanced Airbag on the passenger side has been turned off by the electronic control unit.

Each time you turn on the ignition, the **PASSENGER AIR BAG OFF** light will come on for a few seconds and:

- will stay on if the front passenger seat is not occupied,
- will stay on if there is a small child or child restraint on the front passenger seat,
- will go off if the front passenger seat is occupied by an adult as registered by the weight-sensing mat ⇒ *page 112, Monitoring the Advanced Airbag System*.

The **PASSENGER AIR BAG OFF** light comes on when the control unit detects a total weight on the front passenger seat that requires the front airbag to be turned off.

If the total weight on the front passenger seat is more than that of a typical 1 year-old child but less than the weight of a small adult, the front airbag on the passenger side can deploy (the **PASSENGER AIR BAG OFF** light does not come on). If the **PASSENGER AIR BAG OFF** light does not come on, the front airbag on the passenger side has not been turned off by the electronic control unit and can deploy if the control unit senses an impact that meets the conditions stored in its memory.

For example, the airbag may deploy if:

- a small child that is heavier than a typical 1 year-old child is on the front passenger seat (re-

gardless of whether the child is in one of the child safety seats listed ⇒ *page 124*), or

- a child who has outgrown child restraints is on the front passenger seat.

If the front passenger airbag is turned off, the **PASSENGER AIR BAG OFF** light comes on in the instrument panel and stays on.

The front airbag on the passenger side may *not* deploy (the **PASSENGER AIR BAG OFF** light does not illuminate and stay lit) even if a small adult or teenager, or a passenger who is not sitting upright with their back against a non-reclined backrest with their feet on the vehicle floor in front of the seat is on the front passenger seat ⇒ *page 87, Proper seating position for the driver*.

If the front passenger airbag deploys, the Federal Standard requires the airbag to meet the “low risk” deployment criteria to reduce the risk of injury through interaction with the airbag. “Low risk” deployment occurs in those crashes that take place at lower decelerations as defined in the electronic control unit ⇒ *page 112, PASSENGER AIR BAG OFF light*.

Always remember, a child safety seat or infant carrier installed on the front seat may be struck and knocked out of position by the rapidly inflating passenger’s airbag in a frontal collision. The airbag could greatly reduce the effectiveness of the child restraint and even seriously injure the child during inflation.



WARNING

A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates - even with an Advanced Airbag System.

- The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG**

OFF light does not come on and stay on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.

- Forward-facing child safety seats installed on the front passenger's seat may interfere with the deployment of the airbag and cause serious personal injury to the child.

WARNING

If, in exceptional circumstances, you must install a forward-facing child restraint on the front passenger's seat:

- Always make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.
- Never put the forward-facing child restraint up against or very near the instrument panel.
- Always move the passenger seat into its rearmost position in the seat's fore and aft adjustment range, as far away from the airbag as possible before installing the forward-facing child restraint. The backrest must be adjusted to an upright position.
- Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.

WARNING

To reduce the risk of serious injury, make sure that the **PASSENGER AIR BAG OFF** light will be displayed whenever a child restraint is installed on the front passenger seat and the ignition is switched on.

- If the **PASSENGER AIR BAG OFF** light does not stay on, perform the checks described ⇒ *page 112, Monitoring the Advanced Airbag System*.
- Have the airbag system inspected by your Audi dealer immediately.

- Always carefully follow instructions from child restraint manufacturers when installing child restraints.

WARNING

If, in exceptional circumstances, you must install a forward or rearward-facing child restraint on the front passenger's seat:

- Improper installation of child restraints can reduce their effectiveness or even prevent them from providing any protection.
- An improperly installed child restraint can interfere with the airbag as it deploys and seriously injure or even kill the child – even with an Advanced Airbag System.
- Always carefully follow the manufacturer's instructions provided with the child safety seat or carrier.
- Never place additional items on the seat that can increase the total weight registered by the weight-sensing mat and can cause injury in a crash.

Front airbags

Description of front airbags

The airbag system can provide supplemental protection to properly restrained front seat occupants.



Fig. 115 Location of driver airbag: in steering wheel



Fig. 116 Location of front passenger's airbag: in the instrument panel

Your vehicle is equipped with an “Advanced Airbag System” in compliance with United States Federal Motor Vehicle Safety Standard (FMVSS) 208 as applicable at the time your vehicle was manufactured. The safety belts for the front seats have “pretensioners” that help to take slack out of the belt system. The pretensioners are also activated by the electronic control unit for the airbag system.

The front safety belts also have load limiters to help reduce the forces applied to the body in a crash.

The airbag for the driver is in the steering wheel hub ⇒ *fig. 115* and the airbag for the front passenger is in the instrument panel ⇒ *fig. 116*. The general location of the airbags is marked “AIR-BAG”.

There is a lot you need to know about the airbags in your vehicle. We urge you to read the detailed information about airbags, safety belts and child safety in this and the other chapters that make up the owner's literature. Please be sure to heed the WARNINGS - they are extremely important for your safety and the safety of your passengers, especially infants and small children.



WARNING

Never rely on airbags alone for protection.

- Even when they deploy, airbags provide only supplemental protection.
- Airbags work most effectively when used with properly worn safety belts.
- Therefore, always wear your safety belts and make sure that everybody in your vehicle is properly restrained.



WARNING

A person on the front passenger seat, especially infants and small children, will receive serious injuries and can even be killed by being too close to the airbag when it inflates.

- Although the Advanced Airbag System in your vehicle is designed to turn off the front passenger airbag if an infant or a small child is on the front passenger seat, nobody can absolutely guarantee that deployment under these special conditions is impossible in all conceivable situations that may happen during the useful life of your vehicle.
- The Advanced Airbag System can deploy in accordance with the “low risk” option under the U.S. Federal Standard if a child that is heavier than the typical one-year old child is on the front passenger seat and the other conditions for airbag deployment are met.
- For its own safety, a child should always ride properly restrained for its age and size.

Advanced front airbag system

Your vehicle is equipped with a front Advanced Airbag System in compliance with United States Federal Motor Vehicle Safety Standard 208 as applicable at the time your vehicle was manufactured.

The front Advanced Airbag System supplements the safety belts to provide additional protection for the driver's and front passenger's heads and upper bodies in frontal crashes. The airbags inflate only in frontal impacts when the vehicle deceleration is high enough.

The front Advanced Airbag System for the front seat occupants is not a substitute for your safety belts. Rather, it is part of the overall occupant restraint system in your vehicle. Always remember that the airbag system can only help to protect you, if you are sitting upright, wearing your safety belt and wearing it properly. This is why you and your passengers must always be properly restrained, not just because the law requires you to be.

The Advanced Airbag System in your vehicle has been certified to meet the "low risk" requirements for 3 and 6 year-old children on the passenger side and very small adults on the driver side. The low risk deployment criteria are intended to help reduce the risk of injury through interaction with the front airbag that can occur, for example, by being too close to the steering wheel and instrument panel when the airbag inflates.

In addition, the system has been certified to comply with the "suppression" requirements of the Safety Standard, to turn off the front airbag for infants 12 months old and younger who are restrained on the front passenger seat in child restraints that are listed in the Standard

⇒ *page 124, Child restraints and Advanced Airbags.*

"Suppression" requires the front airbag on the passenger side to be turned off if:

- a child up to about one year of age is restrained on the front passenger seat in one of the rear-facing or forward-facing infant restraints listed in Federal Motor Vehicle Safety Standard 208 with which the Advanced Airbag System in your vehicle was certified. For a listing of the child restraints that were used to certify your vehicle's compliance with the US Safety Standard ⇒ *page 124,*

- weight less than a threshold level stored in the control unit is detected on the front passenger seat.

When a person is detected on the front passenger seat, weighing more than the total weight of a child that is about 1 year old restrained in one of the rear-facing or forward-facing infant restraints (listed in Federal Motor Vehicle Safety Standard 208 with which the Advanced Airbag System in your vehicle was certified), the front airbag on the passenger side may or may not deploy.

The **PASSENGER AIR BAG OFF** light comes on when the electronic control unit detects a total weight on the front passenger seat that requires the front airbag to be turned off. If the **PASSENGER AIR BAG OFF** light does not come on, the front airbag on the passenger side has not been turned off by the control unit and can deploy if the control unit senses an impact that meets the conditions stored in its memory.

If the total weight on the front passenger seat is more than that of a typical 1 year-old, but less than the weight of a small adult, the front airbag on the passenger side may deploy (the **PASSENGER AIR BAG OFF** light does not come on).

For example, the airbag may deploy if:

- a small child that is heavier than a typical 1 year-old child is on the front passenger seat (regardless of whether the child is in one of the child safety seats listed ⇒ *page 124*),
- a child who has outgrown child restraints is on the front passenger seat.

If the front passenger airbag is turned off, the **PASSENGER AIR BAG OFF** light in the center of the instrument panel will come on and stay on.

The front airbag on the passenger side may *not* deploy (the **PASSENGER AIR BAG OFF** light does not illuminate and stay lit) if:

- a small adult or teenager is on the front passenger seat
- a passenger who is not sitting upright with their back against a non-reclined backrest with their feet on the vehicle floor in front of the seat is on the front passenger seat.

If the front passenger airbag deploys, the Federal Standard requires the airbag to meet the “low risk” deployment criteria to help reduce the risk of injury through interaction with the airbag. “Low risk” deployment occurs in those crashes that take place at lower decelerations as defined in the electronic control unit ⇒ *page 112*.

Always remember: Please be sure to read the important information in the sections that follow and be sure to heed all of the WARNINGS.

WARNING

- To reduce the risk of injury when an airbag inflates, always wear safety belts properly.
- If you are unrestrained, leaning forward, sitting sideways or out of position in any way, your risk of injury is much higher.
 - You will also receive serious injuries and could even be killed if you are up against the airbag or too close to it when it inflates - even with an Advanced Airbag ⇒ *page 102*.

WARNING

- A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates - even with an Advanced Airbag System.
- Although the Advanced Airbag System in your vehicle is designed to turn off the front airbag when a rearward-facing child restraint has been installed on the front passenger seat, nobody can absolutely guarantee that deployment is impossible in all conceivable situations that may happen during the useful life of your vehicle.
 - The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door, or roof.
 - If you must install a rearward facing child safety seat on the front passenger seat because of exceptional circumstances and the **PASSENGER AIR BAG OFF** light does not come on and stay on have the airbag system inspected by your Audi dealer.

WARNING

- If, in exceptional circumstances, you must install a forward-facing child restraint on the front passenger's seat:
- Always make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.
 - Never put the forward-facing child restraint up against or very near the instrument panel.
 - Always move the passenger seat into its rearmost position in the seat's fore and aft adjustment range, as far away from the airbag as possible, before installing the forward-facing child restraint. The backrest must be adjusted to an upright position.
 - Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.

Advanced Airbag System components

The front passenger seat in your vehicle has a lot of very important parts of the Advanced Airbag System in it. These parts include the weight-sensing mat, sensors, wiring, brackets, and more. The function of the system in the front passenger seat is checked by the electronic control unit when the ignition is on. The control unit monitors the Advanced Airbag System and turns the airbag indicator light on when a malfunction in the system components is detected. The function of the airbag indicator light is described in greater detail below. Because the front passenger seat contains important parts of the Advanced Airbag System, you must take care to prevent it from being damaged. Damage to the seat may prevent the Advanced Airbag for the front passenger seat from doing its job in a crash.

The front Advanced Airbag System consists of the following:

- Crash sensors in the front of the vehicle that measure vehicle acceleration/deceleration to provide information to the Advanced Airbag System about the severity of the crash.

- An electronic control unit, with integrated crash sensors for front and side impacts. The control unit “decides” whether to fire the front airbags based on the information received from the crash sensors. The control unit also “decides” whether the safety belt pretensioners should be activated.
 - An Advanced Airbag with gas generator for the driver inside the steering wheel hub.
 - An Advanced Airbag with gas generator inside the instrument panel for the front passenger.
 - A weight-sensing mat under the upholstery padding of the front passenger seat cushion that measures the total weight on the seat. The information registered is sent continuously to the electronic control unit to regulate deployment of the front Advanced Airbag on the passenger side.
 - An airbag monitoring system and indicator light in the instrument cluster ⇒ *page 112*.
 - The **PASSENGER AIR BAG OFF** light comes on and stays on in the center of the instrument panel ⇒ *page 112, fig. 118* and tells you when the front Advanced Airbag on the passenger side has been turned off.
 - A sensor below the safety belt latch for the front seat passenger to measure the tension on the safety belt. The tension on the safety belt and the weight registered by the weight-sensing mat help the control unit “decide” whether the front airbag for the front passenger seat should be turned off or not ⇒ *page 103, Child restraints on the front seat – some important things to know*.
 - A sensor in the safety belt latch for the driver and for the front seat passenger that senses whether that safety belt is latched or not and transmits this information to the electronic control unit.
-  **WARNING**

Damage to the front passenger seat can prevent the front airbag from working properly.

 - Improper repair or disassembly of the front passenger and driver seat will prevent the Advanced Airbag System from functioning properly.
- Repairs to the front passenger seat must be performed by qualified and properly trained workshop personnel.
 - Never remove the front passenger or driver seat from the vehicle.
 - Never remove the upholstery from the front passenger seat.
 - Never disassemble or remove parts from the seat or disconnect wires from it.
 - Never carry sharp objects in your pockets or place them on the seat. If the weight-sensing mat in the passenger seat is punctured it cannot work properly.
 - Never carry things on your lap or carry objects on the passenger seat. Such items can increase the weight registered by the weight-sensing mat and send the wrong information to the airbag control unit.
 - Never store items under the front passenger seat. Parts of the Advanced Airbag System under the passenger seat could be damaged, preventing them and the airbag system from working properly.
 - Never place seat covers or replacement upholstery that have not been specifically approved by Audi on the front seats.
 - Seat covers can prevent the Advanced Airbag System from recognizing child restraints or occupants on the front passenger seat and prevent the side airbag in the seat backrest from deploying properly.
 - Never use cushions, pillows, blankets or similar items on the front passenger seat. The additional padding will prevent the weight-sensing mat in the seat from accurately registering the child restraint or person on the seat and prevent the Advanced Airbag System from functioning properly.
 - If you must use a child restraint on the front passenger seat and the child restraint manufacturer's instructions require the use of a towel, foam cushion or something else to properly position the child restraint, make certain that the **PASSENGER AIR BAG OFF** light comes on and stays on whenever the child restraint is installed on the front passenger seat.

- If the **PASSENGER AIR BAG OFF** light does not come on and stay on, have the airbag system inspected by your Audi dealer.

How the Advanced Airbag System components work together

The front Advanced Airbag System and the side airbags supplement the protection offered by the front three-point safety belts with pretensioners and load limiters and the adjustable head restraints to help reduce the risk of injury in a wide range of accident and crash situations. Be sure to read the important information about safety and heed the WARNINGS in this chapter.

Deployment of the Advanced Airbag System and the activation of the safety belt pretensioners depend on the deceleration measured by the crash sensors and registered by the electronic control unit. Crash severity depends on speed and deceleration as well as the mass and stiffness of the vehicle or object involved in the crash.

When the electronic control unit registers a low severity crash and the safety belt is being used, the airbag will not deploy. If the safety belt is not being used, the first stage deploys, followed by the second stage after a much later time in the crash sequence.

If the electronic control unit registers a crash of medium severity, the first stage of the airbag deploys followed by the second stage at a much later time in the crash sequence - regardless of whether the safety belt is being used or not. In higher severity crashes as registered by the electronic control unit, both the first and second stages deploy almost at the same time.

On the passenger side, regardless of safety belt use, the airbag will be turned off if the weight on the passenger seat is less than the amount programmed in the electronic control unit. The front airbag on the passenger side will also be turned off if one of the child safety seats that has been certified under Federal Motor Vehicle Safety Standard 208 has been recognized on the seat. The **PASSENGER AIR BAG OFF** light comes on and stays on to tell you when the front Advanced Airbag on the passenger side has been turned off

⇒ page 103, *Child restraints on the front seat – some important things to know.*



WARNING

- To reduce the risk of injury when an airbag inflates, always wear safety belts properly.
- If you are unrestrained, leaning forward, sitting sideways or out of position in any way, your risk of injury is much higher.
 - You will also receive serious injuries and could even be killed if you are up against the airbag or too close to it when it inflates - even with an Advanced Airbag ⇒ page 102.

More important things to know about front airbags



Fig. 117 Inflated front airbags

Safety belts are important to help keep front seat occupants in the proper seated position so that airbags can unfold properly and provide supplemental protection in a frontal collision.

The front airbags are designed to provide additional protection for the chest and face of the driver and the front seat passenger when:

- safety belts are worn properly,
- the seats have been positioned so that the occupant is properly seated as far as possible from the airbag,
- and the head restraints have been properly adjusted.

Because airbags inflate in the blink of an eye with great force, things you have on your lap or have placed on the seat could become dangerous projectiles, and be pushed into you if the airbag inflates.

When an airbag deploys, fine dust is released. This is normal and is not caused by a fire in the vehicle. This dust is made up mostly of a powder used to lubricate the airbags as they deploy. It could irritate skin.

It is important to remember that while the supplemental airbag system is designed to reduce the likelihood of serious injuries, other injuries, for example swelling, bruising and minor abrasions, can also happen when airbags inflate. Airbags do not protect the arms or the lower parts of the body. Front airbags only supplement the three point safety belts in some frontal collisions in which the vehicle deceleration is high enough to deploy the airbags.

Front airbags will not deploy:

- if the ignition is switched off when a crash occurs,
- in side collisions,
- in rear-end collisions,
- in rollovers,
- when the crash deceleration measured by the airbag system is less than the minimum threshold needed for airbag deployment as registered by the electronic control unit.

The front passenger airbag will also not deploy:

- when the front passenger seat is not occupied,
- when the weight on the front passenger seat as sensed by the Advanced Airbag System indicates that the front airbag on the passenger side has to be turned off by the electronic control unit (the **PASSENGER AIR BAG OFF** light comes on and stays on).

WARNING

Sitting in the wrong position can increase the risk of serious injury in crashes.

- To reduce the risk of injury when the airbags inflate, the driver and passengers must always sit in an upright position, must not lean against or place any part of their body too close to the area where the airbags are located.

- Occupants who are unbelted, out of position or too close to the airbag can be seriously injured by an airbag as it unfolds with great force in the blink of an eye ⇒ *page 103*.

WARNING

A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates - even with an Advanced Airbag System.

- The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, center arm rest, door or roof.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on, the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.

WARNING

Objects between you and the airbag will increase the risk of injury in a crash by interfering with the way the airbag unfolds or by being pushed into you as the airbag inflates.

- Never hold things in your hands or on your lap when the vehicle is in use.
- Never transport items on or in the area of the front passenger seat. Objects could move into the area of the front airbags during braking or other sudden maneuver and become dangerous projectiles that can cause serious personal injury if the airbags inflate.
- Never place or attach accessories or other objects (such as cup holders, telephone brackets, large, heavy or bulky objects) on the doors, over or near the area marked

“AIRBAG” on the steering wheel, instrument panel, seat backrests or between those areas and yourself. These objects could cause injury in a crash, especially when the airbags inflate.

- Never recline the front passenger's seat to transport objects. Items can also move into the area of the side airbag or the front airbag during braking or in a sudden maneuver. Objects near the airbags can become projectiles and cause injury, particularly when the seat is reclined.

WARNING

The fine dust created when airbags deploy can cause breathing problems for people with a history of asthma or other breathing conditions.

- To reduce the risk of breathing problems, those with asthma or other respiratory conditions should get fresh air right away by getting out of the vehicle or opening windows or doors.
- If you are in a collision in which airbags deploy, wash your hands and face with mild soap and water before eating.
- Be careful not to get the dust into your eyes, or into any cuts or scratches.
- If the residue should get into your eyes, flush them with water.

Monitoring the Advanced Airbag System

Airbag monitoring indicator light

*Two separate indicators monitor the function of the Advanced Airbag System: the airbag monitoring indicator light and the **PASSENGER AIR BAG OFF** light.*

The Advanced Airbag System (including the electronic control unit, sensor circuits and system wiring) is monitored continuously to make sure that it is functioning properly whenever the ignition is on. Each time you turn on the ignition, the airbag monitoring indicator light  will come on for a few seconds (self diagnostics).

The system must be inspected when the indicator light :

- does not come on when the ignition is switched on,
- does not go out a few seconds after you have switched on the ignition, or
- comes on while driving.

If an airbag system malfunction is detected, the indicator light will first start flashing to catch the driver's attention and then stay on continuously to serve as a constant reminder to have the system inspected immediately.

If a malfunction occurs that turns the front airbag on the passenger side off, the **PASSENGER AIR BAG OFF** light will come on and stay on whenever the ignition is on.

WARNING

An airbag system that is not functioning properly cannot provide supplemental protection in a frontal crash.

- If the airbag indicator light comes on, it means that there may be something wrong with the Advanced Airbag System. It is possible that the airbag will inflate when it is not supposed to, or will not inflate when it should.
- Have the airbag system inspected immediately by your Audi dealer.

PASSENGER AIR BAG OFF light



Fig. 118 Section from the instrument panel: **PASSENGER AIR BAG OFF** light

The **PASSENGER AIR BAG OFF** light is located in the center of the instrument panel ⇒ *fig. 118*. ►

The **PASSENGER AIR BAG OFF** light will come on and stay on to tell you when the front Advanced Airbag on the passenger side has been turned off by the electronic control unit. Each time you turn on the ignition, the **PASSENGER AIR BAG OFF** light will flash for a few seconds and:

- will stay on if the front passenger seat is not occupied,
- will stay on if there is a small child or child restraint on the front passenger seat,
- will go out if the front passenger seat is occupied by an adult as registered by the weight-sensing mat.

The **PASSENGER AIR BAG OFF light must come on and stay on** if the ignition is on and

- a car bed has been installed on the front seat, or
- a rearward-facing child restraint has been installed on the front passenger seat, or
- a forward-facing child restraint has been installed on the front passenger seat, or
- the weight registered on the front passenger seat is equal to or less than the combined weight of a typical 1 year-old restrained in one of the rear-facing or forward-facing infant restraints listed in Federal Motor Vehicle Safety Standard 208 with which the Advanced Airbag System in your vehicle was certified.

If the front passenger seat is not occupied, the front airbag will not deploy, and the **PASSENGER AIR BAG OFF** light will stay on. Never install a rearward-facing child restraint on the front passenger seat ⇒ *page 103, Child restraints on the front seat – some important things to know* and ⇒ *page 122, Child Safety*.

If the PASSENGER AIR BAG OFF light comes on when one of the conditions listed above is met, be sure to check the light regularly to make certain that the **PASSENGER AIR BAG OFF** light stays on continuously whenever the ignition is on. If the **PASSENGER AIR BAG OFF** light does not appear and not stay on all the time, stop as soon as it is safe to do so and

- reactivate the system by turning the ignition off and then turning it on again;

- remove and reinstall the child restraint. Make sure that the child restraint is properly installed and that the safety belt for the front passenger seat has been correctly routed around the child restraint as described in the child restraint manufacturer's instructions;
- make sure that the convertible locking retractor on the safety belt for the front passenger seat has been activated and that the safety belt has been pulled tight. The belt must not be loose or have loops of slack so that the sensor below the safety belt latch on the seat can do its job ⇒ *page 130*.
- make sure that things that may increase the weight of the child and child safety seat are not being transported on the front passenger seat;
- make sure that the safety belt tension sensor is not blocked. Shake the safety belt latch on the front passenger seat back and forth;
- If a strap or tether is being used to tie the child safety seat to the front passenger seat, make sure that it is not so tight that it causes the weight-sensing mat to measure more weight than is actually on the seat.

If the PASSENGER AIR BAG OFF light still does not come on and does not stay on continuously (when the ignition is switched on),

- take the child restraint off the front passenger seat and install it properly at one of the rear seat positions. Have the airbag system inspected by your Audi dealer immediately.
- move the child to a rear seat position and make sure that the child is properly restrained in a child restraint that is appropriate for its size and age.

The **PASSENGER AIR BAG OFF** light should NOT come on when the ignition is on and an adult is sitting in a proper seating position on the front passenger seat. If the **PASSENGER AIR BAG OFF** light comes on and stays on or flashes for about 5 seconds while driving, under these circumstances, make sure that:

- the adult on the front passenger seat is properly seated on the center of the seat cushion with his or her back up against the backrest and the ►

backrest is not reclined ⇒ *page 87, Proper occupant seating positions*,

- the adult is not taking weight off the seat by holding on to the passenger assist handle above the front passenger door,
- the safety belt is being properly worn and that there is not a lot of slack in the safety belt webbing,
- accessory seat covers or cushions or other things that may cause an incorrect reading or impression on the weight-sensing mat under the upholstery of the seat have been removed from the front passenger seat,
- a safety belt extender has not been left in the safety belt latch for the front passenger seat.

In addition to the **PASSENGER AIR BAG OFF** light in the center of the instrument panel, the message **PASSENGER AIR BAG OFF** or **PASSENGER AIR BAG ON** will briefly appear in the instrument cluster display. This is to inform the driver of the current front passenger airbag status.

Important safety instructions on monitoring the Advanced Airbag System

WARNING

An airbag system that is not functioning properly cannot provide supplemental protection in a frontal crash.

- If the airbag indicator light comes on, it means that there may be something wrong with the Advanced Airbag System. It is possible that the airbag will inflate when it is not supposed to, or will not inflate when it should.
- Have the airbag system inspected immediately by your Audi dealer.

WARNING

If the front airbag inflates, a child without a child restraint, in a rearward-facing child safety seat or in a forward-facing child restraint that has not been properly installed will be seriously injured and can be killed.

- Even though your vehicle is equipped with an Advanced Airbag System, make certain that all children, especially 12 years and

younger, always ride properly restrained for their age and size.

- If you must install a rearward facing child safety seat on the front passenger seat because of exceptional circumstances and the **PASSENGER AIR BAG OFF** light does not appear and stay on have the airbag system inspected by your Audi dealer.
- A tight tether or other strap on a rearward-facing child restraint attached to the front passenger seat can put too much pressure on the weight-sensing mat in the seat and register more weight than is actually on the seat. The heavier weight registered can make the system work as though an adult were on the seat and deploy the Advanced Airbag when it must be suppressed causing serious or even fatal injury to the child.
- If, in exceptional circumstances, you must install a forward-facing child restraint on the front passenger seat, always move the seat into its rearmost position in the seat's fore and aft adjustment range, as far away from the airbag as possible. The backrest must be adjusted to an upright position. Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.

WARNING

- If the **PASSENGER AIR BAG OFF** light does not go out when an adult is sitting on the front passenger seat after taking the steps described above, have the airbag system inspected by your Audi dealer before transporting anyone on the front passenger seat.

Tips

If the weight-sensing mat in the front passenger seat detects an empty seat, the front airbag on the passenger side will be turned off, and **PASSENGER AIR BAG OFF** will stay on.

Repair, care and disposal of the airbags

Parts of the airbag system are installed at many different places on your Audi. Installing, removing, servicing or repairing a part in an area of the ►

vehicle can damage a part of an airbag system and prevent that system from working properly in a collision.

There are some important things you have to know to make sure that the effectiveness of the system will not be impaired and that discarded components do not cause injury or pollute the environment.

WARNING

Improper care, servicing and repair procedures can increase the risk of personal injury and death by preventing an airbag from deploying when needed or deploying an airbag unexpectedly:

- Never cover, obstruct, or change the steering wheel horn pad or airbag cover or the instrument panel or modify them in any way.
- Never attach any objects such as cup holders or telephone mountings to the surfaces covering the airbag units.
- For cleaning the horn pad or instrument panel, use only a soft, dry cloth or one moistened with plain water. Solvents or cleaners could damage the airbag cover or change the stiffness or strength of the material so that the airbag cannot deploy and protect properly.
- Never repair, adjust, or change any parts of the airbag system.
- All work on the steering wheel, instrument panel, front seats or electrical system (including the installation of audio equipment, cellular telephones and CB radios, etc.) must be performed by a qualified technician who has the training and special equipment necessary.
- For any work on the airbag system, we strongly recommend that you see your authorized Audi dealer or qualified workshop.
- Never modify the front bumper or parts of the vehicle body.
- Always make sure that the side airbag can inflate without interference:
 - Never install seat covers or replacement upholstery over the front seatbacks that

have not been specifically approved by Audi.

- Never use additional seat cushions that cover the areas where the side airbags inflate.
- Damage to the original seat covers or to the seam in the area of the side airbag module must always be repaired immediately by an authorized Audi dealer.
- The airbag system can be activated only once. After an airbag has inflated, it must be replaced by an authorized Audi dealer or qualified technician who has the technical information, training and special equipment necessary.
- The airbag system can be deployed only once. After an airbag has been deployed, it must be replaced with new replacement parts designed and approved especially for your Audi model version. Replacement of complete airbag systems or airbag components must be performed by qualified workshops only. Make sure that any airbag service action is entered in your Audi Warranty & Maintenance booklet under *AIRBAG REPLACEMENT RECORD*.
- For safety reasons in severe accidents, the alternator and starter are separated from the vehicle battery with a pyrotechnic circuit interrupter.
 - Work on the pyrotechnic circuit interrupter must only be performed by a qualified dealer - risk of an accident!
 - If the vehicle or the circuit interrupter is scrapped, all applicable safety precautions must be followed.



For the sake of the environment

Undeployed airbag modules and pretensioners might be classified as Perchlorate Material -special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate. When the vehicle or parts of the restraint system including airbag modules and safety belts with pretensioners are scrapped, all applicable laws and regulations must be

observed. Your authorized Audi dealer is familiar with these requirements and we recommend that you have your dealer perform this service for you.

Other things that can affect Advanced Airbag performance

Changing the vehicle's suspension system can change the way that the Advanced Airbag System performs in a crash. For example, using tire-rim combinations not approved by Audi, lowering the vehicle, changing the stiffness of the suspension, including the springs, suspension struts, shock absorbers etc. can change the forces that are measured by the airbag sensors and sent to the electronic control unit. Some suspension changes can, for example, increase the force levels measured by the sensors and make the airbag system deploy in crashes in which it would not deploy if the changes had not been made. Other kinds of changes may reduce the force levels measured by the sensors and prevent the airbag from deploying when it should.

WARNING

Changing the vehicle's suspension including use of unapproved tire-rim combinations can change Advanced Airbag performance and increase the risk of serious personal injury in a crash.

- Never install suspension components that do not have the same performance characteristics as the components originally installed on your vehicle.
- Never use tire-rim combinations that have not been approved by Audi.

WARNING

Items stored between the safety belt buckle and the center console can cause the sensors in the buckle to send the wrong information to the electronic control module and prevent the Advanced Airbag System from working properly.

- Always make sure that nothing can interfere with the safety belt buckles and that they are not obstructed.

Knee airbags

Description of knee airbags

The knee airbag system can provide supplemental protection to properly restrained front seat occupants.




Fig. 119 Driver's airbag

The driver knee airbag is in the instrument panel underneath the steering wheel ⇒ *fig. 119*, the airbag for the passenger is at about the same height in the instrument panel underneath the glove compartment.

The knee airbag offers additional protection to the driver's and passenger's knees lower thigh areas as a supplement to the protection by the safety belts.

If the front airbags deploy, the knee airbags also deploy in frontal collisions when the deployment threshold stored in the control unit is met ⇒ *page 110, More important things to know about front airbags.*

In addition to their normal safety function, safety belts help keeping the driver or front passenger in position in a frontal collision so that the airbags can provide supplemental protection.

The airbag system is not a substitute for your safety belt. Rather, it is part of the overall occupant restraint system in your vehicle. Always remember that the airbag system can only help to protect you if you are wearing your safety belt and wearing it properly. This is why you should always wear your safety belt, not just because the law requires you to do so ⇒ *page 95, General notes.*

Remember too, airbags will deploy only once and only in certain kinds of accidents - your safety belts are always there to offer protection in those accidents in which airbags are not supposed to deploy or when they have already deployed, for example when your vehicle strikes or is struck by another after the first collision.

This is just one of the reasons why an airbag is not a substitute for the safety belt. The airbag system works most effectively when used with the safety belts. Therefore, always wear your safety belts correctly.

It is important to remember that while the supplemental knee airbag system is designed to reduce the likelihood of serious injuries, other injuries, for example, swelling, bruising, minor abrasions and friction burns can also occur when an airbag inflates.

The knee airbag system basically consists of:

- The electronic control module
- Two inflatable airbags (airbag and gas generator), one for the driver and one for the front passenger
- The airbag indicator light in the instrument panel

The knee airbag system will not deploy:

- when the ignition is turned off
- in frontal collisions when the deceleration measured by the control unit is too low
- in side collisions
- in rear-end collisions
- in rollovers
- in the event of a system malfunction (warning/indicator light is on) ⇒ *page 13*.

WARNING

- Safety belts and the airbag system can only provide protection when occupants are in the proper seating position ⇒ *page 110*.
- If the airbag indicator light comes on when the vehicle is being used, have the system inspected immediately by your authorized Audi dealer.

How knee airbags work

The risk of injury to the leg area can be reduced by fully deployed knee airbags.



Fig. 120 Inflated airbags protecting in a frontal collision

The knee airbag system has been designed so that the airbags for the driver and front passenger deploy in certain but not all frontal collisions.

If the front airbags deploy, the knee airbags also deploy in frontal collisions when the deployment threshold stored in the control unit is met.

When the system deploys fill the airbags with a propellant gas, and inflate between the lower part of the instrument panel and the driver and the lower part of the instrument panel and the front passenger ⇒ *page 110, fig. 117*.

Although they are not a soft pillow, they can “cushion” the impact and in this way they can help to reduce the risk of injury to the lower extremities.

All of this takes place in the blink of an eye, so fast that many people don't even realize that the airbags have deployed. The airbags also inflate with a great deal of force and it is important for occupant safety that nothing should be in their way when they deploy.

Fully inflated airbags in combination with properly worn safety belts slow down and limit the occupant's forward movement and help to reduce the risk of injury.

Important safety instructions on the knee airbag system

Airbags are only supplemental restraints. Always wear safety belts correctly and ride in a proper seating position.

There is a lot that you and your passenger must know and do to help the safety belts and airbags to provide supplemental protection.

WARNING

An inflating knee airbag can cause serious injury. Wearing safety belts incorrectly and improper seating positions increase the risk of serious personal injury and death whenever a vehicle is being used.

- The knee airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and the front passenger keep their upper bodies and knees at the following minimum safe distances:
 - at least 10 inches (25 cm) between the chest and the steering wheel/instrument panel.
 - at least 4 inches (10 cm) between the knees and the lower part of the instrument panel.
- The risk of personal injury increases if you lean forward or to the side, or if the seat is improperly positioned and you are not wearing your safety belt. The risk increases even more should the airbag deploy.
- Always make sure that the knee airbag can inflate without interference. Objects between you and the airbag can increase the risk of injury in an accident by interfering with the way the airbag deploys or by being pushed into you as the airbag deploys.
- Never let anybody, especially children or animals in the footwell in front of the passenger seat. If the airbag deploys, this can result in serious or fatal injuries.
- No objects of any kind should be carried in the footwell area in front of the driver's or passenger's seat. Bulky objects (shopping

bags, for example) can hamper or prevent proper deployment of the airbag. Small objects can be thrown through the vehicle if the airbag deploys and injure you or your passengers.

- Make sure there are no cracks, deep scratches or other damage in the area of the instrument panel where the knee airbags are located.
- If children are incorrectly seated, their risk of injury increases in a collision
⇒ page 122, *Child Safety*.

Side airbags

Description of side airbags

The airbag system can provide supplemental protection to properly restrained front seat occupants.



Fig. 121 Side airbag location in the driver's seat

The side airbags are located in the sides of the front seat backrests ⇒ *fig. 121* facing the doors. They are identified by the word "AIRBAG".

The side airbag system basically consists of:

- the electronic control module and external side impact sensors
- the two side airbags located in the sides of the front backrests
- the airbag warning light in the instrument cluster.

The airbag system is monitored electronically to make certain that it is functioning properly at all times. Each time you turn on the ignition, the airbag system indicator light will come on for a few seconds (self diagnostics).

The side airbag system supplements the safety belts and can help to reduce the risk of injury to the driver's and front passenger's upper torso and head injuries on the side of the vehicle that is struck in a side collision. The airbag deploys in side impacts and only when the vehicle acceleration registered by the control unit is high enough. If this rate is below the reference value programmed into the control unit, the side airbags will not be triggered, even though the car may be badly damaged as a result of the collision. It is not possible to define an airbag triggering range that will cover every possible angle of impact, since the circumstances will vary considerably between one collision and another. Important factors include, for example, the nature (hard or soft) of the impacting object, the angle of impact, vehicle speed, etc. ⇒ *page 120, Important safety instructions on the side airbag system.*

Aside from their normal safety function, safety belts work to help keep the driver or front passenger in position in the event of a side collision so that the side airbags can provide protection.

The airbag system is *not* a substitute for your safety belt. Rather, it is part of the overall occupant restraint system in your vehicle. Always remember that the side airbag system can only help to protect you if you are wearing your safety belt and wearing it properly. This is another reason why you should always wear your safety belts, not just because the law requires you to do so ⇒ *page 95, General notes.*

It is important to remember that while the supplemental side airbag system is designed to reduce the likelihood of serious injuries, other injuries, for example, swelling, bruising, and minor abrasions can also be associated with deployed side airbags. Remember too, side airbags will deploy only once and only in certain kinds of accidents - your safety belts are always there to offer protection.

Vehicle damage, repair costs or even the lack of vehicle damage are not necessarily an indication of over-sensitive or failed airbag activation. In some collisions, both front and side airbags may inflate. Remember too, that airbags will deploy only once and only in certain kinds of collisions -

your safety belts are always there to offer protection in those accidents in which airbags are not supposed to deploy or when they have already deployed.

The side airbag system will not deploy:

- when the ignition is turned off
- in side collisions when the acceleration measured by the sensor is too low
- in rear-end collisions
- in rollovers.

In some types of accidents the front airbags and side airbags may be triggered together.



WARNING

- Safety belts and the airbag system will only provide protection when occupants are in the proper seating position ⇒ *page 120.*
- If the airbag indicator light comes on when the vehicle is being used, have the system inspected immediately by your authorized Audi dealer. The airbag may not work properly when the vehicle acceleration in a side collision is high enough to activate the airbag.

How supplemental side airbags work

Side airbags deploy instantly and can help reduce the risk of upper torso injuries for occupants who are properly restrained.




Fig. 122 Inflated side airbags on left side of vehicle

When the system is triggered, the airbag is filled with propellant gas and breaks through a seam in the seat surface area marked "AIRBAG". It expands between the side trim panel and the passenger. In order to help provide this additional

protection, the side airbag must inflate within a fraction of a second at very high speed and with great force. The supplemental side airbag could injure you if your seating position is not proper or upright or if items are located in the area where the supplemental side airbag expands. This applies especially to children ⇒ *page 122, Child Safety*. Supplemental side airbags inflate between the occupant and the door panel on the side of the vehicle that is struck in certain side collision ⇒ *fig. 122*.

Although they are not a soft pillow, they can “cushion” the impact and in this way they can help to reduce the risk of injury to the upper part of the body.

A fine dust may develop when the airbag deploys. This is normal and does not mean there is a fire in the vehicle.

Important safety instructions on the side airbag system

Airbags are only supplemental restraints. Always properly wear safety belts and ride in a proper seating position.

There is a lot that you and your passenger must know and act accordingly to help the safety belts and airbags do their job to provide supplemental protection.

WARNING

An inflating side airbag can cause serious or fatal injury. Improperly wearing safety belts and improper seating positions increase the risk of serious personal injury and death whenever a vehicle is being used.

- In order to reduce the risk of injury when the supplemental side airbag inflates:
 - Always sit in an upright position and never lean against the area where the supplemental side airbag is located.
 - Never let a child or anyone else rest their head against the side trim panel in the area where the supplemental side airbag inflates.
 - Always make sure that safety belts are worn correctly,

- Do not let anyone sitting in the front seat put their hand or any other parts of their body out of the window.
- Always make sure that the side airbag can inflate without interference.
 - Never install seat covers or replacement upholstery over the front seatbacks that have not been specifically approved by Audi.
 - Never use additional seat cushions that cover the areas where the side airbags deploy.
 - Damage to the original seat covers or to the seam in the area of the side airbag module must always be repaired immediately by an authorized Audi dealer.
- Objects between you and the airbag can increase the risk of injury in an accident by interfering with the way the airbag unfolds or by being pushed into you as the airbag inflates.
 - Never place or attach accessories or other objects (such as cup holders, telephone brackets, or even large, bulky objects) on the doors, over or near the area marked “AIRBAG” on the seat backrests.
 - Such objects and accessories can become dangerous projectiles and cause injury when the supplemental side airbag deploys.
 - Never carry any objects or pets in the deployment space between them and the airbags or allow children or other passengers to travel in this position.
- Always prevent the side airbags from being damaged by heavy objects knocking against or hitting the sides of the seatbacks.
- The airbag system can only be triggered once. If the airbag has been triggered, the system must be replaced by an authorized Audi dealership.
- Damage (cracks, deep scratches etc.) to the original seat covers or to the seam in the area of the side airbag module must always be repaired immediately by an authorized Audi dealer.

- If children are seated improperly, their risk of injury increases in the case of an accident
⇒ *page 122, Child Safety.*
- Never attempt to modify any components of the airbag system in any way.
- In a side collision, side airbags will not function properly if sensors cannot correctly measure increasing air pressure inside the doors when air escapes through larger, unclosed openings in the door panel.
- Never drive with interior door trim panels removed.
- Never drive when parts have been removed from the inside door panel and the openings they leave have not been properly closed.
- Never drive when loudspeakers in the doors have been removed unless the speaker holes have been properly closed.
- Always make certain that openings are covered or filled if additional speakers or other equipment is installed in the inside door panels.
- Always have work on the doors done by an authorized Audi dealer or qualified workshop.

Child Safety

Important things to know

Introduction

The physical principles of what happens when your vehicle is in a crash apply also to children ⇒ *page 96, What happens to occupants not wearing safety belts?*. But unlike adults and teenagers, their muscles and bones are not fully developed. In many respects children are at greater risk of serious injury in crashes than adults.

Because children's bodies are not fully developed, they require restraint systems especially designed for their size, weight, and body structure. Many countries and all states of the United States and provinces of Canada have laws requiring the use of approved child restraint systems for infants and small children.

In a frontal crash at a speed of 20-35 mph (30-56 km/h) the forces acting on a 13-pound (6 kg) infant will be more than 20 times the weight of the child. This means the weight of the child would suddenly be more than 260 pounds (120 kg). Under these conditions, only an appropriate child restraint properly used can reduce the risk of serious injury. Child restraints, like adult safety belts, must be used properly to be effective. Used improperly, they can increase the risk of serious injury in an accident.

Consult the child safety seat manufacturer's instructions in order to be sure the seat is right for your child's size ⇒ *page 125, Important safety instructions for using child safety seats*. Please be sure to read and heed all of the important information and WARNINGS about child safety, Advanced Airbags, and the installation of child restraints in this chapter.

There is a lot you need to know about the Advanced Airbags in your vehicle and how they work when infants and children in child restraints are on the front passenger seat. Because of the large amount of important information, we cannot repeat it all here. We urge you to read the detailed

information in this owner's manual about airbags and the Advanced Airbag System in your vehicle and the very important information about transporting children on the front passenger seat. Please be sure to heed the WARNINGS - they are extremely important for your safety and the safety of your passengers, especially infants and small children.

**WARNING**

All vehicle occupants and especially children must be restrained properly whenever riding in a vehicle. An unrestrained or improperly restrained child could be injured by striking the interior or by being ejected from the vehicle during a sudden maneuver or impact. An unrestrained or improperly restrained child is also at greater risk of injury or death through contact with an inflating airbag.

**WARNING**

Children on the front seat of any car even with Advanced Airbags can be seriously injured or even killed when an airbag inflates. A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates.

- The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on, have the airbag system inspected immediately by your Audi dealer.

**WARNING**

If, in exceptional circumstances, you must install a forward-facing child restraint on the front passenger's seat:

- Always make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.
- Always follow the manufacturer's instructions provided with the child safety seat or carrier.
- Always move the passenger seat into its rearmost position in the seat's fore and aft adjustment range, as far away from the airbag as possible before installing the child restraint. The backrest must be adjusted to an upright position.
- Always make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.

Tips

Always replace child restraints that were installed in a vehicle during a crash. Damage to a child restraint that is not visible could cause it to fail in another collision situation.

Advanced front airbag system and children

Your vehicle is equipped with an “Advanced Airbag System” in compliance with United States Federal Motor Vehicle Safety Standard (FMVSS) 208 as applicable at the time your vehicle was manufactured.

The Advanced Airbag system in your vehicle has been certified to meet the “low-risk” requirements for 3- and 6- year-old children on the passenger side and small adults on the driver side. The low risk deployment criteria are intended to reduce the risk of injury through interaction with the airbag that can occur, for example, by being too close to the steering wheel and instrument panel when the airbag inflates. In addition, the system has been certified to comply with the “suppression” requirements of the Safety Standard, to turn off the front airbag for infants up to 12 months who are restrained on the front passenger seat in child restraints that are listed in the Standard.

Even though your vehicle is equipped with an Advanced Airbag system, a child should always ride

in the seat properly restrained for its age and size. The airbag on the passenger side makes the front seat a potentially dangerous place for a child to ride. The front seat is not the safest place for a child in a forward-facing child safety seat. It can be a very dangerous place for an infant or a larger child in a rearward-facing seat.

Advanced Airbags and the weight-sensing mat in the front seat

The Advanced Airbag System in your vehicle detects the presence of an infant or child in a child restraint on the front passenger seat using the weight-sensing mat in the seat cushion and the sensor below the safety belt latch on the front passenger seat that measures the tension on the safety belt.

The weight-sensing mat measures total weight of the child and the child safety seat and a child blanket on the front passenger seat. The weight on the front passenger seat is related to the design of the child restraint and its “footprint”, the size and shape of the bottom of the child restraint as it sits on the seat. The weight of a child restraint and its “footprint” vary for different kinds of child restraints and for the different models of the same kind of child restraint offered by child restraint manufacturers.

The weight ranges for the individual types, makes and models of child restraints that the NHTSA has specified in the Safety Standard together with the weight ranges of typical infants and typical 1 year-old child have been stored in the control unit of the Advanced Airbag System. When a child restraint is being used on the front passenger seat with a typical 1 year-old child, the Advanced Airbag System compares the weight measured by the weight sensing mat with the information stored in the electronic control unit.

The electronic control unit also registers the tension on the front passenger safety belt. The tension on the safety belt for the front passenger seat will be different for an adult who is properly using the safety belt as compared to the tension on the belt when it is used to attach a child restraint to the seat. The sensor below the latch for ►

the safety belt for the front seat passenger measures the tension on the belt. The input from this sensor is then used with the weight to “decide”, whether there is a child restraint with a typical 1 year-old child on the front passenger seat and whether or not the airbag must be turned off.

Child restraints and Advanced Airbags

Regardless of the child restraint that you use, make sure that it has been certified to meet United States Federal Motor Vehicle Safety Standards and has been certified by its manufacturer for use with an airbag. If in exceptional circumstances you must use it on the front passenger seat, carefully read all of the information on child safety and Advanced Airbags and heed all of the applicable WARNINGS. Make certain that the child restraint is correctly recognized by the weight-sensing mat inside the front passenger seat, that the front passenger airbag is turned off and that the airbag status is always correctly signaled by the **PASSENGER AIR BAG OFF** light.

Many types and models of child restraints have been available over the years, new models are introduced regularly incorporating new and improved designs and older models are taken out of production. Child restraints are not standardized. Child restraints of the same type typically have different weights and sizes and different 'footprints,' the size and shape of the bottom of the child restraint that sits on the seat, when they are installed on a vehicle seat. These differences make it virtually impossible to certify compliance with the requirements for advanced airbags with each and every child restraint that has ever been sold in the past or will be sold over the course of the useful life of your vehicle.

For this reason, the United States National Highway Traffic Safety Administration has published a list of specific type, makes and models of child restraints that must be used to certify compliance of the Advanced Airbag System in your vehicle with the suppression requirements of Federal Motor Vehicle Safety Standard 208. These child restraints are:

Subpart A – Car bed child restraints

Model	Manufactured on or after
Angel Guard Angel Ride AA2403FOF	September 25, 2007

Subpart B – Rear-facing child restraints

Model	Manufactured on or after
Century SmartFit 4543	December 1, 1999
Cosco Arriva 22-013PAW and base 22-999WHO	September 25, 2007
Evenflo Discovery Adjust Right 212	December 1, 1999
Evenflo First Choice 204	December 1, 1999
Graco Infant 8457	December 1, 1999
Graco Snugride	September 25, 2007
Peg Perego Primo Viaggio SIP IMUN00US	September 25, 2007

Subpart C – Forward-facing and convertible child restraints

Model	Manufactured on or after
Britax Roundabout E9L02xx	September 25, 2007
Cosco Touriva 02519	December 1, 1999
Cosco Summit Deluxe High Back Booster 22-262	September 25, 2007
Cosco High Back Booster 22-209	September 25, 2007
Evenflo Tribute V 379xxxx	September 25, 2007
Evenflo Medallion 254	December 1, 1999
Evenflo Generations 352xxxx	September 25, 2007
Graco ComfortSport	September 25, 2007
Graco Toddler Safety Seat Step 2	September 25, 2007
Graco Platinum Cargo	September 25, 2007

WARNING

To reduce the risk of serious injury, make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on whenever a child restraint is installed on the front passenger seat and the ignition is switched on.

- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.

Tips

The child seats listed in categories A to C have been statically tested by Audi only for the Advanced Airbag function.

Important safety instructions for using child safety seats

Correct use of child safety seats substantially reduces the risk of injury in an accident!

As the driver, you are responsible for the safety of everybody in the vehicle, especially children:

- ▶ Always use the right child safety seat for each child and always use it properly ⇒ *page 127*.
- ▶ Always carefully follow the child safety seat manufacturer's instructions on how to route the safety belt properly through the child safety seat.
- ▶ When using the vehicle safety belt to install a child safety seat, you must first activate the convertible locking retractor on the safety belt to prevent the child safety seat from moving ⇒ *page 130*.
- ▶ Push the child safety seat down with your full weight to get the safety belt really tight so that the seat cannot move forward or sideways more than one inch (2.5 cm).
- ▶ If a strap or tether is being used to tie the child safety seat to the front passenger seat, make

sure that it is not so tight that it causes the weight-sensing mat to measure more weight than is actually on the seat.

Always remember: Even though your vehicle is equipped with an Advanced Airbag system, a child should always ride in the seat properly restrained for its age and size.

WARNING

Not using a child safety seat, using the wrong child safety seat or improperly installing a child restraint increases the risk of serious personal injury and death.

- All vehicle occupants and especially children must always be restrained properly whenever riding in a vehicle.
- An unrestrained or improperly restrained child can be injured or killed by being thrown against the inside of the vehicle or by being ejected from it during a sudden maneuver or impact.
- An unrestrained or improperly restrained child is at much greater risk of injury or death by being struck by an inflating airbag.
- Commercially available child safety seats are required to comply with U.S. Federal Motor Vehicle Safety Standard (FMVSS) 213 (in Canada CMVSS 213).
- When buying a child restraint, select one that fits your child and the vehicle.
- Only use child restraint systems that fully contact the flat portion of the seat cushion. The child restraint must not tip or lean to either side. Audi does not recommend using child safety seats that rest on legs or tube-like frames. They do not provide adequate contact with the seat.
- Always heed all legal requirements pertaining to the installation and use of child safety seats and carefully follow the instructions provided by the manufacturer of the seat you are using.
- Never let more than one child occupy a child safety seat.

- Never let babies or older children ride in a vehicle while sitting on the lap of another passenger.
- Holding a child in your arms is never a substitute for a child restraint system.
- The strongest person could not hold the child with the forces that exist in an accident. The child will strike the interior of the vehicle and can also be struck by the passenger.
- The child and the passenger can also injure each other in an accident.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.
- Forward-facing child safety seats installed on the front passenger's seat can interfere with the airbag when it inflates and cause serious injury to the child.
- If exceptional circumstances require the use of a forward-facing child restraint on the front passenger's seat, the child's safety and well-being require that the following special precautions be taken:
 - Make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.
 - Always carefully follow the manufacturer's instructions provided with the child safety seat or carrier.
 - Always move the front passenger seat into the rearmost position of the passenger seat's fore and aft adjustment range, and as far away from the airbag as possible before installing the child restraint.
 - Always make sure that nothing prevents the front passenger's seat from being moved to the rearmost position in its fore and aft adjustment range.

- Always make sure that the backrest is in the upright position.
- Always buckle the child safety seat firmly in place even if a child is not sitting in it. A loose child safety seat can fly around during a sudden stop or in a collision.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 95, Safety belts*, ⇒ *page 102, Airbag system* and ⇒ *page 122, Child Safety*.



WARNING

To reduce the risk of serious injury, make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on whenever a child restraint is installed on the front passenger seat and the ignition is switched on.

- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.

Child safety seats

Infant seats

Babies and infants up to about one year old and 20 lbs. or 9 kg need special rearward-facing child restraints that support the back, neck and head in a crash.



Fig. 123 Rearward-facing infant seat, properly installed on the passenger seat

- ▶ When using the vehicle safety belt to install a child safety seat, you must first activate the convertible locking retractor on the safety belt to prevent the child safety seat from moving ⇒ *page 130*.
- ▶ Push the child safety seat down with your full weight to get the safety belt really tight so that the seat cannot move forward or sideways more than one inch (2.5 cm).

Infants up to about one year (20 lbs. or 9 kg) are best protected in special infant carriers and child safety seats designed for their age group. Many experts believe that infants and small children should ride only in special restraints in which the child faces the back of the vehicle. These infant seats support the baby's back, neck and head in a crash ⇒ *fig. 123*.

WARNING

Not using a child safety seat, using the wrong child safety seat or improperly installing a child restraint increases the risk of serious personal injury and death in a crash.

- Never install a rear-facing child restraint in the forward-facing direction. Such restraints are designed for the special needs of infants and very small children and cannot protect them properly if the seat is forward-facing.

- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your authorized Audi dealer.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 95, Safety belts*, ⇒ *page 102, Airbag system* and ⇒ *page 122, Important things to know*.

Convertible child safety seats

Properly used convertible child safety seats can help protect toddlers and children over age one who weigh between 20 and 40 lbs. (9 and 18 kg) in a crash.




Fig. 124 Schematic overview: installation of the seat using the vehicle's safety belt system

- ▶ When using the vehicle safety belt to install a child safety seat, you must first activate the convertible locking retractor on the safety belt to prevent the child safety seat from moving ⇒ *page 130*.
- ▶ Push the child safety seat down with your full weight to get the safety belt really tight so that the seat cannot move forward or sideways more than one inch (2.5 cm) ⇒ *page 130*.

A toddler or child is usually too large for an infant restraint if it is more than one year old and weighs more than 20 lbs. (9 kg).

Toddlers and children who are older than one year up to about 4 years old and weigh more than 20 lbs. (9 kg) up to 40 lbs. (18 kg) must always be properly restrained in a child safety seat certified for their size and weight ⇒ *fig. 124*.

WARNING

Not using a child safety seat, using the wrong child safety seat or improperly installing a child restraint increases the risk of serious personal injury and death in a collision or other emergency situation.

- Children on the front seat of any car, even with Advanced Airbags, can be seriously injured or even killed when an airbag inflates. A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates – even with an Advanced Airbag System.
- The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on have the airbag system inspected immediately by your authorized Audi dealer.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 95, Safety belts*, ⇒ *page 102, Airbag system* and ⇒ *page 122, Important things to know*.

WARNING

If exceptional circumstances require the use of a forward-facing child restraint on the front passenger's seat, the child's safety and well-being require that the following special precautions be taken:

- Make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.

- Always follow the manufacturer's instructions provided with the child safety seat or infant carrier.
- Always move the front passenger seat into the rearmost position of the passenger seat's fore and aft adjustment range, and as far away from the airbag as possible before installing the child restraint.
- Always make sure that nothing prevents the front passenger's seat from being moved to the rearmost position in its fore and aft adjustment range.
- Always make sure the backrest is in an upright position.
- Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.
- If the light does not stay on, perform the checks .
- If the **PASSENGER AIR BAG OFF** light does not come on and stay on have the airbag system inspected immediately by your Audi dealer.

Booster seats and safety belts

Properly used booster seats can help protect children weighing between about 40 lbs. and 80 lbs. (18 kg and 36 kg) who are less than 4 ft. 9 in. (57 inches/1.45 meters) tall.



Fig. 125 Passenger seat: child properly restrained in a booster seat.

The vehicle's safety belts alone will not fit most children until they are at least 4 ft. 9 in. (57 inches/1.45 meters) tall and weigh about 80 lbs. (36 kg). Booster seats raise these children up so that the safety belt will pass properly over the

stronger parts of their bodies and the safety belt can help protect them in a crash.

- ▶ Do not use the convertible locking retractor when using the vehicle's safety belt to restrain a child on a booster seat.
- ▶ The shoulder belt must lie as close to the center of the child's collar bone as possible and must lie and snug on the upper body. It must never lie across the throat or neck. The lap belt must lie across the pelvis and never across the stomach or abdomen. Make sure the belt lies flat and snug. Pull on the belt to tighten if necessary.

Children up to at least 8 years old (over 40 lbs. or 18 kg) are best protected in child safety seats designed for their age and weight. Experts say that the skeletal structure, particularly the pelvis, of these children is not fully developed, and they must not use the vehicle safety belts without a suitable child restraint.

It is usually best to put these children in appropriate booster seats. Be sure the booster seat meets all applicable safety standards.

Booster seats raise the seating position of the child and reposition both the lap and shoulder parts of the safety belt so that they pass across the child's body in the right places. The routing of the belt over the child's body is very important for the child's protection, whether or not a booster seat is used.

Children who are at least 4 ft. 9 in. (57 inches/ 1.45 meters) tall can generally use the vehicle's three point lap and shoulder belts. Never use the lap belt portion of the vehicle's safety belt alone to restrain any child, regardless of how big the child is. Always remember that children do not have the pronounced pelvic structure required for the proper function of lap belt portion of the vehicle's three point lap and shoulder belts. The child's safety absolutely requires that a lap belt portion of the safety belt be fastened snugly and as low as possible around the pelvis. Never let the lap belt portion of the safety belt pass over the child's stomach or abdomen.

In a crash, airbags must inflate within a blink of an eye and with considerable force. In order to do

its job, the airbag needs room to inflate so that it will be there to protect the occupant as the occupant moves forward into the airbag.

A vehicle occupant who is out of position and too close to the airbag gets in the way of an inflating airbag. When an occupant is too close, he or she will be struck violently and will receive serious or possibly even fatal injury.

In order for the airbag to offer protection, it is important that all vehicle occupants, especially any children, who must be in the front seat because of exceptional circumstances, be properly restrained and as far away from the airbag as possible. By keeping room between the child's body and the front of the passenger compartment, the airbag can inflate completely and provide supplemental protection in certain frontal collisions.



WARNING

Not using a booster seat, using the booster seat improperly, incorrectly installing a booster seat or using the vehicle safety belt improperly increases the risk of serious personal injury and death in a collision or other emergency situation. To help reduce the risk of serious personal injury and/or death:

- The shoulder belt must lie as close to the center of the child's collar bone as possible and must lie and snug on the upper body. It must never lie across the throat or neck. The lap belt must lie across the pelvis and never across the stomach or abdomen. Make sure the belt lies flat and snug. Pull on the belt to tighten if necessary.
- Failure to properly route safety belts over a child's body will cause severe injuries in an accident or other emergency situation ⇒ *page 95*.
- Children on the front seat of any car, even with Advanced Airbags, can be seriously injured or even killed when an airbag inflates.
- Never let a child stand or kneel on the seat.
- Never let a child ride in the cargo area of your vehicle.
- Always remember that a child leaning forward, sitting sideways or out of position in

any way during an accident can be struck by a deploying airbag. This will result in serious personal injury or death.

- If you must install a booster seat on the front passenger seat because of exceptional circumstances the **PASSENGER AIR BAG OFF** light must come on and stay on, whenever the ignition is switched on.
- If the **PASSENGER AIR BAG OFF** light does not come on and stay on, perform the checks described .
- If the **PASSENGER AIR BAG OFF** light does not come on and stay on whenever the ignition is switched on the inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your Audi dealer.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 95, Safety belts*, ⇒ *page 102, Airbag system* and ⇒ *page 122, Important things to know*.

Installing a child safety seat

Securing a child safety seat using a safety belt

Safety belts for the front passenger can be locked with the convertible locking retractor to properly secure child safety seats.

The safety belts emergency locking retractors for the front passenger's seat safety belt have a convertible locking retractor for child restraints. The safety belt must be locked so that belt webbing cannot unreel. The retractor can be activated to lock the safety belt and prevent the safety belt webbing from loosening up during normal driving. A child safety seat can only be properly installed when the safety belt is locked so that the child and child safety seat will stay in place.

Always remember: Even though your vehicle is equipped with an Advanced Airbag system, a child should always ride in the seat properly restrained for its age and size.



WARNING

Improperly installed child safety seats increase the risk of serious personal injury and death in a collision.

- Always make sure that the safety belt retractor is locked when installing a child safety seat. An unlocked safety belt retractor cannot hold the child safety seat in place during normal driving or in a crash.
- Always buckle the child safety seat firmly in place even if a child is not sitting in it. A loose child safety seat can fly around during a sudden stop or in a collision.
- The inflating airbag will hit the child safety seat or infant carrier with great force and will smash the child safety seat and child against the backrest, door or roof.
- Forward-facing child safety seats or infant carriers installed on the front passenger's seat may interfere with the deployment of the airbag and cause serious injury to the child.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 122*. Special precautions apply when installing a child safety seat on the front passenger seat ⇒ *page 103, Child restraints on the front seat – some important things to know*.



WARNING

Always take special precautions if you must install a forward or rearward-facing child restraint on the front passenger's seat in exceptional situations:

- Whenever a forward or rearward-facing child restraint is installed on the front passenger seat, the **PASSENGER AIR BAG OFF** light must come on and stay on whenever the ignition is switched on.
- If the **PASSENGER AIR BAG OFF** light does not come on and stay on, perform the checks described .
- If the **PASSENGER AIR BAG OFF** light does not come on and stay on whenever the ignition is switched on the inflating airbag will hit the child safety seat or infant carrier

- with great force and will smash the child safety seat and child against the backrest, door or roof. Have the airbag system inspected immediately by your Audi dealer.
- Improper installation of child restraints can reduce their effectiveness or even prevent them from providing any protection.
 - An improperly installed child restraint can interfere with the airbag as it deploys and seriously injure or even kill the child.
 - Always carefully follow the manufacturer's instructions provided with the child safety seat or carrier.
 - Never place additional items on the seat that can increase the total weight registered by the weight-sensing mat and can cause injury in a crash.

WARNING

Forward-facing child restraints:

- Always make sure the forward-facing seat has been designed and certified by its manufacturer for use on a front seat with a passenger front and side airbag.
- Never put the forward-facing child restraint up, against or very near the instrument panel.
- Always move the passenger seat into its rearmost position in the seat's fore and aft adjustment range, as far away from the airbag as possible before installing the forward-facing child restraint. The backrest must be adjusted to an upright position.
- Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.

WARNING

Rearward-facing child restraints:

- A child in a rearward-facing child safety seat installed on the front passenger seat will be seriously injured and can be killed if the front airbag inflates - even with an Advanced Airbag System.
- The inflating airbag will hit the child safety seat or infant carrier with great force and

will smash the child safety seat and child against the backrest, door or roof.

- Always be especially careful if you must install a rearward facing child safety seat on the front passenger seat in exceptional circumstances.
- A tight tether strap on a rearward-facing child restraint attached to the front passenger seat can put too much pressure on the weight-mat in the seat and register a heavier weight in the Advanced Airbag System. The heavier weight registered can make the system work as though an adult were on the seat and deploy the Advanced Airbag when it must be suppressed causing serious or even fatal injury to the child.
- Make sure that the **PASSENGER AIR BAG OFF** light comes on and stays on all the time whenever the ignition is switched on.
- Never install a rearward facing child safety seat on the front passenger seat unless the **PASSENGER AIR BAG OFF** light comes on and stays on. If the **PASSENGER AIR BAG OFF** light does not come on and stay on have the airbag system inspected immediately by your Audi dealer.

Activating the convertible locking retractor

Use the convertible locking retractor to secure a child restraint.

Always heed the child safety seat manufacturer's instructions when installing a child restraint in your vehicle. To activate the convertible locking retractor:

- ▶ Place the child restraint on a seat.
- ▶ Slowly pull the belt **all the way out**.
- ▶ Route it around or through the child restraint belt path .
- ▶ Push the child safety seat down with your full weight to get the safety belt really tight.
- ▶ Insert the belt tongue into the buckle for that seating position.
- ▶ Guide the safety belt back into the retractor until the belt lies flat and snug on the child safety seat.

- ▶ You should hear a “clicking” noise as the belt winds back into the inertia reel. Test the convertible locking retractor by pulling on the belt. You should no longer be able to pull the belt out of the retractor. The convertible locking retractor is now activated.
- ▶ Make sure that the red release button is facing away from the child restraint so that it can be unbuckled quickly.
- ▶ Pull on the belt to make sure the safety belt is properly tight and fastened so that the seat cannot move forward or sideways more than one inch (2.5 cm).

WARNING

Using the wrong child restraint or an improperly installed child restraint can cause serious personal injury or death in a crash.

- Always make sure that the safety belt retractor is locked when installing a child safety seat. An unlocked safety belt retractor cannot hold the child safety seat in place during normal driving or in a crash.
- Always buckle the child safety seat firmly in place even if a child is not sitting in it. A loose child safety seat can fly around during a sudden stop or in a crash.
- Always make sure the seat backrest to which the child restraint is installed is in an upright position. Otherwise, the seatback with the child safety seat attached to it could fly forward in the event of an accident or other emergency situation.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 122*. Special precautions apply when installing a child safety seat on the front passenger seat ⇒ *page 103, Child restraints on the front seat – some important things to know*.

Deactivating the convertible locking retractor

The convertible locking retractor for child restraints will be deactivated automatically when the belt is wound all the way back into the retractor.

- ▶ Press the red button on the safety belt buckle. The belt tongue will pop out of the buckle.
- ▶ Guide the safety belt all the way back into its stowed position.

Always let the safety belt retract completely into its stowed position. The safety belt can now be used as an ordinary safety belt without the convertible locking retractor for child restraints.

If the convertible locking retractor should be activated inadvertently, the safety belt must be unfastened and guided completely back into its stowed position to deactivate this feature. If the convertible locking retractor is not deactivated, the safety belt will gradually become tighter and uncomfortable to wear.

WARNING

Improperly installed child safety seats increase the risk of serious personal injury and death in a collision.

- Never unfasten the safety belt to deactivate the convertible locking retractor for child restraints while the vehicle is moving. You would not be restrained and could be seriously injured in an accident.
- Always read and heed all WARNINGS whenever using a child restrained in a vehicle is being used ⇒ *page 122*. Special precautions apply when installing a child safety seat on the front passenger seat ⇒ *page 103, Child restraints on the front seat – some important things to know*.

Additional Information

Sources of information about child restraints and their use

There are a number of sources of additional information about child restraint selection, installation and use:

NHTSA advises that the best child safety seat is the one that fits your child and fits in your vehicle, and that you will use correctly and consistently.

Try before you buy!

U.S National Highway Traffic Safety Administration

Tel.: 1-888-327-4236 (TTY: 1-800-424-9153)

www.nhtsa.gov

National SAFE KIDS Campaign

Tel.: (202) 662-0600

www.safekids.org

Safety BeltSafe U.S.A

Tel.: (800) 745-SAFE (English)

Tel.: (800) 747-SANO (Spanish)

www.carseat.org

Transport Canada Information Centre

Tel.: 1 (800) 333-0371 or call 1 (613) 998-8616

if you are in the Ottawa area

<http://www.tc.gc.ca/eng/roadsafety/menu.htm>

Audi Customer Relations

Tel.: (800) 822-2834

Intelligent technology

Notice about data recorded by vehicle control modules

Your vehicle is not equipped with an Event Data Recorder (EDR), installed by some manufacturers for the express purpose of capturing data for retrieval after an accident or crash event. EDR's are sometimes called "crash recorders".

Some state laws restrict the retrieval or downloading of data stored by EDR's that were installed in a vehicle for the express purpose of retrieving data after an accident or crash event without the owner's consent.

Although your vehicle is not equipped with an EDR, it is equipped with a number of electronic control modules for various vehicle systems such as, for example, engine function, emission control, as well as for the airbags and safety belts.

These electronic control modules also record vehicle-related data during normal vehicle operation for diagnostic and repair purposes. The recording capacity of the electronic control modules is limited to data (no sound is recorded) and only a small amount of data is actually recorded over a very limited period of time and stored when a system fault or other condition is sensed by a control unit. Some of the data then stored may relate to vehicle speed, direction, braking as well as restraint system use and performance in the event of a crash or other condition. Stored data can only be read and downloaded with special equipment.

Electronic Stabilization Control (ESC)

Description

ESC helps to improve road holding and vehicle dynamics to help reduce the probability of skidding and loss of vehicle control. It works only when the engine is running. ESC detects certain difficult driving situations, including when the vehicle is beginning to spin (yaw) out of control and helps you to get the vehicle back under control by

selectively braking the wheels, and/or reducing engine power and providing steering assistance to help hold the vehicle on the driver's intended course. The indicator light  in the instrument cluster blinks when ESC is taking action to help you control the vehicle.

ESC has limitations. It is important to remember that ESC cannot overcome the laws of physics. It will not always be able to help out under all conditions you may come up against. For example, ESC may not always be able to help you master situations where there is a sudden change in the coefficient of friction of the road surface. When there is a section of dry road that is suddenly covered with water, slush or snow, ESC cannot perform the same way it would on the dry surface. If the vehicle hydroplanes (rides on a cushion of water instead of the road surface), ESC will not be able to help you steer the vehicle because contact with the pavement has been interrupted and the vehicle cannot be braked or steered. During fast cornering, particularly on winding roads, ESC cannot always deal as effectively with difficult driving situations as at lower speeds.

Always adjust your speed and driving style to road, traffic and weather conditions. ESC cannot override the vehicle's physical limits, increase the available traction, or keep a vehicle on the road if road departure is a result of driver inattention. Instead, ESC improves the possibility of keeping the vehicle under control and on the road during extreme maneuvers by using the driver's steering inputs to help keep the vehicle going in the intended direction. If you are traveling at a speed that causes you to run off the road before ESC can provide any assistance, you may not experience the benefits of ESC.

ESC includes and/or works together with the anti-lock brake system (ABS), brake assist system and anti-slip regulation (ASR). ESC is switched on all the time. In certain situations when you need less traction, you can switch off ESC by pressing the button . Be sure to switch ESC on again when you no longer need less traction. ►

Anti-lock braking system (ABS)

ABS prevents the wheels from locking up when braking. The vehicle can still be steered even during hard braking. Apply steady pressure to the brake pedal. Do not pump the pedal. A pulsing in the brake pedal indicates that the system is helping you to brake the vehicle.

Brake assist system

The brake assist system can decrease braking distance. It increases braking power when the driver presses the brake pedal quickly in emergency situations. You must press and hold the brake pedal until the situation is over.

Anti-slip regulation (ASR)

ASR reduces engine power when the drive wheels begin to spin and adapts the force to the road conditions. This makes it easier to start, accelerate and drive up hills.

Electronic differential lock (EDL)

The EDL brakes wheels that are spinning and transfers the drive power to the other drive wheel or wheels if the vehicle is equipped with all-wheel drive*. This function is available up to about 60 mph (100 km/h).

In extreme cases, EDL automatically switches off to help keep the brake on the braked wheel from overheating. EDL will switch on again automatically when conditions have returned to normal.

WARNING

- ESC, ABS, ASR and EDL cannot overcome the laws of physics. This is especially important on slippery or wet roads. If the systems begin acting to stabilize your vehicle, you should immediately change your speed to match the road and traffic conditions. Do not let the increased safety provided by these systems tempt you to take risks. Doing so will increase the risk of a loss of vehicle control, collision and serious personal injuries.
- Always adapt your speed to road, traffic and weather conditions. The risk of losing control of the vehicle increases when driving

too fast, especially through curves and on slippery or wet roads, and when driving too close to vehicles up ahead. ESC, ABS, the brake assist system, EDL and ASR cannot prevent collisions.

- Always accelerate with special care on even, smooth surfaces such as those that are wet or covered with ice and snow. The drive wheels can spin even with these assistance systems that cannot always help to reduce the risk of loss of vehicle control.

Tips

- ABS and ASR only work correctly when all four wheels are equipped with identical tires. Different tire sizes can lead to a reduction in engine power.
- You may hear noises when the systems described are working.
- If the indicator light  or **ABS** (USA models)/ (Canada models) appears, there may be a malfunction ⇒ [page 15](#), ⇒ [page 15](#).

Switching on/off

ESC turns on automatically when you start the engine.



Fig. 126 Center console with  button

ESC sport mode

In certain situations, it might make sense to allow some slip. For example:

- Rocking the vehicle to free it when it is stuck
- Driving in deep snow or on loose ground
- Driving with snow chains

Press the  button briefly ⇒ *fig. 126*. The  indicator light turns on and **Sport control Warning! Restricted stability** appears in the driver information system display. Driving stability is limited in sport mode.

Switching ESC off

Press and hold the  button for three seconds. The ESC indicator light  turns on and **Stabilization program off** appears in the display. ASR is also switched off when ESC is switched off.

Switching on

Press the  button again. The message **Stabilization program on** appears briefly in the display.

WARNING

You should only switch the ESC off if your driving ability and the traffic situation allow. This could increase the risk of slipping.

- The stabilizing function is limited in ESC sport mode. The driving wheels could spin and the vehicle could swerve, especially on slick or slippery road surfaces.
- There is no vehicle stabilization when ESC is switched off.

Tips

If there is a malfunction in the retractable rear spoiler* or the Audi magnetic ride*, it may not be possible to activate ESC sport mode or normal mode may activate again automatically.

Braking

What affects braking efficiency?

New brake pads

During the first 250 miles (400 km), new brake pads do not possess their full braking effect, they have to be “broken in” first ⇒ . The break-in period can be considerably longer for vehicles with ceramic brake rotors*. You can compensate for this slightly reduced braking power by pushing harder on the brake pedal. Avoid heavy braking loads during the break-in period.

Operating conditions and driving habits

The brakes on today’s automobiles are still subject to wear, depending largely on operating conditions and driving habits ⇒ . On vehicles that are either driven mostly in stop-and-go city traffic or are driven hard, the brake pads should be checked by your authorized Audi dealer more often than specified in the **Warranty & Maintenance booklet**. Failure to have your brake pads inspected can result in reduced brake performance.

On steep slopes, you should use the braking effect of the engine. This way, you prevent unnecessary wear on the brake system. If you must use your brakes, do not hold the brakes down continuously. Pump the brakes at intervals.

Operating noise

Noises may occur when braking depending on the speed, braking force and outside conditions such as temperature and humidity.

Due to the nature of the materials used in ceramic brake rotors*, noises may become more apparent at low speeds.

Effect of water and road salt

In certain situations, for example after driving through water, in heavy rain, after overnight condensation or after washing your car, the braking effect can be reduced by moisture or ice on the brake rotors and brake pads. The brakes must be dried first with a few careful brake applications.

At higher speeds and with the windshield wipers turned on, the brake pads press against the brake rotors for a short amount of time. This occurs at regular intervals without the driver noticing and provides for better brake response time under wet conditions.

The effectiveness of the brakes can be reduced when the vehicle is driven on a salt-covered road and the brakes are not used. Likewise, you clean off accumulated salt coating from brake discs and pads with a few cautious applications of the brake ⇒ .

Due to their surface characteristics, ceramic brake rotors* absorb moisture in such conditions. ►

This can cause a temporary reduction in braking force compared to dry brakes. You can compensate for this by pressing the brake pedal harder.

Corrosion

There may be a tendency for dirt to build up on the brake pads and corrosion to form on the discs if the car is not driven regularly or only for short trips with little use of the brakes.

If the brakes are not used frequently, or if corrosion has formed on the discs, it is advisable to clean off the pads and discs by braking firmly a few times from a moderately high speed ⇒ ⚠.

Faults in the brake system

If you should notice a *sudden* increase in brake pedal travel, then one of the two brake circuits may have failed ⇒ ⚠.

Low brake fluid level

Malfunctions can occur in the brake system if the brake fluid level is too low. The brake fluid level is monitored electronically.

Brake power assist unit

The brake power assist unit increases the pressure that you generate with the brake pedal. It works only when the engine is running.

Brake lining wear status

Brake lining wear may be checked by visual inspection of the condition of the brake pads through the openings in the wheel. If necessary, the wheel may be removed for this inspection ⇒ page 203.



WARNING

- New brake pads don't have the best stopping power and must be "broken-in" during the initial 250 miles (400 km) of normal city driving. The break-in period can be considerably longer for vehicles with ceramic brake rotors*. You can compensate for this by pressing the brake pedal more firmly. This also applies later when new pads are installed.
- You should perform braking maneuvers for the purpose of cleaning the brake system

only if road conditions permit. Other road users must not be put at risk - you may cause an accident!

- Before descending a steep grade, reduce speed and shift transmission into a lower gear or lower driving range. Do not ride the brakes or hold the pedal down too long or too often. This could cause the brakes to get hot and diminish braking efficiency.
- Do not "ride the brakes" by resting your foot on the pedal when you do not intend to brake. This may cause the brakes to overheat, premature wear and increased stopping distance.
- Under certain climatic and operating conditions such as passing through water, driving in heavy rain or after washing the vehicle, the effectiveness of the brakes can be reduced. In winter, ice can accumulate on the brake pads, linings, discs and drums. Carefully apply brakes for a test. Brakes will dry and ice coatings will be cleaned off after a few careful brake applications.
- Driving for an extended period of time on salt-covered roads without using your brakes can also affect braking efficiency. Clean off accumulated salt coating from brake discs and pads with a few cautious brake applications.
- If you damage the front spoiler, or if you install a different spoiler, be sure the air flow to the front brakes is not obstructed. Otherwise the brake system could overheat reducing the effectiveness of the entire brake system.
- Failure of one brake circuit will impair the braking capability resulting in an increased stopping distance. Avoid driving the vehicle and have it towed to the nearest Audi dealer or qualified workshop.
- Never let the vehicle roll to a stop with the engine shut off.
- If the brake booster is not working, for example when towing your vehicle, or because the brake booster has somehow been damaged, the brake pedal must be pressed considerably harder to make up for the lack of booster assistance.

Rear spoiler

The rear spoiler improves vehicle handling and enhances driver control.



Fig. 127 Switch for rear spoiler

The rear spoiler deploys and retracts. Spoiler operation can be set for automatic or manual operation.

Automatic mode (normal operation)

- Extending automatically: This occurs when driving faster than approximately 62 mph (100 km/h) or at a certain engine compartment temperature¹⁾.
- Retracting automatically: This occurs when driving slower than approximately 22 mph (35 km/h) or at a certain engine compartment temperature¹⁾.

Manual mode

- Extending manually: Press the switch ⇒ *fig. 127* briefly to extend the rear spoiler completely.
- Retracting manually: When driving at speeds below approximately 12 mph (20 km/h), press and hold the switch to retract the rear spoiler. When driving at speeds between 12 mph and 62 mph (20 km/h and 100 km/h), press the switch briefly to retract the rear spoiler completely. You cannot retract the rear spoiler if it extended due to the engine compartment temperature.

Indicator light

When the indicator light  appears, there is a system malfunction. The rear spoiler may not be able to extend. This could change the vehicle's driving characteristics at high speeds. Do not exceed 87 mph (140 km/h). Drive to your authorized Audi dealer immediately to have the malfunction corrected.



WARNING

Driving at higher speeds without the rear spoiler deployed can impair handling characteristics, making the vehicle harder to control.

- Improper operation of the rear spoiler can cause crushing injuries. Always make sure that nobody, especially children, is in the way when the rear spoiler is deployed or retracted.
- Always obey speed limits and other traffic laws.
- Hot air from the engine compartment can escape through the rear spoiler when it is open and it could burn you.



Note

- Never push the vehicle or apply force to the rear spoiler – it could be damaged.
- To prevent damage to the rear spoiler do not lean or place anything on it.
- Only operate the rear spoiler manually when the engine compartment lid is closed and the rear spoiler moving parts are not blocked. Otherwise, damage could occur.



Tips

Clean the spoiler compartment every 2 to 3 months. The spoiler compartment must always be free of ice, snow, leaves or other debris.

¹⁾ The rear spoiler only extends or retracts above a certain engine temperature in some models.

Power steering

When the engine is running, power steering makes it easier for the driver to steer.

Power steering helps the driver steer the vehicle with little physical effort.

If the engine is not running, the power steering system is also not working. In this case, you will find it extremely difficult to turn the steering wheel.

If you turn the steering *fully* to the left or right when the vehicle is stationary, you place a very heavy load on the power steering system. Turning the steering wheel fully to the left or right will cause noise in the system. It also reduces engine idle speed.

Note

Do not hold the steering turned fully to the left or right for more than 10 seconds when the engine is running. There is a risk of damage to the power steering system.

Tips

- In the event of a power steering system failure, or if the engine is not running (while being towed), you will still be able to steer the vehicle. However, you will require more effort to do so.
- If the power steering system has a leak or is defective, you should immediately contact a qualified workshop.
- The power steering system requires a special hydraulic fluid. The power steering fluid reservoir is located in the engine compartment. The correct hydraulic fluid level is important for proper operation of the power steering system. The power steering fluid level is checked according to the Audi maintenance service schedule.

Dry sump lubrication

High lateral and longitudinal forces affect the engine and the vehicle during sporty driving. Dry sump lubrication ensures that your engine is sup-

plied with oil and properly lubricated even under these conditions.

In a “normal” vehicle the oil pump sends the oil from the oil pan to the lubrication points in the engine. The oil then returns to the oil pan. In extreme situations, the oil pump may draw in air, which results in insufficient oil pressure.

With dry sump lubrication, the oil is not in the oil pan (it is “dry”), but in a separate oil tank. While one pump supplies the engine with oil, a second pump suctions the oil out of the engine and returns it to the oil tank. Because the oil tank is tall and narrow, oil pressure is constant even under extreme conditions.

In addition, the oil pan in vehicles with dry sump lubrication is noticeably shallower. This allows the engine to be installed lower in the vehicle, bringing down the center of gravity. This improves your vehicle's handling.

Driving with your quattro

With all-wheel drive, all four wheels are driven.

General information

With all-wheel drive, power is distributed to all four wheels. This happens automatically depending on your driving style and the road conditions at the time. See also ⇒ *page 134*.

The all-wheel drive concept is designed for high engine power. Your vehicle is exceptionally powerful and has excellent driving characteristics both under normal driving conditions and on snow and ice. Always read and follow safety precautions ⇒ .

Winter tires

When driving in the winter, your vehicle with all-wheel drive has an advantage, even with regular tires. In winter road conditions it may be advisable to mount winter tires (or all-season tires) for improved driveability and braking: these tires must be mounted on **all four wheels**. See also ⇒ *page 193, Winter tires*. ►

Snow chains

Where tire chains are mandatory on certain roads, this normally also applies to vehicles with all-wheel drive ⇒ *page 194, Snow chains*.

Replacing wheels/tires

Vehicles with all-wheel drive must always have tires of the same size. Also avoid tires with different tread depths. For details see page ⇒ *page 186, New tires and replacing tires and wheels*.

Off-Road driving?

Your Audi does not have enough ground clearance to be used as an off-road vehicle. It is therefore best to avoid rough tracks and uneven terrain as much as possible. Also refer to ⇒ *page 142*.

WARNING

- Always adjust your driving to road and traffic conditions. Do not let the extra safety afforded by all-wheel drive tempt you into taking extra risks.
- Although the all-wheel drive is very effective, always remember that braking capacity is limited by tire traction. You should therefore not drive at excessive speeds on icy or slippery road surfaces.
- On wet road surfaces, be careful not to drive too fast because the front wheels could begin to slide on top of the water (aquaplaning). If this should occur, you will have no warning from a sudden increase in engine speed as with a front-wheel drive vehicle. Always drive at speeds which are suited to the road conditions. – risk of crash.

Energy management

Starting ability is optimized

Energy management controls the distribution of electrical energy and thus optimizes the availability of electrical energy for starting the engine.

If a vehicle with a conventional energy system is not driven for a long period of time, the battery is discharged by idling current consumers (e.g.

immobilizer). In certain circumstances it can result in there being insufficient energy available to start the engine.

Intelligent energy management in your vehicle handles the distribution of electrical energy. Starting ability is markedly improved and the life of the battery is extended.

Basically, energy management consists of **battery diagnosis, idling current management** and **dynamic energy management**.

Battery diagnosis

Battery diagnosis continuously determines the state of the battery. Sensors determine battery voltage, battery current and battery temperature. This determines the current state of charge and the power of the battery.

Idling current management

Idling current management reduces energy consumption while the vehicle is standing. With the ignition switched off, it controls the energy supply to the various electrical components. Data from battery diagnosis is considered.

Depending on the battery's state of charge, individual consumers are gradually turned off to prevent excessive discharge of the battery and thus maintain starting capability.

Dynamic energy management

While the vehicle is being driven, dynamic energy management distributes the energy generated according to the needs of the individual components. It regulates consumption, so that more electrical energy is not being used than is being generated and ensures an optimal state of charge for the battery.

Tips

- But even energy management cannot negate the limits of physics. Consider that the power and life of a battery are limited.
- If starting ability is threatened, you are informed by a warning ⇒ *page 141, Driver notification in the instrument cluster display*.

What you should know

The highest priority is given to maintaining starting capability.

The battery is severely taxed in short-distance driving, in city traffic and during the cold time of year. Abundant electrical energy is required, but only a little is generated. It is also critical if the engine is not running and electrical components are turned on. In this instance energy is being consumed but none is being generated.

It is in precisely these situations that you will notice energy management actively regulating the distribution of energy.

Vehicle stands for an extended period

If you do not drive your vehicle over a period of several days or weeks, electrical components are gradually cut back or switched off. This reduces energy consumption and maintains starting capability over a longer period.

Take into consideration that when you unlock your vehicle, some convenience functions, such as the remote key or power seat adjustment, may not be available. The convenience functions will be available again when you turn on the ignition and start the engine.

With the engine turned off

If you listen to the radio, for example, with the engine turned off, the battery is being discharged.

If starting capability is jeopardized due to energy consumption, a message appears in the driver information display.

You have to start the engine to charge the battery.

With the engine running

Although electrical energy is generated when the vehicle is being driven, the battery can become discharged. This happens mostly when little energy is being generated and a great deal consumed and the battery's state of charge is not optimal.

To bring the energy balance back into equilibrium, consumers which require especially large amounts of energy are temporarily cut back or switched off. Heating systems in particular require a great deal of energy. If you notice, for example, that the heated seats* or the heated rear window are not heating, they have been temporarily cut back or switched off. These systems will be available again as soon as the energy balance has been restored.

You will also notice that engine idle speed has been increased slightly. This is normal and not a cause for concern. By increasing engine idle speed the additional energy required is generated and the battery is charged.

Driver notification in the instrument cluster display

If battery power drops into the range where it can limit the ability of the engine to start, this is shown in the instrument cluster display with the following driver message:

 **Low battery charge: battery will be charged while driving**

This notification reminds you that the starting capability of the engine may be limited. As soon as you start driving again, the battery will be recharged and the notification will go out.

Driver notification appears and goes out again

If this driver notification appears after the ignition is turned on or while driving and it goes out again after a while, the battery has been adequately recharged.

Driver notification appears and does not go out again

If this driver notification appears after the ignition is turned on or while driving and does not go out again, the battery's state of charge is not in the optimal range. Starting ability is restricted. Have the battery checked as soon as possible by an authorized Audi dealer or qualified workshop.

Driving and environment

Break-in period

A new vehicle must be broken in, and the break-in period should be 1,500 miles (2,500 km). Do not use full acceleration for the first 600 miles (1,000 km) and do not exceed the maximum engine speed of 6,000 rpm. You must also not use full acceleration between 600 and 1,200 miles (1,000 to 2,000 km). From 1,200 to 1,500 miles (2,000 to 2,500 km), you can gradually increase maximum engine speed to 8,250 rpm for brief periods.

During the first hours of operation, there is greater friction in the engine and the transmission than later when all the moving parts have broken in.

The way you drive during the first 1,500 miles (2,500 km) affects engine quality. If you drive at moderate engine speeds thereafter, particularly when the engine is cold, you reduce engine wear and increase the potential mileage of the engine.

Do not drive at RPMs that are too *low*. Shift down when the engine is no longer running “smoothly”. Extremely high RPMs are governed automatically.

Avoid damaging the vehicle

When you are driving on poor roads, or over curbs, steep ramps, etc., make certain that low-lying parts such as spoilers and exhaust system parts do not bottom out and get damaged.

This is especially true for vehicles with low-slung chassis (sports chassis) and fully loaded vehicles.

Driving through water on roads

Note the following to avoid vehicle damage when driving through water, for example on flooded roads:

- The water must not be any higher than the bottom of the vehicle body.

- Do not drive faster than walking speed.



WARNING

After driving through water, mud, slush, etc., the brakes may be slow to take effect because of wet brake rotors and pads. Dry the brakes first by braking carefully to restore the full braking effect.



Note

Vehicle components such as the engine, transmission, suspension or electrical system can be severely damaged by driving through water.



Tips

- Check the depth of the water before driving through it.
- Do not stop the vehicle, drive in reverse or switch the engine off when driving through water.
- Keep in mind that oncoming vehicles may create waves that raise the water level and make it too deep for your vehicle to drive through safely.
- Avoid driving through salt water because it can cause corrosion.

Catalytic converter

It is very important that your emission control system (catalytic converter) is functioning properly to ensure that your vehicle is running in an environmentally sound manner.

- ▶ Always use lead-free gasoline ⇒ *page 151, Fuel supply.*
- ▶ Never run the tank down all the way to empty.
- ▶ Never put too much motor oil in your engine ⇒ *page 160, Adding engine oil* .
- ▶ Never try to push- or tow-start your vehicle.

The catalytic converter is an efficient “clean-up” device built into the exhaust system of the vehicle. The catalytic converter burns many of the pollutants in the exhaust gas before they are released into the atmosphere.

The exclusive use of unleaded fuel is critically important for the life of the catalytic converter and proper functioning of the engine.

WARNING

- Do not park or operate the vehicle in areas where the hot exhaust system may come in contact with dry grass, brush, fuel spill or other material which can cause a fire.
- Do not apply additional undercoating or rustproofing on or near the exhaust manifold, exhaust pipes, catalytic converter or heat shields. During driving, the substance used for undercoating could overheat and cause a fire.

Note

- Be aware that just one tank filling with **lead-ed** fuel will already seriously degrade the performance of the catalytic converter.
- Do not exceed the correct engine oil level ⇒ *page 160*.
- Do not drive until the fuel tank becomes completely empty. The engine could misfire. Unburned fuel could also get into the exhaust system and this could cause the catalytic converter to overheat.
- Do not turn off the ignition while the vehicle is moving.
- Do not continue to operate your vehicle under these conditions, as otherwise fuel can reach the catalytic converter. This could result in overheating of the converter, requiring its replacement.
- To assure efficient operation of the Emission Control System:
 - Have your vehicle maintained properly and in accordance with the service recommendations in your Warranty & Maintenance booklet.
 - Lack of proper maintenance as well as improper use of the vehicle will impair the function of the emission control system and could lead to damage.



For the sake of the environment

Even when the Emission Control System is operating properly, the exhaust gas can have a sulfur-like exhaust gas smell under some operating states. This depends on the sulfur content of the fuel being used. Using a different brand of fuel may help, or filling the tank with lead-free super grade gasoline.

Shutting down vehicle

If you would like your vehicle to remain inoperative for a longer period of time, contact an Audi or other specialized dealer. They can advise you on necessary precautions e.g. corrosion prevention, maintenance and storage. Pay attention to additional information concerning the battery. Refer to ⇒ *page 164*.

Operation and maintenance

Fuel economy, environmental impact, and wear on your engine, brakes and tires largely depend on three factors:

- your personal driving style
- operating conditions
- technical limitations

By having your vehicle regularly serviced by an authorized Audi dealer helps to ensure that it runs properly and economically. The condition of your vehicle not only affects its safety and ability to hold its value, it also affects **fuel consumption**.

The amount of oil used is related to engine load and speed.

It is normal for the oil consumption of a new engine to reach its lowest value after a certain mileage has been driven.

You must drive your vehicle about 3,000 miles (5,000 kilometers) before you can properly assess oil consumption.

This also applies to fuel consumption and engine output. ►

Note

- Have your vehicle maintained properly and in accordance with the service recommendations in your Warranty & Maintenance booklet. Lack of proper maintenance as well as improper use of the vehicle will impair the function of the emission control system and could lead to damage.
- Do not alter or remove any component of the Emission Control System unless approved by the manufacturer.
- Do not alter or remove any device, such as heat shields, switches, ignition wires, valves, which are designed to protect your vehicle's Emission Control System and other important vehicle components.

Tips

The consumption estimates as published by the ENVIRONMENTAL PROTECTION AGENCY (EPA) and Transport Canada may not correspond to your actual consumption on the road, which will vary depending upon vehicle load and speed, road and weather conditions, trip length, etc.

Trailer towing

General information

Your Audi R8 Spyder is not designed to tow a trailer.

Towing a trailer with your Audi R8 Spyder is not recommended and can cause damage to the car. Damaged caused by towing a trailer is not covered by your Audi Warranty.

Vehicle care and cleaning

General information

Regular, proper care helps to maintain your vehicle's value. It can also be a requirement when submitting warranty claims for corrosion damage and paint defects on the body.

The required cleaning and care products can be obtained from your authorized Audi dealer or a qualified workshop. Read and follow the instructions for use on the packaging.



WARNING

- Using cleaning and care products incorrectly can be dangerous to your health.
- Always store cleaning and care products out of reach of children to reduce the risk of poisoning.



For the sake of the environment

- Preferably use environmentally-friendly products when buying cleaning agents.
- Do not dispose of leftover cleaning and care products with household trash.

Car washes

The longer deposits remain on the vehicle, the more the surface can be damaged. High temperatures such as those caused by sunlight increase the damaging effect.

Before washing, wet heavy deposits with plenty of water.

Stubborn deposits such as bird droppings or tree sap are best removed with plenty of water and a microfiber cloth.

Also, wash the underside of your vehicle once road salt stops being used for the season.

Pressure washers

When washing your vehicles with a pressure washer, always follow the operating instructions provided with the pressure washer. This is especially important in regard to the pressure and spraying distance. Do not aim the spray directly at seals on side windows, doors, the engine com-

partment lid, the front lid or the convertible top or at tires, rubber hoses, insulating material or sensors* or camera lenses*. Keep a distance of at least 16 inches (40 cm).

Do not remove snow and ice with a pressure washer.

Never use rotary nozzles or high pressure nozzles.

The water temperature must not be above 140 °F (60 °C).

Automatic car washes

Spray off the vehicle before washing.

Make sure that the windows are closed and the windshield wipers are off. Follow instructions from the car wash operator, especially if there are accessories attached to your vehicle.

If possible, use car washes that do not have brushes.

Only use car washes where the vehicle remains stationary and the washing equipment moves around the vehicle when washing and drying. Car washes that move the vehicle through the car wash using a chain are not recommended.

Washing by hand

Clean the vehicle starting from the top and working down using a soft sponge or cleaning brush. Use solvent-free cleaning products.

Washing vehicles with matte finish paint by hand

To avoid damaging the paint when washing, first remove dust and large particles from your vehicle. Insects, grease spots and fingerprints are best removed with a special cleaner for matte finish paint.

Apply the product using a microfiber cloth. To avoid damaging the paint surface, do not use too much pressure.

Rinse the vehicle thoroughly with water. Then clean using a neutral shampoo and a soft microfiber cloth.

Rinse the vehicle thoroughly again and let it air dry. Remove any water residue using a shammy. ►

 **WARNING**

- Only wash the vehicle when the ignition is off and follow the instructions from the car wash operator to reduce the risk of accidents.
- To reduce the risk of cuts, protect yourself from sharp metal components when washing the underbody or the inside of the wheel housings.
- After washing the vehicle, the braking effect may be delayed due to moisture on the brake rotors or ice in the winter. The brakes must be dried first with a few careful brake applications.

 **Note**

- If you wash the vehicle in an automatic car wash, you must retract the extendable rear spoiler* if necessary, and fold the exterior mirrors in to reduce the risk of damage. Power folding exterior mirrors* must only be folded in and out using the power folding function.
- To prevent paint damage, do not wash the vehicle in direct sunlight.
- To reduce the risk of damage, do not wash the power top with a pressure washer.

- To reduce the risk of damage, do not wash decorative decals* with a pressure washer.
- To reduce the risk of damage to the surface, do not use insect removing sponges, kitchen sponges or similar items.
- Matte finish painted vehicle components:
 - To reduce the risk of damage to the surface, do not use polishing agents or hard wax.
 - Never use car wash cycles that apply protective wax. It can destroy the matte finish effect.
 - Do not place any stickers or magnetic signs on vehicle parts painted with matte finish paint. The paint could be damaged when the stickers or magnets are removed.
- Do not wash the vehicle using cleaning products that contain alcohol when the engine is hot. This increases the risk of damage to plastic components, such as cracking.

 **For the sake of the environment**

Only wash the vehicle in facilities specially designed for that purpose. This will reduce the risk of dirty water contaminated with oil from entering the sewer system.

Cleaning and care information

When cleaning and caring for individual vehicle components, refer to the following table. The information contained there is simply recommendations. For questions or for components that

are not listed, refer to an authorized Audi dealer or a qualified workshop. Also follow the information found in ⇒ ⚠.

Cleaning exterior

Component	Situation	Solution
Wiper blades	Dirty	⇒ page 53, <i>Cleaning windshield wiper blades</i>
Headlights/ tail lights	Dirty	Soft sponge with a mild soap solution ^{a)}
Sensors/ camera lenses	Dirty	Sensors: soft cloth with a solvent-free cleaning product Camera lenses: soft cloth with an alcohol-free cleaning solution
	Snow/ice	Hand brush/solvent-free de-icing spray
Wheels	Road salt	Water
	Brake dust	Acid-free special cleaning solution

Component	Situation	Solution
Exhaust tail pipes	Road salt	Water, cleaning solution suitable for stainless steel, if necessary
Power top	Dirty	Clean water, power top cleaning product, if necessary. Clean with the grain of the fabric using a soft brush and allow to air dry.
Wind deflector	Dirty	Water, mild soap solution ^{a)} , if necessary
Decorative parts/trim	Dirty	Mild soap solution ^{a)} , a cleaning solution suitable for stainless steel, if necessary
Paint	Paint damage	Refer to the paint number on the vehicle data label, repair with touch up paint ⇒ <i>page 212</i>
	Spilled fuel	Rinse with water immediately
	Rust film	Rust film remover, then protect with hard wax; for questions, refer to an authorized Audi dealer or a qualified workshop
	Corrosion	Have it removed by an authorized Audi dealer or a qualified workshop
	Water no longer beads on the surface of clean paint	Protect with hard wax (at least twice per year)
	No shine even though paint has been protected/paint looks poor	Treat with suitable polish; then apply paint protectant if the polish that was used does not contain any protectant
	Deposits such as insects, bird droppings, tree sap and road salt	Dampen with water immediately and remove with a microfiber cloth
	Grease-based contaminants such as cosmetics or sunblock	Remove immediately with a mild soap solution ^{a)} and a soft cloth
Carbon parts	Dirty	Clean the same way as painted parts ⇒ <i>page 145, Car washes</i>
Decorative decals	Dirty	Soft sponge with a mild soap solution ^{a)}

^{a)} Mild soap solution: maximum two tablespoons neutral soap in 1 quart (1 liter) of water

Cleaning interior

Component	Situation	Solution
Windows	Dirty	Glass cleaner, then wipe dry
Decorative parts/trim	Dirty	Mild soap solution ^{a)}
Plastic parts	Dirty	Damp cloth
	Heavily soiled	Mild soap solution ^{a)} , solvent-free plastic cleaning solution, if necessary

Component	Situation	Solution
Displays	Dirty	Soft cloth with LCD cleaner
Controls	Dirty	Soft brush, then a soft cloth with a mild soap solution ^{a)}
Safety belts	Dirty	Mild soap solution ^{a)} , allow to dry before letting them retract
Textiles, Vinyl, Alcantara	Stains adhering to the surface	Vacuum cleaner
	Water-based stains such as coffee, tea, blood, etc.	Absorbent cloth and mild soap solution ^{a)}
	Oil-based stains such as oil, make-up, etc.	Apply a mild soap solution ^{a)} , blot away the dissolved oil or dye, treat afterward with water, if necessary
	Special stains such as ball-point pen, nail polish, latex paint, shoe polish, etc.	Special stain remover, blot with absorbent material, treat afterward with mild soap solution ^{a)} , if necessary
Natural leather	Fresh stains	Cotton cloth with a mild soap solution ^{a)}
	Water-based stains such as coffee, tea, blood, etc.	Fresh stains: absorbent cloth Dried stains: stain remover suitable for leather
	Oil-based stains such as oil, make-up, etc.	Fresh stains: absorbent cloth and stain remover suitable for leather dried stains: Oil cleaning spray
	Special stains such as ball-point pen, nail polish, latex paint, shoe polish, etc.	Stain remover suitable for leather
	Care	Regularly apply conditioning cream that protects from light and penetrates into the material. Use specially-colored conditioning cream, if necessary.
Carbon parts	Dirty	Clean the same way as plastic parts

^{a)} Mild soap solution: maximum two tablespoons neutral soap in 1 quart (1 liter) of water

WARNING

The windshield may not be treated with water-repelling windshield coating agents. Unfavorable conditions such as wetness, darkness, or low sun can result in increased glare. Wiper blade chatter is also possible.

Note

– **Headlights/tail lights**

- Never clean headlights or tail lights with a dry cloth or sponge.
- Do not use any cleaning product that contains alcohol, because they could cause cracks to form.

– **Wheels**

- Never use any paint polish or other abrasive materials.
- Damage to the protective layer on the rims such as stone chips or scratches must be repaired immediately.
- **Sensors/camera lenses**
 - Never use warm or hot water to remove snow or ice from the camera lens. This could cause the lens to crack.
 - Never use abrasive cleaning materials or alcohol to clean the camera lens. This could cause scratches and cracks.
- **Power top**
 - Remove bird droppings immediately.

- Never use gasoline, stain remover, benzene, paint thinner or other solvents to remove.

– **Windows**

- Remove snow and ice on windows and exterior mirrors with a plastic scraper. To avoid scratches, move the scraper only in one direction and not back and forth.
- Never remove snow or ice from windows and mirrors using warm or hot water because this could cause cracks to form.
- To avoid damage to the rear window defogger, do not apply any stickers on the heating wires on the inside of the window.

– **Decorative parts/trim**

- Never use chrome care or cleaning products.

– **Paint**

- To reduce the risk of scratches, the vehicle must be free of dirt and dust before polishing or waxing.
- To prevent paint damage, do not polish or wax the vehicle in direct sunlight.
- To reduce the risk of paint damage, do not polish away rust film.
- Remove cosmetics and sunblock immediately. Otherwise, the paint could be damaged.

– **Trim**

- To reduce the risk of damage, do not treat the trim around the panorama sunroof with paint polish.

– **Decorative decals**

- To reduce the risk of damage, do not use any rough powder or abrasive cleaning products.
- To reduce the risk of damage, do not polish decorative parts that have a matte finish.

– **Displays**

- To avoid scratches, do not use dry cleaning methods on displays.

– **Controls**

- Make sure that no fluids enter the controls, because this could cause damage.

– **Safety belts**

- Do not remove the safety belts to clean them.
- Never clean safety belts or their components chemically or with corrosive fluids or solvents and never allow sharp objects to come into contact with the safety belts. This could cause damage to the belt webbing.
- If there is damage to the webbing, the connections, the retractors or the buckles, have them replaced by an authorized Audi dealer or a qualified workshop.

– **Textiles/Vinyl/Alcantara**

- Never treat Vinyl/Alcantara with leather care products, solvents, floor polish, shoe polish, stain remover or similar products.
- To avoid damage, have stubborn stains removed by an authorized Audi dealer or a qualified workshop.
- Never use steam cleaners, brushes, hard sponges, etc. when cleaning.
- Do not turn on the seat heating* to dry the seat.
- Objects with sharp edges such as zippers, rivets on clothing or belts can cause damage to the surface.
- Open hook and loop fasteners, for example on clothing, can damage seat covers. Make sure hook and loop fasteners are closed.

– **Natural leather**

- Never treat leather with solvents, floor polish, shoe polish, stain remover or similar products.
- Objects with sharp edges such as zippers, rivets on clothing or belts can cause damage to the surface.
- Never use steam cleaners, brushes, hard sponges, etc. when cleaning.
- Do not turn on the seat heating* to dry the seat.
- To help prevent the leather from fading, do not leave the vehicle in direct sunlight for long periods of time. If leaving the vehicle parked for long periods of time, you should cover the leather to protect it from direct sunlight.

Tips

- Insects are easier to remove from paint that has been freshly waxed.
- Regular waxing can prevent rust film from forming.
- Decorative parts can go through an agent process, for example by becoming brittle, due to various environmental conditions. The intensity of their color may change if exposed to excessive sunlight.

Fuel supply and filling your fuel tank

Gasoline

Fuel supply

Using the right fuel helps keep the environment clean and prevents engine damage.

Fuel recommendation

The fuel recommended for your vehicle is **unleaded premium** grade gasoline. See also . Audi recommends using TOP TIER Detergent Gasoline with a minimum octane rating of 91 AKI (95 RON). For more information on TOP TIER Detergent Gasoline, please go to the official website (www.toptiergas.com).

The recommended gasoline octane rating for your engine can also be found on a label located on the inside of the fuel filler flap. This rating may be specified as AKI or RON.

Your vehicle may also be operated using unleaded regular gasoline with a minimum octane rating of 87 AKI/91 RON. However, using 87 AKI/91 RON octane fuel will slightly reduce engine performance.

Use unleaded gasoline only. Unleaded gasoline is available throughout the USA, Canada, and in most European countries. We recommend that you do not take your vehicle to areas or countries where unleaded gasoline may not be available.

For more information on refueling your vehicle, see ⇒ *page 152*.

Octane rating

Octane rating indicates a gasoline's ability to resist engine damaging "knock" caused by premature ignition and detonation. Therefore, buying the correct grade of gasoline is very important to help prevent possible engine damage and a loss of engine performance.

Gasoline most commonly used in the United States and Canada has the following octane ratings that can usually be found on the filler pump:

– Premium Grade: 91 - 96 AKI

– Regular Grade: 87 - 90 AKI

Explanation of the abbreviations:

AKI = **A**nti **K**nock **I**ndex = $(R+M)/2 = (RON+MON)/2$

RON = **R**esearch **O**ctane **N**umber

MON = **M**otor **O**ctane **N**umber.

Note

- Do not use any fuel with octane ratings lower than 87 AKI or 91 RON otherwise expensive engine damage will occur.
- Do **not** use leaded gasoline! The use of leaded gasoline will severely damage your vehicle's catalytic converter and its ability to control exhaust emissions.

Blended gasoline

Use of gasoline containing alcohol or MTBE (methyl tertiary butyl ether)

You may use unleaded gasoline blended with alcohol or MTBE (commonly referred to as oxygenates) if the blended mixture meets the following criteria:

Blend of gasoline methanol (wood alcohol or methyl alcohol)

- Anti-knock index must be 87 AKI or higher.
- Blend must contain no more than 3% methanol.
- Blend must contain more than 2% co-solvents.

Blend of gasoline and ethanol (grain alcohol or ethyl alcohol)

- Anti-knock index must be 87 AKI or higher.
- Blend must not contain more than 10% ethanol.

Blend of gasoline and MTBE

- Anti-knock index must be 87 AKI or higher.
- Blend must contain not more than 15% MTBE.

Seasonally adjusted gasoline

Many gasoline grades are blended to perform especially well for winter or summer driving. During seasonal change-over, we suggest that you ►

fill up at busy gas stations where the seasonal adjustment is more likely to be made in time.

Note

- Methanol fuels which do not meet these requirements may cause corrosion and damage to plastic and rubber components in the fuel system.
- Do not use fuels that fail to meet the specified criteria in this chapter.
- If you are unable to determine whether or not a particular fuel blend meets the specifications, ask your service station or its fuel supplier.
- Do not use fuel for which the contents cannot be identified.
- Fuel system damage and performance problems resulting from the use of fuels different from those specified are not the responsibility of Audi and are not covered under the New Vehicle or the Emission Control System Warranties.
- If you experience a loss of fuel economy or driveability and performance problems due to the use of one of these fuel blends, we recommend that you switch to unblended fuel.

Gasoline additives

A major concern among many auto manufacturers is carbon deposit build-up caused by the type of gasoline you use.

Although gasoline grades differ from one manufacturer to another, they have certain things in common. All gasoline grades contain substances that can cause deposits to collect on vital engine parts, such as fuel injectors and intake valves. Although most gasoline brands include additives to keep engine and fuel systems clean, they are not equally effective.

Audi recommends using TOP TIER Detergent Gasoline. For more information on TOP TIER Detergent Gasoline, please go to the official website (www.toptiergas.com).

After an extended period of using inadequate fuels, built-up carbon deposits can rob your engine of peak performance.

Note

Damage or malfunction due to poor fuel quality is not covered by the Audi New Vehicle Limited Warranty.

Fuel tank

Fuel filler neck

The fuel filler neck is located on the right rear side panel behind the fuel filler flap.

If the unlocking system should fail, you can still open the flap manually - for detailed instructions see ⇒ *page 154*.

You can find the fuel tank capacity of your vehicle in **Technical Data**.

The label on the inside of the fuel filler flap tells you the correct fuel for your vehicle. For more information about fuel specifications, see ⇒ *page 151*.

Your vehicle fuel tank has an on-board refueling vapor recovery system. This feature helps to prevent fuel vapors from escaping from the tank and polluting the environment while you refuel your vehicle. In order to fill the tank properly while protecting the environment, please follow this refueling procedure carefully.

WARNING

Under normal operating conditions, never carry additional fuel containers in your car. Gas canisters and other containers used to transport fuel can be dangerous. Such containers, full or empty, may leak and could cause a fire in a collision. If you must transport fuel to use for your lawn mower, snow blower, etc., be very careful and always observe local and state laws regarding the use, transportation and storage of such fuel containers. Make certain the container meets industry standards (ANSI/ASTM F852 - 86).

Note

Never drive your vehicle until the fuel tank is completely dry. The irregular supply of fuel can cause misfiring. Gasoline could enter into the exhaust system and damage the catalytic converter.

Refueling



Fig. 128 Driver's door: Unlocking fuel filler flap



Fig. 129 Fuel cap hooked on the opened fuel filler flap

When adding fuel, the ignition and any cellular phones in the vehicle must be switched *off*.

Taking the fuel cap off

- To open the fuel filler flap, press the button ⇒ *fig. 128*.
- Unscrew fuel filler cap counter-clockwise and hang it on the fuel filler flap ⇒ *fig. 129*.

Refueling procedure

- Insert the fuel nozzle from the gasoline pump into the fuel filler neck as far as it will go.
- Select a medium refueling rate so that the nozzle switches off automatically when the tank is full.

Putting the fuel cap back on

- After filling your tank, twist the fuel filler cap clockwise until you hear a definite click.
- Close the fuel filler flap.

To avoid fuel spilling or evaporating from the fuel tank always close fuel filler cap properly and completely. An improperly closed fuel filler cap may also cause the MIL lamp ⇒ *page 26* to come on.

WARNING

Improper refueling or handling of fuel can cause fire, explosion and severe burns.

- Fuel is highly flammable and can cause severe burns and other injuries.
- Failure to shut the engine off while refueling and/or to insert the pump nozzle fully into the fuel filler neck could cause fuel to spray out of filler neck or to overflow. Fuel spray and overflowing fuel can cause a fire.
- Never use a cellular telephone while refueling. The electromagnetic radiation can cause sparks that can ignite fuel vapors and cause a fire.
- Never get back into your vehicle while refueling. If in exceptional circumstances you must get back in your vehicle while refueling, make certain that you close the door and touch metal to discharge static electricity before touching the filler nozzle again. Static electricity can cause sparks that can ignite fuel vapors released during refueling.
- Never smoke or have an open flame anywhere in or near your vehicle when refueling or filling a portable fuel container.
- For your safety, we strongly recommend that you do not travel with a portable fuel container in your vehicle. The container, full or empty may leak and could cause a fire, especially in a crash.
- If, under exceptional circumstances, you must transport a portable fuel container, please observe the following:
 - Never fill a portable fuel container while it is anywhere in or on the vehicle (for example, in the luggage compartment, or on

the trunk). Static electricity can build up while filling and can ignite fuel vapors causing a fire.

- Always place a portable fuel container on the ground before filling.
- Always keep the filler nozzle completely inside the portable container before and during filling.
- If filling a portable container made of metal, the filler nozzle must always be in contact with the container. This will help prevent static electricity from discharging and cause a fire.
- Never spill fuel inside the vehicle or luggage compartment. Fuel vapors are highly flammable.
- Always observe local and state/provincial laws regarding the use, storage and transportation of fuel containers.
- Make certain the fuel container meets industry standards (ANSI / ASTM F852-86).

Note

If any fuel has spilled onto the car, it should be removed immediately to prevent damage to the paint.

For the sake of the environment

As soon as the correctly operated nozzle switches off automatically for the first time, the tank is full. Do not try to add more fuel because fuel may spill out. In addition, the expansion space in the fuel tank will be filled - causing the fuel to overflow when it becomes warm and pollute the environment.

Tips

- Running your engine while refueling may cause vapors to escape or even fuel to spill out of the tank. This would then shut off the fuel nozzle before the tank is full.
- Do not refuel your vehicle with the ignition switched on. The fuel gauge may otherwise not indicate the correct fuel level after refueling.

Unlocking the fuel filler flap by hand

You can open the fuel filler flap by hand if the power locking system should fail.



Fig. 130 Engine compartment: loosening the fuel filler flap cable



Fig. 131 Engine compartment: releasing the fuel filler flap using the emergency release

You can release the fuel filler flap using a red emergency release loop. It is located in the right side of the engine compartment.

- ▶ Open the engine compartment lid.
- ▶ Loosen the fuel filler flap cable from its mount  on the crossmember ⇒ *fig. 130*.
- ▶ Pull the red loop in the direction of the arrow until the fuel filler flap opens ⇒ *fig. 131*.
- ▶ Once the fuel filler flap is open, secure the cable on the crossmember again.
- ▶ Close the engine compartment lid ⇒ *page 156*.

Checking and filling

Engine compartment lid

Releasing the engine compartment lid

The engine compartment lid is released from inside the vehicle.



Fig. 132 Driver's side: releasing the engine compartment lid

Requirement: The ignition must be switched on.

- ▶ Make sure the rear spoiler is retracted
⇒ page 138.
- ▶ Pull the button **A**. The engine compartment lid opens slightly.
- ▶ Open the engine compartment lid ⇒ ⚠.

⚠ WARNING

Hot engine coolant can burn you. To reduce the risk of being burned, never open the engine compartment lid if you see or hear steam or coolant escaping from the engine compartment. Wait until no steam or coolant can be seen or heard before carefully opening the engine compartment lid.

⚠ Note

To prevent damage to the vehicle, only open the engine compartment lid when the convertible top storage bay lid is closed.

i Tips

An emergency release can be used if the engine compartment lid cannot be released with the button **A** ⇒ page 155.

Engine compartment lid emergency release

The emergency release loop is located under the right trim panel near the front passenger seat.



Fig. 133 Front passenger footwell: emergency release loop

- ▶ Make sure the rear spoiler is retracted
⇒ page 138.
- ▶ Pull the loop forward to release the engine compartment lid. The engine compartment lid opens slightly.
- ▶ Open the engine compartment lid ⇒ ⚠ in Releasing the engine compartment lid on page 155.

⚠ Note

To prevent damage to the vehicle, only open the engine compartment lid when the convertible top storage bay lid is closed.

Working in the engine compartment

Be especially careful whenever you work in the engine compartment!

Whenever you must perform any work in the engine compartment, for example checking and filling the different fluids, there is a risk of injury, burns and accidents. To prevent personal injury always observe the following **WARNINGS**. The engine compartment of any vehicle is a hazardous area! ⇒ ⚠

⚠ WARNING

To help avoid injury, before you check anything under the engine compartment lid:

- Switch off the engine.
- Remove the ignition key.
- Apply the parking brake.

- Move selector lever of S tronic to “N” (Neutral); put manual transmission in Neutral.
- Always let the engine cool down. Hot components will burn skin on contact.
- To reduce the risk of being burned, never open the engine compartment lid if you see or hear steam or coolant escaping from the engine compartment. Wait until no steam or coolant can be seen or heard before carefully opening the engine compartment lid.
- Keep children away from the engine compartment.
- Never spill fluids on hot engine components. They can cause a fire.
- Never open the coolant reservoir cap when the engine is still warm. The coolant system is pressurized and hot coolant could spray out.
- Protect your face, hands and arm from steam or hot engine coolant by placing a thick rag over the cap when you open the coolant reservoir.
- Do not remove the engine cover under any circumstances. This increases the risk of burns.
- If work on the fuel system or the electrical system is necessary:
 - Always disconnect the battery.
 - Never smoke or work near heaters or open flames. Fluids in the engine compartment could start a fire.
 - Keep an approved fire extinguisher immediately available.
- To avoid electrical shock and personal injury while the engine is running or being started, never touch:
 - Ignition cables
 - Other components of the high voltage electronic ignition system.
- If you must perform a check or repair with the engine running:
 - First, fully apply the parking brake, move selector lever of S tronic to “N” (Neutral); put manual transmission in Neutral.
 - Always use extreme caution to prevent clothing, jewelry, or long hair from getting caught in the radiator fan, V-belts or other

moving parts, or from contacting hot parts. Tie back hair before starting, and wear no clothing that will hang or droop into the engine.

- Minimize exposure to emission and chemical hazards ⇒ ⚠.



WARNING

California Proposition 65 Warning:

- Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harms. Wash hands after handling.



Note

When adding fluids, always make sure that they are poured into the proper container or filler opening, otherwise serious damage to vehicle systems will occur.



For the sake of the environment

To detect leaks in time, inspect the vehicle floor pan from underneath regularly. If you see spots from oil or other vehicle fluids, have your vehicle inspected by an authorized Audi dealer.

Closing the engine compartment lid

- Make sure that the rear spoiler is retracted
⇒ *page 138*.
- Pull the engine compartment lid down until the pressure from the struts is reduced.
- Press the engine compartment lid closed ⇒ ⚠. ►



WARNING

- When you close the engine compartment lid, check it to make sure the safety catch has properly engaged. The engine compart-

- ment lid should be flush with the surrounding vehicle body parts.
- If you notice while driving that the engine compartment lid is not secured properly, stop at once and close it.

Engine compartment

These are the most important items that you can check.




Fig. 134 Typical layout for containers, engine oil dipstick and engine oil filler cap (manual transmission)



Fig. 135 Typical layout for containers, engine oil dipstick and engine oil filler cap (S tronic)

With manual transmission:

- ① Power steering fluid reservoir (⊕). 139
- ② Engine oil filler cap (⊕), 160
- ③ Engine oil dipstick 159

With S tronic transmission:

- ① Power steering fluid reservoir (⊕). 139

- ② Engine oil filler cap (⊕) with engine oil dipstick , 161, 160



WARNING

Before you check anything in the engine compartment, always read and heed all WARNINGS ⇒ ⚠ in *Working in the engine compartment* on page 155.

 Tips

The coolant expansion tank is located under the convertible top storage bay lid
⇒ *page 163.*

Engine oil

Engine oil specifications

The engine oil used must conform to exact specifications.

The service interval display in the instrument cluster of your vehicle will inform you when it is time for an oil change. We recommend that you have your oil changed by an authorized Audi Service Advisor.

If you have to top off the oil between oil changes, use the Audi oil quality standard specified in the table.

	Audi oil quality standard
Gasoline engine	VW 502 00 or VW 504 00

Using the proper engine oil is important for the functionality and service life of the engine. Your engine was factory-filled with a high-quality oil which can usually be used throughout the entire year.

 Note

Your Limited New Vehicle Warranty does not cover damage or malfunctions due to failure to follow recommended maintenance and use requirements as set forth in the Audi Owner’s Manual and Warranty & Maintenance booklet.

- Use only a high quality engine oil that expressly complies with the Audi oil quality standard specified for your vehicle's engine. Using any other oil can cause serious engine damage.
- Do not mix any lubricants or other additives into the engine oil. Doing so can cause engine damage.

 Tips

If you need to add oil and there is none available that meets the Audi oil quality standard your engine requires, you may add a total of no more than 0.5 quart/liter of a high-quality “synthetic” oil that meets the following specifications.

- ACEA A3 or API SM with a viscosity grade of SAE 0W-30, SAE 5W-30 or SAE 5W-40.
- For more information about engine oil that has been approved for your vehicle, please contact either your authorized Audi dealer or Audi Customer Relations at 1 (800) 822-2834 or visit our web site at www.audiusa.com or www.audicanada.ca.

Engine oil consumption

The engine in your vehicle depends on an adequate amount of oil to lubricate and cool all of its moving parts.

In order to provide effective lubrication and cooling of internal engine components, all internal combustion engines consume a certain amount of oil. Oil consumption varies from engine to engine and may change significantly over the life of the engine. Typically, engines with a specified break-in period (see ⇒ *page 142*) consume more oil during the break-in period than they consume after oil consumption has stabilized.

Under normal conditions, the rate of oil consumption depends on the quality and viscosity of the oil, the RPM (revolutions per minute) at which the engine is operated, the ambient temperature and road conditions. Further factors are the amount of oil dilution from water condensation or fuel residue and the oxidation level of the oil. As any engine is subject to wear as mileage builds up, the oil consumption may increase over time until replacement of worn components may become necessary.

With all these variables coming into play, no standard rate of oil consumption can be established or specified. There is no alternative to regular and frequent checking of the oil level, see **Note**.

If the yellow engine oil level warning symbol in the instrument cluster  lights up, you should check the oil level as soon as possible ⇒ *page 159*. Top off the oil at your earliest convenience ⇒ *page 160*.

WARNING

Before you check anything in the engine compartment, always read and heed all WARNINGS ⇒  *in Working in the engine compartment on page 155*.

Note

Driving with an insufficient oil level is likely to cause severe damage to the engine.

Tips

- The oil pressure warning display  is not an indicator of the oil level. Do not rely on it. Instead, check the oil level in your engine at regular intervals, preferably each time you refuel, and always before going on a long trip.
- If you have the impression your engine consumes excessive amounts of oil, we recommend that you consult your Audi dealer to have the cause of your concern properly diagnosed. Keep in mind that the accurate measurement of oil consumption requires great care and may take some time. Your Audi dealer has instructions about how to measure oil consumption accurately.

Checking the engine oil level

Applies to vehicles: with manual transmission



Fig. 136 Instrument cluster: Engine oil temperature display




Fig. 137 Markers on oil dipstick

Before you check anything in the engine compartment, **always read and heed all WARNINGS**.

Determining oil level

- ▶ Warm up the engine by driving until the instrument cluster display shows an oil temperature of 210 °F (100 °C) to 230 °F (110 °C) ⇒ *fig. 136*.
- ▶ Park your vehicle so that it is horizontally level.
- ▶ Allow the warm engine to run for about two minutes at idle.
- ▶ Shut the engine off and wait two minutes.
- ▶ Check the oil level on the engine oil dipstick ⇒ *fig. 137*.

Oil level within range

- ▶ Do *not* add oil.

Oil level within range

- ▶ Add 1 quart (1 liter) of oil. *Afterwards*, the oil level should be within range .

Depending on the way the vehicle is driven and the operating conditions, oil consumption can be up to 1 quart per 600 miles (1 liter per 1,000 km). Consumption may be higher within the first 3,000 miles (5,000 km).

Checking the engine oil level

Applies to vehicles: with S tronic



Fig. 138 Instrument cluster: Engine oil temperature display




Fig. 139 Markers on oil dipstick

Before you check anything in the engine compartment, **always read and heed all WARNINGS**.

Determining oil level

- ▶ Warm up the engine by driving until the instrument cluster display shows an oil temperature of 210 °F (100 °C) to 230 °F (110 °C) ⇒ *fig. 138*.
- ▶ Park your vehicle so that it is horizontally level.
- ▶ Allow the warm engine to run for about two minutes at idle.
- ▶ Shut the engine off and wait two minutes.
- ▶ Remove the design cover.
- ▶ Unscrew the cap  to the engine oil filling hole ⇒ *page 157, fig. 135*.
- ▶ Check the oil level on the engine oil dipstick ⇒ *fig. 139*.

To check the oil level, the dipstick must be inserted completely and the bayonet catch must be locked (audible locking, turn all the way to the stop).

Oil level within range **a**

- ▶ Do *not* add oil.

Oil level within range **b**

- ▶ Add 1 quart (1 liter) of oil. *Afterwards*, the oil level should be within range **a**.

Depending on the way the vehicle is driven and the operating conditions, oil consumption can be up to 1 quart per 600 miles (1 liter per 1,000 km). Consumption may be higher within the first 3,000 miles (5,000 km).

Adding engine oil

Applies to vehicles: with manual transmission



Fig. 140 Engine compartment: Oil filler cap location

Before you check anything in the engine compartment, **always read and heed all WARNINGS**

⇒  *in Working in the engine compartment on page 155.*

- ▶ Unscrew the cap  to the engine oil filling hole ⇒ *fig. 140*.
- ▶ Carefully top off with the appropriate oil ⇒ *page 158*.
- ▶ Check the oil level again ⇒ *page 159*.
- ▶ Top off the oil again, if necessary.
- ▶ Screw the cap back on the filling hole and slide the oil dipstick in as far as it will go.

WARNING

- While topping off, the oil must not come in contact with hot engine parts - fire hazard!
- The oil filler cap must be properly secured to prevent oil from being sprayed on the hot engine and exhaust system when the engine is running - fire hazard!

- If your skin has come in contact with the engine oil, you must subsequently cleanse it thoroughly.

! Note

- The oil level must not be above range
⇒ *page 159, fig. 137 a* - danger of converter or engine damage! Contact an authorized Audi dealer to draw off oil, if necessary.
- Audi does not recommend the use of oil additives. They may damage the engine and adversely affect your New Vehicle Warranty.

🌳 For the sake of the environment

- Under no circumstances can the oil come in contact with the sewage network or the soil.
- Observe and follow legal regulations when disposing of empty oil containers.

Adding engine oil

Applies to vehicles: with S tronic



Fig. 141 Engine compartment: cover on the engine oil filler neck

Before you check anything in the engine compartment, **always read and heed all WARNINGS**

⇒ **!** in *Working in the engine compartment* on *page 155*.

- ▶ Shut the engine off.
- ▶ Remove the design cover, if necessary.
- ▶ Unscrew the cap to the engine oil filling hole ⇒ *fig. 141*.
- ▶ Carefully top off with the appropriate oil
⇒ *page 158*.
- ▶ Check the oil level again ⇒ *page 160*.
- ▶ Top off the oil again, if necessary.
- ▶ Slide the oil dipstick in and screw the cap back on the filling hole.

! WARNING

- While topping off, the oil must not come in contact with hot engine parts - fire hazard!
- The oil filler cap must be properly secured to prevent oil from being sprayed on the hot engine and exhaust system when the engine is running - fire hazard!
- If your skin has come in contact with the engine oil, you must subsequently cleanse it thoroughly.

! Note

- The oil level must not be above range
⇒ *page 160, fig. 139 a* - danger of converter or engine damage! Contact an authorized Audi dealer to draw off oil, if necessary.
- Audi does not recommend the use of oil additives. They may damage the engine and adversely affect your New Vehicle Warranty.

🌳 For the sake of the environment

- Under no circumstances can the oil come in contact with the sewage network or the soil.
- Observe and follow legal regulations when disposing of empty oil containers.

Engine cooling system

Coolant

The engine coolant performs two functions: it keeps the engine from overheating and it protects the engine from freezing in the winter.

The cooling system is sealed and generally requires little attention.

The cooling system has been filled at the factory with a permanent coolant which does not need to be changed. The coolant consists of a mixture of specially conditioned water and the manufacturer's glycol-based coolant additive G13 antifreeze with anticorrosion additives (50% for USA models; 60% for Canadian models). This mixture both assures the necessary frost protection and protects metal components in the engine's cooling system from corrosion and scaling. It also raises the boiling point of the coolant.

Do not reduce the concentration of the coolant in the summer by adding plain water. **The proportion of coolant additive must be at least 50% but not more than 60%** to maintain antifreeze protection and cooling efficiency. If the coolant frost protection is too low, the coolant could freeze and damage the vehicle heating and engine cooling system.

For year-round driving, antifreeze is added at the factory for temperatures down to:

- - 31 °F (- 35 °C) USA
- - 40 °F (- 40 °C) Canada.

If you must add coolant, use a mixture of water and coolant additive. Mixing the coolant additive with distilled water is recommended.

WARNING

Before you check anything in the engine compartment, always read and heed all **WARNINGS** ⇒  *in Working in the engine compartment on page 155.*

Note

- Before winter sets in, have the coolant checked to see if the coolant additive in your vehicle is sufficient to meet the climate conditions. This is especially important if you live in a region where the winter is extremely cold. If necessary, increase the proportion of coolant additive to 60%.
- When adding coolant additive to your cooling system, remember:
 - We recommend using only coolant additive G12++ or G13 for your vehicle. This coolant additive is available at authorized Audi dealers. Other types of antifreeze can significantly reduce corrosion protection. The resulting corrosion can cause a loss of coolant and serious engine damage.
- Do not add any type of radiator leak sealant to your vehicle's engine coolant. Adding radiator repair fluid may adversely affect the function and performance of your cooling system and could result in damage not covered by your New Vehicle Limited Warranty.

Checking the engine coolant level

Proceed carefully when checking the coolant.




Fig. 142 Convertible top: service position




Fig. 143 Convertible top storage bay: coolant expansion tank

Before you check anything in the engine compartment, **always read and heed all WARNINGS** ⇒  *in Working in the engine compartment on page 155* and park your vehicle on a level surface.

The coolant expansion tank is located in the right side of the convertible top storage bay under the round metal cover ⇒ *fig. 143*. The convertible top must be in the service position to check the coolant level ⇒ *fig. 142*.

Bringing the closed convertible top into the service position

- ▶ Switch the ignition on.
- ▶ Pull and hold the convertible top switch.
- ▶ Press and hold the rear window switch too until the convertible top moves into the service position ⇒ *fig. 142*.

Bringing the open convertible to into the service position

- ▶ Switch the ignition on.
- ▶ Press and hold the convertible top switch.

- Press and hold the rear window switch too until the convertible top moves into the service position ⇒ *fig. 142*.

Opening the coolant expansion tank cover

- Stop the engine and allow it to cool.
- Switch the ignition off.
- Carefully remove the bolts in the cover ① using a screwdriver and remove the cover. The coolant reservoir is located below ⇒ *fig. 143*.

Checking the engine coolant level

- Place a rag or cloth on the cap of the coolant expansion tank and turn the cap **carefully** to the left (counter-clockwise) ⇒ .
- Read the coolant level inside the coolant expansion tank ⇒ *fig. 143*. With a cold engine, it must be above the “min” mark. With a hot engine, it can be a little above the indicated range.

To obtain an accurate reading, the engine must be switched off.

The expansion tank in your vehicle is equipped with an electric coolant level sensor ⇒ *page 14*. We still recommend you check the coolant level from time to time.

Coolant loss

Coolant loss may indicate a **leak** in the cooling system. In the event of coolant loss, the cooling system should be inspected immediately by your authorized Audi dealer. It is not enough merely to add coolant.

In a **sealed** system, losses can occur only if the boiling point of the coolant is exceeded as a result of overheating.

WARNING

- The cooling system is under pressure. Do not open the cap of the coolant expansion tank when the engine is hot. You risk being scalded.
- The coolant additive, and therefore the coolant itself, is hazardous to health. Keep the coolant additive in the original container out of the reach of children. It is a poison hazard.

Note

Do not add any type of radiator leak sealant to your vehicle's engine coolant. Adding radiator repair fluid may adversely affect the function and performance of your cooling system and could result in damage not covered by your New Vehicle Limited Warranty.

Adding coolant

Before you check anything in the engine compartment, **always read and heed all WARNINGS** ⇒  in *Working in the engine compartment on page 155*.

- Add coolant mixed in the correct ratio ⇒ *page 161, Coolant*.
- Twist the cap on again *tightly*.
- Tighten the cap ① ⇒ *page 162, fig. 143* again.

Replacement engine coolant must conform to exact specifications ⇒ *page 161, Coolant*.

We recommend using only coolant additive G12+, G13 or in an emergency G12+. Do **not** use a different additive. In an emergency use plain water until you can get the correct additive and can restore the correct ratio. This should be done as soon as possible.

If you have lost a considerable amount of coolant, then you should add cold antifreeze and cold water only when the engine is cold.

Always use *new* engine coolant when refilling.

Do not fill coolant above the “max” mark. Excess coolant will be forced out through the pressure relief valve in the cap when the engine becomes hot.

WARNING

- The cooling system is under pressure and can get very hot. Reduce the risk of scalding from hot coolant by following these steps.
 - Turn off the engine and allow it to cool down.
 - Protect your face, hands and arms from escaping fluid and steam by covering the cap with a large, thick rag.

- Turn the cap slowly and very carefully in a counter-clockwise direction while applying light, downward pressure on the top of the cap.
- To avoid being burned, do not spill anti-freeze or coolant on the exhaust system or hot engine parts. Under certain conditions, the ethylene glycol in engine coolant can catch fire.
- Antifreeze is poisonous. Always store antifreeze in its original container and well out of the reach of children.
- If you drain the coolant, it must be caught and safely stored in a proper container clearly marked “poison”.

Note

- Coolant pollutes the environment and could cause an engine fire. Excess coolant will be forced out through the pressure relief valve in the cap when the engine becomes hot.
- If, in an emergency, only water can be added, the correct ratio between water and antifreeze ⇒ *page 161* must be restored as soon as possible.

For the sake of the environment

Drained coolant should not be reused. Always dispose of used coolant while observing all environmental regulations.

Brake fluid

Have the brake fluid changed by an experienced technician.

Brake fluid absorbs moisture from the air. If the water content in the brake fluid is too high, corrosion in the brake system may result after a period of time. The boiling point of the brake fluid will also decrease considerably and decrease braking performance.

Therefore, the brake fluid must be changed **every two years**. Always use new brake fluid which conforms to Federal Motor Vehicle Standard “FMVSS 116 DOT 4”.

Brake fluid is replaced according to the Audi maintenance service schedule. Your authorized Audi dealer is equipped with the necessary special tools and replacement parts, has the necessary expertise, and can dispose of the used fluid.

WARNING

- Brake fluid is poisonous. It must be stored only in the closed original container out of the reach of children!
- Brake failure can result from old or inappropriate brake fluid. Observe these precautions:
 - Use only brake fluid that meets SAE specification J 1703 and conforms to Federal Motor Vehicle Standard 116. Always check with your authorized Audi dealer to make sure you are using the correct brake fluid. The correct type of brake fluid is also indicated on the brake fluid reservoir.
 - The brake fluid must be new. Heavy use of the brakes can cause a vapor lock if the brake fluid is left in the system too long. This can seriously affect the efficiency of the brakes as well as your safety. This could result in an accident.

Note

Brake fluid will damage the paint of your vehicle.

For the sake of the environment

Because of the problem of proper disposal of brake fluid as well as the special tools required and the necessary expertise, we recommend that you have the brake fluid changed by your authorized Audi dealer.

Battery

General information

Your vehicle is equipped with a special battery, an *AGM battery*. This battery is located in the luggage compartment and must be replaced with an original equipment battery. Under normal operating conditions, the battery is **maintenance-free**.

Have the battery checked when you take your vehicle in for service. You are well advised to replace a battery that is older than 5 years.

Disconnecting the battery terminals

Some vehicle functions (power window regulators, for example) are lost if the battery terminals are disconnected. These functions have to be relearned after the battery terminals are connected again. To prevent this, the battery should only be disconnected from the vehicle electrical system when absolutely necessary for repairs.

Vehicles not driven for long periods

If you do not drive your vehicle over a period of several days or weeks, electrical components are gradually cut back or switched off. This reduces energy consumption and maintains starting capability over a longer period ⇒ *page 140*. Some of the convenience functions may not operate, such as the interior lights or power seat adjustment. The convenience functions will be available again when you switch on the ignition and start the engine.

Winter operation

During the winter months, battery capacity tends to decrease as temperatures drop. This is because more power is also consumed while starting, and the headlights, rear window defogger, etc., are used more often.

Avoid unnecessary power consumption, particularly in city traffic or when traveling only short distances. Let your authorized Audi dealer check the capacity of the vehicle battery before winter sets in ⇒ *page 167*. A well charged battery will not only prevent starting problems when the weather is cold, but will also last longer.

Replacing battery

The new battery **must have** the same capacity, voltage (12 volts), amperage, construction and plug sealing, as the original battery. Specifications are listed on the battery housing. Batteries specially developed by Audi fulfill the maintenance, output, and safety requirements.

When installing the battery, make sure the ignition and all electrical consumers are switched off ⇒ .

We recommend that you use maintenance-free or **cycle-resistant/leak-proof** batteries according to the standards TL 825 06 (from April 2008) and VW 7 50 73 (from April 2010).

Replacing the battery should be carried by a qualified workshop. Please follow the instructions on the battery cover.



Note

- All work on the battery requires technical knowledge. Please contact an Audi dealership or another authorized facility for questions about the battery - danger of acid burns and explosion hazard!
- The battery must not be opened! Do not try to change the battery's liquid level, otherwise detonating gas will escape from the battery - explosion hazard!
- The AGM battery in the luggage compartment cannot leak, because the electrolyte for this battery is absorbed into a special glass mat. This leak-proof battery must not be replaced with a conventional battery.
- Make sure the ventilation hose on the side of the battery is connected, otherwise fumes or battery acid can leak out.
- Battery holder and terminals always have to be secured correctly.
- Before all work on the battery follow the **warnings** below ⇒  in *Working on the battery* on *page 166*.



For the sake of the environment

Because of the problem of proper disposal of a battery, we recommend your authorized Audi dealer change the battery for you. Batteries contain sulfuric acid and lead and must always be disposed of properly in compliance with all environmental regulations. Disposing of vehicle batteries improperly is very dangerous to the environment. Make sure that the removed battery cannot overbalance, otherwise sulfuric acid might escape!

 **Tips**

If your vehicle is left standing for several weeks at extremely low temperatures, the vehicle battery should be removed and stored where it will not freeze. This will prevent it from being damaged and having to be replaced.

Working on the battery

Be especially careful when working on or near the battery!

The battery is located in the luggage compartment behind a cover. Before you work on or near the battery, **read and heed all WARNINGS** .

Always heed the **safety warnings**, when working on the vehicle battery or the vehicle electrical system to prevent injury.

The following WARNINGS are very important when working on the battery:

Always heed the following WARNING SYMBOLS and safety precautions when working on the battery.	
	Always wear eye protection.
	Battery acid contains sulfuric acid. Always wear gloves and eye protection.
	No - sparks - flames - smoking.
	When a battery is charged, it produces hydrogen gas which is explosive and could cause personal injury.
	Always keep the battery well out of reach of children.

 **WARNING**

Whenever working on the battery or on the electrical system, there is the risk of injury, accident and even fire. Read and heed the following WARNINGS:

- Always wear eye protection. Do not let battery acid or any lead particles get on your

- skin or clothing. Shield your eyes. Explosive gases can cause blindness or other injury.
- Battery acid contains sulfuric acid. Sulfuric acid can cause blindness and severe burns.
- Always wear gloves and eye protection. Do not tilt the battery because acid could leak out of the ventilation openings.
- If you get battery acid in your eyes or on your skin, immediately rinse with cold water for several minutes and get medical attention.
- If you should ingest any battery acid, seek medical attention immediately.
- Do not expose the battery to an open flame, electric sparks or an open light.
- Do not smoke.
- Do not interchange the positive and negative cables.
- When working on the battery, be sure not to short-circuit the terminals with tools or other metal objects. This would cause the battery to heat up very quickly, which could lead to damage or explosion and personal injury.
- When a battery is charged, it produces hydrogen gas which is explosive and could cause personal injury.
- Always keep the battery well out of the reach of children.
- Before work is done on the electrical system, disconnect the negative ground cable.
- Before performing any work on the electrical system, switch off the engine and ignition as well as any electrical equipment. The negative cable on the battery must be disconnected. If you are just going to replace a light bulb, then it is enough to switch off the lights.
- Before disconnecting the battery, switch off the anti-theft alarm system! Otherwise you will set off the alarm.
- When disconnecting the battery, first disconnect the negative cable and then the positive cable.
- Before reconnecting the battery, make sure all electrical consumers are switched off. Reconnect the positive cable first and then the

negative cable. Never interchange the cables - this could start a fire!

- Never charge a frozen or a thawed-out battery. It could explode! If a battery has frozen, then it must be replaced. A discharged battery can freeze over at 32 °F (0 °C).
- Make sure the vent hose is always attached to the opening on the side of the battery.
- Never use batteries which are damaged. Danger of explosion! Always replace a damaged battery.

! WARNING

California Proposition 65 Warning:

- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive problems. Wash hands after handling.

! Note

- Do not disconnect the vehicle battery when the ignition is switched on or when the engine is running, otherwise, you will damage electronic components in the electrical system.
- If your vehicle is going to stand for a long period of time without being driven, protect the battery from “freezing”, otherwise it will be damaged and will then have to be replaced.

Charging the battery

Connections for charging the battery are located in the luggage compartment.




Fig. 144 Luggage compartment: battery cover




Fig. 145 Luggage compartment: connectors for a charger and jump start cables

Do *not* connect the negative cable directly to the negative terminal on the battery. Connect it to a **jump start pin** instead ⇒ fig. 145.

- ▶ Always read and heed all WARNINGS ⇒ ! in *Working on the battery* on page 166 and ⇒ !.
- ▶ Switch off the ignition and all electrical consumers.
- ▶ Open the luggage compartment lid ⇒ page 32.
- ▶ Remove the battery cover ⇒ fig. 144.
- ▶ Connect the terminal clamps from the charger to the battery terminal (red = “positive”) and the jump start pin ⇒ fig. 145 (black or brown = “negative”) as specified.
- ▶ Only now plug the mains lead for the charging equipment into the wall outlet and turn it on.
- ▶ When the battery is fully charged: Turn the charging equipment off and remove the mains lead from the wall outlet.
- ▶ Now remove the clamps for the charging equipment.
- ▶ Install the battery cover.
- ▶ Close the luggage compartment lid ⇒ page 32.

When charging at low voltages (e.g. with a **trickle charger**), the battery cables do not have to be disconnected first. Before charging at *high* voltages, i.e. “**fast charging**”, you must disconnect both cables. In either case, follow the instructions from the manufacturer of the charger.

Fastcharging a battery is **dangerous** ⇒ ! in *Working on the battery* on page 166. It requires special charging equipment and the knowledge to go with it. We recommend having your battery fast charged only by a qualified workshop.

A discharged battery can **freeze** at temperatures of only 32 °F (0 °C). Allow a frozen battery to

thaw completely before attempting to charge it ⇒ ⚠. However, we recommend not using a thawed battery again because the battery casing can be cracked due to ice formation and can leak battery acid.

Do not open the battery caps when charging the battery.

⚠ WARNING

Charging a battery can be dangerous.

- Never charge a frozen battery. It may explode because of gas trapped in the ice. Allow a frozen battery to thaw out first.
- Do not reuse batteries which were frozen. The battery housing may have cracked and weakened when the battery froze.
- Charge the battery in a well ventilated area. Keep away from open flame or electrical spark. Do not smoke. Hydrogen gas generated by the battery is explosive.
- To reduce the danger of explosion, never connect or disconnect charger cables while the charger is operating.
- Fast charging a battery is dangerous and should only be attempted by a competent technician with the proper equipment.
- Battery acid that may spill during charging should be washed off with a solution of warm water and baking soda to neutralize the acid.

⚠ Note

Never use a fast charger as a booster to start the engine. This will seriously damage sensitive electronic components, such as control units, relays, radio, etc., as well as the battery charger.

i Tips

- The vehicle battery must not be charged with a standard small charger that plugs into the cigarette lighter or outlet.
- Only charge the battery through the connections in the luggage compartment.

Windshield washer container



Fig. 146 Luggage compartment: Windshield washer fluid reservoir

The washer fluid container is marked with the symbol 🚿 on its cap ⇒ *page 157, fig. 134*.

- ▶ Lift the filler cap tongue to add washer fluid. You can fill the container to the top.
- ▶ Press the cap back onto the filler neck after filling the container.

You can find the reservoir **capacity** in the table in ⇒ *page 213*

Clean water should be used when filling up. If possible, use soft water to prevent scaling on the washer jets. Always add a glass cleaner solution (with frost protection in the winter).

⚠ Note

- Do not mix engine coolant antifreeze or any other additives to fill up the windshield washer reservoir.
- Do not use glass cleaners containing paint solvent; you risk damaging the paint.

Tires and wheels

Tires

General notes

Tires may be the least appreciated and most abused parts of a motor vehicle.

Tires may be the least appreciated and most abused parts of a motor vehicle. Tires are, however, one of the most important parts of a vehicle, particularly considering the comparatively small patch of rubber on each tire that assures that all-important contact between you, your vehicle and the road.

Maintaining the correct tire pressure, making sure that your vehicle and its tires do not have to carry more weight than they can safely handle, avoiding damage from road hazards and regularly inspecting tires for damage including cuts, slashes irregular wear and overall condition are the most important things that you can do to help avoid sudden tire failure including tread separation and blowouts.

Avoiding damage

If you have to drive over a curb or similar obstacle, drive very slowly

and as close as possible at a right angle to the curb.

Always keep chemicals including grease, oil, gasoline and brake fluid off the tires.

Inspect the tires regularly for damage (cuts, cracks or blisters, etc.). Remove any foreign bodies embedded in the treads.

Storing tires

Mark tires when you remove them to indicate the direction of rotation. This ensures you to be able to mount them correctly when you reinstall them.

When removed, the wheels or tires should be stored in a cool, dry and preferably dark place.

Store tires in a vertical position if they are not mounted on rims, in a horizontal position if they are mounted on rims.

New tires

New tires have to be broken in
⇒ .

The tread depth of new tires may vary, according to the type and make of tire and the tread pattern. ►

Hidden damage

Damage to tires and rims is often not readily visible. If you notice unusual vibration or the vehicle pulls to one side, this may indicate that one of the tires has been damaged. The tires must be checked immediately by an authorized Audi dealer or qualified workshop.

Unidirectional tires

A unidirectional tire can be identified by arrows on the sidewall, that point in the direction the tire is designed to rotate. You must follow the specified direction of rotation. This is necessary so that these tires can develop their optimum characteristics regarding grip, road noise, wear and hydroplaning resistance. For more information ⇒ *page 203*.

WARNING

New tires or tires that are old, worn or damaged cannot provide maximum control and braking ability.

–New tires tend to be slippery and must be broken in. To reduce the risk of losing control, a collision and serious personal injuries, drive with special

care for the first 350 miles (560 km).

- Driving with worn or damaged tires can lead to loss of control, sudden tire failure, including a blowout and sudden deflation, crashes and serious personal injuries. Have worn or damaged tires replaced immediately.
- Tires age even if they are not being used and can fail suddenly, especially at high speeds. Tires that are more than 6 years old can only be used in an emergency and then with special care and at low speed.
- Never mount used tires on your vehicle if you are not sure of their “previous history.” Old used tires may have been damaged even though the damage cannot be seen that can lead to sudden tire failure and loss of vehicle control.
- If you notice unusual vibration or if the vehicle pulls to one side when driving, always stop as soon as it is safe to do so and check the wheels and tires for damage.

Note

–Please note that summer and winter tires are designed for the conditions that are typical in those seasons. Audi recommends using winter tires during the winter months. Low temperatures significantly decrease the elasticity of summer tires, which affects traction and braking ability. If summer tires are used in very cold temperatures, cracks can form on the tread bars, resulting in

permanent tire damage that can cause loud driving noise and unbalanced tires. Audi is not responsible for this type of damage.

–Burnished, polished or chromed rims must not be used in winter road conditions. The surface of the rims does not have sufficient corrosion protection for this and could be permanently damaged by road salt or similar substances.

Glossary of tire and loading terminology

Accessory weight

means the combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio, and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

Aspect ratio

means the ratio of the height to the width of the tire in percent. Numbers of 55 or lower indicate a low sidewall for improved steer-

ing response and better overall handling on dry pavement.

Bead

means the part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim.

Bead separation

means a breakdown of the bond between components in the bead.

Cord

means the strands forming the plies in the tire. ►

Cold tire inflation pressure

means the tire pressure recommended by the vehicle manufacturer for a tire of a designated size that has not been driven for more than a couple of miles (kilometers) at low speeds in the three hour period before the tire pressure is measured or adjusted.

Curb weight

means the weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, air conditioning and additional weight of optional equipment.

Extra load tire

means a tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire. Extra load tires may be identified as “XL”, “xl”, “EXTRA LOAD”, or “RF” on the sidewall.

Gross Axle Weight Rating (“GAWR”)

means the load-carrying capacity of a single axle system, measured at the tire-ground interfaces.

Gross Vehicle Weight Rating (“GVWR”)

means the maximum total loaded weight of the vehicle.

Groove

means the space between two adjacent tread ribs.

Load rating (code)

means the maximum load that a tire is rated to carry for a given inflation pressure. You may not find this information on all tires because it is not required by law.

Maximum load rating

means the load rating for a tire at the maximum permissible inflation pressure for that tire.

Maximum loaded vehicle weight

means the sum of:

- (a) Curb weight
- (b) Accessory weight
- (c) Vehicle capacity weight, and
- (d) Production options weight

Maximum (permissible) inflation pressure

means the maximum cold inflation pressure to which a tire may be inflated. Also called “maximum inflation pressure.”

Normal occupant weight

means 150 lbs. (68 kilograms) times the number of occupants seated in the vehicle up to the total seating capacity of your vehicle.

Occupant distribution

means distribution of occupants in a vehicle.

Outer diameter

means the overall diameter of an inflated new tire.

Overall width

means the linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs.

Ply

means a layer of rubber-coated parallel cords.

Production options weight

means the combined weight of those installed regular production options weighing over 5 lbs. (2.3 kg) in excess of those standard items which they replace, not previously considered in curb weight or accessory weight, including

heavy duty brakes, ride levelers, heavy duty battery, and special trim.

Radial ply tire

means a pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread.

Recommended inflation pressure

see $\Rightarrow$ page 172, *Cold tire inflation pressure*.

Reinforced tire

means a tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire. Reinforced tires may be identified as "XL", "xl", "EXTRA LOAD", or "RF" on the sidewall.

Rim

means a metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Rim diameter

means nominal diameter of the bead seat. If you change your

wheel size, you will have to purchase new tires to match the new rim diameter.

Rim size designation

means rim diameter and width.

Rim width

means nominal distance between rim flanges.

Sidewall

means that portion of a tire between the tread and bead.

Speed rating (letter code)

means the speed at which a tire is designed to be driven for extended periods of time. The ratings range from 93 mph (150 km/h) to 186 mph (298 km/h)

⇒ *page 189*. You may not find this information on all tires because it is not required by law.

The speed rating letter code, where applicable, is molded on the tire sidewall and indicates the maximum permissible road speeds ⇒ ⚠ in *Winter tires on page 194*.

Tire pressure monitoring system

means a system that detects when one or more of a vehicle's

tires are underinflated and illuminates a low tire pressure warning telltale.

Tread

means that portion of a tire that comes into contact with the road.

Tread separation

means pulling away of the tread from the tire carcass.

Treadwear indicators (TWI)

means the projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread. See

⇒ *page 185, Tread Wear Indicator (TWI)* for more information on measuring tire wear.

Uniform Tire Quality Grading

is a tire information system developed by the United States National Highway Traffic Safety Administration (NHTSA) that is designed to help buyers make relative comparisons among tires. The UTQG is not a safety rating and not a guarantee that a tire will last for a prescribed number of miles or perform in a certain way. It simply gives tire buyers additional information to combine with other considerations, such as price, ►

brand loyalty and dealer recommendations. Under UTQG, tires are graded by the tire manufacturers in three areas: treadwear, traction and temperature resistance. The UTQG information on the tires, molded into the sidewalls.

U.S. DOT Tire Identification Number (TIN)

This is the tire's "serial number" It begins with the letters "DOT" and indicates that the tire meets all federal standards. The next two numbers or letters indicate the plant where it was manufactured, and the last four numbers represent the week and year of manufacture. For example,

DOT ... 2213 ...

means that the tire was produced in the 22nd week of 2013. The other numbers are marketing codes that may or may not be used by the tire manufacturer. This information is used to contact con-

sumers if a tire defect requires a recall.

Vehicle capacity weight

means the rated cargo and luggage load plus 150 lbs. (68 kilograms) times the vehicle's total seating capacity as listed on the label located on the driver's side B-pillar.

Vehicle maximum load on the tire

means that load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing by two.

Vehicle normal load on the tire

means that load on an individual tire that is determined by distributing to each axle its share of the curb weight, accessory weight, and normal occupant weight (distributed in accordance with table below ⇒ *page 176*) and dividing by two. ►

Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, number of occupants	Vehicle normal load, number of occupants	Normally loaded vehicle, occupant distribution
2	2	2 in front

Cold tire inflation pressure

Tire pressure affects the overall handling, performance and safety of a vehicle.



Fig. 147 Tire pressure label: located on driver's side B-pillar

Tire pressure generally refers to the amount of air in a tire that it needs it to do its job and safely carry the combined load of the entire vehicle and its contents. Tire pressure is measured in kilopascals (kPa), the international measuring unit and in pounds per square inch (PSI). Tire pressure is based in part on the vehicle's design and load limit – the greatest amount of weight that the vehicle can carry safely and the tire size. The proper tire pressure is fre-




Fig. 148 Tire pressure label

quently referred to as the “recommended cold tire inflation pressure.” Air in the tires expands when the tire heats up because of internal friction when it flexes in use. The tire pressure is higher when the tire has warmed up than when it is “cold.” It is the inflation pressure in a “cold” tire that counts. Therefore, you should never let air out of a warm tire to match “cold tire inflation pressure” recommendations. The tires ►

would then be underinflated and could fail suddenly.

Maintaining proper tire pressure is one of the most important things you can do to help avoid sudden tire failure. Underinflated tires are a major cause of sudden tire failure. Keeping tires at the right pressure is also important for safe and responsive vehicle handling, traction, braking and load carrying. **Tire pressures are particularly important when the vehicle is being driven at higher speeds, and then especially when heavily loaded even within the permissible load-carrying capacities approved for your vehicle.**

The recommended tire pressures for your Audi depend on the kind of tires on your vehicle and the number of passengers and/or amount of luggage you will be transporting.

The tire pressure label is located on the driver's side B-pillar. The tire pressure label lists the recommended cold tire inflation pressures for the vehicle at its maximum capacity weight and tires that were on your vehicle at the time it was manufactured.

If you wish to improve comfort when operating the vehicle at normal load (up to 2 occupants), you can adjust tire pressures to those specified for normal vehicle load. Before operating the vehicle at maximum load, you must increase the tire pressures to those specified for maximum vehicle load ⇒ .

Bear in mind that the tire pressure monitoring system can only monitor the tire pressures that are stored. The system does not recognize the load condition of your vehicle.

See the illustration ⇒ *fig. 147* for the location of the label on driver's side B-pillar (color of the actual label and exact location on the vehicle will vary slightly).

Note that the following table is accurate at the time of going to press and is subject to change. In the event of discrepancies, the tire pressure label on driver's side B-pillar always takes precedence.

The table below lists the recommended cold tire inflation pressures for the Audi model covered by your Owner's Literature at the vehicle's capacity weight and the ►

tire sizes installed on the respective models as original equipment, or as a factory option.

Model/ Engine	Tire designation	Tire pressure front				Tire pressure rear			
		normal load condition		full load condition		normal load condition		full load condition	
		PSI	kPA	PSI	kPA	PSI	kPA	PSI	kPA
R8: 4.2 liter 8-cylinder	235/35 R19 91Y XL	45	310	45	310	---	---	---	---
	295/30 R19 100Y XL	---	---	---	---	41	280	41	280
	305/30 R19 102Y XL	---	---	---	---	41	280	41	280
R8: 5.2 liter 10-cylinder	235/35 R19 91Y XL	45	310	45	310	---	---	---	---
	295/30 R19 100Y XL	---	---	---	---	41	280	41	280
	305/30 R19 102Y XL	---	---	---	---	41	280	41	280
XL = reinforced or extra load tire. It may also appear as xl, EXTRA LOAD, or RF on the tire sidewall.									

Because technical changes may be made to vehicle equipment during the model year, always compare the tire size designation on the tire pressure label on your vehicle with the tires on your vehicle. Make sure that the tire size information on the vehicle label is the same as the size of the tires on the vehicle. This is especially important if the vehicle belongs to someone else or you bought the vehicle with different rims/tires or you bought the vehicle as a previously owned vehicle.

Remember, your safety and that of your passengers also depends on making sure that load limits are not exceeded. Vehicle load includes everybody and everything

in and on the vehicle. These load limits are technically referred to as the vehicle’s Gross Vehicle Weight Rating (“GVWR”). The Gross Axle Weight Rating (“GAWR”) is the maximum load that can be applied at each of the vehicle’s two axles. The Gross Vehicle Weight Rating and the Gross Axle Weight Rating are listed on the safety compliance sticker label located on the driver’s side B-pillar. The tire pressure label on your Audi lists the maximum combined weight of all of the occupants and luggage or other cargo that the vehicle can carry. For the location of the tire pressure label ⇨ *fig. 147*.

! WARNING

Overloading a vehicle can cause loss of vehicle control, a crash or other accident, serious personal injury, and even death.

- Carrying more weight than your vehicle was designed to carry will prevent the vehicle from handling properly and increase the risk of a loss of vehicle control.
- The brakes on a vehicle that has been overloaded may not be able to stop the vehicle within a safe distance.
- Tires on a vehicle that has been overloaded can fail suddenly causing loss of control and a crash.

! WARNING

- Incorrect tire pressures and/or underinflation can lead to a serious or fatal accident.
- Incorrect tire pressures and/or underinflation cause increased tire wear and can affect the handling of the vehicle.
- Incorrect tire pressures and/or underinflation can also lead to sudden tire failure, including a blowout and sudden deflation, causing loss of vehicle control.

Checking tire pressure

The correct tire pressure for the tires originally installed on your vehicle is listed on the tire pressure label located on driver's side B-pillar.

The recommended tire pressures are on the tire pressure label and in the table ⇒ *page 176, Cold tire inflation pressure*. This means that the pressure must be checked and adjusted when the tire has not been driven for more than a couple of miles (kilometers) at low speeds during the previous three hours. Air in the tires expands when the tire heats up as a result of internal friction as it flexes in use. The tire pressure is higher when the tire has warmed up than when it is “cold”.

It is the inflation pressure in a “cold” tire that counts. Therefore, you should never let air out of a warm tire to match “Cold tire inflation pressure” recommendations ⇒ *page 176*. The tires would then be underinflated and could fail suddenly.

The tire pressure label on your Audi lists the recommended cold tire inflation pressures for the

new, original equipment tires that were on your vehicle at the time it was manufactured. For the location of the label ⇒ *page 176, fig. 147.*

Most tires lose air naturally over time. They can also lose some air if you drive over a pothole or hit a curb while parking. It is usually not possible to see whether the radial tires used today are under-inflated just by looking at them.

Therefore, be sure to check tire pressures at least once a month and always before going on a long trip. Make sure to take the number of people and the amount of luggage into account when adjusting tire pressure for a trip – even one that you would not consider to be “long”. See ⇒ *page 182, Tires and vehicle load limits* for more important information.

Always use an accurate tire pressure gauge when checking and adjusting inflation pressures. Check all of the tires. If the pressure in any tire is too high when the tire is “cold”, let air out of the tire slowly with the edge of the tire gauge and keep checking the

pressure until you reach the pressure that is correct for the load (passengers and luggage) and kind of driving you plan to do.

If the pressure in any tire is too low, note the difference between the pressure in the cold tire and the pressure you need and add the air that you need to reach the correct pressure for the vehicle load (passengers and luggage) for the tires on your vehicle as listed on the on your vehicle and in this manual and the kind of driving you plan to do.

Never exceed the maximum inflation pressure listed on the tire sidewall for any reason.

Remember that the vehicle manufacturer, not the tire manufacturer, determines the correct tire pressure for the tires on your vehicle.

It is important to check the tire pressure when the tires are cold.

- Read the required tire pressure from the tire pressure label located on driver's side B-pillar.
- Turn the valve stem cap counter-clockwise to remove it from the tire valve. ►

- Place the air pressure gauge on the valve.
- The tire pressures should only be checked and adjusted when the tires are cold. The slightly raised pressures of warm tires must not be reduced.
- Adjust the tire pressure to the load you are carrying.
- Reinstall the valve stem cap on the valve.

When should I check the tire pressure?

The correct tire pressure is especially important at high speeds. The pressure should therefore be checked at least once a month and always before starting a journey.

When should I adjust the tire pressures?

Adjust the tire pressure to the load you are carrying. After changing a wheel **or** replacing wheels you have to adjust the tire pressures on all wheels. In addition, you must then initialize the new tire pressures in the tire pressure monitoring system
⇒ *page 196.*



WARNING

Incorrect tire pressures and/or underinflation can lead sudden tire failure, loss of control, collision, serious personal injury or even death.

- When the warning symbol  appears in the instrument cluster, stop and inspect the tires.
- Incorrect tire pressure and/or underinflation can cause increased tire wear and can affect the handling of the vehicle and stopping ability.
- Incorrect tire pressures and/or underinflation can also lead to sudden tire failure, including a blowout and sudden deflation, causing loss of vehicle control.
- The driver is responsible for the correct tire pressures for all tires on the vehicle. The applicable pressure values are located on a sticker on the driver's side B-pillar.
- Only when all tires on the vehicle are filled to the correct pressure, the tire pressure monitoring system can work correctly.

- The use of incorrect tire pressure values can lead to accidents or other damage. Therefore it is essential that the driver observe the specified tire pressure values for the tires and the correct pressures for the function of the tire pressure monitoring system.
- Always inflate tires to the recommended and correct tire pressure before driving off.
- Driving with underinflated tires bend more, letting them get too hot resulting in tread separation, sudden tire failure and loss of control.
- Excessive speed and/overloading can cause heat build-up, sudden tire failure and loss of control.
- If the tire pressure is too low or too high, the tires will wear prematurely and the vehicle will not handle well.
- If the tire is not flat and you do not have to change a wheel immediately, drive at reduced speed to the nearest service station to check the tire pressure and add air as required.



Note

Driving without valve stem caps can cause damage to the tire valves. To prevent this, always make sure that factory installed valve stem caps on all wheels are securely mounted on the valve.



For the sake of the environment

Underinflated tires will also increase the fuel consumption.

Tires and vehicle load limits

There are limits to the amount of load or weight that any vehicle and any tire can carry. A vehicle that is overloaded will not handle well and is more difficult to stop. Overloading can not only lead to loss of vehicle control, but can also damage important parts of the vehicle and can lead to sudden tire failure, including a blowout and sudden deflation that can cause the vehicle to crash.

Your safety and that of your passengers also depends on making sure that load limits are not exceeded. Vehicle load includes everybody and everything in and on the vehicle. These load limits are ►

technically referred to as the vehicle's **Gross Vehicle Weight Rating** ("GVWR").

The "GVWR" includes the weight of the basic vehicle, all factory installed accessories, a full tank of fuel, oil, coolant and other fluids plus maximum load. The maximum load includes the number of passengers that the vehicle is intended to carry ("seating capacity") with an assumed weight of 150 lbs. (68 kg) for each passenger at a designated seating position and the total weight of any luggage in the vehicle.

The **Gross Axle Weight Rating** ("GAWR") is the maximum load that can be applied at each of the vehicle's two axles.

The Gross Vehicle Weight Rating and the Gross Axle Weight Rating are listed on the safety compliance sticker label located on the driver's side B-pillar. Your Audi has 2 seating positions. Each seating position has a safety belt ⇒ *page 95, Safety belts*.

The fact that there is an upper limit to your vehicle's Gross Vehicle Weight Rating means that the total weight of whatever is being

carried in the vehicle is limited. The more passengers in the vehicle or passengers who are heavier than the standard weights assumed mean that less weight can be carried as luggage.

The tire pressure label on your Audi also lists the maximum combined weight of all of the occupants and luggage or other cargo that the vehicle can carry. For the location of the label ⇒ *page 176, fig. 147*.



WARNING

Overloading a vehicle can cause loss of vehicle control, a crash or other accident, serious personal injury, and even death.

- Carrying more weight than your vehicle was designed to carry will prevent the vehicle from handling properly and increase the risk of the loss of vehicle control.
- The brakes on a vehicle that has been overloaded may not be able to stop the vehicle within a safe distance.
- Tires on a vehicle that has been overloaded can fail suddenly, including a blowout and

sudden deflation, causing loss of control and a crash.

Determining correct load limit

Use the example below to calculate the total weight of the passengers and luggage or other things that you plan to transport so that you can make sure that your vehicle will not be overloaded.

Steps for Determining Correct Load Limit

1. Locate the statement “THE COMBINED WEIGHT OF OCCUPANTS AND CARGO SHOULD NEVER EXCEED XXX KG OR XXX LBS” on your vehicle’s placard (tire inflation pressure label)
⇒ *page 176, fig. 147.*
2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
3. Subtract the combined weight of the driver and passengers from “XXX” kilograms or “XXX” pounds shown on the sticker
⇒ *page 176, fig. 147.*
4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the “XXX” amount equals 1400 lbs. and there will be five 150 lbs. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.
(1400-750 (5 x 150) = 650 lbs.)
5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.
 - Check the tire sidewall (⇒ *page 186, fig. 150*) to determine the designated load rating for a specific tire.

Tire service life

The service life of tires depends on a lot of different things including proper installation and balancing, correct tire pressure and driving style.



Fig. 149 Tire tread: tread wear indicators (TWI)

Tread Wear Indicator (TWI)

The original tires on your vehicle have 1/16 inch (1.6 mm) high “wear indicators” ⇒ *fig. 149* running across the tread. Depending on the make, there will be six to eight of them evenly placed around the tire. Marks on the tire sidewall (for example “TWI” or other symbols) indicate the positions of the tread wear indicators. Worn tires must be replaced. Different figures may apply in other countries ⇒ ⚠.

Tire pressure

Incorrect tire pressure causes premature wear and can cause sud-

den tire blow-out. For this reason, tire pressure must be checked at least once a month ⇒ *page 179*.

Driving style

Driving fast around curves, heavy acceleration and hard braking increase tire wear.

Wheel balancing

The wheels on new vehicles are balanced. However, various situations during everyday driving can cause them to become unbalanced, resulting in vibrations you can usually feel through the steering wheel.

Unbalanced wheels must be rebalanced to avoid excessive wear on steering, suspension and tires. A wheel must also be rebalanced when a new tire is installed.

Incorrect wheel alignment

Incorrect wheel alignment can cause excessive tire wear, impairing the safety of the vehicle. If tires show excessive wear, have the wheel alignment checked by an authorized Audi dealer or qualified workshop. ►

All-wheel drive

Only the wheel/tire sizes specified by the manufacturer may be used on vehicles with all-wheel drive. For details see ➔ *page 139*.

 **WARNING**

Sudden tire failure can lead to loss of control, a crash and serious personal injury!

- Never drive a vehicle when the tread on any tire is worn down to the wear indicators.
- Worn tires are a safety hazard, they do not grip well on wet roads and increase your risk of “hydroplaning” and loss of control.
- Always keep chemicals that can cause tire damage, such as grease, oil, gasoline and brake fluid away from tires.
- Tires age even if they are not being used and can fail suddenly, especially at high speeds. Tires that are more than 6 years old can only be used in an emergency and then with special care and at lower speeds.
- Never mount used tires on your vehicle if you are not sure of their “previous history.” Old

used tires may have been damaged even though the damage cannot be seen that can lead to sudden tire failure and loss of vehicle control.

New tires and replacing tires and wheels

New tires and wheels have to be broken in.




Fig. 150 Tire specification codes on the sidewall of a tire

No	Description
1	Passenger car tire (where applicable)
2	Nominal width of tire in millimeters

No	Description
③	Ratio of height to width (aspect ratio)
④	Radial
⑤	Rim diameter code
⑥	Load index and speed rating
⑦	U.S. DOT tire identification number
⑧	Audi Original tire
⑨	Sever snow conditions
⑩	Tire ply composition and materials used
⑪	Maximum load rating
⑫	Treadwear, traction and temperature grades
⑬	Maximum permissible inflation pressure

The tires and rims are essential parts of the vehicle's design. The tires and rims approved by Audi are specially matched to the characteristics of the vehicle and can make a major contribution to good road holding and safe handling when in good condition and properly inflated ⇒ .

We recommend that all work on tires and wheels be performed by an authorized Audi dealer. They are familiar with recommended

procedures and have the necessary special tools and spare parts as well as the proper facilities for disposing of the old tires.

Authorized Audi dealers have the necessary information about technical requirements for installing or changing tires and rims.

Replacing tires and wheels

Tires should be replaced at least in pairs and not individually (for example both front tires or both rear tires together).

Be sure to read and heed the information to the tire pressure monitoring system ⇒ *page 190*.

Always buy replacement radial tires that have the same specifications as the tires approved for your vehicle by Audi. Replacement tires must always have the same load rating specification as the original equipment or approved optional tires listed in the table ⇒ *page 176*.

Audi-approved specification tires are specially matched to your vehicle and its load limits, and can contribute to the important road-holding, driving characteristics, and safety of the vehicle. The

table (⇒ *page 176*) lists specifications of the tires approved for the Audi models covered by your Owner's Literature.

The tire pressure label located on driver's side B-pillar (⇒ *page 176*, *fig. 148*) lists the specifications of the original equipment tires installed on your vehicle at the time it was manufactured.

Federal law requires tire manufacturers to place standardized information on the sidewall of all tires ⇒ *fig. 150*. This information identifies and describes the fundamental characteristics, the quality grade of the tire and also provides a tire identification number for safety standard certification and in case of a recall.

Tire specifications

Knowledge of tire specifications makes it easier to choose the correct tires. Radial tires have the tire specifications marked on the sidewall, for example:

P235 / 35 R 19 91 Y

This contains the following information:

P Indicates the tire is for passenger cars

235 Nominal tire width in mm of the tire from sidewall edge to sidewall edge. In general, the larger the number, the wider the tire

35 Height/width ratio in percent (aspect ratio)

R Tire construction: **R**adial

19 Rim diameter code (in inches)

91 Load rating code

Y Speed rating letter code

XL (or "xl", "EXTRA LOAD", or "RF") indicates that the tire is a "Reinforced" or an "Extra Load" tire

M+S (or "M/S") Indicates that the tire has some mud and snow capability

The tires could also have the information of direction of rotation ⇒ *page 170*.

Tire manufacturing date

The manufacturing date is also indicated on the tire sidewall (possibly only on the *inner* side of the wheel):

"DOT ... 2213..." means, for example, that the tire was produced in the 22nd week of 2013. ►

Speed rating (letter code)

The speed rating letter code on the wheels indicates the maximum permissible road speeds
⇒  in *Winter tires on page 194*.

P	up to 93 mph (150 km/h)
Q	up to 99 mph (158 km/h)
R	up to 106 mph (170 km/h)
S	up to 110 mph (180 km/h)
T	up to 118 mph (190 km/h)
U	up to 124 mph (200 km/h)
H	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h) ¹⁾
Z	over 149 mph (240 km/h) ¹⁾
W	up to 168 mph (270 km/h) ¹⁾
Y	up to 186 mph (298 km/h) ¹⁾

Your vehicle is normally factory equipped with tires, which possess excellent driving characteristics and give your Audi optimum driving comfort ⇒ .

U.S. DOT Tire Identification Number (TIN) and tire manufacture date

This is the tire's "serial number". It begins with the letters "DOT" and indicates that the tire meets all federal standards. The next

two numbers or letters indicate the plant where it was manufactured, and the last four numbers represent the week and year of manufacture. For example, the numbers 2213 mean that the tire was produced in the 22nd week of 2013. The other numbers are marketing codes that may or may not be used by the tire manufacturer. This information is used to contact consumers if a tire defect requires a recall.

Audi Original tire

Tires with the identification "AO" or "RO" have been specially matched with your Audi. We recommend using only these tires because they meet the highest standards regarding safety and driving characteristics when used correctly. Your authorized Audi dealer will gladly provide you with more information. ►

¹⁾ For tires with a maximum speed capability over 149 mph (240 km/h), tire manufacturers sometimes use the letters "ZR."

Tire ply composition and materials used

The number of plies indicates the number of layers of rubber-coated fabric in the tire. In general, the greater the number of plies, the more weight a tire can support. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others.

Maximum Load Rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tire.

Tire quality grading for treadwear, traction, and temperature resistance

Tread wear, traction and temperature grades ⇒ *page 192*.

Maximum Permissible Inflation Pressure

This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

Replacing tires or rims on vehicles equipped with tire pressure monitoring system

The wheels on your vehicle are equipped with a sensor which constantly monitors the air pressure inside the tire, and then transmits this information to the tire pressure monitoring system. If you are going to replace the wheel rims on your vehicle, make sure the new rims also have these sensors. The sensors must be compatible with the tire pressure monitoring system on your vehicle.

If you install rims, which do not have the sensors, or have sensors which are not compatible, then the tire pressure monitoring system will not work properly. In this case, the tire pressure monitoring system would not be able to monitor the tire pressure or warn you if it is necessary.

- The battery inside of the tire pressure sensor has a limited service life.
- Always drive with the valve stem caps securely mounted. We recommend using factory installed ►

valve stem caps. Ask your authorized Audi dealer to replace lost valve stem caps.

The installation of replacement tires with steel cord body plies in the tire sidewall may cause malfunction of the tire pressure monitoring system, and is not recommended (cord material information is molded on the tire sidewall).

Always check your tire pressure monitoring system indicator after replacing one or more tires on your vehicle. If the tire pressure monitoring system indicator flashes, or is on, your system is not working properly.

 WARNING

- Using incorrect or unmatched tires and / or wheels or improper tire and wheel combinations can lead to loss of control, collision and serious personal injury.
- Always use tires, rims and wheel bolts that meet the specifications of original factory-installed tires or other combinations that have been specifically approved by the vehicle manufacturer.

- Tires age even if they are not being used and can fail suddenly, especially at high speeds. Tires that are more than 6 years old can only be used in an emergency and then with special care and at lower speeds.
- Never mount used tires on your vehicle if you are not sure of their “previous history.” Old used tires may have been damaged even though the damage cannot be seen that can lead to sudden tire failure and loss of vehicle control.
- Only the wheel/tire sizes specified by the manufacturer may be used on vehicles with all-wheel drive.
- Never drive faster than the maximum speed for which the tires on your vehicle are rated because tires that are driven faster than their rated speed can fail suddenly.
- Overloading tires cause heat build-up, sudden tire failure, including a blowout and sudden deflation and loss of control.

- Temperature grades apply to tires that are properly inflated and not over or underinflated.
- For technical reasons it is not always possible to use wheels from other vehicles – in some cases not even wheels from the same vehicle model.
- Do not use run-flat tires on your vehicle. Using run-flat tires can lead to vehicle damage or crashes.

Note

- When installing new tires, be careful not to damage the valves or tire pressure monitoring system sensors.
- Never drive without the valve stem cap. The valves could get damaged.
- If the sensors must be replaced, then the valve must also be replaced at the same time.

Note

- For technical reasons, it is not generally possible to use the wheel rims from other vehicles. This can hold true for wheels of the same vehicle type.
- If you should put different wheels and tires on your vehicle (e.g. winter wheels and tires), you must be certain that the wheels and tires are compatible with the tire pressure monitoring system. Otherwise the system will register a malfunction and a fault message will be displayed. For more information, contact your authorized Audi dealer.

For the sake of the environment

Dispose of old tires in accordance with the local requirements.

Tips

Tires with the identification “R01” have been specially matched with your Audi. We recommend using only these tires because they meet the highest standards regarding safety and driving characteristics when used correctly. Your authorized Audi R8 dealer will gladly provide you with more information.

Uniform tire quality grading

- Tread wear
- Traction AA A B C
- Temperature A B C

Quality grades can be found where applicable on the tire side wall between tread shoulder and maximum section width ⇒ *page 186, fig. 150*.

For example: Tread wear **200**, Traction **AA**, Temperature **A**.

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

Tread wear

The *tread wear* grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and one half (1 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The *traction* grades, from highest to lowest, are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance ⇒ ⚠.

Temperature

The *temperature* grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure ⇒ ⚠.

The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels

of performance on the laboratory test wheel than the minimum required by law.

WARNING

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning or peak traction characteristics.

WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Winter tires

Winter tires can improve vehicle handling on snow and ice. At temperatures below 45 °F (7 °C) we recommend changing to winter tires.

In some heavy snow areas, local governments may require true winter or "snow" tires, those with very deeply cut tread. These tires should only be used in pairs and be installed on all four wheels. Make sure you purchase snow tires that are the same size and construction type as the other tires on your vehicle.

If your vehicle is equipped with all-wheel drive*, this will improve traction during winter driving, even with the standard tires. However, we strongly recommend that you always equip all four wheels on your vehicle with correctly fitted winter tires or all-season tires, when winter road conditions are expected. This also improves the vehicle's braking performance and reduces stopping distances.

Summer tires provide less grip on ice and snow.

Winter tires (snow tires) must always be fitted on all four wheels.

Compatible tire pressure monitoring sensors must be installed on all four winter tires for the tire pressure monitoring system to function properly ⇒ *page 190*.

Ask your authorized Audi dealer or qualified workshop for permitted **winter tire sizes**. Use only radial winter tires.

Winter tires lose their effectiveness when the tread is worn down to a depth of 0.157 inch (4 mm).

Only drive with winter tires under winter conditions. Summer tires handle better when there is no snow or ice on the roads and the temperature is above 45 °F (7 °C).

Please always remember that winter tires may have a lower speed rating than the tires originally installed on your vehicle at the time it was manufactured. Please see ⇒ *page 189, Speed rating (letter code)* for a listing of the speed rating letter codes and the maximum speed at which the tires can be driven.

The speed rating letter code (⇒ *page 174*) is on the side wall of the tire ⇒ *page 186*.

WARNING

Winter tires have maximum speed limits that may be lower than your vehicle's maximum speed. Always know the maximum speed before driving off. Never drive faster than the speed permitted for your specific winter tires. This will cause damage to the tires leading to an accident and serious personal injury to you and your passengers.

WARNING

Driving faster than the maximum speed for which the winter tires on your vehicle were designed can cause tire failure including a blowout and sudden deflation, loss of control, crashes and serious personal injuries. Have worn or damaged tires replaced immediately.

- Winter tires have maximum speed rating that may be lower than your vehicle's maximum speed.
- Never drive faster than the speed for which the winter or other tires installed on your vehicle are rated.

WARNING

Always adjust your driving to the road and traffic conditions. Never let the good acceleration of the winter tires and all-wheel drive tempt you into taking extra risks. Always remember:

- When braking, an all-wheel drive vehicle handles in the same way as a front drive vehicle.
- Drive carefully and reduce your speed on icy and slippery roads, even winter tires cannot help under black ice conditions.



For the sake of the environment

Use summer tires when weather conditions permit. They are quieter, do not wear as quickly and reduce fuel consumption.

Snow chains

Snow chains may be fitted only to the rear wheels, and only to certain tire sizes. Ask your authorized Audi dealer on which tire sizes snow chains can be used.

The snow chains must have low-profile links and must not be thicker than 0.53 inch (13.5 mm), including the lock.

Remove wheel center covers before putting snow chains on your vehicle ⇒ . For safety reasons cover caps must then be fitted over the wheel bolts. These are available from authorized Audi dealers.

WARNING

Using the wrong snow chains for your vehicle or installing them incorrectly can increase the risk of loss of control leading to serious personal injury.

- Snow chains are available in different sizes. Always make sure to follow the instructions provided by the snow chain manufacturer.
- When driving with snow chains, never drive faster than the speed permitted for your specific snow chains.
- Always observe local regulations.

Note

- Remove snow chains before driving on roads not covered with snow to avoid damaging tires and wearing the snow chains down unnecessarily.
- Snow chains, which come into direct contact with the wheel rim, can scratch or damage it. Therefore, make sure that the snow chains are suitably covered. Check the position of the snow chains after driving a few yards and correct if necessary. Follow the instructions from the snow chain manufacturer when doing so.

Tips

Where snow chains are mandatory on certain roads, this normally also applies to vehicles with all-wheel drive.

- Never use different wheels bolts on your vehicle.
- Always maintain the correct tightening torque for the wheel bolts to reduce the risk of a wheel loss. If the tightening torque of the wheel bolts is too low, they can loosen and come out when the vehicle is moving. If the tightening torque is too high, the wheel bolts and threads can be damaged and the wheel can become loose.

Note

The specified torque for the wheel bolts is 90 ft lb (120 Nm) with a tolerance of ± 7.4 ft lb (± 10 Nm). Torque wheel bolts diagonally. After changing a wheel, the torque must be checked as soon as possible with a torque wrench – preferably by an authorized Audi dealer or qualified workshop.

Wheel bolts

Wheel bolts must always be tightened to the correct torque.

The design of wheel bolts is matched to the factory installed rims. If different rims are fitted, the correct wheel bolts with the right length and correctly shaped bolt heads must be used. This ensures that wheels are fitted securely and that the brake system functions correctly.

In certain circumstances, you may not use wheel bolts from a different vehicle – even if it is the same model ⇒ *page 217*.

WARNING

- Improperly tightened or maintained wheel bolts can become loose causing loss of control, a collision and serious personal injury.
- Always keep the wheel bolts and the threads in the wheel hubs clean so the wheel bolts can turn easily and be properly tightened.
 - Never grease or oil the wheel bolts and the threads in the wheel hubs. They can become loose while driving if greased or oiled, even if tightened to the specified torque.
 - Only use wheel bolts that belong to the rim being installed.

Low aspect ratio tires

Your Audi is factory-equipped with low aspect ratio tires. These tires have been thoroughly tested and been selected specifically for your model for their superb performance, road feel and handling under a variety of driving conditions. Ask your authorized Audi dealer for more details.

The low aspect ratio of these tires is indicated by a numeral of **55 or less** in the tire's size designation. The numeral represents the ratio of the tire's sidewall height in relation to its tread width expressed in percentage. Conventional tires have a height/width ratio of 60 or more.

The performance of low-aspect-ratio tires is particularly sensitive to improper inflation pressure. It is therefore important that low aspect ratio tires are inflated to the specified pressure and that the inflation pressure is regularly checked and maintained. Tire pressures should be checked at least once a month and always before a long trip ⇒ *page 179, Checking tire pressure*.

What you can do to avoid tire and rim damage

Low aspect ratio tires can be damaged more easily by impact with potholes, curbs, gullies or ridges on the road, particularly if the tire is underinflated.

In order to minimize the occurrence of impact damage to the tires of your vehicle, we recommend that you observe the following precautions:

- Always maintain recommended inflation pressures. Check your tire pressure every 2.000 miles (3.000 km) and add air if necessary.
- Drive carefully on roads with potholes, deep gullies or ridges. The impact from driving through or over such obstacles can damage your tires. Impact with a curb may also cause damage to your tires.
- After any impact, immediately inspect your tires or have them inspected by the nearest authorized Audi dealer. Replace a damaged tire as soon as possible.
- Inspect your tires every 2.000 miles (3.000 km) for damage and wear. Damage is not always easy to see. Damage can lead to loss of air and underinflation, which could eventually cause tire failure. If you believe that a tire may have been damaged, replace the tire as soon as possible.
- These tires may wear more quickly than others.
- Please also remember that, while these tires deliver responsive handling, they may ride less comfortably and make more noise than other choices.

Reduced performance in winter/cold season conditions

All tires are designed for certain purposes. The low aspect ratio, ultra high performance tires originally installed on your vehicle are intended for maximum dry and wet road performance and handling. They are not suitable for cold, snowy or icy weather conditions. If you drive under those circumstances, you should equip your vehicle with all-season or winter tires, which offer better traction under those conditions. We suggest you

use the recommended snow or all-season tires specified for your vehicle, or their equivalent.

Refer to ⇒ *page 193* for more detailed information regarding winter tires.

Tire pressure monitoring system

General notes

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.).

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon ►

subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Introduction

The tire pressure monitoring system monitors air pressure in all four road wheels while the vehicle is moving.

As soon as the tire pressure monitoring system senses a significant loss of air pressure in one or several tires, text messages and yellow symbols appear in the instrument cluster display to alert the driver. The  warning light in the instrument cluster comes on when the tire is significantly underinflated.

The warning light  also illuminates in the case of a system malfunction.

Be aware that tire pressure is also dependent on the temperature of the tire. For every 18 °F (10 °C) increase in tire temperature, tire pressure increases by about 1.5 psi (0.1 bar). The tire warms up while the vehicle is moving and tire pressure rises. So you should adjust tire pressure only when they are *cold*, when the temperature of the tires is roughly the same as the ambient air temperature.

In order to keep the tire pressure monitoring system properly calibrated, tire pressure on all four tires should be checked at regular intervals.

The tire pressure is shown on the label located on the driver's side B-pillar (visible when the door is open).



WARNING

When the tire pressure monitoring system warning light is lit, one or more of your tires is significantly under-inflated. You should stop and check your tires as soon as possible, and inflate them to the proper pressure as indicated on the vehicle's tire pressure label ⇒ *page 176*. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also is likely to impair the vehicle's handling and stopping ability.



For the sake of the environment

Driving with under-inflated tires reduces fuel efficiency and tire tread life.



Tips

- Each tire should be checked monthly when the temperature of the tires is about the same as ambient air temperature and set to the recommended inflation pressure as specified on the tire pressure label ⇒ *page 176*.
- The tire pressure monitoring system helps the driver to keep an eye on tire pressures. But the driver still has the responsibility for maintaining the correct tire pressure.
- Tire pressure must only be adjusted when the temperature of the tires is about the same as ambient air temperature.
- When tires are replaced, the sensors and valves should not be exchanged. The valve core, nut, valve sealing and seal washer (replacement kit) needs to be replaced. If necessary, the valve and the wheel electronics have to be replaced.
- The tire pressure monitoring system on your Audi was calibrated using tires with “RO” identification. We recommend using these tires.
- If you should put different wheels and tires on your vehicle (e.g. winter wheels and tires), you must be certain that the wheels

and tires are compatible with the tire pressure monitoring system. Otherwise the system will register a malfunction and a fault message will be displayed. For more information, contact your authorized Audi dealer.

- For Declaration of Compliance to United States FCC and Industry Canada regulations ⇒ *page 218*.

Programming a new set of tires

Applies to vehicles: with tire pressure monitoring system

When driving with a new set of tires, you can program them to the tire pressure monitoring system using the menu display.

- ▶ Turn the ignition on.
- ▶ Select the menu: **Set > Tire pressure > Wheel change**.
- ▶ Confirm that you would like to begin the programming process. The message **Wheel sensors are being initialised. This may take a few minutes...** appears in the instrument cluster display.

You can switch between programmed tire sets at any time without reinitializing the system.

Tips

- If the programming process was not completed successfully, the message **Wheel sensors could not be initialised** appears in the display and the **TPMS** indicator light turns on. If this happens, repeat the procedure.
- Do not store the tire pressure if there are snow chains on the tire.

TPMS Tire pressure monitoring system malfunction

A malfunction can have various causes.

If the  warning light in the instrument cluster flashes for approximately one minute and then remains continuously illuminated and additionally the **TPMS** symbol appears in the display, the tire pressure monitoring system is not available. The

text **Tire pressure! System malfunction** appears in the display. This can have various causes.

- A wheel sensor or other component may have failed.
- During initialization the system has detected more than 4 wheels on the vehicle, for example while driving next to another car with a tire pressure monitoring system.
- Audi replacement parts were not used.
- If snow chains are being used, system function can be compromised due to the shielding properties of the chains.
- The tire pressure monitoring system may not be available because of a radio malfunction.
- Transmitters with the same frequency, such as radio headphones in the vehicle or radio equipment, can cause a temporary disruption of the system through excessive electromagnetic fields.
- Eliminate the interference if you can and then proceed as follows: Turn off the engine for 20 minutes. Then drive another 10 minutes. If the warning light comes on again, you should contact your authorized Audi dealer immediately to have the problem corrected.
- Do not use commercially available tire sealants. Otherwise, the electrical components of the tire pressure monitoring system will no longer work properly and the sensor for the tire pressure monitoring system will have to be replaced by a qualified workshop.

What do I do now?

Trunk escape handle

Applies to vehicles: with trunk escape handle

In case of an emergency, the front lid can be opened from the inside using the trunk escape handle.

- To open the front lid pull the handle.

The trunk escape handle inside the luggage compartment is made of fluorescent material to glow in the dark.

WARNING

The trunk escape handle is to be used only in an emergency.

Vehicle tool kit

The tools are stored underneath the floor panel in the luggage compartment.




Fig. 151 Luggage compartment: vehicle tool kit

- Swing the luggage compartment floor upwards.
- Remove the vehicle tool kit.

The onboard tool kit includes:

- Hook for removing hub cap
- Lug wrench
- Alignment pin for changing wheels
- Screwdriver with reversible blade
- Towing eye
- Jack* (not a vehicle component; contact your authorized Audi dealer if needed)

Some of the onboard items listed above are provided on certain models only or are optional extras.

Before returning the jack* to its place, retract the jack arm fully.

WARNING

Improper use of the vehicle jack can cause serious personal injuries.

- Never use the screw driver hex head to tighten wheel bolts, since the bolts cannot attain the necessary tightening torque if you use the hex head, potentially causing an accident.
- The factory-supplied jack is intended only for your vehicle model. Under no circumstances should it be used to lift heavy vehicles or other loads; you risk injuring yourself.
- Never start the engine when the vehicle is raised, which could cause an accident.
- Support the vehicle securely with appropriate stands if work is to be performed underneath the vehicle; otherwise, there is a potential risk for injury.
- Never use the jack supplied with your Audi on another vehicle, particularly on a heavier one. The jack is only suitable for use on the vehicle it came with.

Tire repair

General and safety pointers

Applies to vehicles: with Tire Mobility System

Tire repair is intended only for temporary, short-term use.



Fig. 152 Tire damage for which the Tire Mobility System is not suited

Your vehicle is equipped with a tire repair kit, the **Tire Mobility System (TMS)**.

In the event of a tire failure, the **TMS** is in the luggage compartment under the floor. It consists of the tire sealant and an electric air pump.

Using **TMS**, tire damage caused by foreign bodies up to about **0.16 inch (4 mm)** in diameter can be sealed reliably.

The foreign object can stay in the tire.

The tire sealant must not be used:

- for cuts or punctures in the tire which are larger than 0.16 inch (4 mm) ⇒ *fig. 152* ①
- for damage to the rim ②
- if you have been driving with very low tire pressures or tires with no air ③

Using the **TMS** is described in the section ⇒ *page 201, Preliminary steps*.

TMS can be used at temperatures down to – 4 °F (– 20 °C).

WARNING

Take the following precautions after repairing the tire:

- Do not drive faster than 50 mph (80 km/h)!
- Avoid full-throttle acceleration, heavy braking and fast cornering.
- The vehicle's road behavior can be affected.
- Tires sealed with **TMS** are intended only for **temporary, short-term** use.
- After using the tire sealant the tire pressure monitoring system may no longer work properly. Drive carefully to the next professional repair facility.
- **TMS** must **NOT** be used,
 - for cuts or punctures in the tire which are larger than 0.16 inch (4 mm)
 - for damage to the rim
 - if you have been driving with very low tire pressures or tires with no air
- Seek professional assistance if it is not possible to repair the tire with the tire sealant.

WARNING

The tire sealant must not come into contact with skin, eyes or clothing.

- If you get any tire sealant in your eyes or come into contact with it, rinse the affected area thoroughly with clean water. Find a physician immediately!
- Change any clothing contaminated with tire sealant immediately.
- Do not inhale the vapor!
- If you have swallowed tire sealant, rinse your mouth thoroughly right away and drink plenty of water.
 - Do not induce vomiting! Find a physician immediately!
- If you have allergic reactions, find a physician immediately.
- Keep the tire sealant away from children.

Note

Do not use commercially available tire sealants. The electrical components of the tire pressure monitoring system will no longer work properly.

For the sake of the environment

Used sealant bottles can be dropped off at a recycling facility.

Tips

- If sealant has run out, allow it to dry. Then you can peel it off.
- Have the tire sealant replaced every 4 years at a dealership.

Preliminary steps

Applies to vehicles: with Tire Mobility System

Some preliminary steps are necessary for tire repair.



Fig. 153 Tire Mobility System under luggage compartment floor

- ▶ If you have a flat tire, park the vehicle as far as possible from moving traffic.
- ▶ Apply the **parking brake** firmly.
- ▶ Shift to **1st gear** (manual transmission). In vehicles with automatic transmissions, make sure the automatic parking lock is set as well ⇒ *page 75*.
- ▶ Check whether a repair using the Tire Mobility System is possible ⇒ *page 199, General and safety pointers*.
- ▶ Have all passengers **leave** the vehicle and stay away from the danger zone ⇒ .
- ▶ Take the **sealant bottle** and the **electric air pump** from the luggage compartment under the floor ⇒ *fig. 153*.
- ▶ Remove the “max. 50 mph” (80 km/h) sticker from the sealant bottle and affix it to the instrument cluster in the driver's view.

WARNING

- Turn the hazard flashers on and set up the warning triangle if you have a flat tire in moving traffic. In this way you protect yourself and other road users.
- Make sure that all passengers are in a safe place, out of the danger zone (for example, behind a guard rail).

Note

Particular care is necessary if you are making a tire repair on a steep incline.

Tips

Obey all laws.

Making a tire repair

Applies to vehicles: with Tire Mobility System

Tire repair consists of the following sections.




Fig. 154 Parts of the Tire Mobility System




Fig. 155 Connector for the Tire Mobility System

Assembling Tire Mobility System

- ▶ Open the lid (2) of the electric air pump ⇒ *fig. 154*.
- ▶ Pull the plug (4) and the pressure hose (5) with the gauge out of the housing.
- ▶ Screw the pressure hose (5) of the electric air pump onto the flange (6) of the sealant bottle (1).
- ▶ Push the sealant bottle with the flange down into the recess (3) on the lid of the electric air pump.
- ▶ Remove the dust cap from the valve of the defective tire.
- ▶ Screw the hose (10) onto the valve (7) ⇒ *fig. 155*.
- ▶ Insert the plug (4) ⇒ *fig. 154* into the socket for the cigarette lighter.

Inflating tire

- ▶ Move the switch **8** ⇒ *fig. 155* on the electric air pump ¹⁾ to position **I**. After 5 minutes, tire pressure must have reached at least 1.8 bar.
- ▶ Switch the electric air pump off - switch in position **0**. If the required tire pressure of at least 1.8 bar has not been reached, follow the instructions in the section *Re-inflating tire*.

Re-inflating tire

- ▶ Remove the hose from the valve and pull the plug out of the socket.
- ▶ Drive the vehicle slowly 10 meters backward or forward. This helps to distribute the sealant better.
- ▶ Remove the empty inflation bottle and screw the hose **5** ⇒ *fig. 154* from the electric pump directly onto the valve.
- ▶ Insert the plug **4** into the socket for the cigarette lighter.
- ▶ Switch on the ignition.
- ▶ Move the switch **8** ⇒ *fig. 155* on the electric air pump ¹⁾ to position **I**. After 5 minutes, tire pressure must have reached at least 1.8 bar.
- ▶ Switch the electric air pump off - switch in position **0**. If the required tire pressure of at least 1.8 bar has not been reached, it is not possible to make a repair with the tire sealant. Seek professional assistance.

Disassembling Tire Mobility System

- ▶ Remove the hose from the valve and pull the plug out of the socket.
- ▶ Screw the dust cap onto the valve.
- ▶ Place the empty sealant bottle back in the original packaging and clip it in place under the floor so that no tire sealant can run out into the vehicle.
- ▶ Start driving right away so that the sealant is distributed in the tire.

¹⁾ The electric air pump should never run for longer than 6 minutes.



WARNING

- Follow the manufacturer's safety instructions on the decal for the air pump and the sealant bottle.
- If a tire pressure of 1.8 bar cannot be achieved after pumping for 5 minutes, the tire is too severely damaged. Do not continue to drive.
- Seek professional assistance if it is not possible to repair the tire with the tire sealant.



Tips

- Do not operate the electric air pump for more than 6 minutes without stopping, otherwise it can overheat. When the air pump has cooled down, you can continue to use it.
- If sealant has escaped, allow it to dry, then you can peel it off.

Final check

Applies to vehicles: with Tire Mobility System

After driving for a short distance, tire pressure must be checked

- ▶ After driving for about 10 minutes, stop and check the tire pressure.
- ▶ If tire pressure is still at least 1.3 bar, inflate the tire to specified pressure (see driver's side B-pillar), drive to the next repair shop and have the tire and the sealant bottle replaced.
- ▶ If tire pressure is less than 1.3 bar, the tire is too severely damaged. Do not continue to drive. Seek professional assistance.



WARNING

If tire pressure is less than 1.3 bar after driving for 10 minutes, the tire is too severely damaged. Do not continue to drive. Seek professional assistance.



Tips

After a tire repair, have the sealant bottle replaced at a dealership. This restores full functionality to the Tire Mobility System.

What should I be aware of when changing a tire?

Tires with unidirectional tread design

Tires with unidirectional tread design must be mounted with their tread pattern pointed the right direction.

A unidirectional tire can be identified by **arrows on the sidewall**, which point in the direction of the rotation. You must follow the specified direction of rotation. This is necessary in order for these tires to develop their optimum characteristics regarding grip, road noise, wear, and hydroplaning.

Anti-theft wheel bolts

A special adapter is needed to turn the anti-theft wheel bolts.




Fig. 156 Anti-theft wheel bolts with adapter

- Install the adapter (2) as far as it will go onto the anti-theft wheel bolt (1).
- Push the wheel wrench over the adapter (2) as far as it will go.
- Loosen or tighten the wheel bolt ⇒ *page 205*.

We recommend always keeping the wheel bolt adapter with you in the vehicle. It should be stored in the vehicle tool kit.

There is a **code number** for the wheel bolt locking device, stamped on the face of the adapter. You can use this number to obtain a replacement adapter at an authorized Audi dealership, if necessary.

Tips

Write down the wheel bolt locking device code number and store it in a safe place, away from the vehicle.

Raising the vehicle

Applies to vehicles: with original Audi jack

The vehicle must be lifted with the jack first before the wheel can be removed.*




Fig. 157 Sill panels: markings




Fig. 158 Sill: positioning the vehicle jack

The description for using the vehicle jack only applies to the original jack* (not a vehicle component; contact your authorized Audi dealer if needed).

- Apply the **parking brake** firmly to prevent your vehicle from rolling unintentionally.
- Shift to **1st gear** (manual transmission). In vehicles with automatic transmissions, make sure the automatic parking lock is set as well ⇒ *page 75*.
- Find the **lifting point** in the sill on the side with the affected wheel ⇒ *fig. 157*.
- Extend the **jack** under the lifting point on the door sill until its arm is positioned directly under the lifting point ⇒ .

- ▶ Align the jack so that its arm **(A)** ⇒ *fig. 158* engages in the designated lifting point in the door sill and the movable base **(B)** lies flat on the ground. The base **(B)** must be *vertical* under the lifting point **(A)**.
- ▶ Wind the jack up further until the flat tire comes off the ground ⇒ .

Position the vehicle jack **only** under the designated lifting points on the sill ⇒ *fig. 157*. There is exactly *one* location for each side of the vehicle. The jack must not be positioned at any other location ⇒  ⇒ .

An **unstable surface** under the jack can cause the vehicle to slip off the jack. Always provide a firm base for the jack on the ground. If necessary place a sturdy board or similar support under the jack. On **hard, slippery surfaces** (such as tiles) use a rubber mat or similar to prevent the jack from slipping ⇒ .

WARNING

- You or your passengers could be injured while changing a wheel if you do not follow safety precautions:
- Position the vehicle jack only at the designated lifting points and align the jack. Otherwise, the vehicle jack could slip and cause an injury if it does not have sufficient hold on the vehicle.
- A soft or unstable surface under the jack may cause the vehicle to slip off the jack. Always provide a firm base for the jack on the ground. If necessary, use a sturdy board under the jack.
- On hard, slippery surface (such as tiles) use a rubber mat or similar to prevent the jack from slipping.
- To help prevent injury to yourself and your passengers:
- Do not raise the vehicle until you are sure the jack is securely engaged.
- Passengers must not remain in the vehicle when it is jacked up.
- Make sure that passengers wait in a safe place away from the vehicle and well away from the road and traffic.

- Make sure jack position is correct, adjust as necessary and then continue to raise the jack.

Note

A floor jack or the pads on the hoist arms must **not** be positioned at the points shown *-arrow-*.

Removing the wheel

Follow these instructions step-by-step for changing the wheel.



Fig. 159 Wheel change: using the screwdriver handle (with the blade removed) to turn the bolts



Fig. 160 Wheel change: alignment pin inside the top hole

After you have loosened all wheel bolts and raised the vehicle off the ground, perform the following steps to remove and replace the wheel:

Removing the wheel

- ▶ Use the **hexagonal socket in the screwdriver handle** to completely turn out the topmost wheel bolt and set it aside on a *clean* surface.
- ▶ Screw the threaded end of the **alignment pin** from the tool kit hand-tight into the now vacant bolt hole ⇒ *fig. 160*.

- ▶ Then completely unscrew the other wheel bolts as described above.
- ▶ Take off the wheel leaving the alignment pin in the bolt hole ⇒ .

Putting on the wheel

- ▶ Lift the spare wheel and carefully slide it over the alignment pin to guide it in place ⇒ .
- ▶ Use the hexagonal socket in the screwdriver handle to screw in and tighten all wheel bolts *slightly*.
- ▶ Unscrew the alignment pin and insert and tighten the remaining wheel bolt slightly like the rest.
- ▶ Turn the jack handle counter-clockwise to lower the vehicle until the jack is fully released.

The wheel bolts must be clean and turn easily. Check the contact surfaces of wheel and hub. Remove contaminants on these surfaces before installing the wheel.

The hexagonal socket in the screwdriver handle makes it easier to handle the wheel bolts. The reversible blade should be removed.

When mounting **unidirectional** tires, observe the direction of rotation ⇒ *page 203*.

Note

When removing or installing the wheel, the rim could hit the brake rotor/ceramic brake rotor* and damage the rotor. Work carefully and have a second person help you.

Tips

Never use the hexagonal socket in the handle of the screwdriver to loosen or tighten the wheel bolts.

Tightening wheel bolts

- ▶ Fit the **wheel bolt wrench** over the wheel bolt and push it down as far as it will go ¹⁾.
- ▶ Close your grip around the *end* of the wrench handle for maximum torque and turn each wheel bolt **clockwise** until it sits tight.

¹⁾ You need the appropriate adapter to tighten the anti-theft wheel bolts ⇒ *page 203*.

Have the **tightening torque** of the wheel bolts checked as soon as possible with a torque wrench. It should be 120 Nm.

Check the **tire pressure** as soon as possible.

Return the vehicle tool kit to its proper place.

WARNING

Loosening the wheel bolts is prohibited; danger of an accident!

Tips

- Never try and use the hexagonal socket in the handle of the screwdriver to loosen or tighten the wheel bolts.
- If you have determined that wheel bolts are corroded and difficult to turn, the bolts must be replaced before checking the torque.
- Until the tightening torque is checked, drive at reduced speeds as a precaution.

Notes on wheel change

Please read the information ⇒ *page 186, New tires and replacing tires and wheels*, if you are going to use a spare tire which is different from the tires on your vehicle.

After you change a tire:

- **Check the tire pressure on the spare immediately after mounting.**
- **Have the wheel bolt tightening torque checked with a torque wrench as soon as possible by your authorized Audi dealer or a qualified service station.**
- **With steel and alloy wheel rims, the wheel bolts are correctly tightened at a torque of 90 ft lb (120 Nm).**
- **If you notice while changing a tire that the wheel bolts are corroded and difficult to turn, then they should be replaced before you check the tightening torque.**

- Replace the flat tire with a new one and have it installed on your vehicle as soon as possible. Remount the wheel cover.

Until then, drive with extra care and at reduced speeds.

WARNING

- If you are going to equip your vehicle with tires or rims which differ from those which were factory installed, then be sure to read the information ⇒ *page 186, New tires and replacing tires and wheels.*
- Always store the tools securely in luggage compartment. Otherwise, in an accident or sudden maneuver they could fly forward, causing injury to passengers in the vehicle.

Note

Do not use commercially available tire sealants. Otherwise, the electrical components of the tire pressure monitoring system* will no longer work properly and the sensor for the tire pressure monitoring system will have to be replaced by a qualified workshop.

Jump-starting

General

If necessary, the engine can be started by connecting it to the battery of another vehicle.

If the engine should fail to start because of a discharged or weak battery, the battery can be connected to the battery of *another* vehicle, using a **pair of jumper cables** to start the engine.

Both batteries must be rated at 12 volts. The **capacity** (Ah) of the booster battery must not be substantially less than the capacity of the discharged battery.

Jumper cables

Use *only* jumper cables of sufficiently large **cross section** to safely carry the starter current. Refer to the manufacturer's specifications.

Use only jumper cables which have *insulated* terminal clamps and are properly marked for distinction:

plus (+) cable: in most cases colored **red**

minus (-) cable: in most cases colored **black**

WARNING

Batteries contain electricity, acid, and gas. Any of these can cause very serious or fatal injury. Follow the instructions below for safe handling of your vehicle's battery.

- Always shield your eyes and avoid leaning over the battery whenever possible.
- A discharged battery can already freeze at temperatures just below 32 °F (0 °C). Before connecting a jumper cable, the frozen battery must be thawed completely, otherwise it could explode.
- Do not allow battery acid to contact eyes or skin. Flush any contacted area with water immediately.
- Improper use of a booster battery to start a vehicle may cause an explosion.
- Vehicle batteries generate explosive gases. Keep sparks, flame and lighted cigarettes away from batteries.
- Do not try to jump start any vehicle with a low acid level in the battery.
- The voltage of the booster battery must also have a 12-Volt rating. The capacity (Ah) of the booster battery should not be lower than that of the discharged battery. Use of batteries of different voltage or substantially different "Ah" rating may cause an explosion and personal injury.
- Never charge a frozen battery. Gas trapped in the ice may cause an explosion.
- Never charge or use a battery that has been frozen. The battery case may have been weakened.
- Use of batteries of different voltage or substantially different capacity (Ah) rating may cause an explosion and injury. The capacity (Ah) of the booster battery should not be lower than that of the discharged battery.
- Before you check anything in the engine compartment, always read and heed all WARNINGS ⇒ *page 155, Working in the engine compartment.*

! Note

- Applying a higher voltage booster battery will cause expensive damage to sensitive electronic components, such as control units, relays, radio, etc.
- There must be no electrical contact between the vehicles as otherwise current could already start to flow as soon as the positive (+) terminals are connected.

i Tips

- The discharged battery must be properly connected to the vehicle's electrical system.
- Switch off any car phone, or follow the car phone instructions for this situation.

Use of jumper cables

Make sure to connect the jumper cable clamps in exactly the order described below!




Fig. 161 Luggage compartment: connectors for a charger and jump start cables




Fig. 162 Jump start using the battery in another vehicle: A - Female socket, B - Discharge

The battery is located in the luggage compartment ⇒ *page 166*. The front lid can be opened in an emergency ⇒ *page 33*.

Do *not* connect the negative cable directly to the negative terminal on the battery. Connect it to a **jump start pin** instead ⇒ *fig. 161*.

Connect the positive cable (red) to the positive terminal

1. Connect one end of the red jumper cable ⇒ *fig. 162* ① to the positive terminal of discharged battery ②.
2. Connect the other end of the red jumper cable to the positive terminal ② of the booster battery ①.

Connect the negative cable (black) to the negative terminal

3. Connect one end of the black jumper cable ③ to the negative terminal of the booster battery ①.
4. Secure the other end to the jump start pin ④ for the discharged battery ②.

Starting the engine

- ▶ Start the engine of the vehicle providing assistance and allow it to run at idle.
- ▶ Now start the engine of the vehicle with the discharged battery.
- ▶ If the engine does not start: Stop trying after 10 seconds and then try again after about 30 seconds.
- ▶ Disconnect the cable while the engine is running in exactly *reverse* order to that described.

The battery is vented to the outside to prevent gases from entering the vehicle interior. Make sure that the jumper clamps are well connected with their *metal parts in full contact* with the battery terminals.

! WARNING

To avoid serious personal injury and damage to the vehicle, heed all warnings and instructions of the jumper cable manufacturer. If in doubt, call for road service.

- Jumper cables must be long enough so that the vehicles do not touch.
- When connecting jumper cables, make sure that they cannot get caught in any moving parts in the engine compartment.

- Before you check anything in the engine compartment, always read and heed all **WARNINGS** ⇒ *page 155, Working in the engine compartment.*

Note

Improper hook-up of jumper cables can ruin the generator.

- Always connect **POSITIVE (+)** to **POSITIVE (+)**, and **NEGATIVE (-)** to **NEGATIVE (-)** ground post of the battery manager control unit.
- Check that all screw plugs on the battery cells are screwed in firmly. If not, tighten plugs prior to connecting clamp on negative battery terminal.
- Please note that the procedure for connecting a jumper cable as described above applies specifically to the case of your vehicle being jump started. When you are giving a jump start to another vehicle, do *not* connect the negative (-) cable to the negative (-) terminal on the discharged battery **4**. Instead, securely connect the negative (-) cable to either a solid metal component that is firmly bolted to the engine block or to the engine block itself. If the battery that is being charged does not vent to the outside, escaping battery gas could ignite and explode!

Emergency towing with commercial tow truck

General hints

Your Audi requires special handling for towing.

The following information is to be used by commercial tow truck operators who know how to operate their equipment safely.

- Never tow your Audi, towing will cause damage to the engine and transmission.
- Never wrap the safety chains or winch cables around the brake lines.
- To prevent unnecessary damage, your Audi must be transported with a car carrier (flat bed truck).

- To load the vehicle on to the flat bed, use the towing loop found in the vehicle tools and attach to the front anchorage ⇒ *page 208.*

WARNING

A vehicle being towed is not safe for passengers. Never allow anyone to ride in a vehicle being towed, for any reason.

Note

The vehicle has very low ground clearance. Make sure that no damage is caused to the underside of the vehicle when it is being loaded onto a flat bed truck.

Front towing loop

Do not install the front towing loop until it is needed.




Fig. 163 Right front bumper without grille: Towing loop fully screwed in

On the right front in the bumper, there is a threaded hole behind the air intake grill into which the towing loop is screwed.

- ▶ Remove the towing loop from the vehicle tool kit ⇒ *page 199.*
- ▶ Pull the lower part of the grill forward and out.
- ▶ Screw the towing loop tightly into the threaded hole as far as it will go ⇒ *fig. 163* and tighten it with the wheel wrench.

When it is no longer needed, unscrew the towing loop and put it back into the on-board toolkit. Make sure to have the towing loop stored in the vehicle at all times.

When installing the grill for the air duct, be sure that the tabs on the grill are first inserted into

their guides on the vehicle. Then push the grill into position.

**WARNING**

If the towing loop is not screwed in as far as it will go, the thread can pull out when the vehicle is towed - potential risk of an accident.

**Tips**

Check carefully to make sure the hook-up is secure.

Fuses and bulbs

Electrical fuses

Replacing fuses

Fuses that have blown will have metal strips that have burned through.



Fig. 164 Passenger's side wheel well: Foot rest with fuse arrangement

The fuses are located in the footwell area on the passenger's side behind a cover.

- ▶ Switch the ignition and all electrical equipment off.
- ▶ Check the following table to see which fuse belongs to the equipment.
- ▶ Remove the floor mat.
- ▶ Fold the foot rest back ⇒ fig. 164.
- ▶ Remove the clamp from the holder in the fuse box.
- ▶ Remove the fuse using the clamp and replace the blown fuse with an identical new one.
- ▶ Fold the foot rest down again.

Fuse color identification

Color	Current in amps
Black	1
Purple	3
Light brown	5
Brown	7.5
Red	10
Blue	15
Yellow	20
White or transparent	25
Green	30
Orange	40

! WARNING

Do not repair fuses and never replace a blown fuse with one that has a higher amp rating. This can cause damage to the electrical system and a fire.

! Note

If a new fuse blows again shortly after you have installed it, have the electrical system checked by an authorized Audi dealer or authorized Audi Service Facility.

i Tips

- The following table does not list fuse locations that are not used.
- Some of the equipment listed in the following tables applies only to certain model versions or certain optional equipment.

Fuse assignment




Fig. 165 Passenger footwell: Fuse panel

Fuse panel B

No.	Consumer
1	VDA interface
2	Heated windshield washer nozzle

Fuse panel (B)

No.	Consumer
3	Parking system
4	Engine compartment lid release
5	Diagnostic interface, light switch, indicator light Passenger Air Bag OFF , selector lever
6	Networking gateway
7	Right headlight
8	Automatically dimming inside mirror, garage door opener (HomeLink), washer pump relay, power outlets relay
9	Left headlight
10	 button
11	Pressure sensor, climate controls
12	Airbag

Fuse panel (C)

No.	Consumer
1	Radiator fan (1)
2	Radiator fan (2)
3	Exterior lighting
4	Exterior lighting
6	Blower regulator

Fuse panel (D)

No.	Consumer
1	Rear view camera
2	Tire pressure monitoring system
4	Cell phone package, telephone antenna amplifier
5	Instrument cluster
6	Networking gateway
7	Steering column lever
8	Diagnostic interface, brake pedal switch, selector lever
9	Rain/light sensor
10	Light switch
11	Special functions control module
15	Sound amplifier
16	Radio

Fuse panel (E)

No.	Consumer
3	Auxiliary water pump
5	Supply terminal 15, starter
6	Pump for brake booster
7	Horn
8	Wiper motor
9	Wiper motor
10	Headlight washer system
12	Power outlets and cigarette lighter

Fuse panel (F)

No.	Consumer
1	Electronic Stabilization Program
2	Electronic Stabilization Program
3	Partition window defogger
4	Rear window defogger
5	Power locking system
6	Interior lights, washer nozzles
7	Anti-theft alarm system
8	Climate controls
9	Heated seats
10	Lumbar support
11	Control module for doors
12	Control module for doors

Bulbs**Note**

Your vehicle is equipped with maintenance-free headlights and rear lights. However, if a bulb has to be changed, please consult your authorized Audi dealer or other qualified workshop.

Technical Data

Vehicle identification



Fig. 166 Vehicle Identification Number (VIN) plate: location on driver's side dash panel




Fig. 167 The vehicle identification label – inside the luggage compartment

Vehicle Identification Number (VIN)

The Vehicle Identification Number is located in different places:

- under the windshield on the driver's side
⇒ *fig. 166*.
- in the Driver Information display ⇒ *page 22*.
- on the vehicle identification label.

Vehicle identification label

The Vehicle identification label is located with the fuses in the footwell on the passenger's side
⇒ *page 210*.

The label ⇒ *fig. 167* shows the following vehicle data:

- ① Vehicle Identification Number (VIN)
- ② Vehicle type, engine output, transmission
- ③ Engine and transmission code
- ④ Paint number and interior
- ⑤ Optional equipment numbers

The information of the vehicle identification label can also be found in your Warranty & Maintenance booklet.

Safety compliance sticker

The Safety compliance sticker is your assurance that your new vehicle complies with all applicable Federal Motor Vehicle Safety Standards which were in effect at the time the vehicle was manufactured. You can find this sticker on the left door jamb. It shows the month and year of production and the vehicle identification number of your vehicle (perforation) as well as the Gross Vehicle Weight Rating (GVWR) and the Gross Axle Weight Rating (GAWR).

High voltage warning label

The high voltage warning label is located on the lock carrier. The spark ignition system complies with the Canadian standard ICES-002.

Weights

Gross Vehicle Weight Rating

The Gross Vehicle Weight Rating (GVWR), and the Gross Axle Weight Rating (GAWR) for front and rear are listed on a sticker on the left door jamb.

The Gross Vehicle Weight Rating includes the weight of the basic vehicle plus full fuel tank, oil and coolant, plus maximum load, which includes passenger weight (150 lbs/68 kg per designated seating position) and luggage weight. ►

Gross Axle Weight Rating

The Gross Axle Weight Rating is the maximum load that can be applied at each axle of the vehicle ⇒ ⚠.

Vehicle capacity weight

The vehicle capacity weight (max. load) is listed either on the driver's side B-pillar or inside the fuel filler flap.


WARNING

- The actual Gross Axle Weight Rating at the front and rear axles should not exceed the permissible weights, and their combination must not exceed the Gross Vehicle Weight Rating.

- Exceeding permissible weight ratings can result in vehicle damage, accidents and personal injury.


Note

- The vehicle capacity weight figures apply when the load is distributed evenly in the vehicle (passenger and luggage). When transporting a heavy load in the luggage compartment, carry the load as near to the rear axle as possible so that the vehicle's handling is not impaired.
- Do not exceed the maximum permissible axle loads or the maximum gross vehicle weight. Always remember that the vehicle's handling will be affected by the extra load. Therefore, adjust your speed accordingly.
- Always observe local regulations.

Dimensions

Length	in (mm)	174.6 (4435)
Width (across mirrors)	in (mm)	80.0 (2029)
Height (unloaded) ^{a)}	in (mm)	49 (1252)

^{a)} The height of the vehicle depends on the tires and the suspension.

When driving up steep ramps, on rough roads, over curbs, etc. it is important to remember that some parts of your vehicle, such as spoilers or ex-

haust system components, may be close to the ground. Be careful not to damage them.

Capacities

Fuel tank: total capacity	gal (liters)	approx. 21.1 (80.0)
Windshield and headlight* washer fluid container	quarts (liters)	approx. 4.2 (4.0)

Gasoline engines

R8 Spyder 4.2, 8 cylinder

Maximum output SAE net	hp @ rpm	430 @ 7900
Maximum torque SAE net	lb-ft @ rpm	317 @ 4500 - 6000
Displacement	CID (cm ³)	254 (4163)
Engine oil with filter change	quarts (liters)	10.6 (10.0)
Fuel	Premium unleaded (91 AKI), ⇨ page 151, Gasoline	

R8 Spyder 5.2, 10 cylinder (525 hp)

Maximum output SAE net	hp @ rpm	525 @ 8000
Maximum torque SAE net	lb-ft @ rpm	391 @ 6500
Displacement	CID (cm ³)	318 (5204)
Engine oil with filter change	quarts (liters)	8.8 (8.3)
Fuel	Premium unleaded (91 AKI), ⇨ page 151, Gasoline	

R8 Spyder 5.2, 10 cylinder (550 hp)

Maximum output SAE net	hp @ rpm	550 @ 8000
Maximum torque SAE net	lb-ft @ rpm	398 @ 6500
Displacement	CID (cm ³)	318 (5204)
Engine oil with filter change	quarts (liters)	8.8 (8.3)
Fuel	Premium unleaded (91 AKI), ⇨ page 151, Gasoline	

Consumer Information

Warranty coverages

Your Audi is covered by the following warranties:

- *New Vehicle Limited Warranty*
- *Limited Warranty Against Corrosion Perforation*
- *Emissions Control System Warranty*
- *Emissions Performance Warranty*
- *California Emissions Control Warranty (USA vehicles only)*
- *California Emissions Performance Warranty (USA vehicles only)*

Detailed information regarding your warranties can be found in your **Warranty & Maintenance booklet**.

Operating your vehicle outside the U.S.A. or Canada

Government regulations in the United States and Canada require that automobiles meet specific emission regulations and safety standards.

Therefore, vehicles built for the U.S.A. and Canada differ from vehicles sold in other countries.

If you plan to take your vehicle outside the continental limits of the United States or Canada, there is the possibility that:

- unleaded fuels for vehicles with catalytic converter may not be available;
- fuel may have a considerably lower octane rating. Improper fuel may cause engine damage;
- service may be inadequate due to lack of proper service facilities, tools or testing equipment;
- replacement parts may not be readily available.
- Navigation systems for vehicles built for the U.S.A. and Canada will not necessarily work in Europe, and may not work in other countries outside of North America.

Note

Audi cannot be responsible for mechanical damage that could result from inadequate fuel, service or parts availability.

Audi Service Repair Manuals and Literature

Audi Official Factory Service Manuals and Literature are published as soon as possible after model introduction. Service Manuals and literature are available to order from the Audi Technical Literature Ordering Center at:

<https://www.audi.techliterature.com>

Maintenance

General

Your vehicle has been designed to help keep maintenance requirements to a minimum. However, a certain amount of regular maintenance is still necessary to assure your vehicle's safety, economy and reliability. For detailed vehicle maintenance consult your **Warranty & Maintenance booklet**.

Under difficult operating conditions, for example at extremely low outside temperatures, in very dusty regions, etc., some service work should be performed between the intervals specified. This applies particularly to:

- oil changes, and
- cleaning or replacing the air filter.

For the sake of the environment

By regularly maintaining your vehicle, you help make sure that emission standards are maintained, thus minimizing adverse effects on the environment.

Important considerations for you and your vehicle

The increasing use of electronics, sophisticated fuel injection and emission control systems, and the generally increasing technical complexity of today's automobiles, have steadily reduced the

scope of maintenance and repairs which can be carried out by vehicle owners. **Also, safety and environmental** concerns place very strict limits on the nature of repairs and adjustments to engine and transmission parts which an owner can perform.

Maintenance, adjustments and repairs usually require special tools, testing devices and other equipment available to specially trained workshop personnel in order to assure proper performance, reliability and safety of the vehicle and its many systems.

Improper maintenance, adjustments and repairs can impair the operation and reliability of your vehicle and even void your vehicle warranty. Therefore, proof of servicing in accordance with the maintenance schedule may be a condition for upholding a possible warranty claim made within the warranty period.

Above all, operational safety can be adversely affected, creating unnecessary risks for you and your passengers.

If in doubt about any servicing, have it done by your authorized Audi dealer or any other properly equipped and qualified workshop. We strongly urge you to give your authorized Audi dealer the opportunity to perform all scheduled maintenance and necessary repairs. Your dealer has the facilities, original parts and trained specialists to keep your vehicle running properly.

Performing limited maintenance yourself

The following pages describe a limited number of procedures which can be performed on your vehicle with ordinary tools, should the need arise and trained personnel be unavailable. Before performing any of these procedures, always thoroughly read all of the applicable text and carefully follow the instructions given. Always rigorously observe the **WARNINGS** provided.

Before you check anything in the engine compartment, always read and heed all WARNINGS

⇒  **and** ⇒  *in Working in the engine compartment on page 155.*



WARNING

- Serious personal injury may occur as a result of improperly performed maintenance, adjustments or repairs.
- Always be extremely careful when working on the vehicle. Always follow commonly accepted safety practices and general common sense. Never risk personal injury.
- Do not attempt any of the maintenance, checks or repairs described on the following pages if you are not fully familiar with these or other procedures with respect to the vehicle, or are uncertain how to proceed.
- Do not do any work without the proper tools and equipment. Have the necessary work done by your authorized Audi dealer or another properly equipped and qualified workshop.
- Always remove the ignition key before anyone gets under the vehicle.
- Always support your vehicle with safety stands if it is necessary to work underneath the vehicle. The jack* is not adequate for this purpose and could collapse causing serious personal injury.
- If you must work underneath the vehicle with the wheels on the ground, always make sure the vehicle is on level ground, that the wheels are always securely blocked and that the engine cannot be started.
- Always make sure the transmission selector lever is in “N” (Neutral) (S tronic) or Neutral (manual transmission) and the hand brake is firmly applied.



For the sake of the environment

- Changing the engine settings will adversely affect emission levels. This is detrimental to the environment and increases fuel consumption.
- Always observe environmental regulations when disposing of old engine oil, used brake fluid, dirty engine coolant, spent batteries or worn out tires.

- Undeployed airbag modules and pretensioners might be classified as Perchlorate Material -special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate. When the vehicle or parts of the restraint system including airbag modules safety belts with pretensioners are scrapped, all applicable laws and regulations must be observed. Your authorized Audi dealer is familiar with these requirements and we recommend that you have your dealer perform this service for you.

Additional accessories, modifications and parts replacement

Additional accessories and parts replacement

Always consult an authorized Audi dealer before purchasing accessories.

Your vehicle incorporates the latest safety design features ensuring a high standard of active and passive safety.

This safety could be compromised by non-approved changes to the vehicle. For this reason, if parts have to be replaced, please observe the following points when installing additional accessories:

Approved Audi accessories and genuine Audi parts are available from authorized Audi dealers.

These dealers also have the necessary facilities, tools and trained specialists to install the parts and accessories properly.

WARNING

Using the wrong spare parts or using non-approved accessories can cause damage to the vehicle and serious personal injury.

- Use only accessories expressly approved by Audi and genuine Audi spare parts
- These parts and accessories have been specially designed to be used on your vehicle.
- Never install accessories such as telephone cradles or beverage holders on airbag covers

or within the airbag deployment zones. Doing so will increase the risk of injury if airbags are triggered in an accident!

- Before you check anything in the engine compartment, always read and heed all WARNINGS ⇒ *page 155*.

Note

- If items other than genuine Audi spare parts, add-on equipment and accessory items are used or if repair work is not performed according to specified methods, this can result in severe damage to your vehicle's engine and body (such as corrosion) and adversely affect your vehicle's warranty.
- The innovative aluminium concept of your Audi means that all servicing, repairs or other work on the vehicle body must be carried out exclusively by an Audi workshop.
- If emergency repairs must be performed elsewhere, have the vehicle examined by an authorized Audi dealership as soon as possible.
- The manufacturer cannot be held liable for damage which occurs due to failure to comply with these stipulations.

Technical Modifications

Our guidelines must be complied with when technical modifications are made.

Always consult an authorized Audi dealer **before** starting work on any modifications.

This will help ensure that vehicle function, performance and safety are not impaired ⇒ .

Attempting to work on electronic components and the software used with them can cause malfunctions. Because of the way electronic components are interconnected with each other, such malfunctions can also have an adverse affect on other systems that are not directly involved. This means that you risk both a substantial reduction in the operational safety of your vehicle and an increased wear of vehicle parts ⇒ .

Authorized Audi dealers will perform this work in a professional and competent manner or, in special cases, refer you to a professional company that specializes in such modifications.

WARNING

Improper repairs and modifications can change the way vehicle systems work and cause damage to the vehicle and serious personal injury.

Note

If emergency repairs must be performed elsewhere, have the vehicle examined by an authorized Audi dealership as soon as possible.

Declaration of Compliance, Telecommunication or Electronic Systems

Radio Frequency Devices and Radiocommunication Equipment User Manual Notice.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.

Devices

The following devices each comply with FCC Part 15.19, FCC Part 15.21 and RSS-Gen Issue 1:

- Cell phone package
- Electronic immobilizer
- Garage door opener (HomeLink)
- Remote control key
- Tire pressure monitoring system

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-Gen Issue 1

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

A

A/C operation	65	Defrost	63
Accessories	217	Economical use	65
Active rollover protection system	93	Fan	62
Retracting rollover protection	94	Rear window defogger	64
Adding		Switching on and off	62
Engine coolant	163	Temperature	62
Engine oil	160, 161	Air distribution	63
Additional accessories	217	Air recirculation mode	
Additives	160, 161	Air conditioning	64
Adjustable steering column	66	Alcantara	
Adjusting front seats	56	Cleaning	148
Advanced Airbag System		All-wheel drive	139
Children	123	Winter tires	193
Components	108	Alternator	14
Front airbags	106	Anti-freeze	
How the components work together	110	<i>refer to</i> Engine coolant system	161
Monitoring	112	Anti-lock brake system	
Weight-sensing mat	123	Warning/indicator lights	15
Airbag		Anti-lock braking system	134
Warning/indicator lights	13	Anti-slip regulation	134
Airbag system	102, 119	Anti-theft alarm system	33
Care	114	Anti-theft wheel bolts	203
Child restraints	124	Ashtray	59
Components (front airbags)	108	Asterisk	
Danger of fitting a child safety seat on the		What does it mean when something is	
front passenger seat	103	marked with an asterisk?	5
Disposal	114	Audi magnetic ride	18, 72
Front airbags	106	Description	72
How do the front airbags work?	110	Indicator light	18
How many airbags does my vehicle have?	108	Audi Service Repair Manuals and Literature	215
Important safety instructions on the knee		Automatic belt retractor	98
airbag system	118	Automatic headlight	46
Important things to know	102	Automatic transmission	75
Indicator light	112	<i>also refer to</i> S tronic (Automatic transmis-	
Knee airbags	116	sion)	75
Monitoring	112	Automatic transmission (S tronic)	
PASSENGER AIR BAG OFF light	112	Parking lock emergency release	79
Repairs	114	Automatic transmission (tiptronic)	
Side airbags	118	Emergency mode	78
When must the system be inspected? ...	112	Auto Safety Hotline	92
Air conditioning		Average fuel mileage	21
A/C operation	65	Average speed	21
Air distribution	63	Avoid damaging the vehicle	142
Air recirculation mode	64		
Automatic mode	64		
Controls	61		

B

Battery	164
Charging	167
Connecting	164
Disconnecting	164
Important warnings	166
Location	166
Low	140
Replacing the battery	165
State of charge	140
Winter operation	164
Working on the battery	166
Before driving	86
Blended gasoline	151
Booster seats	128
Brake system	
Anti-lock brake system	15
Brake assist system	134
Brake fluid	164
Brake light defective	18
Brake power assist unit	136
Brakes	136
Ceramic brakes	136
Malfunction	12
Warning/indicator lights	12
Worn brake pads symbol	16
Break-in period	142
Brake pads	136
Bulbs	211

C

California Proposition 65 Warning	156
Battery specific	167
Capacities	213
Carbon parts	
Cleaning	147, 148
Care	145
Cargo area	
<i>refer to</i> Luggage compartment	91
Catalytic converter	142
Ceramic brake rotors	
New brake pads	136
Certification	218
Changing a flat tire	203
Chassis	
<i>refer to</i> Audi magnetic ride	72

Checking	
Engine coolant level	162
Tire pressure	179
Child restraint	
Danger of using child restraints in the front seat	103
Child restraints	
Where can I get additional information about child restraints and their use?	132
Child safety	122
Convertible locking retractor	130
Important safety instructions for using child safety seats	125
Important things to know when driving with children	122
Child safety seat	127
Convertible locking retractor	130
Installing	130
Child safety seats	
Booster seats	128
Convertible child seats	127
How do I properly install a child safety seat in my vehicle?	125
Infant seats	127
Safety instructions	125
Cigarette lighter	59
Cleaning	145
Climate controls	61
Dust filter	61
Heating	61
Pollen filter	61
Ventilation	61
Clock	9
Closing	
Engine compartment lid	156
Cold tire inflation pressure	176
coming home	46
Compass mirror	54
Compliance	218
Consumer Information	92, 215
Contacting NHTSA	92
Controls	
Cleaning	148
Controls and displays	6
Convertible child safety seats	127

- Convertible locking retractor
 - Activating 131
 - Deactivating 132
 - Using to secure a child safety seat .. 130, 131
 - Convertible top
 - Emergency operation 41
 - Error message 39
 - General information 38
 - Indicator light 15
 - Malfunction 39
 - Opening/closing 38
 - Retracting/extending rear window 40
 - Wind deflector 40
 - Coolant system 161
 - Adding coolant 163
 - Checking the engine coolant level 162
 - Cruise control 71
 - Changing speed 72
 - Presetting your speed 72
 - Switching off 72
 - Switching on 71
 - Warning/indicator lights 19
 - Cup holder 58
 - Current fuel mileage 21
- D**
- Damping
 - refer to* Audi magnetic ride 72
 - Data recorder 134
 - Date display 9
 - Daytime running lights 46
 - Declaration of compliance
 - Cell phone package 218
 - Electronic immobilizer 218
 - Garage door opener (HomeLink) 218
 - Remote control key 218
 - Tire pressure monitoring system 218
 - Decorative decals
 - Cleaning 147
 - Decorative parts/trim
 - Cleaning 147
 - def 10
 - Defective light bulb warning 17
 - Defrosting the windows 63
 - Determining correct load limit 184
 - Digital compass 54
 - Dimensions 213
 - Dimming the rearview mirror 50
 - Dipstick 159, 160
 - Displays
 - Cleaning 148
 - Distance 21
 - Doors
 - Emergency locking 32
 - Driver information system
 - Menu button 23
 - Menu display 22
 - Open door or front lid warning 20
 - Outside temperature display 20
 - Red symbols 11
 - Service interval display 24
 - Setting 23
 - Sound system display 20
 - Trip computer 21
 - yellow symbols 11
 - Driver seat
 - refer to* Seating position 87, 88
 - Driving safely 86
 - Driving through water 142
 - Dry sump lubrication 139
 - Duplicate key 27
 - Dust filter 62
- E**
- Efficiency program
 - Memory levels 21
 - Elapsed time 21
 - Electrical voltage 11
 - Electronic differential lock (EDL) 134
 - Warning/indicator lights 15
 - Electronic immobilizer 10, 28
 - Electronic power control
 - EPC warning/indicator light 16
 - Electronic Stabilization Control (ESC) 134
 - Warning/indicator lights 15
 - Emergency flasher 48
 - Warning/indicator lights 18
 - Emergency locking 32
 - Emergency operation
 - Convertible top 41

Emergency release			
Front lid	33		
Parking lock	79		
Emergency starting	206		
Emergency towing	208		
Energy management	140		
Battery power	141		
Driver notification	141		
Engine			
Coolant	161		
Data	214		
Engine compartment lid	155		
Starting	66, 67		
Stopping	68		
Engine compartment	157		
Safety instructions	155		
Engine compartment lid			
Closing	156		
Release lever	155		
Engine coolant system	161		
Malfunction	14		
Temperature gauge	9		
Engine oil	158		
Adding	160, 161		
Additives	160, 161		
Checking the engine oil level	159, 160		
Dry sump lubrication	139		
Indications and conditions requiring extra checking	159, 160		
Oil consumption	158		
Oil grades	158		
Specification and viscosity	158		
Temperature display	8		
Engine oil level	17		
Engine oil pressure (malfunction)	14		
Engine oil sensor defective	17		
Engine speed limitation	17		
Environment			
Catalytic converter	142		
Disposing of your vehicle battery	165		
Fuel	153		
Unleaded fuel	151		
What should I do with an old battery?	165		
EPC			
<i>refer to</i> Electronic power control	16		
ESC (Electronic Stabilization Control)			
Warning/indicator lights	15		
Event Data Recorder (EDR)	134		
Exhaust tail pipes			
Cleaning	147		
Expansion tank	162		
Exterior mirrors			
Adjusting	49		
Dimming	50		
Heating	49		
F			
Fan	62		
Fastening			
Booster seats	128		
Convertible child safety seats	127		
Infant seats	127		
Flat bed truck	208		
Flat tire			
Changing	203		
Floor mats	90		
Folding master key with remote control	27		
Foot pedals	90		
For the sake of the environment			
Gasoline fumes and the environment	153		
Letting your engine warm up	67		
Refueling	153		
Front airbags			
Description	106		
How they work	110		
Frontal collisions and the laws of physics	96		
Front lid			
Emergency release	33		
light	49		
Power locking system	32		
Trunk escape handle	199		
Front passenger			
<i>refer to</i> Seating position	87, 88		
Front seats	56		
Child restraints in the front seat	103		
Front towing loop	208		
Fuel			
Additives	151		
Blended gasoline	151		
Current fuel mileage	21		
Filler neck	152		
Fuel supply too low	17		
Gasoline	151		

Gasoline additives	152	Hydroplaning	186
Octane rating	151	I	
Recommendation	151	Ignition	66
Refueling	153	Immobilizer	10
Reserve	10	Important things to do before driving	86
Tank capacity	213	Improperly worn safety belts	100
Unlocking the fuel filler flap by hand	154	Indicator light	
Fuel gauge	10	Airbag system	112
Fuses		Audi magnetic ride	18
Assignment	210	Convertible top	15
Replacing	210	PASSENGER AIR BAG OFF	112
G		Indicator lights	11
Garage door opener (HomeLink)	35	<i>also refer to</i> Warning/indicator lights	11
Gearshift lever	74	Infant seats	127
Gearshift lever (S tronic)		Installing child safety seats	
Positions	75	Safety belts	130
Generator (warning/indicator lights)	14	Instrument cluster and controls	8
Glossary of tire and loading terminology ..	171	Instrument panel illumination	49
Glove compartment	60	Instruments and controls	
Gross Vehicle Weight Rating (GVWR)	212	General illustration	6
H		Interior lights	48
Headlight		Luggage compartment	49
Defective	17	J	
Headlights	46	Jump-starting	206
Cleaning	146	K	
Head restraints	58, 89	Key	27
Adjusting	89	Battery replacement	28
Heated		Emergency key	27
Exterior mirrors	49	Key replacement	27
Rear window defogger	64	Master key	27
Seats	64	Valet key	27
Heated washer jets		Kick-down	77
Wiper and washer system	51	Knee airbags	116
Heating	61	Description	116
High beam	46, 47	How they work	117
High voltage warning label	212	Important safety instructions	118
Hill hold assist		L	
Starting on hills	69	Lap timer	25
HomeLink (garage door opener)	35	Launch control program	77
Horn	6	Launch Control Program	
How many airbags does my vehicle have? ..	108	Manual transmission	74
How often should I check my tire pressures?	181		
How safety belt pretensioners work	100		

Leather cleaning/protection	148
leaving home	46
Lifting jack	203
Light	
coming/leaving home	46
Exterior lighting	46
Light/rain sensor	
Light sensor package	46
Light/rain sensor defective	18
Lights	
Instrument panel illumination	49
switching on and off	46
Light sensor package	46
Loading the luggage compartment	91
Locking	
Power locking system	31
Remote master key	30
Luggage compartment	49
Emergency exit	199
light	49
Loading	91

M

Maintenance	215
Malfunction Indicator Lamp (MIL)	17, 26
Manual transmission	
Gearshift lever	74
Launch Control Program	74
Matte finish paint cleaning	145
Menu button	23
Menu display	22
Mirror	
Vanity mirror	51
Mirrors	
Activating the digital compass	54
Adjusting the exterior mirrors	49
dimming	50
Monitoring the Advanced Airbag System ..	112

N

Natural leather	
Cleaning	148
New tires and wheels	186
NHTSA	
Contacting	92

Number of seats	95
-----------------------	----

O

Octane rating	151
Odometer	10
Oil	
<i>refer to</i> Engine oil	158
On-Board Diagnostic System (OBD)	
Data Link Connector (DLC)	26
Malfunction Indicator Lamp (MIL)	26
Open door or front lid warning	20
Optional equipment	
Marked with an asterisk	5
Outside mirrors	
<i>refer to</i> Exterior mirrors	49
Outside temperature display	20
Owner's manual	
How the Owner's Manual is organized	5

P

Paint damage	147
Paint No.	212
Park assist	
Cleaning sensors/camera lenses	146
Parking	
on a decline	69
on an incline	69
Parking brake	68
Parking brake warning	13
Parking system advanced	80
Adjusting the display	85
Adjusting the warning tones	85
Parallel Parking	84
Reverse parking	83
Safety precautions	80
Switching on and off	82
Parts replacement	217
PASSENGER AIR BAG OFF light	112
Passive safety system	86
Pedals	90
Physical principles of a frontal collision	96
Plastic parts	
Cleaning	147
Polishing	147
Pollen filter	62

Power locking system	29	Check light	27
Emergency locking	32	Unlocking and locking	30
Front lid	32	Repair manuals	215
Locking	31	Repairs	
Locking and unlocking the vehicle from in- side	31	Airbag system	114
Switches	31	Replacement parts	217
Unlocking	31	Replacing	
Unlocking and locking vehicle	30	Bulbs	211
Power seats	57	Fuses	210
Power steering	139	Rims	186
Power top		Tires and wheels	187
Cleaning	147	Wheel rims	190
Power windows	34	Reporting Safety Defects	92
Reactivating the system	35	Reset button	10
Pregnant women		Resetting remote control	31
Special considerations when wearing a safe- ty belt	99	Retractor	98
Proper safety belt position	99	Reverse gear (S tronic)	75
Proper seating position		Rims	
Driver	87	Cleaning	146
Front passenger	88	Replacing	186, 190
Protecting	147	Rollbar	
		<i>refer to Active rollover protection system</i> .	93
Q			
Quartz clock	9	S	
Question		SAFE	10, 28
What happens to unbelted occupants? . . .	96	Safe driving habits	86
Why safety belts?	95	Safety belt position	99
		Safety belts worn by pregnant women	99
R			
Rain sensor defective	18	Safety belt pretensioner	
Rear light		Service and disposal	101
Defective	17	Safety belts	98
Rear spoiler	138	Cleaning	148
Rear view camera		Danger to passengers who do not wear a safety belt	96
Parallel Parking	84	Fastening	98
Reverse parking	83	Improperly worn	100
Rear view mirror	50	Not worn	96
Rear window	40	pretensioners	100
Rear window defogger	64	Safety belt position	99
Refueling	153	Safety instructions	97
Remote control	31	Securing child safety seats	130
<i>also refer to Remote master key</i>	28	Special considerations for pregnant women	99
Remote master key		Unfastening	100
Battery replacement	27, 28	Warning/indicator light	95
		Why YOU MUST wear them	95
		Worn properly	97

Safety belt warning light	14	Speedometer	10
Safety compliance sticker	212	Speed rating letter code	189
Safety equipment	86	Speed warning system	69
Safety features for occupant restraint and protection	86	Spoiler	138
Safety guidelines		Sport function (S tronic)	75
Seat adjustment	56	Sport mode	135
Safety instructions		Starting on hills	
For using child safety seats	125	Hill hold assist	69
For using safety belts	97	Starting the engine	66, 67
Monitoring the Advanced Airbag System	114	What should I do if the engine does not start?	67
Seat adjustment		Steering column	
Driver's seat	56	Adjusting	66
Front passenger's seat	57	Locking the steering	66
Front seats	56	Steering wheel	
Head restraints	89	Shift paddles (S tronic)	78
Power seats	57	Steps for determining correct load limit	184
Safety guidelines	56	Stopping the engine	68
Seat covers		Storage	59
Cleaning	148	S tronic (Automatic transmission)	75
Seating capacity	95	Automatic shifting	77
Seating position		Kick-down	77
Driver	87	Launch control program	77
Front passenger	88	Manual shifting	76
Incorrect seat position	89	Parking	76
Seats		Sport function	75
Number of seats	95	Steering wheel with shift paddles	78
Selector lever (S tronic)		Sun visors	51
Positions	75	Symbols	
Service and disposal		<i>refer to</i> Warning/Indicator lights	11
Safety belt pretensioner	101		
Service interval display	24	T	
Service position for windshield wipers	53	Tachometer	9
Set menu	23	Tail lights	
Setting the time	9	Cleaning	146
Shift paddles (S tronic)	78	Tank flap	
Shutting down vehicle	143	Unlocking the fuel filler flap by hand	154
Side airbags		Technical Data	212
Description	118	Technical modifications	217
How they work	119	Temperature	62
Side marker lights	46	Textiles	
Snow chains	194	Cleaning	148
Socket	59	Tightening wheel bolts	203
Sound system display	20	Tire mobility system	199
Sources of information about child restraints and their use	132	Tire pressure	179

T

Tachometer	9
Tail lights	
Cleaning	146
Tank flap	
Unlocking the fuel filler flap by hand	154
Technical Data	212
Technical modifications	217
Temperature	62
Textiles	
Cleaning	148
Tightening wheel bolts	203
Tire mobility system	199
Tire pressure	179

Tire pressure monitoring system	196	Trip computer	21
Malfunctions	198	Single-trip memory	21
Sensors	190	Total-trip memory	21
Tires and wheels	190	Trip odometer	10
Valves	190	Turn signals	47
Warning/indicator light	18	Warning/indicator lights	18
Tire repair kit	199		
Tires	169	U	
Pressure	196	Unfastening safety belts	100
Replacing	186, 190	Unidirectional tires	170
Service life	185	Uniform tire quality grading	192
Speed rating letter code	189	Unlocking	
Tire manufacturing date	188	Power locking system	31
Tire pressure monitoring system	196	Remote control key	30
Tire specifications	188		
Tread depth	185	V	
Uniform tire quality grading	192	Vanity mirror	51
Winter tires	193	Vehicle	
Tires/Wheels		care/cleaning	145
Low aspect ratio tires	195	Vehicle electrical system	14
Tire mobility system	199	Vehicle Identification Number (VIN)	212
Tire repair kit	199	Vehicle jack	203
Tires and vehicle load limits	182	Vehicle literature	4
Tires and wheels		Vehicle shut-down	143
Checking tire pressure	179	Vehicle tool kit	199
Cold tire inflation pressure	176	Ventilation	61
Dimensions	186	Vinyl	
General notes	169	Cleaning	148
Glossary of tire and loading terminology	171	Voltmeter display	11
New tires and wheels	186		
Replacing	187	W	
Snow chains	194	Warning/indicator lights	8
Tire pressure monitoring system	190	Airbag system	13
Tires and vehicle load limits	182	Anti-lock brake system (ABS)	15
Wheel bolts	195	Brake system	12
Winter tires	193	Cruise control	19
Tire service life	185	Electronic power control	16
Tool kit	199	Electronic Stabilization Control (ESC)	15
Towing		Generator	14
Tow truck procedures	208	Malfunction Indicator Lamp (MIL)	17
Towing loop	208	Parking brake	12
Trailer towing	144	Safety belt	14
Transmission		Safety systems	13
Manual transmission	74	Tire pressure monitoring system	18
Transmission malfunction (indicator light)	78	Turn signals	18
Transport Canada	92		
Tread Wear Indicator (TWI)	185		

Warning/Indicator lights		
Rear spoiler	18	
Warning lights	11	
Warranty coverages	215	
Wear indicator	185	
Weights	212	
What happens if you wear your safety belt too loose?	99	
What happens to unbelted occupants?	96	
What impairs driving safety?	87	
What should I do after changing a wheel?	181	
Wheel bolts		
Torque	195	
Wheels	169	
Checking tire pressure	179	
Cleaning	146	
Cold tire inflation pressure	176	
General notes	169	
Glossary of tire and loading terminology	171	
New tires and wheels	186	
Tires and vehicle load limits	182	
When must the airbag system be inspected?	112	
When should I adjust the tire pressures?	181	
When should I check the tire pressures?	181	
Where can I find the tire pressures for my car?	179	
Why safety belts?	95, 96	
Wind deflector	40	
Cleaning	147	
Windows		
Cleaning/removing ice	147	
Defrost	63	
Windshield washer fluid	17	
Windshield wipers	168	
Cleaning	53	
Installing new wiper blades	53	
Service position	53	
Winter operation		
Battery	164	
Car washes	145	
Coolant system	161	
Defrosting windows	63	
Heated seats	64	
Removing ice from windows	147	
Windshield wipers	168	
Winter tires	193	
All-wheel drive	193	
Wiper and washer system	51	
Intermittent wiping	51	
One-tap wiping	51	
Wiper blades		
<i>refer to</i> Windshield wipers	53	

It has always been Audi's policy to continuously improve its products. Audi, therefore, reserves the right to make changes in design and specifications, and to make additions or improvements in its products, without incurring any obligation to install them on products previously manufactured.

Text, illustrations and specifications in this manual are based on the most up-to-date information available at the time of printing.

All rights reserved. May not be reproduced or translated in whole or in part without the written

consent of AUDI AG. Specifications are subject to change without notice.

Editorial deadline: 09/02/2014



For the sake of the environment

Printed on environmentally friendly paper
(bleached without chlorine, recyclable).

Printed in Germany

© 2014 AUDI AG

Owner's Manual
2015 Audi R8 Spyder
Englisch Nordamerika 11.2014
152.561.427.21



15256142721

www.audi.com