


NOTICE: When inspecting or repairing the SRS, perform service in accordance with the following precautionary instructions and the procedure, and precautions in the Repair Manual applicable for the model year.

- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- **Work must be started more than 90 seconds after the ignition SW is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.**
(The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may deploy.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be cleared. So before starting work, make a record of the contents in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. Some vehicles have power tilt steering, power telescopic steering, power seat and power outside rear view mirror which are all equipped with memory function. However, it is not possible to make a record of these memory contents. So when the work is finished, it will be necessary to explain it to your customer, and ask the customer to adjust the features and reset the memory. To avoid erasing the memory in each system, never use a back-up power supply from outside the vehicle.
- Before repair, remove the airbag sensor if shocks are likely to be applied to the sensor during repair.
- Do not expose the following parts directly to hot air or flame;
- Even in cases of a minor collision where the SRS does not deploy, the following parts should be inspected;
- Never use SRS parts from another vehicle. When replacing parts, replace with new parts.
- For the purpose of reuse, never disassemble and repair the following parts.
- If the following parts have been dropped, or have cracks, dents and other defects in their case, bracket, and connector, replace with new one.
- Use a volt/ohmmeter with high impedance (10 k Ω /V minimum) for troubleshooting electrical circuits of the system.
- Information labels are attached to the periphery of the SRS components. Follow the instructions of the notice.
- After work on the SRS is completed, check the SRS warning light.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.

- * Steering wheel pad
- * Front passenger airbag assembly
- * Seat belt pretensioner
- * Center airbag sensor assembly
- * Front airbag sensor assembly



System Outline

The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts. When the ignition SW is turned to ON, the current from the ignition SW flows to TERMINAL 21 of the airbag sensor assembly center.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the ignition SW flows to TERMINALS (A) 5, (A) 4, (B) 2 and (C) 4 of the airbag sensor assembly center to the airbag squibs and the front seat outer belt TERMINALS (A) 6, (A) 3, (B) 1 and (C) 5 of the airbag sensor assembly center to TERMINAL (A) 25, (A) 26 or BODY GROUND to GROUND, so that current flows to the airbag squibs and the front seat outer belt and causes them to operate. The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver. The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A12	48 (LHD)	B6	C	56 (RHD)	H23
	56 (RHD)	B7	B	44 (*1)	
A13	48 (LHD)			52 (*4)	H32
	56 (RHD)	B23	A	50 (LHD)	
B4	48 (LHD)		B	58 (RHD)	H41
	56 (RHD)	B25	A	50 (LHD)	
B5	48 (LHD)		B	58 (RHD)	J1
	56 (RHD)	H20		49 (LHD)	
B6	48 (LHD)			57 (RHD)	

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
5D	30	Instrument Panel Wire and Instrument Panel J/B (Left Side of Instrument Panel)
5E	30	Engine Room Main Wire and Instrument Panel J/B (Left Side of Instrument Panel)
5H	30	Instrument Panel Wire and Instrument Panel J/B (Left Side of Instrument Panel)
5M	31	
5S		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
AB2	64 (LHD)	Cowl to Head Lamp Wire and Engine Room Main Wire (RH Side of Instrument Panel R/B)
	72 (RHD)	Cowl to Head Lamp Wire and Engine Room Main Wire (Near the Parking Brake SW)
HB1	64 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Under the Instrument Panel J/B)
	72 (RHD)	
HB3	64 (LHD)	
	72 (RHD)	
HJ1	64 (LHD)	Instrument Panel Wire and Instrument Panel No.3 Wire (Upper Side of Glove Box)
	72 (RHD)	

▽ : Ground Points

Code	See Page	Ground Points Location
B3	60 (*1)	Front Floor Panel Left
	61 (*2)	
	62 (*3)	
	68 (*4)	
	69 (*5)	
	70 (*6)	
H1	64 (LHD)	Instrument Panel Reinforcement
	72 (RHD)	

* 1 : LHD 2TR-FE * 2 : LHD 2KD-FTV * 3 : LHD 5L-E * 4 : RHD 2TR-FE * 5 : RHD 2KD-FTV * 6 : RHD 5L-E * 7 : 2TR-FE
 * 8 : 2KD-FTV, 5L-E

