
FUEL SYSTEM

VARIABLE VENTURI TYPE CARBURETOR

CONTENTS

1. SPECIFICATIONS	13B-1- 1
GENERAL SPECIFICATIONS	13B-1- 1
CARBURETOR SPECIFICATIONS	13B-1- 3
SERVICE SPECIFICATIONS	13B-1- 4
TORQUE SPECIFICATIONS	13B-1- 5
2. SPECIAL TOOLS	13B-2- 1
3. FUEL PUMP	13B-3- 1
4. CARBURETOR ASSEMBLY	13B-4- 1
5. CARBURETOR (Types "A" and "B")	13B-5- 1

1. SPECIFICATIONS

GENERAL SPECIFICATIONS – 1991 MODEL

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater	
				Type	Identification No.	Choke type	Fuel cut solenoid		
EC	Colt Lancer/ (C51V, C51A, C52A, C61A, C62A)	4G13	M/T	A	31A 1	Automatic (Wax type)	X	—	
		4G15	M/T	A	51A 1	Automatic (Wax type)	X	—	
			A/T	A	51B 1	Automatic (Wax type)	X	—	
	Lancer station wagon	4G15	M/T	A	51A 1	Automatic (Wax type)	X	—	
			A/T	A	51B 1	Automatic (Wax type)	X	—	
	Australia	Lancer (C62A)	4G15	M/T	A	53G 1	Automatic (Wax type)	X	—
A/T				A	53H 1	Automatic (Wax type)	X	—	
EXP	Colt/ Lancer (C51A, C52A, C61A, C62A)	4G13	M/T	B	32B 1	Manual	X	—	
				A	32F 1	Automatic (Wax type)	X	—	
				A	34F 1	Automatic (Wax type)	X	—	
				A/T	B	32C 1	Manual	X	—
					A	32D 1	Automatic (Wax type)	X	—
					A	35D 1	Automatic (Wax type)	X	—
		4G15	M/T	B	52C 1	Manual	X	—	
				A	52A 1	Automatic (Wax type)	X	—	
				A	51A 1	Automatic (Wax type)	X	—	
				A/T	B	52D 1	Manual	X	—
					A	52B 1	Automatic (Wax type)	X	—
					A	51B 1	Automatic (Wax type)	X	—

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater
				Type	Identification No.	Choke type	Fuel cut solenoid	
EXP	Lancer station wagon	4G13	M/T	B	32B 1	Manual	X	—
				A	32F 1	Automatic (Wax type)	X	—
				A	34F 1	Automatic (Wax type)	X	—
		4G15	M/T	B	52C 1	Manual	X	—
				A	52A 1	Automatic (Wax type)	X	—
				A	51A 1	Automatic (Wax type)	X	—
			A/T	B	52D 1	Manual	X	—
				A	52B 1	Automatic (Wax type)	X	—
				A	51B 1	Automatic (Wax type)	X	—
GCC	Colt/ Lancer (C51A, C52A, C61A, C62A)	4G13	M/T	A	34F 1	Automatic (Wax type)	X	—
		4G15	M/T	A	51A 1	Automatic (Wax type)	X	—
			A/T	A	51B 1	Automatic (Wax type)	X	—
	Lancer station wagon	4G15	M/T	A	51A 1	Automatic (Wax type)	X	—
			A/T	A	51B 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1992 MODELS

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater
				Type	Identification No.	Choke type	Fuel cut solenoid	
EXP	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	32H 1	Automatic (Wax type)	X	—
				A	12F 1	Automatic (Wax type)	X	—
			A/T	A	32J 1	Automatic (Wax type)	X	—
				A	12G 1	Automatic (Wax type)	X	—
		4G15	M/T	A	62A 1	Automatic (Wax type)	X	—
				A	82J 1	Automatic (Wax type)	X	—
			A/T	A	62B 1	Automatic (Wax type)	X	—
				A	82K 1	Automatic (Wax type)	X	—
GCC	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1993 MODELS

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EC	Colt/ Lancer (C61A, C62A)	4G13	M/T	A	31A 1	Automatic (Wax type)	X	—
		4G15	M/T	A	51A 1	Automatic (Wax type)	X	—
			A/T	A	51B 1	Automatic (Wax type)	X	—
Australia	Colt/ Lancer (C62A, CA2A, CB2A)	4G15	M/T	A	63C 1	Automatic (Wax type)	X	—
			A/T	A	63D 1	Automatic (Wax type)	X	—

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EXP	Colt/ Lancer (C62A)	4G15	M/T	A	62A 1	Automatic (Wax type)	X	—
				A	82J 1	Automatic (Wax type)	X	—
			A/T	A	62B 1	Automatic (Wax type)	X	—
				A	82K 1	Automatic (Wax type)	X	—
	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	32H 1	Automatic (Wax type)	X	—
				A	12F 1	Automatic (Wax type)	X	—
			A/T	A	32J 1	Automatic (Wax type)	X	—
				A	12G 1	Automatic (Wax type)	X	—
		4G15	M/T	A	62A 1	Automatic (Wax type)	X	—
				A	82J 1	Automatic (Wax type)	X	—
			A/T	A	62B 1	Automatic (Wax type)	X	—
				A	82K 1	Automatic (Wax type)	X	—
GCC	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—
	Lancer station wagon (CB1W)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1994 MODELS

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater
				Type	Identification No.	Choke type	Fuel cut solenoid	
EXP	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	32H 1	Automatic (Wax type)	X	—
				A	12F 1	Automatic (Wax type)	X	—

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater
			Type	Identification No.	Choke type	Fuel cut solenoid	
EXP	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	A/T	A	32J 1	Automatic (Wax type)	X	–
			A	12G 1	Automatic (Wax type)	X	–
			M/T	27D 1	Automatic (Wax type)	X	–
				22C 1	Automatic (Wax type)	X	–
		4G15	M/T	62A 1	Automatic (Wax type)	X	–
				82J 1	Automatic (Wax type)	X	–
			A/T	62B 1	Automatic (Wax type)	X	–
				82K 1	Automatic (Wax type)	X	–
			M/T	67G 1	Automatic (Wax type)	X	–
				62K 1	Automatic (Wax type)	X	–
			A/T	82A 1	Automatic (Wax type)	X	–
	Lancer station wagon (CB1W, CB2W)	4G13	M/T	32H 1	Automatic (Wax type)	X	–
				12F 1	Automatic (Wax type)	X	–
			A/T	32J 1	Automatic (Wax type)	X	–
				12G 1	Automatic (Wax type)	X	–
		4G15	M/T	22C 1	Automatic (Wax type)	X	–
			M/T	62A 1	Automatic (Wax type)	X	–
				82J 1	Automatic (Wax type)	X	–
			A/T	62B 1	Automatic (Wax type)	X	–
				82K 1	Automatic (Wax type)	X	–
			M/T	62K 1	Automatic (Wax type)	X	–
			A/T	82A 1	Automatic (Wax type)	X	–

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GENERAL SPECIFICATIONS – 1995 MODELS

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater
				Type	Identification No.	Choke type	Fuel cut solenoid	
Australia	Colt/ Lancer (C62A, CA2A, CB2A)	4G15	M/T	A	63C 1	Automatic (Wax type)	X	—
			A/T	A	63D 1	Automatic (Wax type)	X	—
EXP	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	32H 1	Automatic (Wax type)	X	—
				A	12F 1	Automatic (Wax type)	X	—
			A/T	A	32J 1	Automatic (Wax type)	X	—
				A	12G 1	Automatic (Wax type)	X	—
			M/T	A	27D 1	Automatic (Wax type)	X	—
				A	22C 1	Automatic (Wax type)	X	—
				A	38H 1	Automatic (Wax type)	X	—
				A	38K 1	Automatic (Wax type)	X	—
		4G15	M/T	A	62A 1	Automatic (Wax type)	X	—
				A	82J 1	Automatic (Wax type)	X	—
			A/T	A	62B 1	Automatic (Wax type)	X	—
				A	82K 1	Automatic (Wax type)	X	—
			M/T	A	67G 1	Automatic (Wax type)	X	—
				A	62K 1	Automatic (Wax type)	X	—
				A	68A 1	Automatic (Wax type)	X	—
				A	68B 1	Automatic (Wax type)	X	—
			A/T	A	82A 1	Automatic (Wax type)	X	—
				A	68E 1	Automatic (Wax type)	X	—
				A	68F 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission
A/T: Automatic Transmission
X: Applicable
–: Not Applicable

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EXP	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	32H 1	Automatic (Wax type)	X	—
				A	12F 1	Automatic (Wax type)	X	—
			A/T	A	32J 1	Automatic (Wax type)	X	—
				A	12G 1	Automatic (Wax type)	X	—
			M/T	A	22C 1	Automatic (Wax type)	X	—
				A	38H 1	Automatic (Wax type)	X	—
				A	38K 1	Automatic (Wax type)	X	—
			A/T	A	28A 1	Automatic (Wax type)	X	—
		4G15	M/T	A	62A 1	Automatic (Wax type)	X	—
				A	82J 1	Automatic (Wax type)	X	—
			A/T	A	62B 1	Automatic (Wax type)	X	—
				A	82K 1	Automatic (Wax type)	X	—
			M/T	A	62K 1	Automatic (Wax type)	X	—
				A	68A 1	Automatic (Wax type)	X	—
				A	68B 1	Automatic (Wax type)	X	—
			A/T	A	82A 1	Automatic (Wax type)	X	—
				A	68E 1	Automatic (Wax type)	X	—
				A	68F 1	Automatic (Wax type)	X	—
GCC	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
				A	27D 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

Vehicle model		Engine	Trans- mission	Carburetor			Cold mixture heater	
				Type	Identification No.	Choke type		Fuel cut solenoid
GCC	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
			A/T	A	35J 1	Automatic (Wax type)	X	—
			M/T	A	27D 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—

GENERAL SPECIFICATIONS – 1996 MODELS

Vehicle model		Engine	Trans- mission	Carburetor				Cold mixture heater
				Type	Identification No.	Choke type	Fuel cut solenoid	
Australia	Colt/ Lancer (CA2A, CB2A)	4G15	M/T	A	83B 1	Automatic (Wax type)	X	—
			A/T	A	83C 1	Automatic (Wax type)	X	—
GCC	Colt/ Lancer (CA1A, CA2A, CB1A, CB2A)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
			A/T	A	35J 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—
	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1997 MODELS

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EXP	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	12F 1	Automatic (Wax type)	X	—
				A	18F 1	Automatic (Wax type)	X	—
				A	22C 1	Automatic (Wax type)	X	—
			A/T	A	12G 1	Automatic (Wax type)	X	—
				A	18G 1	Automatic (Wax type)	X	—
		4G15	M/T	A	82J 1	Automatic (Wax type)	X	—
				A	88J 1	Automatic (Wax type)	X	—
				A	62K 1	Automatic (Wax type)	X	—
				A	68A 1	Automatic (Wax type)	X	—
			A/T	A	82K 1	Automatic (Wax type)	X	—
				A	88K 1	Automatic (Wax type)	X	—
				A	82A 1	Automatic (Wax type)	X	—
				A	68F 1	Automatic (Wax type)	X	—
GCC	Lancer station wagon (CB1W, CB2W)	4G13	M/T	A	34H 1	Automatic (Wax type)	X	—
			A/T	A	35J 1	Automatic (Wax type)	X	—
		4G15	M/T	A	64A 1	Automatic (Wax type)	X	—
			A/T	A	64B 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1998 MODELS

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EXP	Lancer	4G13	M/T	A	12J 1	Automatic (Wax type)	X	—
				A	14J 1	Automatic (Wax type)	X	—
				A	22C 1	Automatic (Wax type)	X	—
		4G15	A/T	A	12B 3	Automatic (Wax type)	X	—
				A	14D 2	Automatic (Wax type)	X	—
				A	92C 1	Automatic (Wax type)	X	—
	A/T	A	92D 1	Automatic (Wax type)	X	—		

NOTE

M/T: Manual Transmission

4WD: For Wheel Drive

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

GENERAL SPECIFICATIONS – 1999 MODELS

Vehicle model	Engine	Trans- mission	Carburetor				Cold mixture heater	
			Type	Identification No.	Choke type	Fuel cut solenoid		
EXP	Colt	4G13	M/T	A	14C 1	Automatic (Wax type)	X	—
		4G15	M/T	A	84F 1	Automatic (Wax type)	X	—
			A/T	A	84G 1	Automatic (Wax type)	X	—
	Lancer	4G13	M/T	A	12J 1	Automatic (Wax type)	X	—
				A	14J 1	Automatic (Wax type)	X	—
				A	22C 1	Automatic (Wax type)	X	—
			A/T	A	12B 3	Automatic (Wax type)	X	—
				A	14D 2	Automatic (Wax type)	X	—
		4G15	M/T	A	92C 1	Automatic (Wax type)	X	—
			A/T	A	92D 1	Automatic (Wax type)	X	—

NOTE

M/T: Manual Transmission

4WD: For Wheel Drive

A/T: Automatic Transmission

X: Applicable

–: Not Applicable

GCC: Gulf Cooperation Council

Intentionally blank

CARBURETOR SPECIFICATIONS

Carburetor identification No.	Throttle bore mm (in.)	Main jet mm (in.)	Dash pot	Throttle position sensor
12F 1	42 (1.654)	3 (0.118)	–	–
12G 1	42 (1.654)	3 (0.118)	Conventional type	–
14C 1	42 (1.654)	3 (0.118)	–	–
18F 1	42 (1.654)	3 (0.118)	–	–
18G 1	42 (1.654)	3 (0.118)	Conventional type	–
22C 1	42 (1.654)	3 (0.118)	–	–
27D 1	42 (1.654)	3 (0.118)	–	–
28A 1	42 (1.654)	3 (0.118)	Conventional type	–
31A 1	42 (1.654)	3 (0.118)	Conventional type	–
32B 1	42 (1.654)	3 (0.118)	–	–
32C 1	42 (1.654)	3 (0.118)	Conventional type	–
32D 1	42 (1.654)	3 (0.118)	Conventional type	–
32F 1	42 (1.654)	3 (0.118)	–	–
32H 1	42 (1.654)	3 (0.118)	–	–
32J 1	42 (1.654)	3 (0.118)	Conventional type	–
34F 1	42 (1.654)	3 (0.118)	–	–
34H 1	42 (1.654)	3 (0.118)	–	–
35D 1	42 (1.654)	3 (0.118)	Conventional type	–
35J 1	42 (1.654)	3 (0.118)	Conventional type	–
38H 1	42 (1.654)	3 (0.118)	–	–
38K 1	42 (1.654)	3 (0.118)	–	–
51A 1	42 (1.654)	3 (0.118)	–	–
51B 1	42 (1.654)	3 (0.118)	Conventional type	–
52A 1	42 (1.654)	3 (0.118)	–	–
52B 1	42 (1.654)	3 (0.118)	Conventional type	–
52C 1	42 (1.654)	3 (0.118)	–	–
52D 1	42 (1.654)	3 (0.118)	Conventional type	–

13B-1-3a**VARIABLE VENTURI CARB – Specifications**

Carburetor identification No.	Throttle bore mm (in.)	Main jet mm (in.)	Dash pot	Throttle position sensor
53G 1	42 (1.654)	3 (0.118)	–	–
52H 1	42 (1.654)	3 (0.118)	Conventional type	–
62A 1	42 (1.654)	3 (0.118)	–	–
62B 1	42 (1.654)	3 (0.118)	Conventional type	–
62K 1	42 (1.654)	3 (0.118)	–	–
63C 1	42 (1.654)	3 (0.118)	–	–
63D 1	42 (1.654)	3 (0.118)	Conventional type	–
64A 1	42 (1.654)	3 (0.118)	–	–
64B 1	42 (1.654)	3 (0.118)	Conventional type	–
67G 1	42 (1.654)	3 (0.118)	–	–
68A 1	42 (1.654)	3 (0.118)	–	–
68B 1	42 (1.654)	3 (0.118)	–	–
68E 1	42 (1.654)	3 (0.118)	Conventional type	–
68F 1	42 (1.654)	3 (0.118)	Conventional type	–
82A 1	42 (1.654)	3 (0.118)	Conventional type	–
82J 1	42 (1.654)	3 (0.118)	–	–
82K 1	42 (1.654)	3 (0.118)	Conventional type	–
83B 1	42 (1.654)	3 (0.118)	–	–
83C 1	42 (1.654)	3 (0.118)	Conventional type	–
84F 1	42 (1.654)	3 (0.118)	–	–
84G 1	42 (1.654)	3 (0.118)	Conventional type	X
88J 1	42 (1.654)	3 (0.118)	–	–
88K 1	42 (1.654)	3 (0.118)	Conventional type	–

NOTE

–: Not Applicable

Intentionally blank

SERVICE SPECIFICATIONS

CARBURETOR

Carburetor identification No.	Main jet adjusting screw initial set value mm (in.)	Mixture adjusting screw initial set value mm (in.)	Float level adjustment	
			Needle valve to float lever clearance mm (in.)	Float to air horn clearance mm (in.)
12F 1	—*	—*	1.0 (0.039)	4.3 (0.169)
12G 1	—*	—*	1.0 (0.039)	4.3 (0.169)
12B 3	—*	—*	1.0 (0.039)	4.3 (0.169)
12J 1	—*	—*	1.0 (0.039)	4.3 (0.169)
14C 1	—*	—*	1.0 (0.039)	4.3 (0.169)
14D 2	—*	—*	1.0 (0.039)	4.3 (0.169)
14J 1	—*	—*	1.0 (0.039)	4.3 (0.169)
22C 1	3.0 – 4.4 (0.118 – 0.173)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
18F 1	—*	—*	1.0 (0.039)	4.3 (0.169)
18G 1	—*	—*	1.0 (0.039)	4.3 (0.169)
27D 1	3.0 – 4.4 (0.118 – 0.173)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
28A 1	3.0 – 4.4 (0.118 – 0.173)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
31A 1	2.8 – 4.2 (0.110 – 0.165)	4.3 – 5.7 (0.169 – 0.224)	1.0 (0.039)	4.3 (0.169)
32B 1	3.4 – 4.8 (0.134 – 0.189)	8.0 – 9.4 (0.315 – 0.370)	1.0 (0.039)	4.3 (0.169)
32C 1	3.4 – 4.8 (0.134 – 0.189)	8.0 – 9.4 (0.315 – 0.370)	1.0 (0.039)	4.3 (0.169)
32D 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
32F 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
32H 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
32J 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
34F 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
34H 1	2.8 – 4.2 (0.110 – 0.165)	4.3 – 5.7 (0.169 – 0.224)	1.0 (0.039)	4.3 (0.169)
35D 1	2.8 – 4.2 (0.110 – 0.165)	8.3 – 9.7 (0.327 – 0.382)	1.0 (0.039)	4.3 (0.169)
35J 1	3.0 – 4.4 (0.118 – 0.173)	3.5 – 5.2 (0.138 – 0.205)	1.0 (0.039)	4.3 (0.169)

Carburetor identification No.	Main jet adjusting screw initial set value mm (in.)	Mixture adjusting screw initial set value mm (in.)	Float level adjustment	
			Needle valve to float lever clearance mm (in.)	Float to air horn clearance mm (in.)
38H 1	3.0 – 4.4 (0.118 – 0.173)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
38K 1	3.0 – 4.4 (0.118 – 0.173)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
51A 1	3.6 – 5.0 (0.142 – 0.197)	4.1 – 5.5 (0.161 – 0.217)	1.0 (0.039)	4.3 (0.169)
51B 1	3.6 – 5.0 (0.142 – 0.197)	4.1 – 5.5 (0.161 – 0.217)	1.0 (0.039)	4.3 (0.169)
52A 1	3.6 – 5.0 (0.142 – 0.197)	8.1 – 9.5 (0.319 – 0.374)	1.0 (0.039)	4.3 (0.169)
52B 1	3.6 – 5.0 (0.142 – 0.197)	8.1 – 9.5 (0.319 – 0.374)	1.0 (0.039)	4.3 (0.169)
52C 1	3.3 – 4.7 (0.130 – 0.185)	7.9 – 9.3 (0.311 – 0.366)	1.0 (0.039)	4.3 (0.169)
52D 1	3.3 – 4.7 (0.130 – 0.185)	7.9 – 9.3 (0.311 – 0.366)	1.0 (0.039)	4.3 (0.169)
53G 1	3.0 – 4.4 (0.118 – 0.173)	4.0 – 5.4 (0.157 – 0.213)	1.0 (0.039)	4.3 (0.169)
53H 1	3.0 – 4.4 (0.118 – 0.173)	4.0 – 5.4 (0.157 – 0.213)	1.0 (0.039)	4.3 (0.169)
62A 1	3.6 – 5.0 (0.142 – 0.197)	8.1 – 9.5 (0.319 – 0.374)	1.0 (0.039)	4.3 (0.169)
62B 1	3.6 – 5.0 (0.142 – 0.197)	8.1 – 9.5 (0.319 – 0.374)	1.0 (0.039)	4.3 (0.169)
62K 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
63C 1	2.8 – 4.2 (0.110 – 0.165)	4.0 – 5.4 (0.157 – 0.213)	1.0 (0.039)	4.3 (0.169)
63D 1	2.8 – 4.2 (0.110 – 0.165)	4.0 – 5.4 (0.157 – 0.213)	1.0 (0.039)	4.3 (0.169)
64A 1	3.6 – 5.0 (0.142 – 0.197)	4.1 – 5.5 (0.161 – 0.217)	1.0 (0.039)	4.3 (0.169)
64B 1	3.6 – 5.0 (0.142 – 0.197)	4.1 – 5.5 (0.161 – 0.217)	1.0 (0.039)	4.3 (0.169)
67G 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
68A 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
68B 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
68E 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
68F 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)

Carburetor identification No.	Main jet adjusting screw initial set value mm (in.)	Mixture adjusting screw initial set value mm (in.)	Float level adjustment	
			Needle valve to float lever clearance mm (in.)	Float to air horn clearance mm (in.)
82A 1	3.2 – 4.6 (0.126 – 0.181)	7.8 – 9.2 (0.307 – 0.362)	1.0 (0.039)	4.3 (0.169)
82J 1	—*	—*	1.0 (0.039)	4.3 (0.169)
82K 1	—*	—*	1.0 (0.039)	4.3 (0.169)
83B 1	—*	—*	1.0 (0.039)	4.3 (0.169)
83C 1	—*	—*	1.0 (0.039)	4.3 (0.169)
84F 1	—*	—*	1.0 (0.039)	4.3 (0.169)
84G 1	—*	—*	1.0 (0.039)	4.3 (0.169)
88J 1	—*	—*	1.0 (0.039)	4.3 (0.169)
88K 1	—*	—*	1.0 (0.039)	4.3 (0.169)
92C 1	—*	—*	1.0 (0.039)	4.3 (0.169)
92D 1	—*	—*	1.0 (0.039)	4.3 (0.169)

NOTE


*: The main jet adjusting screw and the mixture adjusting screw should be adjusted to obtain proper idling speed and CO concentration by referring to the Service Adjustment Procedure in Group 11 "Engine" of the applicable vehicle model's Workshop Manual – chassis.

TORQUE SPECIFICATIONS

	Nm	Torque kgm	ft.lbs.
Carburetor mounting bolt	18	1.8	13
Stud	9	0.9	7

NOTES


2. SPECIAL TOOLS

Tool	Number	Name	Use
	MD998299	MAS driver	Adjustment of idle mixture and removal and installation of MAS



NOTES

3. FUEL PUMP

REMOVAL AND INSTALLATION



1FU0688



SERVICE POINTS OF REMOVAL

◈A◈ REMOVAL OF FUEL PUMP

- (1) Placing the piston in No. 2 cylinder at TDC on the compression stroke makes the fuel pump stroke lift the smallest, allowing easy removal of the pump.

INSPECTION

FUEL PUMP

Check the following and replace if faulty. The fuel pump cannot be disassembled. Therefore, replace as an assembly if necessary.


- (1) Check the breather pipe and hole for oil or fuel leaks.
- (2) Check parts for damage and cracks.
- (3) Check the rocker arm for wear.

SERVICE POINTS OF INSTALLATION

◈A◈ INSTALLATION OF FUEL PUMP


- (1) Bring the piston in No. 2 cylinder to TDC on the compression stroke. This provides the smallest lift of the eccentric cam, allowing easy installation of the fuel pump.

NOTES


4. CARBURETOR ASSEMBLY**REMOVAL AND INSTALLATION – Types "A" and "B"****Removal steps**

1. Stud
2. Bolt with spring washer
- ◆◆ 3. Carburetor
- ◆◆ 4. Upper gasket
- ◆◆ 5. Insulator
- ◆◆ 6. Lower gasket


Type A




1FU0763




1FU0146



1FU0764



1FU0762



1FU0798

SERVICE POINT OF INSTALLATION

INSTALLATION OF LOWER GASKET / INSULATOR / UPPER GASKET / CARBURETOR

<Where the upper is of fiber type>

- (1) Upper and lower gaskets are identified by the protrusions shown in the figure.

- (2) Set the lower gasket on the intake manifold in such a way that the protrusion is located at the illustrated position.

NOTE

No direction of installation is specified for the type B gasket.

- (3) Set the insulator onto the intake manifold, with the embossed mark on the insulator facing in the direction shown in the figure.

- (4) Install the upper gasket on the insulator so that the protrusion comes to the position shown in the illustration beside Step (2).


NOTE

No direction of installation is specified for the type B gasket.

- (5) Install the carburetor and tighten four carburetor bolts to the specified torque.

<Where the upper gasket is of metal type>


- (1) Using the threaded holes for mounting the carburetor on the intake manifold, stand two guide rods [threaded end dia.: 6.6 mm (0.26 in.), shank dia.: 8.0 mm (0.31 in.)]. Stand two guide rods diagonally as illustrated.



- (2) Set the lower gasket, insulator, upper gasket and the carburetor on the intake manifold along the guide rods. At this time, note that the lower gasket, insulator and upper gasket are so installed that their respective identification marks may face the directions shown in the illustration.

NOTE

After setting, do not move the carburetor.




- (3) Insert the carburetor attaching bolts to the two vacant screw holes and tighten them finger-tight.
- (4) Remove the guide rods, insert the carburetor attaching bolts in their place and tighten finger-tight.
- (5) Tighten the four carburetor attaching bolts to specified torque.

NOTES

5. CARBURETOR – Types "A" and "B"

DISASSEMBLY AND REASSEMBLY



Disassembly steps

1. Hose (A/T)
2. Hose (A/T)
3. Delay valve (A/T)
4. Special screw
5. Pump lever sub assembly
6. Float bowl
7. Spring
8. Pump plunger
9. Boot
10. Pin
11. Float
12. Needle valve
13. Hook
14. Push pin
15. Spring
16. Gasket
17. Needle valve seat
18. Gasket
19. Adaptor
20. Gasket
21. Fuel cut solenoid valve
22. O-ring
23. Gasket
24. Dash pot (A/T)
25. Wax back spring (outer)
26. Wax back spring (inner)
27. Cold enrichment rod
28. Boot
29. Compensator
30. Fast idle cam
31. Cold enrichment rod
32. Spring
33. Boot
34. Compensator
35. Gasket
36. Plug plate
37. O-ring
38. Pin
39. Suction chamber
40. Suction spring
41. Suction piston
42. Concealment plug (For Australia)
43. Mixture adjusting screw (MAS)
44. Needle
45. Spring
46. Plate
47. Main jet plug
48. Gasket
49. Main jet adjusting screw
50. O-ring
51. Plug plate
52. Pin
53. Gasket
54. Main jet
55. Spring
56. O-ring
57. O-ring
58. Speed adjusting screw (SAS)
59. Dash pot adjusting screw (A/T)
60. Carburetor body sub assembly


1FU0799

SERVICE POINTS OF DISASSEMBLY

The following parts must not be disassembled at the time of disassembly.

- (1) Throttle valve and throttle shaft.
- (2) Painted adjusting screw.
- (3) Carburetor body sub assembly.


When loosening a cross recessed head screw, use a Phillips screwdriver which is an exact fit, as the screw has been tightened securely.

**◊A◊ REMOVAL OF FLOAT BOWL**

- (1) Do not attempt to remove the float bowl at one time as it is held firmly in position by the gasket. Insert a screwdriver blade between the carburetor body and the float bowl as illustrated and lightly pry it up and lift up gently.

NOTE


- (1) Do not apply excessive force.
- (2) The gasket cannot be removed unless the float has been removed. Do not attempt to remove the gasket simultaneously with the float bowl.

**◊B◊ REMOVAL OF ADAPTOR**


- (1) Do not attempt to remove the adaptor at one time as it is held firmly in position by the gasket. Insert a screwdriver blade between the carburetor body and the adaptor as illustrated and lightly pry it up and lift up gently.

NOTE


Do not apply excessive force.

**◊C◊ REMOVAL OF MAX BACK SPRING**

- (1) Hook a metal wire to the wax back spring as illustrated and remove the spring.


**◊D◊ REMOVAL OF FAST IDLE CAM / COLD ENRICHMENT ROD / SPRING / BOOT**

- (1) Remove the snap retainer shown in the illustration.
- (2) Remove the link from the snap retainer.
- (3) Loosen the fast idle cam set bolt to remove the cam from the cold enrichment rod.
- (4) Remove the cold enrichment rod, spring and boot.



◊E◊ REMOVAL OF COMPENSATOR

- (1) The gasket will have adhered in position. Don't apply undue force but remove it prying lightly with a screwdriver as illustrated.




◊F◊ REMOVAL OF PLUG PLATE

- (1) Screw a bolt (thread diameter 4 mm, length 20 mm or more) into the plug plate and remove the plate using pliers and a wrench.

NOTE

Set the wrench across the air cleaner support mounting screw holes as illustrated.




◊G◊ REMOVAL OF SUCTION CHAMBER SUBASSEMBLY

- (1) When removing the suction chamber from the carburetor body, do not pry or apply undue force. It can be easily removed by turning the suction chamber clockwise and counterclockwise.
- (2) Lifting up the metering needle a little with a finger to prevent it from interfering with the main jet, pull out the suction piston squarely.


Caution

- A smooth sliding motion of the suction piston is important for carburetor performance. Do not change the combination of the suction piston and suction chamber. Do not damage the inside surface of the suction piston or suction chamber either.
- Once the metering needle is removed from the suction piston, the needle is likely to come loose. Do not, therefore, remove it from the suction piston.
- The metering needle is easily deformed. Handle carefully after removal.




◊H◊ REMOVAL OF CONCEALMENT PLUG

- (1) Using a chisel, remove the concealment plug.




For EC




❖I❖ REMOVAL OF MIXTURE ADJUSTING SCREW (MAS)

- (1) Using the special tool (MAS Driver), remove the idle limiter cap and the MAS.




❖J❖ REMOVAL OF MAIN JET ADJUSTING SCREW

- (1) Holding the main jet adjusting screw with pliers, turn it counterclockwise to remove it from the main jet plug.



- (2) Using 5 φ pin punch, 21 mm socket wrench and hammer, remove the plug plate from the main jet plug.



❖K❖ REMOVAL OF PIN / GASKET

- (1) Using care not to allow paint fragments to fall into the carburetor, remove the yellow paint from around the pin.
- (2) Remove the pin and gasket while paying attention to the main jet jumping out of place.

NOTE


Gasket may have been adhered to by the yellow paint.

INSPECTION

GENERAL INSPECTION

Check the following and repair or replace parts if faulty.

- (1) Check fuel passages (jets) and air passages (jets or orifices) for clogging. If clogged, wash thoroughly with cleaning solvent or detergent and remove dirt by compressed air. Do not use wire or other metal pieces.
- (2) Check diaphragms, O-rings and springs for damage and cracks.
- (3) Check that needle valve operates lightly. If the valve is hard to operate or is binding, repair or replace. If there is overflow, poor valve to seat contact is suspected. Check thoroughly.
- (4) Check the fuel inlet filter (located above the needle valve) for clogging and damage.
- (5) Check the float operation. Check float and lever for deformation and damage and replace if necessary.
- (6) Check operation of the throttle valve, enrichment rod and link. If they do not operate lightly, wash well and apply engine oil sparingly to their shaft.
- (7) Check the float bowl and carburetor body for damage and cracks.




INSPECTION OF LINEAR BALL BEARING

- (1) Insert the suction piston in the suction chamber and make sure that it moves smoothly.
- (2) If the suction piston does not move smoothly, apply lubricant to the linear ball bearing.

Specified lubricant:

3M 4way part No. 051135-08902 or equivalent.

- (3) If the suction piston still fails to move smoothly after lubrication, replace the suction piston, metering needle, suction chamber and spring as a set.



INSPECTION OF DASH POT (A/T)


- (1) Check the dash pot diaphragm for damage. Apply a negative pressure of 500 mmHg using a hand vacuum pump and check if the pressure is held. Also check that the dash pot rod is pulled up when the negative pressure is applied. If the pressure is not held, the diaphragm is damaged. Replace the dash pot.

SERVICE POINTS OF DISASSEMBLY

Caution


When washing and cleaning the parts, pay attention to the following.

- Do not damage the suction piston, suction chamber surface, carburetor body bore or main jet path by using a brush, etc.
- Do not attempt to wash the compensator. Do not allow dust to enter the bleed path.
- Do not bend or damage the main jet or metering needle.




◆A◆ INSTALLATION OF MAIN JET

- (1) Install two O-rings onto the main jet and install them together with the spring into the carburetor body.
- (2) Pushing the main jet into the carburetor body using a Phillips screwdriver, align the main jet groove with the carburetor body pin hole and fit the pin with the gasket.




- (3) Press the main jet with a Phillips screwdriver to make sure that the main jet slides smoothly.



◆B◆ INSTALLATION OF MAIN JET ADJUSTING SCREW


- (1) Tighten the main jet adjusting screw in the main jet plug with fingers.
- (2) Using a screwdriver, tighten the main jet adjusting screw plug, turning it counterclockwise. Do not damage the threads by overtightening the screw.



- (3) Install the main jet plug into the carburetor body through the gasket.
- (4) Make the initial setting of the main jet adjusting screw by using a slide caliper.


NOTE

Refer to the table in SERVICE SPECIFICATIONS for the set value.



INSTALLATION OF MIXTURE ADJUSTING SCREW


- (1) While using a wire to guide the plate, install the plate with its rubber portion directed toward the innermost side. Then, install the spring, needle and mixture adjusting screw in that order.



- (2) Make the initial setting of the mixture adjusting screw by using a slide caliper.

NOTE

Refer to the table in SERVICE SPECIFICATIONS for the set value.




INSTALLATION OF SUCTION CHAMBER SUB-ASSEMBLY

- (1) Using care not to bend the metering needle, insert the suction piston into the carburetor body. Do not force the piston to turn or push it hard when inserting.


NOTE

If the metering needle tip interferes with the main jet and is hard to insert, lift the needle up a little with your fingers.



◆E◆ INSTALLATION OF PIN / O-RING / PLUG PLATE


- (1) Align the suction piston groove with the carburetor body hole and, using a screwdriver, install the pin so that its protrusion is seated in the piston groove.
- (2) Make sure that the suction piston does not rotate.



- (3) Install the O-ring.
- (4) Tighten a 4 mm thread diameter bolt into the plug plate and strike until the plug plate is flush with the carburetor body surface.


Caution

- Place wood block, etc. under the carburetor to isolate the carburetor link mechanism from the work bench so that the link mechanism will be protected from weight and shock.
- Make sure that O-ring is not caught between the plug plate and the carburetor body.




◆F◆ INSTALLATION OF COMPENSATOR

- (1) Tighten the three screws lightly and then tighten them firmly in the order shown in the figure.




◆G◆ INSTALLATION OF COLD ENRICHMENT ROD

- (1) Install in correct direction.




◆H◆ INSTALLATION OF WAX BACK SPRING

- (1) Hook the wax back spring (inner) to the wax back spring (outer).
- (2) Using a metal wire, fit the wax back spring correctly as illustrated.




INSTALLATION OF FLOAT / PIN

- (1) When assembling these parts, make the float level adjustment.
- (2) For adjustment of the float level, see the following.




ADJUSTMENT OF FLOAT LEVEL

- (1) With the carburetor body turned upside down, remove the hook attached to the needle valve.
- (2) Attach the float and pin.




- (3) Lightly push up the float until it stops and measure the clearance between the needle valve and float lever.

Standard value: 1.0 mm (0.039 in.)



- (4) If the clearance is out of specification, adjust by bending or straightening the stopper indicated in illustration.


	Clearance
When stopper is bent	Greater
When stopper is straightened	Smaller



- (5) With the float at the position, to which it is lowered by its own weight, check for float to carburetor body clearance.

Standard value: 4.3 mm (0.169 in.)

13B-5-10 VARIABLE VENTURI CARB – Carburetor-Types "A" and "B"



- (6) If the clearance is not up to the specified reference value, adjust by bending the portion indicated in illustration.
- (7) Remove the float and attach the hook to the needle valve.
- (8) Install the float, while hooking the float claw to the hook.