


CRUISE CONTROL

Component Index

- Automatic Transmission Mode Switch
- Brake Switch
- Cruise Control Actuator
- Cruise Control Unit
- Dash Fuse Box
- Noise Suppression Filter #1


CRUISE CONTROL

Circuit Schematic




CRUISE CONTROL

Circuit Schematic



CRUISE CONTROL

Circuit Schematic



CRUISE CONTROL

Component Location Index

(Refer to Section 201 for photographs.)

Component

Photo No.

Automatic Transmission

Mode Switch	Underneath vehicle, on left side of transmission	78
Brake Switch	Below I/P, on brake pedal support	44
Cruise Control Actuator	Right rear corner of engine compartment	24
Cruise Control Unit	Behind right kick panel	56
Dash Fuse Box	Behind left I/P side trim panel	36
Noise Suppression Filter #1 ...	Behind left kick panel	40

Connector

B-4 (7-WHT)	Behind left side of I/P, on rear of meter assembly	49
C-37 (4-BLK)	Behind lower left of I/P	44
C-42 (14-BLK)	Behind lower left I/P, right of steering column	47
H-7 (16-BLK)	Lower left front of engine compartment	13
H-9 (16-GRN)	Lower left front of engine compartment	13
H-13 (22-WHT)	Behind left side of I/P, above left kick panel on bracket	42
H-18 (20-WHT)	Behind I/P right side panel	58
H-19 (22-WHT)	Behind I/P right side panel	58
M-25 (8-BLK)	On left side of transmission	77

Ground

C-31	Behind right kick panel	57
------------	-------------------------------	----

CRUISE CONTROL

Circuit Operation

The cruise control system uses mechanical, electrical, and vacuum operated devices to maintain vehicle speed at a setting selected by the driver.

System Description

The cruise control unit receives command signals from the cruise control switch. It receives information about operating conditions from the brake switch, the speedometer, the clutch switch (manual transmission), and the automatic transmission mode switch and powertrain control module (PCM)(automatic transmission).

The cruise control unit sends operational signals to the devices that regulate the throttle position. The throttle position maintains the selected vehicle speed. The control unit compares the actual speed of the vehicle to the selected speed. The control unit then uses the result of that comparison to open or close the throttle.

The brake switch releases the system's control of the throttle at the instant the driver depresses the brake pedal. The switch sends a signal to the cruise control unit when the brake pedal is depressed; the cruise control unit responds by allowing the throttle to close. The clutch switch or the automatic transmission mode switch sends a disengage signal input to the cruise control unit that also allows the throttle to close.

System Operation

The cruise control system will set and automatically maintain any speed above 25 mph (40 km/h). To set, press the cruise control main switch so that the "CRUISE MAIN" indicator is on. After reaching the desired speed, press the set switch. The cruise control unit will receive a set signal input and will activate the cruise control actuator.

Pushing the cruise control main switch cancels the cruise control system. This removes power to the cruise control unit and erases the set speed from memory. The cruise control system also disengages when cruising speed is lower than the preset speed by 12 mph (19 km/h) or more. If the system is disengaged temporarily by the brake switch, clutch switch, or the automatic transmission mode switch and vehicle speed is still above 25 mph (40 km/h), turn and release the resume/accel switch. With the resume/accel switch turned and released, the set memory is retained, the vehicle automatically returns to the previous set speed.

For gradual acceleration without depressing the accelerator pedal, turn the resume/accel switch and hold it there until the desired speed is reached. This will send an acceleration signal input to the cruise control unit. When the switch is released, the system will be reprogrammed for the new speed. Quickly turning and releasing the resume/accel switch allows you to tap up the preset cruising speed. Each turn increases the preset speed by 1 mph (1.6 km/h). The preset speed can be increased by up to 10 mph (16 km/h) in this manner.

To slow the vehicle down, depress and hold the set/coast switch. This will send a deceleration signal input to the cruise control unit, causing the vehicle to coast until the desired speed is reached. When the desired speed is reached, release the set/coast switch. This will reprogram the system for the new speed. Quickly depressing and releasing the set/coast switch allows you to tap down the preset cruising speed. Each depress decreases the preset speed by 1 mph (1.6 km/h). The preset speed can be decreased to a minimum of 25 mph (40 km/h) in this manner.