

POWER MIRRORS

CONTENTS

	page		page
DESCRIPTION AND OPERATION		MIRROR SWITCH	1
HEATED MIRROR	1	REMOVAL AND INSTALLATION	
INTRODUCTION	1	INSIDE MIRROR/READING LAMP ASSEMBLY ..	2
DIAGNOSIS AND TESTING		INSIDE MIRROR/READING LAMP BULB/LENS .	2
HEATED MIRROR	1	MIRROR ASSEMBLY	2
MIRROR MOTOR	1	MIRROR SWITCH	3

DESCRIPTION AND OPERATION

INTRODUCTION

Power mirrors are controlled by a single switch located on the driver's door. The switch has a rocker buttons mark L (left) and R (right) for mirror selection and four buttons for mirror direction movement (Fig. 1).

The motors which operate the mirrors are part of the mirror assembly and cannot be replaced separately.

The vehicle is equipped with an Ignition-Off Draw Fuse which is used when it is originally shipped from the factory. This fuse is located in the junction block and helps to prevent battery discharge during storage when disconnected.

This fuse is included in the power mirror circuitry and should be checked if the mirrors are inoperative.

rear window defogger is on. The mirror should become warm to the touch.

DIAGNOSIS AND TESTING

HEATED MIRROR

(1) Using a ohmmeter, check Pin 1 of the mirror motor harness connector for continuity to ground. If OK, go to Step 2. If not OK, repair as necessary. Refer to Group 8W, Wiring Diagrams.

(2) Activate the rear window defogger switch, use a voltmeter and check Pin 2 for battery voltage.

(a) If OK, go to Step 3. If not OK, check fuse 5 in the Junction Block and repair as necessary.

(b) Check rear window defogger switch, refer to Group 8N, Rear Window Defogger. If OK, go to Step 3. If not OK, replace HVAC control.

(c) If no voltage repair wire as necessary. Refer to Group 8W, Wiring Diagrams.

(3) Remove mirror glass and check wires. If wires are OK, replace mirror glass. If not OK, repair as necessary or replace mirror.

MIRROR MOTOR

(1) Remove door trim panel. Refer to Group 23, Body.

(2) Disconnect wire connector from the switch.

(3) Using two jumper wires, one connected to a 12 volt battery source, and the other connected to a good body ground. Refer to the Mirror Test (Fig. 2) for appropriate mirror response, using the mirror switch wiring harness connector.

(4) If test results are not obtained as shown in the (Fig. 2), check for open or shorted circuit, or replace mirror assembly as necessary.

MIRROR SWITCH

(1) Remove switch from door trim panel.

(2) Disconnect wire connector.





Fig. 1 Power Mirror Switch

HEATED MIRROR

Heated mirrors are available with Power Mirrors and Rear Window Defogger only. The heated mirror is controlled by the rear window defogger switch. Only time that the heated mirror is on is when the

DIAGNOSIS AND TESTING (Continued)

MIRROR SWITCH HARNESS CONNECTOR			
12 Volt	Ground	Mirror Reaction	
		Left	Right
PIN 4	PIN 5		UP
PIN 8	PIN 5	UP	
PIN 5	PIN 4		DOWN
PIN 5	PIN 8	DOWN	
PIN 6	PIN 3		RIGHT
PIN 6	PIN 7	RIGHT	
PIN 3	PIN 6		LEFT
PIN 7	PIN 6	LEFT	




806dc197

Fig. 2 Mirror Motor Test

- (3) Using an ohmmeter, test for continuity between the terminals of the switch as shown in the Mirror Switch Test (Fig. 3).
- (4) If test results are not obtained as shown in the (Fig. 3), replace the switch.

SWITCH POSITION Move Button	CONTINUITY BETWEEN TERMINALS
Mirror in L Position	
▲	PIN 1 to 5 PIN 2 to 8
▶	PIN 1 to 7 PIN 2 to 6
▼	PIN 1 to 8 PIN 2 to 5
◀	PIN 1 to 6 PIN 2 to 7
Mirror in R Position	
▲	PIN 1 to 5 PIN 2 to 4
▶	PIN 1 to 3 PIN 2 to 6
▼	PIN 1 to 4 PIN 2 to 5
◀	PIN 1 to 6 PIN 2 to 3



80a20ea2

Fig. 3 Mirror Switch Test

REMOVAL AND INSTALLATION


INSIDE MIRROR/READING LAMP ASSEMBLY

REMOVAL

- (1) Remove attaching screws from header (Fig. 4).
- (2) Lower mirror, and disconnect the wire harness connector.
- (3) Remove mirror assembly.

INSTALLATION

For installation, reverse the above procedure.



80a24331

Fig. 4 Inside Mirror/Reading Lamps

INSIDE MIRROR/READING LAMP BULB/LENS

REMOVAL

- (1) Using a small thin blade tool, pry at the center of the lens nearest the mirror to remove lens (Fig. 4).
- (2) Remove lamp and replace if necessary.

INSTALLATION

Install lens by setting into position and apply pressure until it is locked into position.

MIRROR ASSEMBLY

REMOVAL

- (1) For door trim panel and mirror removal, refer to Group 23, Body.
- (2) Disconnect mirror.
- (3) Remove attaching nuts.
- (4) Test operation of mirror before installing door trim panel.

INSTALLATION

For installation, reverse the above procedures.

MIRROR SWITCH

REMOVAL

- (1) Place a small flat blade tool into the slot above the L–R selector end of the switch. Pushing against the switch and pulling upward will release the mounting clip located directly below. This will allow the switch to be release from the door trim panel.
- (2) Disconnect wire connector.

INSTALLATION

For installation, reverse the above procedures.