
INTAKE AND EXHAUST

CONTENTS

15109000090

GENERAL INFORMATION	2	INTAKE MANIFOLD	3
SERVICE SPECIFICATION	2	EXHAUST MANIFOLD	6
SPECIAL TOOL	2	EXHAUST PIPE AND MAIN MUFFLER	7
ON-VEHICLE SERVICE	2		
Intake Manifold Vacuum Check	2		

GENERAL INFORMATION

15100010061

The intake manifold is made of an aluminium alloy, and the shape provides an increased intake inertia effect and has a good volumetric efficiency.

The exhaust manifold is made of stainless steel. The exhaust pipe is divided into three parts: the front pipe, the centre pipe, and the main muffler.


SERVICE SPECIFICATION

15100030074

Items	Standard value	Limit
Manifold distortion of the installation surface mm	0.15 or less	0.2

SPECIAL TOOL

15100060066

Tool	Number	Name	Use
	MD998770	Oxygen sensor wrench	Removal/Installation of oxygen sensor

ON-VEHICLE SERVICE

15100180090

INTAKE MANIFOLD VACUUM CHECK

Refer to GROUP 11A – On-vehicle Service.

INTAKE MANIFOLD

15100300182


REMOVAL AND INSTALLATION

Pre-removal Operation

- (1) Fuel Discharge Prevention (Refer to GROUP 13A – On-vehicle Service.)
- (2) Engine Coolant Draining (Refer to GROUP 14 – On-vehicle Service.)
- (3) Battery Removal



Post-installation Operation

- (1) Battery Installation
- (2) Engine Coolant Supplying (Refer to GROUP 14 – On-vehicle Service.)
- (3) Accelerator Cable Adjustment (Refer to GROUP 17 – On-vehicle Service.)



Removal steps

1. Accelerator cable connection
2. Breather hose
3. Air intake hose
4. Injector connector
5. Ignition coil connector
6. Power transistor connector
7. Capacitor connector
8. TPS connector
9. Detonation sensor connector
10. Engine coolant temperature sensor connector
11. ISC connector
12. Camshaft position sensor connector
13. Crankshaft position sensor connector
14. A/C compressor connector
15. Control wiring harness



16. PCV hose connection
 17. Vacuum hose connection
 18. Spark plug cable connection
 19. Fuel return hose connection
 20. Vacuum hose connection
 21. Vacuum pipe
 22. Brake booster vacuum hose connection
 23. Water hose connection
 24. Heater hose connection
 25. High-pressure fuel hose connection
 26. Delivery pipe, injector and pressure regulator

27. Insulator
 28. Insulator
 29. Power transistor
 30. Ignition coil
 31. EGR valve assembly
 32. Intake manifold stay
 33. Engine hanger
 34. Intake manifold
 35. Intake manifold gasket
 36. Throttle body



00004409


REMOVAL SERVICE POINTS

◀A▶ HIGH-PRESSURE FUEL HOSE DISCONNECTION

Relieve pressure in the fuel pipe line to prevent fuel outflow. (Refer to GROUP 13A – On-vehicle Service.)

Caution

Cover the fuel pipe line with shop towel after relieving pressure as certain pressure may still remain.



◀B▶ DELIVERY PIPE, FUEL INJECTOR AND PRESSURE REGULATOR ASSEMBLY REMOVAL

Remove the delivery pipe with the fuel injector and pressure regulator attached.

Caution

Do not drop the injector when removing the delivery pipe

INSTALLATION SERVICE POINT

▶A◀ HIGH-PRESSURE FUEL HOSE CONNECTION

When connecting the high-pressure fuel hose to the delivery pipe, apply a small amount of new engine oil to the hose union, and then insert, being careful not to damage the O-ring.

Caution

Do not let engine oil get into the delivery pipe.

INSPECTION

15100310154

Check the following points; replace the part if a problem is found.

INTAKE MANIFOLD CHECK


1. Check for damage or cracking of any part.
2. Check for obstruction of the negative pressure (vacuum) outlet port, and for obstruction of the water passage or gas passage.
3. Using a straight edge and a thickness gauge, check for distortion of the cylinder head installation surface.

Standard value: 0.15 mm or less

Limit: 0.2 mm

EXHAUST MANIFOLD

15100330211

REMOVAL AND INSTALLATION

A05X0181

Removal steps

1. Front exhaust pipe connection
2. Gasket
3. Heat protector
4. Engine hanger
5. Exhaust manifold
6. Exhaust manifold gasket


EXHAUST PIPE AND MAIN MUFFLER

15100540140

REMOVAL AND INSTALLATION

Pre-removal and Post-Installation Operation

- Under Cover Removal and Installation



A05X0178

Main muffler removal steps

1. Main muffler assembly
2. Gasket
3. Hanger
4. Hanger
5. Rear hanger
6. Rear floor heat protector panel

Centre exhaust pipe removal steps


7. Centre exhaust pipe
8. Gasket
9. Hanger protector
10. Hanger
11. Center hanger

Catalytic converter removal steps

12. Catalytic converter
13. Gasket
14. Catalytic converter bracket
15. Hanger protector
16. Hanger
17. Front hanger
18. Front floor heat protector panel

Front exhaust pipe removal steps

- ◀A▶ ▶A▶
19. Oxygen sensor
 20. Front exhaust pipe
 21. Gasket

**REMOVAL SERVICE POINT****◀A▶ OXYGEN SENSOR REMOVAL****INSTALLATION SERVICE POINT****▶A◀ OXYGEN SENSOR INSTALLATION**