UNDERHOOD MAINTENANCE COMPONENT LOCATIONS—5.4L ENGINE

1. Windshield washer solvent reservoir
2. Battery
3. Automtic transmission dipstick
4. PCV valve
5. Spark plugs and ignition coils (4 on each side)
6. Drive belt
7. Engine oil fill cap
8. Power steering pump reservoir
9. Brake master cylinder reservoir
10. Engine compartment fusebox
11. Air cleaner assembly
12. Coolant recovery tank