UNDERHOOD MAINTENANCE COMPONENT LOCATIONS—5.8/7.5L ENGINE

1. Battery
2. Spark plugs and plug wires (4 on each side)
3. PCV valve
4. Distributor cap & rotor
5. Drive belt
6. Engine oil fill cap
7. Engine oil dipstick
8. Clutch master cylinder
9. Brake master cylinder
10. Engine compartment fusebox
11. Air cleaner assembly
12. Coolant recovery tank