1997-00 SCHEDULED MAINTENANCE INTERVALS
(FORD F-150, LIGHT-DUTY F-250, EXPEDITION & NAVIGATOR)

FREQUENT OPERATION MAINTENANCE (SEVERE SERVICE)—continued

Engine oil & filter - replace every 3,000 miles.
Tires - rotate and inspect every 6,000 miles.
Clutch reservoir fluid level - inspect every 6,000 miles.
Automatic transmission shift linkage - lubricate every 6,000 miles.
Steering linkage, suspension, U-joints - lubricate every 6,000 miles.
Exhaust system - inspect for leaks or damage every 6,000 miles.
Fuel filter - replace every 15,000 miles.
Automatic transmission fluid - change every 21,000 miles.
Crankcase emission air filter - replace every 60,000 miles.
PCV valve - replace every 60,000 miles.
Accessory drive belt - inspect every 60,000 miles.
Spark plugs - replace every 99,000 miles.

1997-00 SCHEDULED MAINTENANCE INTERVALS
(HEAVY-DUTY F-250, F-350, AND SUPER-DUTY)

TO BE SERVICED	TYPE OF SERVICE	VEHICLE MILEAGE INTERVAL (x1000)																			
		5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100
Accessory drive belt	S/I																				✓
Air cleaner filter ①②	R						✓						✓						✓		
Automatic transmission fluid ③	R						✓						✓						✓		
Engine coolant ④⑤	R										✓						✓				
Engine cooling system hoses, clamps & coolant ⑥	S/I			✓			✓			✓			✓			✓			✓		
Engine oil & filter	R	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Exhaust system	S/I			✓			✓			✓			✓			✓			✓		
Front wheel bearings	S/I & L																		✓		
Front/rear axle lubricant ⑦	R																				✓
Fuel filter ⑧	R						✓						✓						✓		
PCV valve	R	Every 120,000 miles																			
Rotate tires	S/I	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Spark plugs	R																				✓
Steering linkage, suspension, driveshaft U-joints	S/I & L	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

①Perform this at the mileage shown or every 30 months, whichever occurs first.
②7.3L DIT Diesel engine: the air filter should be replaced when the restriction gauge is in the red zone.
③Except the E40D transmission.
④Drain, flush and refill the cooling system initially at 50,000 miles or 48 months, whichever occurs first, then every 30,000 miles or 30 months thereafter.
⑤7.3L DIT Diesel engine: add 4 pints of FW-15 each time the coolant is replaced.
⑥7.3L DIT Diesel engine: add 8-10 oz. of FW-15 to the engine coolant every 15,000 miles.
⑦The axle lubricant must be replaced every 100,000 miles or if the axle has been submerged under water. Otherwise the lube should not be checked or changed unless a repair is required.
⑧7.3L DIT Diesel engine: the fuel filter should be replaced when the restriction lamp is illuminated.

R - Replace S/I - Inspect and service, if needed L - Lubricate A - Adjust C - Clean