Rear Wheel Anti-Lock Brake System (RABS)

Diagnostic Trouble Codes

Diagnostic Trouble Code (DTC) 2 — Open RABS II Isolation Solenoid Circuit

Diagnostic Trouble Code (DTC) 3 — Open RABS II Dump Solenoid Circuit

Diagnostic Trouble Code (DTC) 4 — Open/Grounded RABS Valve Reset Circuit

Diagnostic Trouble Code (DTC) 5 — Excessive Dump Solenoid Activity

Diagnostic Trouble Code (DTC) 6 — Erratic Rear Anti-Lock Brake Sensor Circuit

Diagnostic Trouble Code (DTC) 7 — No Isolation Solenoid During Self-Check

Diagnostic Trouble Code (DTC) 8 — No Dump Solenoid During Self-Check

Diagnostic Trouble Code (DTC) 9 — High Speed Sensor Resistance

Diagnostic Trouble Code (DTC) 10 — Low Speed Sensor Resistance

Diagnostic Trouble Code (DTC) 11 — Brake Pedal Position (BPP) Switch Always Closed

Diagnostic Trouble Code (DTC) 12 — Loss Of Hydraulic Brake Fluid During An Anti-Lock Stop

Diagnostic Trouble Code (DTC) 13 — RABS II Module Failure

Diagnostic Trouble Codes (DTC) 16 — RABS System OK