Automatic Transmission - 6L80 (MYC) or 6L90 (MYD) - Component Locator - Sierra, Silverado

COMPONENT LOCATOR

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

DISASSEMBLED VIEWS

Case and Associated Parts




Fig. 1: Transmission Components
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name

cardiagn.com

Callout	Component Name
1	Torque Converter Assembly
2	Torque Converter (with Fluid Pump) Housing Assembly - Model Dependent
3	Bolt, M10 x 50 mm
4	Torque Converter Housing Access Hole Cover - Model Dependent
5	A/Trans Fluid Pump Seal
6	Torque Converter Housing Locator Pin
7	A/Trans Case Assembly
9	A/Trans Connector Seal
10	A/Trans Connector (O-ring) Seal
11	A/Trans Electrical Connector Passage Sleeve
12	A/Trans Case Plug
13	Output Shaft Bushing
14	Output Shaft Seal Assembly - 4WD Models
16	Bolt, M10 x 40 mm - Model Dependent
18	A/Trans Fluid Pump Seal Assembly
19	A/Trans Fluid Pump Seal Assembly
20	Center Support Fluid Passage Seal Assembly
21	Control (with Body and Valve) Valve Assembly
22	Bolt, M5 x 73 mm
23	Bolt, M6 x 14.5 mm
24	Manual Shaft Detent Assembly
25	A/Trans Fluid Filter Seal Assembly
26	A/Trans Fluid Filter Assembly
27	A/Trans Fluid Pan Gasket
28	A/Trans Fluid Pan Magnet
29	A/Trans Fluid Pan Assembly
30	Bolt, M6 x 20 mm
32	Torque Converter Housing Access Hole Cover
33	A/Trans Case Extension Seal - 2WD Models
34	A/Trans Case Extension - 2WD Models
35	Prop Shaft Front Slip Yoke Bushing - 2WD Models
36	Prop Shaft Front Slip Yoke Oil Seal - 2WD Models

Clutch Assemblies and Associated Parts

cardiagn.com




Fig. 2: Clutch Assemblies and Associated Parts
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
51	1-2-3-4 and 3-5 Reverse Clutch Assembly
52	Input Carrier Assembly
53	Input Sun Gear
54	Input Sun Gear Thrust Bearing
55	Input Sun Gear Thrust Washer
56	4-5-6 (w/ Turbine Shaft) Clutch Assembly
57	Turbine Shaft Thrust Bearing Assembly
58	4-5-6 Clutch (w/ Output Carrier Shaft and Dampener) Hub Assembly
59	4-5-6 Clutch Hub Thrust Bearing Assembly
60	Output Carrier Inner Sun Gear Shaft (Front) Bushing
61	1-2-3-4 Clutch (w/ Output Carrier Inner Sun Gear Shaft) Hub Assembly
62	Output Carrier Inner Sun Gear Shaft Bushing
63	1-2-3-4 Clutch Hub Thrust Bearing Assembly
64	2-6 and 3-5 Reverse Clutch (w/ Output Carrier Outer Sun Gear Shaft) Hub Assembly

cardiagn.com

Callout	Component Name
65	2-6 and 3-5 Reverse Clutch Hub Thrust Bearing Assembly
66	Center Support Retaining Ring
67	Center (w/ 2-6 Low and Reverse Clutch) Support Assembly
68	Output Carrier Assembly
69	Output Carrier Thrust Bearing Assembly
70	Output Shaft Assembly - Model Dependent
71	Output Shaft Thrust Bearing Assembly
72	Propeller Shaft Oil Seal Sleeve - 2WD Models Only

Torque Converter (w/Fluid Pump) Housing Assembly




Fig. 3: Torque Converter (w/Fluid Pump) Housing Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
200	Torque Converter Fluid Seal Retaining Ring
201	Torque Converter Fluid Seal Assembly
202	Line Pressure Test Hole Plug
203	Torque Converter Housing - Model Dependent
204	A/Trans Vent Pipe
205	Trans Fluid Cooler Pipe Fitting Seal
206	Torque Converter Bushing
207	A/Trans Fluid Pump Vane Ring
208	A/Trans Fluid Pump Rotor Guide
209	A/Trans Fluid Pump Slide Fluid Seal Ring

cardiagn.com

Callout	Component Name
210	A/Trans Fluid Pump Slide (O-ring) Seal
211	A/Trans Fluid Pump Slide Outer Spring
212	A/Trans Fluid Pump Slide
213	A/Trans Fluid Pump Slide Seal
214	A/Trans Fluid Pump Slide Seal Support
215	A/Trans Fluid Pump Slide Pivot Pin
216	A/Trans Fluid Pump Vane
217	A/Trans Fluid Pump Rotor
218	Turbine Shaft Front Bushing
219	A/Trans Fluid Pump Cover Assembly
220	Converter Feed Limit Valve
221	Converter Feed Limit Valve Spring
222	Valve Spring Retainer
223	Pressure Relief Ball Valve Spring Pin
224	Pressure Relief Ball Valve Spring
225	Pressure Relief Ball Valve
226	TCC Control Valve Spring
227	TCC Control Valve
228	Turbine Shaft Rear Bushing
229	1-2-3-4 and 3-5 Reverse Clutch Housing Thrust Washer
230	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
231	Bolt, M6 x 40 mm
232	A/Trans Fluid Pump Locator Pin
233	Pressure Regulator Valve
234	Pressure Regulator Valve Outer Spring
235	Pressure Regulator Valve Inner Spring
236	Isolator Valve
237	Isolator Valve Sleeve
238	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring - Inner O-Ring (Qty: 3) - Model Dependent

Control (with Body and Valve) Valve Assembly

cardiagn.com




Fig. 4: Control (with Body and Valve) Valve Assembly Component Views
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
301	Bolt, M5 x 36 mm
302	Bolt, M6 x 20 mm
303	A/Trans Input and Output Speed Sensor Assembly - Model Dependent
304	Control Valve Upper Body Assembly
305	Control Valve Body Spacer (w/ Gasket) Plate Assembly
306	Control Valve Body Ball Check Valve
307	Control Valve Lower Body Assembly
308	A/Trans Manual Shift Shaft Position Switch Assembly
309	Bolt, M5 x 45 mm
310	Bolt, M5 x 55 mm
311	Filter Plate Assembly
312	Bolt, M5 x 53 mm
314	Control Solenoid (w/ Body and TCM) Valve Assembly
315	A/Trans Manual Shaft Position Switch Wiring Harness Clip
316	A/Trans Input and Output Speed Sensor Wiring Harness Clip - Model Dependent

cardiagn.com

Upper Control Valve Body Assembly




Fig. 5: View Of Upper Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
313	Control Valve Body Locator Pin
321	Control Valve Upper Body
322	Control Valve Body Locator Pin
323	Retainer
324	Actuator Feed Limit Valve Spring
325	Actuator Feed Limit Valve
326	Clutch Regulator Valve Spring
327	CBR1/4-5-6 Clutch Regulator Valve
328	Clutch Regulator Valve Bore Plug
329	Clutch Boost Valve
330	Clutch Boost Valve Spring
334	2-6 Clutch Regulator Valve
335	2-6 Clutch Regulator Valve Gain Valve
336	3-5 Reverse Clutch Regulator Valve
337	1-2-3-4 Clutch Regulator Valve
338	Shuttle Valve

Lower Control Valve Body Assembly

cardiagn.com




Fig. 6: View Of Lower Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
323	Retainer
328	Clutch Regulator Valve Bore Plug
338	Shuttle Valve
351	Control Valve Lower Body
352	Clutch Select Solenoid Valve 3
353	TCC Regulator Apply Valve Spring
354	Manual Valve
355	TCC Regulator Apply Valve
356	Clutch Piston Dam Feed Regulator Valve
357	Clutch Piston Dam Feed Regulator Valve Spring
358	Clutch Select Solenoid Valve Spring
359	Clutch Select Solenoid Valve 2

1-2-3-4 and 3-5 Reverse Clutch Assembly

cardiagn.com




Fig. 7: 1-2-3-4 and 3-5 Reverse Clutch Assembly Component Views
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
400	3-5 Reverse Clutch Backing Plate Retaining Ring
401	3-5 Reverse Clutch Backing Plate
402	3-5 Reverse Clutch Plate Assembly
403	3-5 Reverse Clutch Plate
404	3-5 Reverse Clutch (Waved) Plate
405	3-5 Reverse Clutch Apply Ring
407	1-2-3-4 Clutch Backing Plate
408	1-2-3-4 Clutch Plate Assembly
409	1-2-3-4 Clutch Plate
410	1-2-3-4 Clutch (Waved) Plate
411	1-2-3-4 Clutch Piston Dam Retaining Ring
412	1-2-3-4 Clutch Piston Dam Assembly
413	1-2-3-4 Clutch Spring
414	1-2-3-4 Clutch Piston
415	1-2-3-4 Clutch Piston Housing Retaining Ring

cardiagn.com

Callout	Component Name
416	1-2-3-4 Clutch Piston Seal
417	1-2-3-4 Clutch Piston Housing
418	3-5 Reverse Clutch Piston Dam (O-ring) Seal
419	3-5 Reverse Clutch Piston Inner Seal
420	3-5 Reverse Clutch Spring
421	3-5 Reverse Clutch Piston
422	3-5 Reverse Clutch Piston Outer Seal
423	1-2-3-4 Clutch Piston Inner Seal
424	1-2-3-4 Clutch Piston Housing Seal
425	1-2-3-4 Clutch Piston Housing Seal
426	1-2-3-4 and 3-5 Reverse Clutch Housing Rear Bushing
427	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly
428	1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly
429	1-2-3-4 Clutch Backing Plate Retaining Ring

4-5-6 (w/Turbine Shaft) Clutch Assembly




Fig. 8: 4-5-6 (w/Turbine Shaft) Clutch Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
431	4-5-6 Clutch Backing Plate Retaining Ring
432	4-5-6 Clutch Backing Plate
433	4-5-6 Clutch Plate Assembly
434	4-5-6 Clutch Plate

cardiagn.com

Callout	Component Name
435	4-5-6 Clutch (Waved) Plate
436	4-5-6 Clutch Piston Dam Retaining Ring
437	4-5-6 Clutch Piston Dam Assembly
438	4-5-6 Clutch Spring
439	4-5-6 Clutch Piston Assembly
440	Output Carrier Shaft Housing Bushing
441	4-5-6 (w/Turbine Shaft) Housing Assembly
442	Turbine Shaft Fluid Seal Ring
443	Turbine Shaft (O-ring) Seal

2-6 Clutch Assembly




Fig. 9: 2-6 Clutch Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
450	2-6 Clutch Backing Plate Retaining Ring
451	2-6 Clutch Backing Plate
452	2-6 Clutch Plate Assembly
453	2-6 Clutch Plate
454	2-6 Clutch (Waved) Plate
455	2-6 Clutch Spring Retaining Ring
456	2-6 Clutch Spring
457	2-6 Clutch Piston Assembly
458	Output Carrier Outer Sun Gear Shaft (Front) Bushing

cardiagn.com

Callout	Component Name
459	Center Support Assembly
460	Output Carrier Outer Sun Gear Shaft Rear Bushing

Low and Reverse Clutch Assembly




Fig. 10: Low and Reverse Clutch Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
459	Center Support Assembly
461	Low and Reverse Clutch Backing Plate Retaining Ring
462	Low and Reverse Clutch Backing Plate
463	Low and Reverse Clutch Plate Assembly
464	Low and Reverse Clutch Plate
465	Low and Reverse Clutch (Waved) Plate
466	Low and Reverse Clutch Spring Retaining Ring
467	Low Clutch Sprag Assembly
468	Low Clutch Sprag Seal
469	Low and Reverse Clutch Spring

cardiagn.com

Callout	Component Name
470	Low and Reverse Clutch Piston Assembly

4-5-6 Clutch Hub Assembly




Fig. 11: 4-5-6 Clutch Hub Assembly Component Views
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
475	4-5-6 Clutch (w/ Output Carrier Shaft) Hub Assembly
476	4-5-6 Clutch Dampener
477	4-5-6 Clutch Dampener Apply Plate
478	4-5-6 Clutch Dampener Retaining Ring

Output Carrier Assembly

cardiagn.com




Fig. 12: Output Carrier Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
485	Center Support Roller Bearing Assembly
486	Output Carrier Front Sun Gear Thrust Bearing Assembly
487	Output Carrier Front Sun Gear
488	Output Carrier Front Sun Gear Rear Thrust Bearing Assembly
489	Output Carrier Rear Sun Gear
490	Output Carrier
491	Output Carrier Rear Sun Gear Thrust Bearing Assembly - Captured

Output Shaft Assembly

cardiagn.com




Fig. 13: Output Shaft Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
493	Output Internal Gear Assembly - Model Dependent
494	Output Carrier Internal Gear Retaining Ring
495	Output Carrier Internal Front Gear
496	Output Carrier Internal Gear Spacer
497	Output Carrier Internal Rear Gear
498	Output Carrier Bushing
499	Output Shaft Assembly - Model Dependent

Park System Components

cardiagn.com




Fig. 14: Park System Components
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
12	A/Trans Case Plug
500	Park Pawl Shaft
501	Park Pawl Spring
502	Park Pawl
503	Park Pawl Actuator Assembly
504	Manual Shaft Detent Lever Hub Pin
505	Manual Shaft Detent Lever Assembly
506	Manual Shift Shaft Pin
507	Manual Shift Shaft Seal
508	Manual Shift Shaft
509	Park Pawl Actuator Guide
510	Park Pawl Actuator Guide (O-ring) Seal
511	Park Pawl Actuator Guide Pin

COMPONENT LOCATION (6L80/6L90)

cardiagn.com




Fig. 15: Component Locations (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Torque Converter Assembly
2	Torque Converter (with Fluid Pump) Housing Assembly
21	Control (with Body and Valve) Valve Assembly
51	1-2-3-4 and 3-5 Reverse Clutch Assembly
52	Input Carrier Assembly
53	Input Sun Gear
56	4-5-6 (w/Turbine Shaft) Clutch Assembly
58	4-5-6 Clutch (w/Output Carrier Shaft and Dampener) Hub Assembly
61	1-2-3-4 Clutch (w/Output Carrier Inner Sun Gear Shaft) Hub Assembly
64	2-6 and 3-5 Reverse Clutch (w/Output Carrier Outer Sun Gear Shaft) Hub Assembly
67	Center (w/2-6 Low and Reverse Clutch) Support Assembly
68	Output Carrier Assembly
70	Output Shaft Assembly
303	A/Trans Input and Output Speed Sensor Assembly
402	3-5 Reverse Clutch Plate Assembly
408	1-2-3-4 Clutch Plate Assembly
452	2-6 Clutch Plate Assembly
463	Low and Reverse Clutch Plate Assembly
467	Low Clutch Sprag Assembly

cardiagn.com

Callout	Component Name
487	Output Carrier Front Sun Gear
489	Output Carrier Rear Sun Gear
495	Output Carrier Internal Front Gear
497	Output Carrier Internal Rear Gear
502	Park Pawl
503	Park Pawl Actuator Assembly
505	Manual Shaft Detent Lever Assembly
508	Manual Shift Shaft

BUSHING, BEARING, AND WASHER LOCATIONS

Bushing, Bearing, and Washer




Fig. 16: Transmission Bushing, Bearing And Washer Locations
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
13	Output Shaft Bushing
35	Prop Shaft Front Slip Yoke Bushing

cardiagn.com

Callout	Component Name
54	Input Sun Gear Thrust Bearing
55	Input Sun Gear Thrust Washer
57	Turbine Shaft Thrust Bearing Assembly
59	4-5-6 Clutch Hub Thrust Bearing Assembly
60	Output Carrier Inner Sun Gear Shaft (Front) Bushing
62	Output Carrier Inner Sun Gear Shaft Bushing
63	1-2-3-4 Clutch Hub Thrust Bearing Assembly
65	2-6 and 3-5 Reverse Clutch Hub Thrust Bearing Assembly
69	Output Carrier Thrust Bearing Assembly
71	Output Shaft Thrust Bearing Assembly
206	Torque Converter Bushing
218	Turbine Shaft Front Bushing
228	Turbine Shaft Rear Bushing
229	1-2-3-4 and 3-5 Reverse Clutch Housing Thrust Washer
426	1-2-3-4 and 3-5 Reverse Clutch Housing Rear Bushing
428	1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly
440	Output Carrier Shaft Housing Bushing
458	Output Carrier Outer Sun Gear Shaft (Front) Bushing
460	Output Carrier Outer Sun Gear Shaft Rear Bushing
485	Center Support Roller Bearing Assembly
486	Output Carrier Front Sun Gear Thrust Bearing Assembly
488	Output Carrier Front Sun Gear Rear Thrust Bearing Assembly
491	Output Carrier Rear Sun Gear Thrust Bearing - Captured
498	Output Carrier Bushing

SEAL LOCATIONS

Seals

cardiagn.com




Fig. 17: Seal Locations
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
5	A/Trans Fluid Pump Seal
9	A/Trans Connector Seal
10	A/Trans Connector (O-ring) Seal
14	Output Shaft Seal Assembly - 4WD Models
18	A/Trans Fluid Pump Seal Assembly
19	A/Trans Fluid Pump Seal Assembly
20	Center Support Fluid Passage Seal Assembly
25	A/Trans Fluid Filter Seal Assembly
27	A/Trans Fluid Pan Gasket
33	A/Trans Case Extension Seal - 2WD Models
36	Prop Shaft Front Slip Yoke Oil Seal - 2WD Models
201	Torque Converter Fluid Seal Assembly
209	A/Trans Fluid Pump Slide Fluid Seal Ring
210	A/Trans Fluid Pump Slide (O-ring) Seal
213	A/Trans Fluid Pump Slide Seal

cardiagn.com

Callout	Component Name
230	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
238	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Rings - Inner O-rings
412	1-2-3-4 Clutch Piston Dam Assembly
416	1-2-3-4 Clutch Piston Seal
418	3-5 Reverse Clutch Piston Dam (O-ring) Seal
419	3-5 Reverse Clutch Piston Inner Seal
422	3-5 Reverse Clutch Piston Outer Seal
423	1-2-3-4 Clutch Piston Inner Seal
424	1-2-3-4 Clutch Piston Housing Seal
425	1-2-3-4 Clutch Piston Housing Seal
437	4-5-6 Clutch Piston Dam Assembly
439	4-5-6 Clutch Piston Assembly
442	Turbine Shaft Fluid Seal Ring
443	Turbine Shaft (O-ring) Seal
457	2-6 Clutch Piston Assembly
468	Low Clutch Sprag Seal
470	Low and Reverse Clutch Piston Assembly
507	Manual Shift Shaft Seal
510	Park Pawl Actuator Guide (O-ring) Seal

BALL CHECK VALVE LOCATIONS




Fig. 18: Ball Check Valve Locations
Courtesy of GENERAL MOTORS COMPANY

cardiagn.com

I.D.	Input Oil	Input Oil	Output Oil
1	Drive 1-6	DRV B	CB26/C1234 FD
2	Sol 1	Reverse (Park)	CSV2 Enable
3	Sol 2	C456	CSV3 Enable
4	PS4	C456	CSV2 Latch
5	Drive 1-6	C35R Rev FD	C35R Supply
6	CB26/C1234 FD	-	C1234 FD
7	C35R Supply	-	C35R FD
8	CBR1/CBR FD	-	CBR 1

Article GUID: A00854653

cardiagn.com

Automatic Transmission - 6L80 (MYC) or 6L90 (MYD) - Description and Operation - Sierra, Silverado

DESCRIPTION AND OPERATION

DEFINITIONS AND ABBREVIATIONS

Throttle Positions

Engine Braking

A condition where the engine is used to slow the vehicle by manually downshifting during a zero throttle coastdown.

Full Throttle Detent Downshift

A quick apply of the accelerator pedal to its full travel, forcing a downshift.

Heavy Throttle

Approximately 3/4 of accelerator pedal travel, 75 percent throttle position.

Light Throttle

Approximately 1/4 of accelerator pedal travel, 25 percent throttle position.

Medium Throttle

Approximately 1/2 of accelerator pedal travel, 50 percent throttle position.

Minimum Throttle

The least amount of throttle opening required for an upshift.

Wide Open Throttle (WOT)

Full travel of the accelerator pedal, 100 percent throttle position.

Zero Throttle Coastdown

A full release of the accelerator pedal while the vehicle is in motion and in drive range.

Shift Condition Definitions

Bump

A sudden and forceful apply of a clutch or a band.

Chuggle

A bucking or jerking. This condition may be most noticeable when the converter clutch is engaged. It is similar to the feel of towing a trailer.

cardiagn.com

Delayed

A condition where a shift is expected but does not occur for a period of time. This could be described as a clutch or band engagement that does not occur as quickly as expected during a part throttle or wide open throttle apply of the accelerator, or during manual downshifting to a lower range. This term is also defined as LATE or EXTENDED.

Double Bump - Double Feel

Two sudden and forceful applies of a clutch or a band.

Early

A condition where the shift occurs before the car has reached proper speed. This condition tends to labor the engine after the upshift.

End Bump

A firmer feel at the end of a shift than at the start of the shift. This is also defined as END FEEL or SLIP BUMP.

Firm

A noticeably quick apply of a clutch or band that is considered normal with a medium to heavy throttle. This apply should not be confused with HARSH or ROUGH.

Flare

A quick increase in engine RPM along with a momentary loss of torque. This most generally occurs during a shift. This condition is also defined as SLIPPING.

Harsh - Rough

A more noticeable apply of a clutch or band than FIRM. This condition is considered undesirable at any throttle position.

Hunting

A repeating quick series of upshifts and downshifts that causes a noticeable change in engine RPM, such as a 4-3-4 shift pattern. This condition is also defined as BUSYNESS.

Initial Feel

A distinctly firmer feel at the start of a shift than at the finish of the shift.

Late

A shift that occurs when the engine RPM is higher than normal for a given amount of throttle.

Shudder

A repeating jerking condition similar to CHUGGLE but more severe and rapid. This condition may be most noticeable during certain ranges of vehicle speed.

cardiagn.com

Slipping

A noticeable increase in engine RPM without a vehicle speed increase. A slip usually occurs during or after initial clutch or band apply.

Soft

A slow, almost unnoticeable clutch or band apply with very little shift feel.

Surge

A repeating engine related condition of acceleration and deceleration that is less intense than CHUGGLE.

Tie-Up

A condition where two opposing clutch and/or bands are attempting to apply at the same time causing the engine to labor with a noticeable loss of engine RPM.

Noise Conditions

Drive Link Noise

A whine or growl that increases or fades with vehicle speed, and is most noticeable under a light throttle acceleration. It may also be noticeable in PARK or NEUTRAL operating ranges with the vehicle stationary.

Final Drive Noise

A hum related to vehicle speed which is most noticeable under a light throttle acceleration.

Planetary Gear Noise

A whine related to vehicle speed, which is most noticeable in FIRST gear, SECOND gear, FOURTH gear or REVERSE. The condition may become less noticeable, or go away, after an upshift.

Pump Noise

A high pitched whine that increases in intensity with engine RPM. This condition may also be noticeable in all operating ranges with the vehicle stationary or moving.

Torque Converter Noise

A whine usually noticed when a vehicle is stopped, and the transmission is in DRIVE or REVERSE. The noise will increase with engine RPM.

Driver Shift Control

Driver shift control (DSC) allows the driver to change gears similar to a manual transmission.

Transmission Abbreviations

A/C

Air Conditioning

cardiagn.com

AC

Alternating Current

AT

Automatic Transmission

CCDIC

Climate Control Driver Information Center

DC

Direct Current

DIC

Driver Information Center

DLC

Data Link Connector

DMM

Digital Multimeter

DSC:

Driver Shift Control

DTC

Diagnostic Trouble Code

EBTCM

Electronic Brake/Traction Control Module

ECCC

Electronically-Controlled Capacity Clutch

ECT

Engine Coolant Temperature

EMI

Electromagnetic Interference

IAT

Intake Air Temperature

cardiagn.com

IGN

Ignition

IMS

Internal Mode Switch

ISS

Input Speed Sensor

MAP

Manifold Absolute Pressure

MIL

Malfunction Indicator Lamp

NC

Normally Closed

NO

Normally Open

OBD

On Board Diagnostic

OSS

Output Speed Sensor

PC

Pressure Control

PCM

Powertrain Control Module

PCS

Pressure Control Solenoid

PS

Pressure Switch

PWM

Pulse Width Modulation

cardiagn.com

RPM

Revolutions Per Minute

SS

Shift Solenoid

STL

Service Transmission Lamp

TAP

Transmission Adaptive Pressure

TCC

Torque Converter Clutch

TFP

Transmission Fluid Pressure

TFT

Transmission Fluid Temperature

TP

Throttle Position

VSS

Vehicle Speed Sensor

WOT

Wide Open Throttle

TRANSMISSION IDENTIFICATION INFORMATION

Identification Label

cardiagn.com




Fig. 1: Transmission Identification Label
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Model Year
2	Model Code
3	Transmission Family
4	Transmission Assembly Number
5	Julian date
6	Sequential Serial Number
7	Source Code
8	Broadcast Code
9	Bar Code
10	Transmission I.D.
11	Calender Year
12	Machine Readable Matrix
13	Production Shift

TRANSMISSION GENERAL DESCRIPTION

The Hydra-matic 6-Speed RWD is a fully automatic, 6-speed, rear-wheel drive, electronic-controlled transmission. It consists primarily of a 4-element torque converter, an integral fluid pump and converter housing, a single and double planetary gear set, friction and mechanical clutch assemblies, and a hydraulic pressurization and control system. There are four variants of the transmission, all based on torque capacity. Architecture is common between the variants, and component differences are primarily related to size.

The 4-element torque converter contains a pump, a turbine, a pressure plate splined to the turbine, and a stator

cardiagn.com

assembly. The torque converter acts as a fluid coupling to smoothly transmit power from the engine to the transmission. It also hydraulically provides additional torque multiplication when required. The pressure plate, when applied, provides a mechanical direct drive coupling of the engine to the transmission.

The planetary gear sets provide the 6 forward gear ratios and reverse. Changing gear ratios is fully automatic and is accomplished through the use of a transmission control module (TCM) located inside the transmission. The TCM receives and monitors various electronic sensor inputs and uses this information to shift the transmission at the optimum time.

The TCM commands shift solenoids and variable bleed pressure control solenoids to control shift timing and feel. The TCM also controls the apply and release of the torque converter clutch which allows the engine to deliver the maximum fuel efficiency without sacrificing vehicle performance. All the solenoids, including the TCM, are packaged into a self-contained control solenoid valve assembly.

The hydraulic system primarily consists of a vane-type pump, 2 control valve body assemblies, converter housing and case. The pump maintains the working pressures needed to stroke the clutch pistons that apply or release the friction components. These friction components, when applied or released, support the automatic shifting qualities of the transmission.

The friction components used in this transmission consist of 5 multiple disc clutches. The multiple disc clutches combine with one mechanical sprag clutch to deliver 7 different gear ratios, 6 forward and one reverse, through the gear sets. The gear sets then transfer torque through the output shaft.

The transmission may be operated in any of the following gear ranges:

PARK (P)

This position locks the rear wheels and prevents the vehicle from rolling either forward or backward. PARK is the best position to use when starting the vehicle. Because the transmission utilizes a shift lock control system, it is necessary to fully depress the brake pedal before shifting out of PARK. For safety reasons, use the parking brake in addition to the PARK position.

REVERSE (R)

This position allows the vehicle to be operated in a rearward direction.

NEUTRAL (N)

This position allows the engine to be started and operated while driving the vehicle. If necessary, you may select this position in order to restart the engine with the vehicle moving. This position should also be used when towing the vehicle.

DRIVE (D)

Drive range should be used for all normal driving conditions for maximum efficiency and fuel economy. Drive range allows the transmission to operate in each of the 6 forward gear ratios. Downshifts to a lower gear, or higher gear ratio, are available for safe passing by depressing the accelerator or by manually selecting a lower gear in the manual mode range.

MANUAL MODE (M)

This position allows the driver to select a range of gears appropriate for current driving conditions. Refer to the vehicle owner's manual for specific manual mode information.

cardiagn.com

TRANSMISSION COMPONENT AND SYSTEM DESCRIPTION

The mechanical components of the 6-Speed RWD are as follows:

- A torque converter with an electronically controlled capacity clutch (ECCC). ECCC was developed to reduce the possibility of noise, vibration, or chuggle caused by TCC apply. In a torque converter with ECCC, the pressure plate does not always fully lock to the torque converter cover. Instead, the pressure plate maintains a small amount of slippage. In RWD 6-Speed transmissions, this slippage can range from 0-50 RPM. Full lockup (0 RPM slip) is still available on some applications. TCC may apply in 2nd, 3rd, 4th, 5th, or 6th gears. The specific TCC apply points and the amount of clutch slippage are determined by a number of operating conditions, including throttle position, vehicle speed, gear, as well as specific vehicle application. Transmission fluid temperature will also affect TCC apply points.
- Vane-type fluid pump assembly
- 1-2-3-4 and 3-5 Reverse clutch assembly
- Input sun gear and carrier assembly
- 4-5-6 clutch assembly with turbine shaft
- 4-5-6 clutch hub assembly
- 1-2-3-4 clutch hub assembly
- 2-6 and 3-5 reverse clutch hub assembly
- Center support assembly, with 2-6 clutch assembly, and low and Reverse clutch assembly
- Low clutch sprag assembly
- A double planetary output carrier assembly
- Output shaft assembly
- Control valve body assembly

The electrical components of the 6-Speed RWD are as follows:

- Input and output speed sensor assembly
- Manual shift shaft position switch
- Control solenoid valve assembly, which contains the following components:
  - Transmission control module (TCM)
  - 5 variable bleed line pressure control (PC) solenoids
  - Transmission fluid pressure (TFP) switch assembly
  - Torque converter clutch (TCC) pressure control solenoid
  - 2 shift solenoids

For more information, refer to **Electronic Component Description**.

SHIFT STABILIZATION DESCRIPTION AND OPERATION

Shift stabilization is a function within the vehicle's software/calibration that determines if and when to prevent upshifts under load. The purpose of shift stabilization is to reduce shift busyness during conditions that would otherwise produce frequent upshifts and downshifts, such as trailering, operating on grades or at higher altitudes.

Shift stabilization calculates the required torque at the wheels in the current gear as well as the maximum torque available at the wheels in the next higher gear. If the torque in the higher gear is not sufficient, the transmission

cardiagn.com

will remain in the current gear. If the torque in the higher gear is greater than or equal to the required torque, then an upshift is allowed.

Shift stabilization is active in normal driving mode, cruise mode, and in tow/haul mode. However, shift stabilization will be disabled during high throttle maneuvers, and may be disengaged momentarily if the cruise control "decrease" button is tapped or held, or if a significant "bump" in the road is encountered.

MANUAL MODE DESCRIPTION AND OPERATION

Transmission Gear Shift Lever

Manual Mode operation can be entered into when the shift lever is place in Manual (M) position. When manual mode is selected, the letter M of the PRNDM display will illuminate to indicate the transmission is in manual mode.

Transmission Manual Shift Switch - Up/Down

The transmission manual shift switch is mounted on the transmission gear shift lever handle. The manual shift switch is a momentary type that has three positions. The three positions are neutral or open, plus (+) for upshifts and minus (-) for downshifts. When selecting a gear, a number 1 through 6 for 6L transmission and 1 through 8 for 8L transmissions, will be displayed next to the letter M on the instrument panel, to indicate the current gear the operator has selected.

The transmission manual shift switch is an input signal to the body control module. The upshift or downshift signal commands are processed and sent out on the serial data line from the body control module to the engine control module and transmission control module.

Transmission Control Module

In manual mode, the Transmission Control Module will always have final authority of when to allow an upshift or downshift. The Transmission Control Module only allows an upshift or downshift into the appropriate gear based on engine RPM, vehicle speed and other control parameters. The transmission will not automatically downshift to the next lower gear if it would cause an engine over speed condition or an upshift if it would result in too low of engine RPM.

If the Transmission Control Module prevents an upshift or downshift for any reason, a SHIFT DENIED message will be displayed on the instrument cluster.

Manual Mode Shifting Operation

1. With the engine running, place the shift lever in Manual (M) position. The letter M of PRNDM display will illuminate to indicate Manual Mode. A number will be illuminated next to the letter M to indicate the current gear selected.
2. Momentary pressing the Transmission Manual Shift Switch - plus (+) will command the transmission to the next higher gear. The current number indicated on the PRNDM display will change to a number to indicate the gear that the vehicle operator has selected, and if conditions are appropriate, commands the Transmission Control Module to upshift to that gear.
3. Momentary pressing the Transmission Manual Shift Switch - minus (-) will command the transmission to the next lower gear. The current number indicated on the PRNDM display will change to a number to indicate the gear that the vehicle operator has selected, and if conditions are appropriate, commands the Transmission Control Module to downshift to that gear.
4. To exit Manual Mode, place the shift lever in Drive (D) position.

cardiagn.com

TOW/HAUL MODE DESCRIPTION AND OPERATION

Tow/haul mode is a function within the vehicle's software/calibration that optimizes transmission gear selection for operation during towing or with heavy loads. This optimization includes improving acceleration performance during launches, reducing shift busyness, assisting brake performance and speed control during engine braking situations, and improving vehicle speed control while requiring less throttle pedal activity.

In general, tow/haul mode maintains lower gears longer and increases shift pressures. It is designed to be most effective when the vehicle and trailer combined weight is at least 75% of the vehicle's Gross Combined Weight Rating (GCWR). Operation of tow/haul in a lightly loaded or non-loaded vehicle will not cause damage. However, there is no benefit to the selection of tow/haul when the vehicle is unloaded, and use of tow/haul mode during unloaded driving conditions will decrease fuel economy and may generate shift feel concerns.

TRANSMISSION ADAPTIVE FUNCTIONS

The Hydra-MaticÂ® 6-Speed RWD transmission utilizes a line pressure control system during upshifts to compensate for the normal wear of transmission components. As the apply components within the transmission wear or change over time, shift time (the time required to apply a clutch) increase or decreases. In order to compensate for these changes, the transmission control module (TCM) adjusts the pressure commands to the various PC solenoids, to maintain the originally calibrated shift timing. The automatic adjusting process is referred to as "adaptive learning" and it is used to ensure consistent shift feel plus increase transmission durability. The TCM monitors the A/T input speed sensor (ISS) and the A/T output speed sensor (OSS) during commanded shifts to determine if a shift is occurring too fast (harsh) or too slow (soft) and adjusts the corresponding pressure control (PC) solenoid signal to maintain the set shift feel.

The purpose of the adapt function is to automatically compensate the shift quality for the various vehicle shift control systems. The adapt function is a continuous process that will help to maintain optimal shift quality throughout the life of the vehicle.

TRANSMISSION INDICATORS AND MESSAGES

The following transmission-related indicators and messages may be displayed on the Instrument Panel Cluster (IPC). For a complete listing and description of all vehicle indicators and messages, refer to **Indicator/Warning Message Description and Operation** .

"TRANSMISSION HOT IDLE ENGINE"

This message is displayed when the TCM detects a transmission fluid temperature (TFT) equal to or greater than 132Â°C (270Â°F) for 5 seconds.

"SERVICE TRANSMISSION"

This message displays when there is a problem with the transmission.

ELECTRONIC COMPONENT DESCRIPTION

The control solenoid (w/body and TCM) valve assembly contains the following components:

- Transmission control module (TCM)
- Clutch pressure control solenoids (Clutch PC Sol)
- Shift solenoids (SS)
- Line pressure control solenoid (Line PC Sol)

cardiagn.com

- Torque converter clutch pressure control solenoid (TCC PC Sol)
- Transmission fluid temperature sensor (TFT Sensor)
- TCM temperature sensor
- Power-up temperature sensor
- Transmission fluid pressure switches (TFP Sw)

These components are not serviced separately. The control solenoid (w/body and TCM) valve assembly utilizes a lead-frame system to connect these components electrically to the TCM. No wires are used for these components. The control solenoid (w/body and TCM) valve assembly bolts directly to the lower and upper valve body assemblies inside the transmission. The control solenoid (w/body and TCM) valve assembly connects to the engine harness 16-way connector via a pass-thru sleeve.

Control Solenoid (W/Body and TCM) Valve Assembly




Fig. 2: Control Solenoid (W/Body and TCM) Valve Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Line Pressure Control (PC) Solenoid
2	Torque Converter Clutch (TCC) Pressure Control (PC) Solenoid
3	Shift Solenoid (SS) 2
4	16 Pin Connector
5	Pressure Control (PC) Solenoid 3
6	Transmission Fluid Pressure (TFP) Switch 5
7	Pressure Control (PC) Solenoid 4
8	Pressure Control (PC) Solenoid 2
9	Transmission Fluid Pressure (TFP) Switch 3
10	Transmission Fluid Pressure (TFP) Switch 1
11	Transmission Fluid Pressure (TFP) Switch 4
12	Pressure Control (PC) Solenoid 5
13	Shift Solenoid (SS) 1

Internal Mode Switch (IMS)

cardiagn.com




Fig. 3: Identifying Internal Mode Switch (IMS)
Courtesy of GENERAL MOTORS COMPANY

The transmission manual shift shaft switch assembly is a sliding contact switch attached to the manual shift shaft inside the transmission case. The five inputs to the TCM from the transmission manual shift shaft switch assembly indicate the transmission gear selector lever position. This information is used for engine controls as well as determining the transmission shift patterns. The state of each input is available for display on the scan tool. The five input parameters represented are Signal A, Signal B, Signal C, Signal P (Parity) and Signal N (P/N Start).

Input Speed Sensor (ISS)

cardiagn.com




Fig. 4: Identifying Input Speed Sensor (ISS)
Courtesy of GENERAL MOTORS COMPANY

The input speed sensor (ISS) is a hall-effect type sensor. The ISS mounts to the control valve upper body assembly and connects to the control solenoid valve assembly through a wire harness and connector. The sensor faces the 1-2-3-4 and 3-5-R clutch housing machined teeth surface. The sensor receives 8.3-9.3 volts on the ISS/OSS Supply Voltage circuit from the TCM. As the 1-2-3-4 and 3-5-R clutch housing rotates, the sensor produces a signal frequency based on the machined surface of the 1-2-3-4 and 3-5-R clutch housing. This signal is transmitted through the ISS signal circuit to the control solenoid valve assembly. The control solenoid valve assembly uses the ISS signal to determine line pressure, transmission shift patterns, torque converter clutch (TCC) slip speed and gear ratio.

Output Speed Sensor (OSS)

cardiagn.com




Fig. 5: Identifying Output Speed Sensor (OSS)
Courtesy of GENERAL MOTORS COMPANY

The output speed sensor (OSS) is a hall-effect type sensor. The OSS mounts to the control valve upper body assembly and connects to the control solenoid valve assembly through a wire harness and connector. The sensor faces the output shaft machined teeth surface. The sensor receives 8.3-9.3 volts on the ISS/OSS supply voltage circuit from the TCM. As the output shaft rotates, the sensor produces a signal frequency based on the machined surface of the output shaft. This signal is transmitted through the OSS signal circuit to the TCM. The TCM uses the OSS signal to determine line pressure, transmission shift patterns, torque converter clutch (TCC) slip speed and gear ratio.

AUTOMATIC TRANSMISSION INLINE 16-WAY CONNECTOR DESCRIPTION

cardiagn.com




Fig. 6: Identifying Automatic Transmission Inline 16-Way Connector
Courtesy of GENERAL MOTORS COMPANY

The transmission electrical connector is an important part of the transmission operating system. Any interference with the electrical connection can cause the transmission to set diagnostic trouble codes or affect proper operation. The following items can affect the electrical connection:

- Bent pins in the connector from rough handling during connection and disconnection
- Wires backing away from the pins or coming uncrimped, in the external wiring harness
- Dirt contamination entering the connector when disconnected
- Transmission fluid leaking into the connector, wicking up into the external wiring harness and degrading the wire insulation
- Moisture intrusion in the connector
- Low pin retention in the external connector from excessive connection and disconnection of the wiring connector assembly
- Pin corrosion from contamination
- Damaged connector assembly

Remember the following points:

cardiagn.com

- Limit twisting or wiggling the connector during removal. Bent pins can occur.
- Do not pry the connector off with a screwdriver or other tool.
- Whenever the transmission external wiring connector is disconnected from the internal harness and the engine is operating, DTCs will set. Clear these DTCs after reconnecting the external connector.

Use the following procedure to disconnect the engine side of the 16-way connector from the transmission side:

1. Unlock the slide lock on the engine wiring harness connector.
2. Rotate the connector lever counterclockwise and remove the connector from the electrical connector passage sleeve.

Use the following procedure to reconnect the engine side of the 16-way connector to the transmission side:

1. Orient the alignment slot on the engine side of the connector with the alignment tab on the electrical connector passage sleeve.
2. Slide the engine side connector through the electrical connector passage sleeve and into the transmission side connector.
3. Rotate the connector lever clockwise until the connector is fully seated.
4. Lock the slide lock on the connector.

PARK - ENGINE RUNNING

When the gear selector lever is in the Park (P) position, fluid is drawn into the pump through the transmission fluid filter assembly, from the transmission fluid pan assembly. Line pressure is then directed to the following valves:

Fluid Pressure Directed in Preparation for a Shift

Manual Valve

Mechanically controlled by the gear selector lever, the manual valve is in the Park (P) position and prevents line pressure from the pressure regulator valve from entering the reverse and drive circuits.

CBR1/C456 Pressure Control (PC) Solenoid 3

The CBR1/C456 pressure control solenoid (PCS) is energized (HIGH) allowing actuator feed limit fluid to enter the PCS CBR1/C456 CL fluid circuit. PCS CBR1/C456 CL fluid is then routed through orifice #31 to the 4-5-6 clutch boost valve and through orifice #39 to the CBR1/ C456 clutch regulator valve.

CBR1/C456 Clutch Regulator Valve

PCS CBR1/C456 CL fluid at the CBR1/C4-5-6 clutch regulator valve moves the valve against CBR1/C4-5-6 clutch regulator spring force and CBR1/FDBK fluid. This allows line pressure to pass through the valve and enter the CBR1/456CL FD circuit. CBR1/456CL FD is then routed to clutch select valve 2.

Shift Solenoid 1

Shift solenoid 1 is energized (ON) allowing actuator feed limit fluid to enter the solenoid 1 circuit. Solenoid 1 fluid is routed to the #2 ball check valve and through orifice #10 to the torque converter clutch (TCC) regulator valve and shuttle valve (SHTL).

TCC Regulator Valve and Shuttle Valve

cardiagn.com

Solenoid 1 fluid is routed to the TCC regulator valve and shuttle valve and moves the valve against TCC regulator valve spring force.

#2 Ball Check Valve

Solenoid 1 fluid seats the #2 ball check valve against the reverse fluid passage and fluid is forced through orifice #22 into the CSV2 enable fluid circuit.

Clutch Select Valve 2

CSV2 enable fluid is routed to the clutch select valve 2 and moves the valve against clutch select valve 2 spring force. This allows CBR1/456 CL FD fluid to pass through the valve and enter the CBR1/CBR FD circuit. CBR1/CBR FD fluid is then routed: to clutch select valve 3, into the CBR1 fluid circuit and, through orifice #49 where it enters the CBR fluid circuit and an exhaust passage at the clutch select valve 3 (this fluid is intended to keep the low and reverse clutch full of fluid but not pressurized). CBR1 fluid is then routed to the low & reverse clutch assembly in preparation for a shift into low or reverse gear.

Shift Solenoid 2

Shift solenoid 2 is energized (ON) allowing actuator feed limit fluid to enter the solenoid 2 fluid circuit and is then routed to the #3 ball check valve.

3-5 Reverse Clutch Regulator Valve

Actuator feed limit fluid is routed through the valve and into the PS1 fluid passage. PS1 fluid is then sent to the normally closed #1 pressure switch and opens the switch.

#3 Ball Check Valve

Solenoid 2 fluid seats the #3 ball check valve against 456 CL fluid passage and fluid is forced through orifice #20 into the CSV3 enable fluid circuit. CSV3 enable fluid is then routed to the clutch select valve 3.

Clutch Select Valve #3

CSV3 enable fluid moves the clutch select valve 3 against clutch select valve 3 spring force. CBR fluid at the clutch select valve 3 passes through the valve and exhausts.

Park- Engine Running

cardiagn.com




Fig. 7: Park-- Engine Running Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

REVERSE

When the gear selector lever is moved to the Reverse (R) position (from the Park position) the normally high C35R pressure control solenoid 2 is commanded ON and the following changes occur in the transmission's hydraulic and electrical systems:

Fluid Pressure Directed in Preparation for a Shift

Manual Valve

With the manual valve in the reverse position, line pressure is directed into the reverse fluid circuit to the #2 ball check valve and clutch select valve 3.

#2 Ball Check Valve

Reverse fluid seats the #2 ball check valve against the solenoid 1 fluid passage and fluid is forced through orifice #22 into the CSV2 enable circuit.

Clutch Select Valve 2

CSV2 enable fluid, present at the valve from Park position, continues to hold the clutch select valve 2 against clutch select valve 2 spring force.

Low and Reverse Clutch Applies

Clutch Select Valve 3

cardiagn.com

Reverse fluid from the manual valve is routed to clutch select valve 3 to combine with clutch select valve 3 spring force to keep the valve in the off position. This allows reverse fluid to pass through the valve and enter the 3-5 clutch reverse feed circuit. The 3-5 clutch reverse feed fluid from the clutch select valve 3 is also routed to #5 ball check valve. CBR1/CBR FD fluid is also directed through the clutch select valve 3 to the low and reverse clutch assembly.

Low and Reverse Clutch

CBR and CBR1 fluid pressures are routed to both the inner and outer areas of the low and reverse clutch piston to hold the piston against spring force and hold the low and reverse clutch plates. The clutch was already applied in Park, but is applied with more holding capacity in Reverse (both piston areas are pressurized).

#5 Ball Check Valve

The 3-5 clutch reverse feed fluid seats #5 ball check valve against the drive 1-6 circuit allowing 3-5 clutch reverse feed fluid to enter the 3-5 reverse supply circuit. The 3-5 reverse supply fluid is then routed to #7 ball check valve and through orifice #25 where it enters the 3-5 reverse feed circuit. The 3-5 reverse feed passes through orifice #46 and then is routed to the 3-5 reverse clutch regulator valve.

3-5 Reverse Clutch Applies

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is energized (HIGH) allowing actuator feed limit fluid to enter the PCS 3-5 reverse clutch circuit. PCS 3-5 reverse clutch fluid is then routed through orifice #48 to the 3-5 reverse clutch regulator valve and through orifice #40 to the 3-5 reverse boost valve.

3-5 Reverse Clutch Regulator Valve

PCS 3-5 reverse clutch fluid moves the 3-5 reverse clutch regulator valve against 3-5 reverse clutch regulator valve spring force and 3-5 reverse clutch feedback fluid. This allows 3-5 reverse feed to pass through the valve and enter the 3-5 reverse clutch circuit. The 3-5 reverse clutch fluid is then routed to the 3-5 reverse clutch and the 3-5 reverse boost valve. PS1 fluid from pressure switch 1 exhausts through the valve allowing the switch to close.

3-5 Reverse Boost Valve

PCS 3-5 reverse clutch fluid pressure acts on a differential area moving the 3-5 reverse clutch boost valve against the 3-5 reverse clutch boost valve spring. The 3-5 reverse clutch fluid passes through the valve and enters the 3-5 reverse clutch feedback circuit. As PCS 3-5 reverse clutch fluid pressure is increased to a given value, the 3-5 reverse clutch boost valve opens the 3-5 reverse clutch feedback circuit to exhaust. This results in the 3-5 reverse clutch regulator valve moving to the full feed position sending full 3-5 clutch reverse feed pressure (full line pressure) to the clutch.

3-5 Reverse Clutch

The 3-5 reverse clutch fluid enters the 1-2-3-4 and reverse clutch housing to move the piston against spring force and compensator feed fluid to apply the 3-5 reverse clutch plates.

Reverse

cardiagn.com




Fig. 8: Reverse Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

NEUTRAL - ENGINE RUNNING

When the gear selector is moved to the Neutral (N) position, the hydraulic and electrical system operation is identical to Park (P) range. However, if Neutral is selected after the vehicle was operating in Reverse (R), the normally high C35R pressure control solenoid 2 is commanded OFF and the following changes would occur in the hydraulic system:

3-5 Reverse Clutch Releases

Manual Valve

The manual valve is moved to the Neutral position and blocks line pressure from entering the reverse and drive fluid circuits. The reverse fluid from the #2 ball check valve and clutch select valve 3 is opened to an exhaust passage at the manual valve.

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is commanded OFF allowing PCS 3-5 reverse clutch fluid from the 3-5 reverse clutch boost valve and 3-5 reverse clutch regulator valve to exhaust.

3-5 Reverse Clutch Boost Valve

The 3-5 reverse boost valve spring force moves the valve to allow 3-5 reverse clutch feedback fluid from the 3-5 reverse clutch regulator valve to enter the 3-5 reverse clutch circuit and exhaust.

3-5 Reverse Clutch Regulator Valve

cardiagn.com

The 3-5 reverse clutch regulator valve spring force moves the valve to allow 3-5 reverse clutch fluid from the 3-5 reverse clutch and clutch select valve 2 to pass through the valve and enter the exhaust backfill fluid circuit. The 3-5 reverse clutch fluid then enters the exhaust backfill fluid circuit and is routed through orifice #30 to the exhaust backfill pressure relief valve where excess pressure is exhausted.

3-5 Reverse Clutch

The 3-5 reverse clutch spring force combined with a force from the compensator moves the 3-5 reverse clutch piston to release the 3-5 reverse clutch plates and force 3-5 reverse clutch fluid to exhaust from the 1-2-3-4 and 3-5 reverse clutch housing. The 3-5 reverse clutch fluid is then routed to the 3-5 reverse clutch regulator valve allowing the 3-5 reverse clutch to release.

Clutch Select Valve 3

When reverse fluid exhausts through the manual valve, CSV3 enable fluid moves the valve against clutch select valve 3 spring force. The 3-5 reverse feed fluid is routed around #7 ball check valve and into the 3-5 reverse supply circuit. The 3-5 reverse supply fluid is routed around #5 ball check valve and into the 3-5 clutch reverse feed circuit and exhausts at the clutch select valve 3.

Neutral- Engine Running




Fig. 9: Neutral-- Engine Running Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, FIRST GEAR ENGINE BRAKING

When the gear selector lever is moved to the Drive (D) range from the Neutral (N) position, the transmission will provide engine braking. In this operating range, the normally-low C1234 pressure control solenoid 5 is commanded ON and in the engine braking mode the following changes occur within the hydraulic circuits:

cardiagn.com

Fluid Pressure is Directed to the 1-2-3-4 Clutch and the Low and Reverse Clutch to Provide Engine Braking

Manual Valve

The manual valve is moved to the Drive (D) position and allows line fluid pressure to enter the drive fluid circuit. Drive fluid is then routed to the clutch select valve 2.

Clutch Select Valve 2

Drive fluid at the clutch select valve 2 passes through the valve and enters the drive brake circuit. Drive brake fluid is then routed to the clutch select valve 3.

Clutch Select Valve 3

Drive brake fluid at the clutch select valve 3 passes through the valve and enters the Drive B fluid circuit. Drive B fluid is then routed to #1 ball check valve.

#1 Ball Check Valve

Drive B fluid seats the #1 ball check valve against drive 1-6 fluid to force drive B fluid into the CB26/C1234 feed passage. CB26/C1234 feed fluid is routed to the #6 ball check valve, through orifice #43 and, to the 2-6 clutch regulator valve. CB26/C1234 feed fluid passes through the 2-6 clutch regulator valve and enters the pressure switch 3 (PS3) fluid circuit. PS3 fluid is then routed to the normally closed pressure switch 3 and opens the switch.

#6 Ball Check Valve

CB26/C1234 feed fluid seats the #6 ball check valve against the 1234 clutch feed passage forcing CB26/C1234 feed fluid through orifice #32 before entering the 1234 clutch feed circuit. The 1234 clutch feed fluid is routed through orifice #33 and then to the 1-2-3-4 clutch regulator valve.

1-2-3-4 Clutch Applies

C1234 Pressure Control Solenoid 5

The C1234 pressure control solenoid 5 is commanded ON allowing actuator feed limit fluid to enter the PCS1234 clutch fluid circuit. PCS1234 clutch fluid is then routed through orifice #35 to the 1-2-3-4 clutch regulator valve. PCS1234 clutch fluid is also routed through orifice #29 and then to the 1-2-3-4 clutch boost valve.

1-2-3-4 Clutch Regulator Valve

PCS1234 clutch fluid moves the 1-2-3-4 clutch regulator valve against 1-2-3-4 clutch regulator valve spring force to allow 1234 clutch feed fluid to pass through the valve and enter the 1234 clutch fluid circuit. The 1234 clutch fluid is then routed to the 1234 clutch boost valve and the 1-2-3-4 clutch.

1-2-3-4 Clutch Boost Valve

PCS1234 clutch fluid pressure acts on a differential area moving the 1234 clutch boost valve against the 1234 clutch boost valve spring. The 1234 clutch fluid passes through the valve and enters the 1234 clutch feedback circuit. As PCS 1234 clutch fluid pressure is increased to a given value, the 1234 clutch boost valve opens the 1234 clutch feedback circuit to exhaust. This results in the 1234 clutch regulator valve moving to the full feed position sending full 26 CL/1234 CL feed pressure (full line pressure) to the clutch.

cardiagn.com

1-2-3-4 Clutch

The 1234 clutch fluid enters the 1234 clutch housing to move the piston against spring force and compensator feed fluid to apply the 1-2-3-4 clutch plates.

Drive Range, First Gear Engine Braking




Fig. 10: Drive Range, First Gear Engine Braking Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, FIRST GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, throttle position sensor and other vehicle sensors to determine the precise moment to deenergize or "turn off" shift solenoid 1 and command OFF the normally-high CBR1/C456 pressure control solenoid 3.

Low & Reverse Clutch Releases

Shift Solenoid 1

When shift solenoid 1 is "turned OFF", CSV2 enable fluid from the clutch select valve 2 passes by the #2 ball check valve and enters the solenoid 1 fluid circuit. Solenoid 1 fluid from the #2 ball check valve and TCC regulator valve is then routed to the solenoid where it exhausts.

Clutch Select Valve 2

Clutch select valve 2 (CSV2) enable fluid is exhausted from the clutch select valve 2 and clutch select valve 2 spring force moves the valve to the released position. With clutch select valve 2 in the released position, drive

cardiagn.com

fluid from the manual valve passes through the valve and enters the drive 1-6 fluid circuit. Drive 1-6 fluid then feeds all clutch regulator valves and the TCC regulator valve.

CBR1/C456 Pressure Control Solenoid 3

The CBR1/C456 pressure control solenoid 3 is commanded OFF allowing PCS CBR1/C456 fluid from the CBR1/C456 clutch regulator valve and 456 clutch boost valve to exhaust.

CBR1/C456 Clutch Regulator Valve

CBR1/C456 clutch regulator valve spring force moves the valve to exhaust the CBR1/456 clutch feed circuit and allow drive 1-6 fluid to enter the PS5 fluid circuit. PS5 fluid is then routed to the normally-closed pressure switch 5 and opens the switch. PS5 fluid is also routed to the #4 ball check valve and flows into the CSV2 latch fluid circuit.

#4 Ball Check Valve

PS5 fluid pressure seats the #4 ball check valve against the 456 clutch fluid circuit. PS5 fluid is then directed into the CSV2 latch fluid circuit and routed to the clutch select valve 2. CSV2 latch fluid combines with clutch select valve 2 spring force and holds the valve in this position during all 6 forward gear ranges.

#5 Ball Check Valve

Drive 1-6 fluid pressure seats the #5 ball check valve against the 35 clutch reverse feed fluid passage. Drive 1-6 fluid is then directed into the 35R supply fluid circuit which is routed to the #7 ball check valve and orifice #25.

#7 Ball Check Valve

The 35R supply fluid seats the #7 ball check valve against the 35R feed fluid passage to force 35R supply fluid through orifice #25 before entering the 35R feed circuit. The 35R feed fluid is then routed to the 3-5 reverse clutch regulator valve.

Low and Reverse Clutch

Low and reverse clutch spring force moves the low and reverse clutch piston which forces clutch braking (CBR) and CBR1 fluid out of the center support. CBR fluid is routed to the clutch select valve 3 where it exhausts. CBR1 fluid is routed to the clutch select valve 2 where it exhausts. The low and reverse clutch is in the released position.

Drive Range, First Gear

cardiagn.com




Fig. 11: Drive Range, First Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, SECOND GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, the throttle position sensor and other vehicle sensors to determine the precise moment to command ON the normally-low pressure control solenoid 4.

Second Clutch Applies

CB26 Pressure Control Solenoid 4

The CB26 pressure control solenoid 4 is commanded ON, allowing actuator feed limit fluid to enter the pressure control solenoid (PCS) 26 clutch fluid circuit. PCS 26 clutch fluid is then routed through orifice #44 to the 2-6 clutch regulator gain valve.

2-6 Clutch Regulator Gain Valve

The 2-6 clutch regulator gain valve allows the gain (valve input to output pressure magnification factor) of the 2-6 clutch regulator valve to be different for a 1-2 shift verses a 5-6 shift. For a 1-2 shift, PCS 26 clutch fluid pressure acts on a differential area resulting in the "high gain" pressure output.

2-6 Clutch Regulator Valve

PCS 26 clutch fluid moves the 2-6 clutch regulator / gain valve assembly against the 2-6 clutch regulator valve spring force to allow 26 clutch/1234 clutch feed fluid to pass through the valve. The 26 clutch/1234 clutch feed fluid is routed into the 26 clutch fluid circuit where it passes through orifice #41 and then to the spring end of the 2-6 clutch regulator valve, and to the 2-6 clutch within the center support.

cardiagn.com

2-6 Clutch

The 26 clutch fluid from the 2-6 clutch regulator valve is routed through the center support and to the 2-6 clutch piston assembly. The 26 clutch fluid pressure moves the piston against 2-6 clutch spring force to apply the 2-6 clutch plates.

Drive Range, Second Gear




Fig. 12: Drive Range, Second Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, THIRD GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, the throttle position sensor and other vehicle sensors to determine the precise moment to command OFF the normally-low CB26 pressure control solenoid 4. At the same time the C35R pressure control solenoid 2 is also commanded ON to regulate 3-5 clutch apply.

3-5 Reverse Clutch Applies

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is commanded ON allowing actuator feed fluid to enter the pressure control solenoid (PCS) 35 reverse clutch fluid circuit. PCS 35 reverse clutch fluid is routed through orifice #48 and then to the 3-5 reverse clutch regulator valve. PCS 35 reverse clutch fluid is also routed through orifice #40 and then to the 3-5 reverse clutch boost valve.

3-5 Reverse Clutch Boost Valve

cardiagn.com

PCS 35 reverse clutch fluid pressure acts on a differential area moving the 3-5 reverse clutch boost valve against the 3-5 reverse clutch boost valve spring. The 35 reverse clutch fluid passes through the valve and enters the 35 reverse clutch feedback circuit. As PCS 35 reverse clutch fluid pressure is increased to a given value, the 3-5 reverse clutch boost valve opens the 35 reverse clutch feedback circuit to exhaust. This results in the 3-5 reverse clutch regulator valve moving to the full feed position sending full 35 reverse clutch feed pressure (full line pressure) to the clutch.

3-5 Reverse Clutch Regulator Valve

PCS 35 reverse clutch fluid moves the 3-5 reverse clutch regulator valve against 3-5 reverse clutch regulator valve spring force and 35 reverse clutch feedback fluid. This allows 35 reverse feed to pass through the valve and enter the 35 reverse clutch circuit. The 35 reverse clutch fluid is then routed to the 3-5 reverse clutch, the 3-5 reverse boost valve and the clutch select valve 2. When the 3-5 reverse clutch regulator valve is in this position, PS1 fluid from the pressure switch 1 exhausts through the valve allowing the switch to close.

3-5 Reverse Clutch

The 35 reverse clutch fluid enters the 1-2-3-4 and 3-5 reverse clutch housing to move the piston against spring force combined with force from the compensator to apply the 3-5 reverse clutch plates.

2-6 Clutch Releases

CB26 Pressure Control Solenoid 4

The CB26 pressure control solenoid 4 is commanded OFF allowing PCS 26 clutch fluid from the 2-6 clutch regulator valve to exhaust. The 26 clutch/1234 clutch feed fluid at the 2-6 clutch regulator valve passes through the valve and enters the PS3 fluid circuit. PS3 fluid is then routed to pressure switch 3 and opens the normally-closed switch.

2-6 Clutch Regulator Valve

The 2-6 clutch regulator valve spring force moves the valve to allow 26 clutch fluid from the 2-6 clutch to pass through the valve and enter the exhaust backfill fluid circuit.

2-6 Clutch

The 2-6 clutch spring force moves the 2-6 clutch piston to release the 2-6 clutch plates and forces 26 clutch fluid to exhaust from the center support. The 26 clutch fluid is routed through the 2-6 clutch regulator valve where it enters the exhaust backfill fluid circuit and is routed through orifice #30 to the exhaust backfill pressure relief valve where excess pressure is exhausted.

Drive Range, Third Gear

cardiagn.com




Fig. 13: Drive Range, Third Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, THIRD GEAR DEFAULT

If the transmission is in 1st, 2nd or 3rd gear during a transmission electrical component failure, the transmission will default to 3rd gear. All solenoids will default to their normal state. If the torque converter clutch was applied, it will release. This default action will enable the vehicle to be safely driven to a service center.

1-2-3-4 Clutch Stays Applied

Shift Solenoid 2

Shift solenoid 2 defaults to it's normally-closed state (OFF), and SOL 2 fluid exhausts through the solenoid.

Clutch Select Valve 3

Solenoid 2 fluid pressure no longer holds the clutch select valve 3 open. When the valve moves back to the closed position, it opens the 1234 clutch default fluid circuit, and 1234 default fluid is routed to the 1-2-3-4 clutch regulator valve.

1-2-3-4 Clutch Regulator Valve

With the absence of PCS 1234 clutch fluid, due to the default state of the C1234 pressure control solenoid 5, the 1-2-3-4 regulator valve would close from spring force. However, the 1234 clutch default fluid enters behind the 1-2-3-4 regulator shuttle valve and keeps the valve in the open position.

1-2-3-4 Clutch

cardiagn.com

With the 1-2-3-4 clutch regulator valve still held in the open position, the 1-2-3-4 clutch will stay applied.

3-5 Reverse Clutch Applied or Applies

C35R Pressure Control Solenoid 2

The normal state for the C35R pressure control solenoid 2 is ON, therefore PSC 35 reverse clutch fluid will still be routed to the 3-5 reverse clutch regulator valve and the 3-5 reverse clutch boost valve.

3-5 Reverse Clutch Regulator Valve

PCS 3-5 reverse clutch fluid moves the 3-5 reverse clutch regulator valve against 3-5 reverse clutch regulator valve spring force and 3-5 reverse clutch feedback fluid. This allows 3-5 reverse feed to pass through the valve and enter the 3-5 reverse clutch circuit. 3-5 reverse clutch fluid is then routed to the 3-5 reverse clutch, the 3-5 reverse boost valve and the clutch select valve 2. When the 3-5 reverse clutch regulator valve is in this position, PS1 fluid from the pressure switch 1 exhausts through the valve, allowing the switch to close.

3-5 Reverse Clutch Boost Valve

PCS 3-5 reverse clutch fluid pressure acts on a differential area moving the 3-5 reverse clutch boost valve against the 3-5 reverse clutch boost valve spring. The 3-5 reverse clutch fluid passes through the valve and enters the 3-5 reverse clutch feedback circuit. As PCS 3-5 reverse clutch fluid pressure is increased to a given value, the 3-5 reverse clutch boost valve opens the 3-5 reverse clutch feedback circuit to exhaust. This results in the 3-5 reverse clutch regulator valve moving to the full feed position sending full 3-5 reverse clutch feed pressure (full line pressure) to the clutch.

3-5 Reverse Clutch

The 3-5 reverse clutch fluid enters the 1-2-3-4 and 3-5 reverse clutch housing to move the piston against spring force combined with force from the compensator to apply the 3-5 reverse clutch plates.

Drive Range, Third Gear Default

cardiagn.com




Fig. 14: Drive Range, Third Gear Default Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, FOURTH GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, the throttle position sensor and other vehicle sensors to determine the precise moment to command OFF the normally-high C35R pressure control solenoid 2. At the same time the normally-low CBR1/C456 pressure control solenoid 3 is commanded ON to regulate 4-5-6 clutch apply.

4-5-6 Clutch Applies

CBR1/C456 Pressure Control Solenoid 3

The CBR1/C456 pressure control solenoid 3 (PCS) is commanded ON allowing actuator feed fluid to enter the PCS CBR1/456 clutch fluid circuit. PCS CBR1/456 clutch fluid is routed through orifice #39 to the CBR1/C456 clutch regulator valve and, through orifice #31 to the CBR1/C456 clutch boost valve.

CBR1/C456 Clutch Regulator Valve

PCS CBR1/456 clutch fluid moves the CBR1/C456 clutch regulator valve against CBR1/C456 clutch regulator valve spring force to allow line fluid to pass through the valve an enter the CBR1/456 clutch feed circuit. CBR1/456 clutch feed is then routed to the 4-5-6 clutch boost valve and clutch select valve 2.

4-5-6 Clutch Boost Valve

PCS CBR1/456 clutch fluid pressure acts on a differential area moving the CBR1/456 clutch boost valve against the CBR1/456 clutch boost valve spring. CBR1/456 clutch fluid passes through the valve and enters the

cardiagn.com

CBR1/456 clutch feedback circuit. As PCS CBR1/456 clutch fluid pressure is increased to a given value, the CBR1/456 clutch boost valve opens the CBR1/456 clutch feedback circuit to exhaust. This results in the CBR1/456 clutch regulator valve moving to the full feed position, sending full line pressure to the clutch.

Clutch Select Valve 2

CBR1/456 clutch feed fluid passes through the clutch select valve 2 and enters the 456 clutch feed circuit. The 456 clutch feed fluid is routed to the clutch select valve 3 where it passes through the valve and enters the 456 clutch fluid circuit. The 456 clutch fluid is routed to the 4-5-6 clutch, the 2-6 clutch regulator gain valve and to the #3 ball check valve. The 456 clutch fluid seats the #3 ball check valve against solenoid 2 fluid passage and directed into the CSV3 enable fluid circuit where it is routed through orifice #20 and to clutch select valve 3.

4-5-6 Clutch

The 456 clutch fluid enters the 4-5-6 clutch housing to move the piston against spring force, combined with force from the compensator to apply the 4-5-6 clutch plates.

3-5 Reverse Clutch Releases

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is commanded OFF, allowing PCS 35 reverse clutch fluid from the 3-5 reverse clutch boost valve and the 3-5 reverse clutch regulator valve to exhaust through the solenoid.

3-5 Reverse Clutch Boost Valve

The 3-5 reverse boost valve spring force moves the valve to allow 35 reverse clutch feedback fluid from the 3-5 reverse clutch regulator valve to enter the 35 reverse clutch fluid circuit and exhaust.

3-5 Reverse Clutch Regulator Valve

The 3-5 reverse clutch regulator valve spring force moves the valve to allow 35 reverse clutch fluid from the 3-5 reverse clutch to pass through the valve and enter the exhaust backfill fluid circuit. The 35 reverse clutch fluid then enters the exhaust backfill fluid circuit and is routed through orifice #30 to the exhaust backfill pressure relief valve where excess pressure is exhausted.

3-5 Reverse Clutch

The 3-5 reverse clutch spring force combined with force from the compensator move the 3-5 reverse clutch piston to release the 3-5 clutch plates and forces 35 reverse clutch fluid to exhaust from 1- 2-3-4 and 3-5 reverse clutch housing. The 35 reverse clutch fluid is then routed to the 3-5 reverse clutch regulator valve and exhausted.

Drive Range, Fourth Gear

cardiagn.com




Fig. 15: Drive Range, Fourth Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, FIFTH GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, the throttle position sensor and other vehicle sensors to determine the precise moment to command ON the normally-high C35R pressure control solenoid 2. At the same time the normally-low C1234 pressure control solenoid 5 is commanded OFF.

3-5 Reverse Clutch Applies

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is commanded ON, allowing actuator feed fluid to enter the PCS 35 reverse clutch fluid circuit. PCS 35 reverse clutch fluid is routed through orifice #48 and then to the 3-5 reverse clutch regulator valve. PCS 35 reverse clutch fluid is also routed through orifice #40 and then to the 3-5 reverse clutch boost valve.

3-5 Reverse Clutch Boost Valve

PCS 35 reverse clutch fluid pressure acts on a differential area moving the PCS 3-5 reverse clutch boost valve against the 3-5 reverse clutch boost valve spring. The 35 reverse clutch fluid passes through the valve and enters the 35 reverse clutch feedback circuit. As PCS 35 reverse clutch fluid pressure is increased to a given value, the 3-5 reverse clutch boost valve opens the 35 reverse clutch feedback circuit to exhaust. This results in the 3-5 reverse clutch regulator valve moving to the full feed position sending full 35 reverse clutch feed pressure (full line pressure) to the clutch.

3-5 Reverse Clutch Regulator Valve

cardiagn.com

PCS 35 reverse clutch fluid moves the 3-5 reverse clutch regulator valve against 3-5 reverse clutch regulator valve spring force and 35 reverse clutch feedback fluid. This allows 35 reverse feed to pass through the valve and enter the 35 reverse clutch circuit. The 35 reverse clutch fluid is then routed to the 3-5 reverse clutch, the 3-5 reverse boost valve and the clutch select valve 2. When the 3-5 reverse clutch regulator valve is in this position, PS1 fluid from the pressure switch 1 exhausts through the valve allowing the switch to close.

Clutch Select Valve 2

The 35 reverse clutch fluid passes through the clutch select valve 2 and enters the 1234 clutch default feed fluid circuit. The 1234 clutch default feed fluid is then routed to the clutch select valve 3.

3-5 Reverse Clutch

The 35 reverse clutch fluid enters the 1-2-3-4 and 3-5 reverse clutch housing to move the piston against spring force combined with force from the compensator to apply the 3-5 reverse clutch plates.

1-2-3-4 Clutch Releases

C1234 Pressure Control Solenoid 5

The C1234 pressure control solenoid 5 is commanded OFF, allowing PCS 1234 clutch fluid from the 1-2-3-4 clutch regulator valve and 1-2-3-4 clutch boost valve to exhaust.

1-2-3-4 Clutch Regulator Valve

The 1-2-3-4 clutch regulator valve spring force moves the valve to allow 1234 clutch feed fluid from the 1-2-3-4 clutch to pass through the valve and enter the exhaust backfill fluid circuit. The 1234 clutch fluid the enters the exhaust backfill fluid circuit and is routed through orifice #30 to the exhaust backfill pressure relief valve where excess pressure is exhausted. Also, 1234 clutch regulator valve spring force moves the valve to allow 1234 clutch feed fluid to pass through the valve and enter the PS4 fluid circuit. PS4 fluid is then routed to pressure switch 4 and opens the normally-closed switch.

1-2-3-4 Clutch Boost Valve

The 1-2-3-4 clutch boost valve spring force moves the valve to allow 1234 clutch feedback fluid from the 1-2-3-4 clutch regulator valve to enter the 1234 clutch circuit and exhaust.

1-2-3-4 Clutch

The 1-2-3-4 clutch spring force combined with force from the compensator moves the 1-2-3-4 clutch piston to release the clutch plates and force 1234 clutch fluid from the 1-2-3-4 and 3-5 reverse clutch housing. The 1234 clutch fluid is routed through the 1-2-3-4 clutch regulator valve where it enters the exhaust backfill fluid circuit.

Drive Range, Fifth Gear

cardiagn.com




Fig. 16: Drive Range, Fifth Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, FIFTH GEAR DEFAULT

If the transmission is in 4th, 5th or 6th gear during a transmission electrical component failure, the transmission will default to 5th gear. All solenoids will default to their normal state. If the torque converter clutch was applied, it will release. The transmission will stay in 5th gear default range until the ignition has been turned off or transmission shifted to reverse. When the vehicle is restarted, and shifted back into drive, the transmission will then operate in the 3rd gear default range. This default action will enable the vehicle to be safely driven to a service center.

3-5 Reverse Clutch Applies

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 defaults to ON, allowing actuator feed fluid to enter the pressure control solenoid (PCS) 35 reverse clutch fluid circuit. PCS 35 reverse clutch fluid is routed through orifice #48 and then to the 3-5 reverse clutch regulator valve. PCS 35 reverse clutch fluid is also routed through orifice #40 and then to the 3-5 reverse clutch boost valve.

3-5 Reverse Clutch Boost Valve

PCS 3-5 reverse clutch fluid pressure acts on a differential area moving the PCS 3-5 reverse clutch boost valve against the 3-5 reverse clutch boost valve spring. The 3-5 reverse clutch fluid passes through the valve and enters the 3-5 reverse clutch feedback circuit. As PCS 3-5 reverse clutch fluid pressure is increased to a given value, the 3-5 reverse clutch boost valve opens the 3-5 reverse clutch feedback circuit to exhaust. This results in the 3-5 reverse clutch regulator valve moving to the full feed position sending full 3-5 reverse clutch feed pressure (full line pressure) to the clutch.

cardiagn.com

3-5 Reverse Clutch Regulator Valve

PCS 3-5 reverse clutch fluid moves the 3-5 reverse clutch regulator valve against 3-5 reverse clutch regulator valve spring force and 3-5 reverse clutch feedback fluid. This allows 3-5 reverse feed to pass through the valve and enter the 3-5 reverse clutch circuit. The 3-5 reverse clutch fluid is then routed to the 3-5 reverse clutch, the 3-5 reverse boost valve and the clutch select valve 2. When the 3-5 reverse clutch regulator valve is in this position, PS1 fluid from the pressure switch 1 exhausts through the valve, allowing the switch to close.

3-5 Reverse Clutch

The 3-5 reverse clutch fluid enters the 1-2-3-4 and 3-5 reverse clutch housing to move the piston against spring force combined with force from the compensator to apply the 3-5 reverse clutch plates.

Clutch Select Valve 3

Once the clutch select valve 3 is moved to the ON position in 4th gear, it will remain in this position throughout the 5th gear default range, until the ignition has been turned OFF. When the ignition is OFF, fluid will exhaust from the valve, thus when the vehicle is restarted, the transmission will then be in the 3rd gear default range.

1-2-3-4 Clutch Releases or 2-6 Clutch Releases

C1234 Pressure Control Solenoid 5

If the transmission was in 4th gear when an electrical condition commands a protection mode, the C1234 pressure control solenoid 5 defaults to the OFF position, allowing PCS 1234 clutch fluid from the 1-2-3-4 clutch, the 1-2-3-4 clutch regulator valve and 1- 2-3-4 clutch boost valve to exhaust.

2-6 CB26 Pressure Control Solenoid 4

If the transmission was in 6th gear when an electrical condition commands a protection mode, the CB26 pressure control solenoid 4 defaults to the OFF position, allowing PCS 26 clutch fluid from the 2-6 clutch regulator valve, and the 2-6 clutch to exhaust.

Torque Converter Clutch Releases

TCC Pressure Control Solenoid

The torque converter clutch (TCC) pressure control solenoid will default to it's normal state, OFF. PCS TCC fluid will exhaust from the TCC control valve, and spring force will shuttle the valve to the off position. TCC apply fluid will then be routed to the cooler, and TCC release fluid will be routed to the torque converter for complete TCC release.

Drive Range, Fifth Gear Default

cardiagn.com




Fig. 17: Drive Range, Fifth Gear Default Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

DRIVE RANGE, SIXTH GEAR

As the vehicle speed increases, the transmission control module (TCM) receives input signals from the automatic transmission input and output speed sensors, the throttle position sensor and other vehicle sensors to determine the precise moment to command ON the normally-low CB26 pressure control solenoid 4 (PCS). At the same time the normally-high C35R pressure control solenoid 2 is commanded OFF.

2-6 Clutch Applies

CB26 Pressure Control Solenoid 4

The CB26 pressure control solenoid 4 is commanded ON, allowing actuator feed fluid to enter the PCS 26 clutch fluid circuit. PCS 26 fluid is routed through orifice #44 and then to the 2-6 clutch regulator gain valve.

2-6 Clutch Regulator Gain Valve

The 2-6 clutch regulator gain valve allows the gain (valve input to output pressure magnification factor) of the 2-6 clutch regulator valve to be different for a 1-2 shift verses a 5-6 shift. For a 5-6 shift PCS 26 clutch fluid pressure passes through the hollow valve and only acts on the 26 regulator valve area, resulting in the "low gain" pressure output.

2-6 Clutch Regulator Valve

PCS 26 clutch fluid moves the 2-6 clutch regulator/gain valve assembly against the 2-6 clutch regulator valve spring force to allow 26 clutch/1234 clutch feed fluid to pass through the valve. The 26 clutch/1234 clutch feed fluid is routed into the 26 clutch fluid circuit where it passes through orifice #41 and then to the spring end of

cardiagn.com

the 2-6 clutch regulator valve, and to the 2-6 clutch within the center support.

2-6 Clutch

The 26 clutch fluid from the 2-6 clutch regulator valve is routed through the center support and to the 2-6 clutch piston assembly. The 26 clutch fluid pressure moves the piston against 2-6 clutch spring force to apply the 2-6 clutch plates.

3-5 Clutch Releases

C35R Pressure Control Solenoid 2

The C35R pressure control solenoid 2 is commanded OFF, allowing PCS 35 reverse clutch fluid from the 3-5 reverse clutch boost valve and the 3-5 reverse clutch regulator valve to exhaust through the solenoid.

3-5 Reverse Clutch Boost Valve

The 3-5 reverse boost valve spring force moves the valve to allow 35 reverse clutch feedback fluid from the 3-5 reverse clutch regulator valve to enter the 35 reverse clutch circuit and exhaust.

3-5 Reverse Clutch Regulator Valve

The 3-5 reverse clutch regulator valve spring force moves the valve to allow 35 reverse clutch fluid from the 3-5 reverse clutch to pass through the valve and enter the exhaust backfill fluid circuit. The 35 reverse clutch fluid then enters the exhaust backfill fluid circuit and is routed through orifice #30 to the exhaust backfill pressure relief valve where excess pressure is exhausted.

3-5 Reverse Clutch

The 3-5 reverse clutch spring force combined with force from the compensator move the 3-5 reverse clutch piston to release the 3-5 clutch plates and forces 35 reverse clutch fluid to exhaust from 1-2-3-4 and 3-5 reverse clutch housing. The 35 reverse clutch fluid is then routed to the 3-5 reverse clutch regulator valve where it enters the exhaust backfill circuit.

Drive Range, Sixth Gear

cardiagn.com




Fig. 18: Drive Range, Sixth Gear Hydraulic Diagram
Courtesy of GENERAL MOTORS COMPANY

FLUID PASSAGES

Torque Converter Housing- Fluid Pump Cover Side

cardiagn.com




Fig. 19: Torque Converter Housing - Fluid Pump Cover Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
2	Line
4	Converter Feed
5	Converter Feed Limit
6	TCC Release
7	TCC Apply
8	Cooler Feed
9	Center Lube
10	Regulator Apply
38	PCS TCC
49	PCS Line
51	Exhaust
52	Void
55	Vent
56	Torque Converter Seal Drainback

Fluid Pump Cover- Torque Converter Housing Side

cardiagn.com




Fig. 20: Fluid Pump Cover - Torque Converter Housing Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Suction
2	Line
4	Converter Feed
5	Converter Feed Limit
6	TCC Release
7	TCC Apply
8	Cooler Feed
9	Center Lube
10	Regulator Apply
38	PCS TCC
49	PCS Line
51	Exhaust
52	Void
55	Vent

Fluid Pump Cover - Case Side

cardiagn.com




Fig. 21: Fluid Pump Cover - Case Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Suction
2	Line
9	Center Lube
10	Regulator Apply
11	Compensator Feed
14	3-5 Reverse Clutch
26	1-2-3-4 Clutch
34	4-5-6 Clutch
38	PCS TCC
49	PSC Line
51	Exhaust
52	Empty
55	Ventilate

Case- Top Channel Plate Side

cardiagn.com




Fig. 22: Case - Top Channel Plate Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
9	Center Lube
29	CBR1 (Manual 1st)
30	CBR (Reverse)
46	26 Clutch
52	Void

Control Valve Upper Body Assembly - Case Side

cardiagn.com




Fig. 23: Control Valve Upper Body Assembly - Case Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
2	Line
9	Center Lube
10	Regulator Apply
11	Compensator Feed
14	3-5 Reverse Clutch
26	1-2-3-4 Clutch
29	CBR1 (Manual 1st)
30	CBR (Reverse)
34	4-5-6 Clutch
38	PCS TCC
46	2-6 Clutch
49	PCS Line
51	Exhaust
52	Empty

Control Valve Upper Body Assembly - Bottom Channel Plate Side

cardiagn.com




Fig. 24: View Of Control Valve Upper Body Assembly - Bottom Channel Plate Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
2	Line
9	Center Lube
10	Regulator Apply
11	Compensator Feed
12	Actuator Feed Limit
13	Reverse
14	3-5 Reverse Clutch
15	3-5 Reverse Clutch Feedback
16	CSV2 Enable
17	Solenoid 1
19	CSV3 Enable
21	Drive 1-6
24	1-2-3-4 Clutch DFLT
25	1-2-3-4 Clutch Feed
26	1-2-3-4 Clutch
27	1-2-3-4 Clutch Feedback
29	CBR1
30	CBR
31	CBR1/4-5-6 Clutch Feed
32	CBR1 Feedback
34	4-5-6 Clutch
35	CSV2 Latch

cardiagn.com

Callout	Component Name
37	3-5 Reverse Feed
38	PCS TCC
39	PCS 1-2-3-4 Clutch
40	PS4
41	PS1
42	PS3
43	PS5
44	2-6 Clutch/1-2-3-4CL Feed
45	PCS 3-5 Rev Clutch
46	2-6 Clutch
47	PCS 2-6 Clutch
48	PCS CBR1/4-5-6 Clutch
49	PCS Line
50	Exhaust BF
51	Exhaust
52	Empty
53	3-5 Rear Feed

Control Valve Upper Body Assembly - Control Solenoid Valve Assembly Side




Fig. 25: Control Valve Upper Body Assembly - Control Solenoid Valve Assembly Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
12	Actuator Feed Limit

cardiagn.com

Callout	Component Name
17	Solenoid 1
18	Solenoid 2
38	PCS TCC
39	PCS 1-2-3-4 Clutch
40	PS4
41	PS1
42	PS3
43	PS5
45	PCS 3-5 Rev Clutch
47	PCS 2-6 Clutch
48	PCS CBR1/4-5-6 Clutch
49	PCS Line
51	Exhaust
52	Empty

Control Valve Lower Body Assembly - Control Valve Upper Body Assembly Side




Fig. 26: Control Valve Lower Body Assembly - Control Valve Upper Body Assembly Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
2	Line
9	Center Lube
10	Regulator Apply
11	Compensator Feed

cardiagn.com

Callout	Component Name
12	Actuator Feed Limit
13	Reverse
14	3-5 Reverse Clutch
15	3-5 Reverse Clutch Feedback
16	CSV2 Enable
17	Solenoid 1
18	Solenoid 2
19	CSV3 Enable
20	Drive
21	Drive 1-6
22	Drive Brake
23	1-2-3-4 Clutch DFLT Feed
24	1-2-3-4 Clutch DFLT
25	1-2-3-4 Clutch Feed
26	1-2-3-4 Clutch
27	1-2-3-4 Clutch Feedback
28	CBR1/CBR Feed
29	CBR1
30	CBR
31	CBR1/4-5-6 Clutch Feed
32	CBR1 Feedback
33	4-5-6 Clutch Feed
34	4-5-6 Clutch
35	CSV2 Latch
36	Drive Brake
37	3-5 Reverse Feed
38	PCS TCC
39	PCS 1-2-3-4 Clutch
40	PS4
41	PS1
42	PS3
43	PS5
44	2-6 Clutch/1-2-3-4 CL Feed
45	PCS 3-5 Rev Clutch
46	2-6 Clutch
47	PCS 2-6 Clutch
48	PCS CBR1/4-5-6 Clutch
49	PSC Line
50	Exhaust BF
51	Exhaust
52	Empty
54	3-5 Clutch Reverse Feed

Control Valve Body Spacer Plate Assembly - Bottom Channel Plate Side

cardiagn.com




Fig. 27: Control Valve Body Spacer Plate Assembly - Bottom Channel Plate Side
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
2	Line
8	Cooler Feed
9	Center Lube
10	Regulator Apply
11	Compensator Feed
12	Actuator Feed Limit
13	Reverse
14	3-5 Reverse Clutch
15	3-5 Reverse Clutch Feedback
16	CSV2 Enable
17	Solenoid 1
18	Solenoid 2
19	CSV3 Enable
21	Drive 1-6
24	1-2-3-4 Clutch DFLT
25	1-2-3-4 Clutch Feed
26	1-2-3-4 Clutch
27	1-2-3-4 Clutch Feedback
28	CBR1/CBR Feed
29	CBR1
30	CBR
31	CBR1/4-5-6 Clutch Feed

cardiagn.com

Callout	Component Name
32	CBR1 Feedback
34	4-5-6 Clutch
35	CSV2 Latch
36	Drive Brake
37	3-5 Reverse Feed
38	PCS TCC
39	PCS 1-2-3-4 Clutch
40	PS4
41	PS1
42	PS3
43	PS5
44	2-6 Clutch/1-2-3-4 CL Feed
45	PCS 3-5 Rev Clutch
46	2-6 Clutch
47	PCS 2-6 Clutch
48	PCS CBR1/4-5-6 Clutch
49	PCS Line
50	Exhaust BF
51	Exhaust
53	3-5 Rear Feed
54	3-5 Clutch Reverse Feed

Article GUID: A00854546

cardiagn.com

DIAGNOSTIC INFORMATION AND PROCEDURES

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

DTC P0601, P0603, P0604, OR P062F: CONTROL MODULE MEMORY

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0601

Control Module Read Only Memory Performance

DTC P0603

Control Module Long Term Memory Reset

DTC P0604

Control Module Random Access Memory Performance

DTC P062F

Control Module Long Term Memory Performance

Circuit/System Description

This is an internal fault detection of the control solenoid valve assembly. This fault is carried out inside the Transmission Control Module and no external circuits are involved.

Conditions for Running the DTC

DTC P0601, P0603, P0604, or P062F is not set.

Conditions for Setting the DTC

P0601

cardiagn.com

- The read only memory has detected an incorrect program or calibration checksum error.
- This condition has been present 5 or more times within a 16 count time period.

P0603

- The TCM has detected a long term memory checksum error during power up.
- This DTC runs continuously.

P0604

- The TCM has detected a single word failure with the random access memory.
- This condition has been present 5 or more times within a 16 count time frame.

P062F

- The TCM has detected the non-volatile memory is incorrect during power-down.
- This DTC runs continuously.

Action Taken When the DTC Sets

P0601, P0603, P0604, and P062F

- The high side driver is turned Off.
- The TCC is turned Off.
- The TCM request maximum line pressure.
- The ECM reduces engine torque based on transmission input speed.
- Neutral idle is inhibited.
- Tap Up/Down is inhibited.
- Tow/Haul mode is inhibited.

Conditions for Clearing the DTC

DTCs P0601, P0603, P0604, and P062F are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

Electronic Component Description

Electrical Information Reference

cardiagn.com

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Ignition OFF for one minute. Ignition ON.
2. Verify with a scan tool that DTC P0601, P0603, P0604, or P062F is not set.
   - **If any of the DTCs set**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If none of the DTCs set**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Replace the Q8 Control Solenoid Valve Assembly

   - **If the DTC does not set**
5. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0634: CONTROL MODULE OVERTEMPERATURE

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

cardiagn.com

DTC P0634

Control Module Overtemperature

Circuit/System Description

The transmission control module temperature sensor is located inside of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module monitors the Transmission Control Module sensor for over temperature protection.

Conditions for Running the DTC

- Ignition voltage is between 8.6-32 V.
- The TCM internal temperature is between 0-170Â°C (32-338Â°F) for 0.25 s.

Conditions for Setting the DTC

Condition 1

The internal temperature of the TCM is greater than 142Â°C (288Â°F) for 5 s.

Condition 2

- Ignition voltage is 18 V or greater for 2 s.
- The internal temperature of the TCM is greater than 50Â°C (122Â°F) for 2 s.

Action Taken When the DTC Sets

- DTC P0634 is a Type A DTC.
- TCM disables TAP Up/Down shift operation.
- TCM enables torque management.
- TCM limits the transmission to Reverse and 4th or 5th gear operation.
- TCM inhibits manual shifting of forward gears.
- TCM commands maximum line pressure.
- TCM turns Off.

Conditions for Clearing the DTC

DTC P0634 is a Type A DTC.

Diagnostic Aids

During a road test, the TCM temperature should steadily increase to a normal operating temperature, then stabilize.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

cardiagn.com

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

Electronic Component Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
    - **If the transmission fluid level and condition is not correct**

      Repair as necessary.

    - **If the transmission fluid level and condition is correct**
2. Operate the vehicle until normal engine temperature is reached.
3. Verify with a scan tool the ECT Sensor parameter is less than 125Â°C (257Â°F).
    - **If greater than 125Â°C (257Â°F)**

      Refer to **Symptoms - Engine Cooling** .

    - **If less than 125Â°C (257Â°F)**
4. Verify the scan tool Transmission Control Module Temperature is less than 142Â°C (287Â°F).
    - **If greater than 142Â°C (287Â°F)**

      Inspect the transmission fluid lines for being misrouted, kinked, or damage. Repair or replace as necessary. If the transmission fluid lines are OK, replace the Q8 Control Solenoid Valve Assembly.

    - **If less than 142Â°C (287Â°F)**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.

cardiagn.com

- **If the DTC sets**

  Replace the Q8 Control Solenoid Valve Assembly.

- **If the DTC does not set**

7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LV3)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L83, L86 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LC8, L96 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L86 with M5U)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L8B)** .
- **Control Module References** for Control Solenoid Valve Assembly replacement, programming, and setup.

DTC P0658 OR P0659: ACTUATOR HIGH CONTROL CIRCUIT GROUP 1

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0658

Actuator High Control Circuit Group 1 Low Voltage

DTC P0659

Actuator High Control Circuit Group 1 High Voltage

Circuit/System Description

The Transmission Control Module high side driver 1 is located inside of the control solenoid valve assembly which has no serviceable parts. The high side driver 1 provides power to the Transmission Control Module pressure control solenoids and shift solenoids. This fault is handled inside the Transmission Control Module and no external circuits are involved.

Conditions for Running the DTC

P0658

- Ignition voltage is between 8.6-32 V.
- High side driver 1 is On.
- DTC P0658 is not set.

cardiagn.com

P0659

- DTC P0659 is not set.
- Ignition switch transitions from OFF to ON position.

Conditions for Setting the DTC

P0658

The Transmission Control Module detects an internal open or short to ground on the high side driver 1 for 1 s.

P0659

The Transmission Control Module detects an internal short to voltage on the high side driver 1 circuit for 1 s after engine start.

Action Taken When the DTC Sets

P0658

- DTC P0658 is a Type A DTC.
- The TCM turns OFF high side driver.
- The TCM turns OFF all solenoids.
- The TCM commands maximum line pressure.
- The TCM freezes transmission adaptive functions.
- The TCM commands the TCC OFF.
- The TCM inhibits the TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM limits the transmission to Reverse and 5th gear.

P0659

DTC P0659 is a Type C DTC.

Conditions for Clearing the DTC

- DTC P0658 is a Type A DTC.
- DTC P0659 is a Type C DTC.

Diagnostic Aids

When DTC P0658 sets, the line pressure control solenoid, and pressure control solenoids 2 and 3, will default to maximum pressure. This results in maximum line pressure to the 3-5 reverse clutch, low/reverse clutch and the 4-5-6 clutch assemblies.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

cardiagn.com

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine running and the gear selector lever is in the park position.
2. Verify the scan tool High Side Driver 1 parameter displays ON.
    - **If ON is not displayed**

      Refer to Circuit/System Testing.

    - **If ON is displayed**
3. Engine Running and the gear selector lever is in the park position.
4. Verify the scan tool parameters listed below do not display Malfunction.
    - High Side Driver 1 Circuit High Voltage Test Status
    - High Side Driver 1 Circuit Open Test Status
    - High Side Driver 1 Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Refer to Circuit/System Testing.

    - **If Malfunction is not displayed**

cardiagn.com

5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
    - **If contaminated**

      Repair as necessary.

    - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
    - **If resistance is not within range**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters do not display Malfunction.
    - High Side Driver 1 Circuit High Voltage Test Status
    - High Side Driver 1 Circuit Open Test Status
    - High Side Driver 1 Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.

cardiagn.com

- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0667, P0668, OR P0669: CONTROL MODULE TEMPERATURE SENSOR

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0667

Control Module Temperature Sensor Performance

DTC P0668

Control Module Temperature Sensor Circuit Low Voltage

DTC P0669

Control Module Temperature Sensor Circuit High Voltage

Circuit/System Description

The Transmission Control Module temperature sensor is located inside of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module temperature sensor provides the temperature of the Transmission Control Module substrate. This temperature reading is used in various diagnostic routines in the Transmission Control Module software. This fault is handled inside the Transmission Control Module and no external circuits are involved.

Conditions for Running the DTC

DTC P0667

- DTC: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, or P2730 is not set.
- Engine speed is 400-7,500 RPM or greater for 5 s.
- Ignition voltage is between 8.6-32 V.
- Brake torque is not active.
- Engine torque signal is valid.
- Throttle position signal is valid.

DTC P0668

- Engine speed is 400-7,500 RPM or greater for 5 s.
- Ignition voltage is between 8.6-32 V.

DTC P0669

cardiagn.com

- DTC P0716, P0717, P0722 or P0723 is not set.
- Engine speed is 400-7,500 RPM or greater for 5 s.
- Ignition voltage is between 8.6-32 V.

Conditions for Setting the DTC

P0667

- The TCM detects a 20-50Â°C (36-90Â°F) or greater difference between the transmission fluid temperature and the TCM substrate temperature, which depends on the average of the transmission fluid temperature, TCM substrate temperature, and the TCM power up temperature.
- The TCM detects a 8-10Â°C (14-18Â°F) or greater difference between the TCM power up temperature and the TCM substrate temperature, which depends on the average of the transmission fluid temperature, the TCM substrate temperature, and the TCM power up temperature.
- The above conditions have to be met for 5 min.

P0668

The TCM internal temperature is -249Â°C (-416Â°F) or less for 1 min.

P0669

The TCM internal temperature is 249Â°C (480Â°F) or greater for 1 min.

Action Taken When the DTC Sets

- DTCs P0667, P0668, and P0669 are Type B DTCs.
- The TCM defaults to a calculated value for the substrate temperature based on the TCM power up temperature.

Conditions for Clearing the DTC

DTCs P0667, P0668, and P0669 are Type B DTCs.

Diagnostic Aids

During a road test, the TCM temperature should steadily increase to a normal operating temperature, and then stabilize.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**

cardiagn.com

- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Circuit/System Verification

1. Engine idling at normal operating temperature.
2. Verify the scan tool Transmission Control Module Temperature parameter is between -247 and +247Â°C (-412 and +477Â°F).
   - **If not between -247 and +247Â°C (-412 and +477Â°F)**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If between -247 and +247Â°C (-412 and +477Â°F)**
3. Verify the scan tool Transmission Control Module temperature parameter increases greater than 2Â°C (3.5Â°F) after operating the vehicle at 64 km/h (40 mph) for 10 minutes.
   - **If the temperature does not increase greater than 2Â°C (3.5Â°F)**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If the temperature does increase greater than 2Â°C (3.5Â°F)**
4. Verify the scan tool Transmission Control Module Temperature and the Transmission Fluid Temperature parameters are within 10Â°C (18Â°F) of each other.
   - **If the temperature is not within 10Â°C (18Â°F)**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If the temperature is within 10Â°C (18Â°F)**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If the DTC does not set**

cardiagn.com

7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P06AC, P06AD, OR P06AE: CONTROL MODULE POWER UP TEMPERATURE SENSOR

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P06AC

Control Module Power Up Temperature Sensor Performance

DTC P06AD

Control Module Power Up Temperature Sensor Circuit Low Voltage

DTC P06AE

Control Module Power Up Temperature Sensor Circuit High Voltage

Circuit/System Description

The Transmission Control Module power up temperature sensor is located inside of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module power up temperature sensor provides the temperature of the Transmission Control Module when the Transmission Control Module power is on. This temperature reading is used in various shifting and diagnostic routines and also to protect the control solenoid valve assembly and Transmission Control Module. This fault is handled inside the Transmission Control Module and no external circuits are involved.

Conditions for Running the DTC

P06AC

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, or P2730 is not set.
- Engine speed is between 400-7,500 RPM for 5 s.
- Ignition voltage is between 8.6-32 V.
- Brake torque is not active.
- Engine speed is valid.

cardiagn.com

- Throttle position is valid.
- Transmission input speed sensor signal is 200 RPM or less.
- Engine throttle position signal is 30 percent or greater.
- Vehicle speed is 8 km/h (5 mph) or less.

P06AD

- DTC P06AD, P0716, P0717, P0722 or P0723 is not set.
- Engine speed is between 400-7,500 RPM for 5 s.
- Ignition voltage is between 8.6-32 V.

P06AE

- DTC P06AE is not set.
- Engine speed is 400 RPM or greater for 5 s.
- Ignition voltage is between 8.6-32 V.

Conditions for Setting the DTC

P06AC

- The TCM detects a 8-10Â°C (14-18Â°F) or greater difference between the TCM substrate temperature and TCM power up temperature, which depends on the average of transmission fluid temperature, TCM substrate temperature, and TCM power up temperature.
- The TCM detects a 20-50Â°C (36-90Â°F) or greater difference between the transmission fluid temperature and TCM power up temperature, which depends on the average of transmission fluid temperature, TCM substrate temperature, and TCM power up temperature.
- The above conditions have to be met for 5 min within a 6 min period.

P06AD

The TCM power up temperature is -59Â°C (-74Â°F) or less for 1 min.

P06AE

The TCM power up temperature is 164Â°C (327Â°F) or greater for 1 min.

Action Taken When the DTC Sets

- DTCs P06AC, P06AD, and P06AE are Type B DTCs.
- The TCM defaults the TCM power up temperature to the TCM substrate temperature with an offset value.

Conditions for Clearing the DTC

DTCs P06AC, P06AD, and P06AE are Type B DTCs.

Diagnostic Aids

During a road test, the TCM Power-Up temperature should steadily increase to a normal operating temperature, and then stabilize.

cardiagn.com

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

Electronic Component Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Ignition ON, clear the DTCs with a scan tool.
2. Operate the vehicle at 64 km/h (40 mph) for 10 min.
3. Verify DTC P06AC, P06AD or P06AE is not set.
    - **If any of the DTCs set**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If none of the DTCs set**
4. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
5. Verify the DTC does not set.
    - **If the DTC sets**

cardiagn.com

Replace the Q8 Control Solenoid Valve Assembly.

- **If the DTC does not set**

6. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0711-P0713: TRANSMISSION FLUID TEMPERATURE SENSOR

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0711

Transmission Fluid Temperature Sensor Performance

DTC P0712

Transmission Fluid Temperature Sensor Circuit Low Voltage

DTC P0713

Transmission Fluid Temperature Sensor Circuit High Voltage

Circuit/System Description

The transmission fluid temperature sensor is located inside of the Transmission Control Module assembly which has no serviceable parts. The transmission fluid temperature sensor provides transmission fluid temperature information to the Transmission Control Module. This fault is handled inside the Transmission Control Module and no external circuits are involved.

Conditions for Running the DTC

P0711

- DTCs: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, or P2730 is not set.
- Ignition voltage is between 8.6-32 V.
- The engine speed is 400-7,500 RPM or greater for 5 s.
- The vehicle speed is 8 km/h (5 mph) or greater for 5 min.

cardiagn.com

- The accelerator pedal position signal is valid.
- The engine torque signal is valid.

P0712

- DTC P0712, P0716, P0717, P0722, or P0723 is not set.
- The engine speed is greater than 400-7,500 RPM for 5 s.
- Ignition voltage is between 8.6-32 V.

P0713

- DTC P0713, P0716, P0717, P0722, or P0723 is not set.
- The engine speed is greater than 400-7,500 RPM for 5 s.
- Ignition voltage is between 8.6-32 V.

Conditions for Setting the DTC

P0711

- The TCM detects a 20-50Â°C (36-90Â°F) or greater difference between the transmission fluid temperature and the TCM substrate temperature, which depends on the average of the transmission fluid temperature, the TCM substrate temperature, and the TCM power up temperature.
- The TCM detects a 20-50Â°C (36-90Â°F) or greater difference between the transmission fluid temperature and the power up temperature, which depends on the average of the transmission fluid temperature, the TCM substrate temperature, and the TCM power up temperature.
- The above conditions have to be met for 5 min within a 6 min time period.

P0712

The transmission fluid temperature is -74Â°C (-101Â°F) or less for 1 min.

P0713

The transmission fluid temperature is 174Â°C (345Â°F) or greater for 1 min.

Action Taken When the DTC Sets

- DTCs P0711, P0712, and P0713 are Type B DTCs.
- The TCM freezes transmission adaptive functions.
- The TCM allows the vehicle to operate in transmission protection mode.
- The TCM defaults to the TCM temperature with an offset.

Conditions for Clearing the DTC

DTCs P0711, P0712, and P0713 are Type B DTCs.

Diagnostic Aids

During a road test, the transmission fluid temperature should steadily increase to a normal operating temperature, and then stabilize.

cardiagn.com

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825 Control Solenoid Test Plate

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine idling at normal operating temperature.
2. Verify the scan tool Transmission Fluid Temperature parameter is between -74 and +174Â°C (-101 and +345Â°F).
   - **If not between -74 and +174Â°C (-101 and +345Â°F)**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If between -74 and +174Â°C (-101 and +345Â°F)**
3. Verify the scan tool Transmission Fluid Temperature parameter increases greater than 2Â°C (3.5Â°F) after operating the vehicle at 64 km/h (40 mph) for 10 minutes.
   - **If the temperature does not increase greater than 2Â°C (3.5Â°F)**

cardiagn.com

Replace the Q8 Control Solenoid Valve Assembly.

- **If the temperature does increase greater than 2Â°C (3.5Â°F)**

4. Verify the scan tool Transmission Fluid Temperature and the Transmission Control Module Temperature parameters are within 20Â°C (68Â°F) of each other.
   - **If the temperatures are not within 20Â°C (68Â°F)**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If the temperatures are within 20Â°C (68Â°F)**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If the DTC does not set**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0716 OR P0717: INPUT SPEED SENSOR

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0716

Input Speed Sensor Performance

DTC P0717

Input Speed Sensor Circuit No Signal

Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
9 V Reference	P0716, P0717	P0716, P0717	-	P0716
Signal	P0716, P0717	P0716, P0717	P0716, P0717	P0716

cardiagn.com

Typical Scan Tool Data

ISS Signal

Circuit	Short to Ground	Open	Short to Voltage
Operating Conditions: Engine running, normal operating temperature **Parameter Normal Range:** 450-7000 RPM			
9 V Reference	0 RPM	0 RPM	-
ISS Signal	0 RPM	0 RPM	0 RPM

ISS/OSS Supply Voltage

Circuit	Short to Ground	Open/High Resistance	Short to Voltage
Operating Conditions: Key ON, Engine OFF or Engine running, normal operating temperature **Parameter Normal Range:** OK			
9 V Reference	Out of Range	OK	Out of Range
Signal	OK	OK	OK

Circuit/System Description

The automatic transmission input and output speed sensor (ISS and OSS) assembly each are part of a single harness. The ISS is a hall-effect type sensor. The ISS/OSS mounts to the control valve upper body assembly. The ISS sensor end faces the splines on the 1-2-3-4 and 3-5-R clutch housing outside diameter surface. The sensor receives 9 volts on the ISS/OSS supply voltage circuit from the control solenoid valve assembly. As the 1-2-3-4 and 3-5-R clutch housing rotates, the sensor produces a signal frequency based on the splines on the clutch housing outside diameter surface. This signal is transmitted through the ISS signal circuit to the control solenoid valve assembly. The control solenoid valve assembly uses the ISS signal to determine line pressure, transmission shift patterns, torque converter clutch (TCC) slip speed and gear ratio.

Conditions for Running the DTC

P0716

- DTC P0101, P0102, P0103, P0121, P0122, P0123, P0717, P0752, P0753, or P0974 is not set.
- The engine speed is 400-7,500 RPM or greater for 5 s.
- The engine torque signal is valid.
- Engine torque is between 0 (0 lb ft) and 8191.88 (6042.01 lb ft).
- Ignition voltage is between 9-17.5 V.
- The vehicle speed is greater than 10 km/h (6.21 mph).
- The throttle position signal must be valid.

P0717

- DTC P0101, P0102, P0103, P0722 or P0723 is not set.
- The engine speed is 400-7,500 RPM or greater for 5 s.
- Ignition voltage is between 9-17.5 V.
- The engine torque signal is valid.
- The vehicle speed is greater than 16 km/h (10 mph).
- The engine torque is between 50 (37 lb ft) and 8191.88 (6042.01 lb ft).

cardiagn.com

Conditions for Setting the DTC

P0716

The TCM detects the transmission input speed sensor signal dropped greater than 900 RPM for 1 s.

P0717 - Condition 1

The TCM detects the transmission input shaft speed is less than 67 RPM for 5 s.

P0717 - Condition 2

The TCM detects that P0722 set and the transmission input speed is less than 653 RPM for 5 s.

Action Taken When the DTC Sets

P0716

- DTC P0716 is a Type A DTC.
- The high side driver is turned Off.
- The TCM commands TCC Off.
- The ECM reduces engine torque based on transmission input speed.
- The TCM inhibits Tap Up/Down.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits Tow/Haul mode.

P0717

- DTC P0717 is a Type A DTC.
- The TCM inhibits shift adaptive functions.
- The TCM commands maximum line pressure.
- The ECM reduces engine torque based on transmission input speed.
- The TCM inhibits neutral idle.
- The TCM inhibits Tap Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits manual shifting of forward gears.
- The TCM commands neutral gear if the output speed sensor signal is 1,500 RPM or greater.
- The TCM commands second gear if the output speed sensor signal is less than 1,500 RPM.

Conditions for Clearing the DTC

DTC P0716 and P0717 are Type A DTCs.

Diagnostic Aids

Inspect the ISS/OSS, harness, connector, and control solenoid valve assembly for metallic debris and the 1-2-3-4 and 3-5-R clutch housing splines on the outside diameter surface for damage or misalignment. Proper torque of the ISS/OSS mounting bolt is critical to proper speed signal operation.

Reference Information

cardiagn.com

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

Electronic Component Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825-10** Jumper Harness
- **J-38522** Variable Signal Generator

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Ignition ON.
2. Verify the scan tool ISS/OSS Supply Voltage parameter displays OK.
    - **If OK is not displayed**

      Refer to Circuit/System Testing.

    - **If OK is displayed**
3. Engine idling in park position.
4. Verify the scan tool Transmission ISS parameter varies with engine RPM and does not drop out.
    - **If the Transmission ISS does not vary with engine speed or drops out**

      Refer to Circuit/System Testing.

    - **If the Transmission ISS does vary with engine speed and does not drop out**

cardiagn.com

5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Ignition Off, remove the Q8 Control Solenoid Valve Assembly.
2. Connect the **DT-47825-10** Jumper Harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector.
3. Disconnect the B14A/B14C Transmission Input and Output Speed Sensor harness connector X3 at the Q8 Control Solenoid Valve Assembly. Ignition ON.
4. Test for 8.8-9.2 V between the 9 V reference circuit terminal B at the Q8 Control Solenoid Valve Assembly and ground.
    - **If not between 8.8-9.2 V**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If between 8.8-9.2 V**
5. Ignition Off, connect the red lead of the **J-38522** Variable Signal Generator to the ISS signal circuit terminal A at the Q8 Control Solenoid Valve Assembly and ground at the transmission case.
6. Set the **J-38522** Variable Signal Generator to the following specifications:
    - Signal Switch to 8 V
    - Frequency switch to 300
    - Duty cycle switch to the 50 or the Normal position
7. Ignition On.
8. Verify the scan tool Transmission ISS parameter is between 760-785 RPM.
    - **If not between 760-785 RPM**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If between 760-785 RPM**
9. Verify there is no damage or misalignment with the machined teeth on the 1-2-3-4 and 3-5 clutch housing.
    - **If the machined surfaces are damaged or misaligned**

      Repair or replace as necessary.

    - **If the machined surfaces are not damaged or misaligned**
10. Replace the B14A/B14C Transmission Input and Output Speed Sensor.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

cardiagn.com

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Perform the **Input and Output Speed Sensor Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup
- Perform the **Control Solenoid Valve and Transmission Control Module Assembly Input Shaft Speed/Output Shaft Speed Input Test**.

DTC P071A: TRANSMISSION TOW MODE SWITCH

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

DTC P071A

Transmission Tow Mode Switch Circuit

Circuit/System Description

Tow/haul mode enables the operator to achieve enhanced shift performance when towing or hauling a load. When tow/haul mode is selected, the tow/haul switch input signal to the body control module (BCM) is momentarily toggled from 12 volts to zero volts. The BCM then sends a signal out on the serial data line to the transmission control module (TCM) to increase transmission line pressure and extend the time between upshifts. Selecting the tow/haul switch again disables tow/haul mode and returns the transmission to a normal shift pattern.

Conditions for Running the DTC

- DTC P1762 is not set.
- The engine speed is greater than 400 RPM for 5 seconds.
- The ignition voltage is 8.6 volts or greater.

Conditions for Setting the DTC

The Tow/Haul Mode switch remains closed, in a low voltage condition, for 10 seconds.

Action Taken When the DTC Sets

DTC P071A is a Type C DTC.

Conditions for Clearing the DTC

DTC P071A is a Type C DTC.

Diagnostic Aids

If the electrical circuit tests are OK and the shift pattern is not occurring, there may be a mechanical/hydraulic condition that prevents operation. Refer to **Symptoms - Automatic Transmission**.

Reference Information

cardiagn.com

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

COMPONENT CONNECTOR END VIEWS - INDEX

Description and Operation

Electronic Component Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Circuit/System Verification

1. Ignition ON, cycle the S74 Tow/Haul Mode switch while observing the Tow/Haul switch parameter on the scan tool in the Transmission Controls Data list. The S74 Tow/Haul Mode switch parameter should change states from Inactive to Active with each cycle of the switch.
    - **If the Tow/Haul Mode switch parameter does not change from Inactive to Active**

      Refer to Circuit/System Testing.

    - **If the Tow/Haul Mode switch parameter does change from Inactive to Active**
2. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
3. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
4. All OK.

Circuit/System Testing

1. Ignition OFF, transmission in Park. Disconnect the S3 transmission shift lever electrical connector.
2. Ignition OFF, test for less than 1 Ω between terminal 2 on the S3 transmission shift lever vehicle harness

cardiagn.com

connector and ground at the battery negative post.

- **If 1 Ω or greater**

1. Ignition OFF.
2. Test for less than 1 Ω in the ground circuit wire, end to end.
    - If 1 Ω or greater, repair the open/high resistance in the wire circuit.
    - If less than 1 Ω, repair the open/high resistance in the ground connection or the terminal connection at the S3 transmission shift lever.

- **If less than 1 Ω**

3. Ignition ON, test for greater than 11 volts on the signal circuit terminal 1 on the S3 transmission shift lever vehicle harness connector and ground at the battery negative post.

- **If less than 11 volts**

1. Ignition OFF.
2. Test for less than 1 Ω in the signal circuit wire, end to end.
    - If 1 Ω or greater, repair the open/high resistance in the signal circuit wire.
    - If less than 1 Ω, repair the open/high resistance in either terminals on the signal circuit wire.

- **If greater than 11 volts**

4. Ignition OFF, test for less than 3 ohms between terminal 1 and terminal 2 on the S3 transmission shift lever component harness connector while depressing the S74 Tow/Haul Mode switch button.

- **If greater than 3 Ω**

  Replace the S3 transmission shift lever assembly.

- **If less than 3 Ω**

5. If all circuits test normal, replace the K9 body control module.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Automatic Transmission Range Selector Lever Replacement**
- **Control Module References** for BCM replacement, programming, and setup.

DTC P0722 OR P0723: OUTPUT SPEED SENSOR

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0722

Output Speed Sensor Circuit No Signal

DTC P0723

cardiagn.com

Output Speed Sensor Circuit Intermittent

Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
9 V Reference	P0722, P0723	P0722, P0723	-	P0723
Signal	P0722, P0723	P0722, P0723	P0722, P0723	P0723

Typical Scan Tool Data

Output Speed Sensor (OSS) Signal

Circuit	Short to Ground	Open/High Resistance	Short to Voltage
Operating Conditions: Engine running, normal operating temperature **Parameter Normal Range:** 0-7000 RPM			
9 V Reference	0 RPM	0 RPM	0-7000 RPM
OSS Signal	0 RPM	0 RPM	0 RPM

ISS/OSS Supply Voltage

Circuit	Open/High Resistance	Short to Voltage
Operating Conditions: Key ON, engine OFF or engine running **Parameter Normal Range:** OK		
9 V Reference	OK	Out of Range
Signal	Out of Range	-

Circuit/System Description

The automatic transmission input and output speed sensor (ISS and OSS) assembly each are part of a single harness. The OSS is a hall-effect type sensor. The ISS/OSS mounts to the control valve upper body assembly. The sensor end faces the output shaft housing machined slots. The sensor receives 9 volts on the ISS/OSS supply voltage circuit from the control solenoid valve assembly. As the output shaft rotates, the sensor produces a signal frequency based on the machined slots of the output shaft housing. This signal is transmitted through the OSS signal circuit to the control solenoid valve assembly. The control solenoid valve assembly uses the OSS signal to determine line pressure, transmission shift patterns, torque converter clutch (TCC) slip speed and gear ratio.

Conditions for Running the DTC

P0722

- DTC P0101, P0102, P0103, P0121, P0122, P0123, P0716, P0717, or P0723 is not set.
- Ignition voltage is between 9-17.5 V.
- The transmission fluid temperature is -40Â°C (-40Â°F) or greater.
- The engine speed is 400-7,500 RPM or greater for 5 s.
- The engine torque signal is valid.
- The engine torque is 50 (36.87 lb ft) or greater.
- Accelerator pedal position signal is valid.
- The throttle position signal is valid.
- The throttle position is 8 percent or greater.

cardiagn.com

P0723

- DTC P0101, P0102, P0103, P0121, P0122, P0123, P0973, P0974, P0976, or P0977 is not set.
- Ignition voltage is between 9-17.5 V.
- The engine speed is 400-7,500 RPM for 5 s.
- Greater than 5 s since the last transmission upshift or downshift.
- The TCM must receive a valid torque signal from the ECM.
- Accelerator pedal position signal is valid.

Conditions for Setting the DTC

P0722

The transmission output speed is 35 RPM or less for 4.5 s.

P0723

- The transmission output speed is greater than 105 RPM.
- The TCM detects the transmission output speed dropped is greater than 650 RPM for 1.5 s.
- The transmission is in a forward drive gear.

Action Taken When the DTC Sets

P0722

- DTC P0722 is a Type A DTC.
- The TCM turns Off the TCC.
- The TCM commands maximum line pressure.
- The ECM reduces engine torque based on input speed.
- The TCM inhibits Tap up/Down function.
- The TCM inhibits manual shifting of all forward gears.
- The TCM commands neutral gear if the output speed sensor signal is 1,350 RPM or greater.
- The TCM commands 2nd gear if the output speed sensor signal is less than 1,350 RPM.

P0723

- DTC P0723 is a Type A DTC.
- The high side driver is turned OFF.
- The TCM inhibits TCC.
- The TCM commands maximum line pressure.
- The ECM reduces engine torque based on the signal from the input speed sensor signal.
- The TCM inhibits neutral idle.
- The TCM inhibits Tap up/Down function.
- The TCM inhibits manual shifting.

Conditions for Clearing the DIC/DTC

cardiagn.com

DTCs P0722 and P0723 are Type A DTCs.

Diagnostic Aids

Inspect the ISS/OSS, harness, connector and control solenoid valve assembly for metallic debris and output shaft housing machined slots for damage or misalignment. Proper torque of the ISS/OSS mounting bolt is critical to proper speed sensor operation.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

Electronic Component Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825-10** Jumper Harness
- **J-38522** Variable Signal Generator

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Ignition ON.
2. Verify the scan tool ISS/OSS Supply Voltage parameter displays OK.
    - **If OK is not displayed**

      Refer to Circuit/System Testing.

cardiagn.com

- **If OK is displayed**

3. Road test the vehicle.
4. Verify the scan tool Transmission OSS parameter changes with vehicle speed and does not drop while operating the vehicle within 16-32 km/h (10-20 mph).
   - **If the Transmission OSS does not vary with engine speed or drops out**

     Refer to Circuit/System Testing.

   - **If the Transmission OSS does vary with engine speed and does not drop out**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Ignition Off, remove the Q8 Control Solenoid Valve Assembly.
2. Connect the **DT-47825-10** Jumper Harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector.
3. Disconnect the B14A/B14C Transmission Input and Output Speed Sensor harness connector X3 at the Q8 Control Solenoid Valve Assembly. Ignition ON.
4. Test for 8.8-9.2 V between the 9 V reference circuit terminal B at the Q8 Control Solenoid Valve Assembly and ground.
   - **If not between 8.8-9.2 V**

     Replace the Q8 Control Solenoid Valve Assembly

   - **If between 8.8-9.2 V**
5. Ignition Off, connect the red lead of the **J-38522** Variable Signal Generator to the signal circuit terminal C at the Q8 Control Solenoid Valve Assembly and ground at the transmission case.
6. Set the **J-38522** Variable Signal Generator to the following specifications:
   - Signal Switch to 8 V
   - Frequency switch to 300
   - Duty cycle switch to the 50 or the Normal position
7. Ignition On.
8. Verify the scan tool Transmission OSS parameter is between 495-505 RPM.
   - **If not between 495-505 RPM**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If between 495-505 RPM**
9. Verify there is no damage or misalignment with the machined slots on the Output Shaft Assembly.

cardiagn.com

- **If the machined slots are damaged or misaligned**

  Repair or replace as necessary.

- **If the machined slots are not damaged or misaligned**

10. Replace the B14A/B14C Transmission Input and Output Speed Sensor.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Perform the **Input and Output Speed Sensor Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.
- Perform the **Control Solenoid Valve and Transmission Control Module Assembly Input Shaft Speed/Output Shaft Speed Input Test**.

DTC P0741 OR P0742:/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P0741

Torque Converter Clutch (TCC) System - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P0742

Torque Converter Clutch (TCC) System - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The torque converter clutch (TCC) pressure control solenoid is part of the control solenoid valve assembly which has no serviceable parts. The TCC pressure control solenoid is a normally low pressure control solenoid. The TCC pressure control solenoid regulates transmission fluid to the TCC regulator valve in the lower valve body and the TCC control valve in the pump cover. When vehicle operating conditions are appropriate to apply the converter clutch, the Transmission Control Module will increase TCC pressure control current flow (duty cycle) to the TCC solenoid. The TCC pressure control solenoid directs fluid pressure to move the TCC control valve to the apply position, and moves the TCC regulator apply valve to the regulating position. The TCC regulator valve regulates TCC apply fluid pressure proportional to TCC solenoid pressure. When the TCC is fully applied, the engine is coupled directly to the transmission. TCC release is accomplished by the Transmission Control Module decreasing current flow to the TCC pressure control solenoid. This results in decreasing the apply pressure which allows the TCC control valve to move to the release position. The

cardiagn.com

Transmission Control Module calculates torque converter slip speed based on engine speed and transmission input shaft speed.

Conditions for Running the DTC

P0741

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, P0742, P2763, or P2764 is not set.
- Ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission fluid temperature is -6.6 to +130Â°C (+20 to +266Â°F).
- The accelerator pedal position signal is valid.
- The throttle position is greater than 8 percent.
- The TCM must receive a valid torque signal from the ECM.
- The engine torque is greater than 50 N.m (36 lb ft).
- The TCC is commanded ON and PWM duty cycle is greater than 60 percent for 5 s.
- The gear ratios listed below should be in range when the specific gear while the TCC is On:
  - The 2nd gear ratio is between 2.20-2.53.
  - The 3rd gear ratio is between 1.44-1.65.
  - The 4th gear ratio is between 1.07-1.23.
  - The 5th gear is between 0.79-0.91.
  - The 6th gear is between 0.62-0.72.

P0742

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, P0741, P2763, or P2764 is not set.
- DTC P0742 has not passed this key ON.
- Ignition voltage is between 8.6-32 V.
- The engine speed is 400-7,500 RPM for 5 s.
- The transmission fluid temperature is -6.6 to +130Â°C (+20 to +266Â°F).
- The accelerator pedal position signal is valid.
- The throttle position is greater than 8 percent.
- The TCM must receive a valid torque signal from the ECM.
- The engine torque is greater than 115 N.m (85 lb ft).
- The vehicle speed is greater than 16 km/h (10 mph).
- The gear ratio is between 0.62-1.63.
- The commanded gear is 2nd.
- The TCC is commanded OFF.

Conditions for Setting the DTC

cardiagn.com

P0741

- The TCC Pressure is greater than 750 Kpa (109 PSI) for 6 s.
- The TCM detects TCC slip greater than 130 RPM for 5 s when the TCC is commanded ON. This condition must occur 2 times.

P0742

- The TCM detects the TCC slip between -50 and +13 RPM for 6 s when the TCC is commanded OFF.
- The above condition must occur 2 times.

Action Taken When the DTC Sets

P0741

- DTC P0741 is a Type B DTC.
- The TCM inhibits TCC.
- The TCM inhibits high gear in hot mode.
- The TCM freezes transmission adaptive functions.

P0742

- DTC P0742 is a Type A DTC.
- The TCM disables neutral idle.
- The TCM enables high gear in hot mode.
- The TCM freezes transmission adaptive functions.

Conditions for Clearing the DIC/DTC

- DTC P0741 is a Type B DTC.
- DTC P0742 is a Type A DTC.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**

cardiagn.com

- **Transmission Component and System Description**
- **Transmission General Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825 Control Solenoid Test Plate

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the Transmission Control Module DTCs with a scan tool.

NOTE: **During the road test, the Transmission Control Module must see 2 attempts at Torque Converter lockup.**

4. Verify the transmission operation performs as indicated in the road test instructions and DTCs P0741 or

cardiagn.com

P0742 did not set. Refer to **Road Test**.

- **If DTC P0741 or P0742 set**

  Refer to Circuit/System Testing.

- **If DTC P0741 or P0742 did not set**

5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If pressures are within range**
2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If a pressure change does occur**
4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P0741 or P0742 - A/Trans Fluid Pump cover Assembly (219)

- TCC Control Valve (227) stuck/sticking - debris, binding, damaged valve, or scored bore.
- Converter Feed Limit Valve (220) stuck/sticking - debris, binding, damaged valve, or scored bore.
- Pressure Regulator Valve (233) stuck/sticking - debris, binding, damaged valve, or scored bore.
- Turbine Shaft Bushings (218), (228) damaged or loose.
- Leak between stator/tower assembly and cover.

P0741 - 4-5-6 (w/Turbine Shaft) Housing Assembly (441)

TCC Turbine Shaft O-ring Seal (443) damaged or leaking.

P0741 - Torque Converter Assembly (1)

- TCC friction material debonded or excessively worn.

cardiagn.com

- One way stator clutch distressed.
- Internal leak - missing or damaged seal.
- Overheated due to lack of lubrication/cooler flow.

P0741 or P0742 - Lower Control Valve Body Assembly (351)

- TCC Regulator Apply Valve (355) stuck/sticking - debris, binding, damaged valve, or scored bore. Bore plug (328) undersized or leaking.
- Clutch Select Valve 2 (352) stuck/sticking - debris, binding, damaged valve, or scored bore.

P0741 or P0742 - Q8 Control Solenoid Valve Assembly (314)

TCM incorrectly reporting high OSS, causing early TCC apply or late TCC release.

P0742 - A/Trans Input and Output Speed Sensor Assembly (303)

Incorrect, high, OSS signal, causing early TCC apply or late TCC release.

P0741 - Control Solenoid Valve Assembly (21)

A/Trans Fluid Pump Seal Assembly (18) damaged or leaking.

P0741 - Torque Converter Diagnosis

Refer to **No Torque Converter Clutch Apply**.

P0742 - Torque Converter Diagnosis

Refer to **No Torque Converter Clutch Release**.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0751 OR P0752: SHIFT SOLENOID VALVE 1 PERFORMANCE - STUCK OFF/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P0751

cardiagn.com

Shift Solenoid Valve 1 Performance - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P0752

Shift Solenoid Valve 1 Performance - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The shift solenoid 1 is part of the control solenoid valve assembly which has no serviceable parts. The control solenoid valve assembly is attached to the lower control valve body. The solenoid operates by the Transmission Control Module opening or closing the ground circuit. With the solenoid circuit grounded (solenoid on), the internal plunger and metering ball block the exhaust fluid creating signal fluid pressure. The signal fluid acts against the clutch select valve 2 to overcome the valve spring force moving it to the apply position, allowing the shift. The shift solenoid 1 is commanded ON in Park, Reverse, Neutral and Drive 1 Engine Braking, and commanded OFF in Drive 1-6 gear ranges.

Conditions for Running the DTC

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- Ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The internal mode switch range is not PARK, NEUTRAL or REVERSE.
- High Side Driver is enabled.
- The transmission fluid temperature is -6.6 to +130Â°C (+20 to +266Â°F).
- Accelerator pedal position signal is valid.
- The throttle position signal is valid.
- The output shaft speed is 0 RPM or greater.
- The TCM must receive a valid torque signal from the ECM.

Conditions for Setting the DTC

P0751

- 1st gear is commanded.
- TCM detects a gear ratio of 1.09-1.20.
- Gear slip is greater than 400 RPM for 2 s.
- The above conditions have to occur 8 times to set.

P0752

- 3rd gear is commanded.
- Transmission has achieved 1st or 2nd gear.
- Gear slip is 400 RPM for 1.5 s.
- TCM commands 4th gear if the above condition exist and detects a gear ratio of 3.82-4.22 for 1.5 s.
- The above conditions have to occur 5 times.

Action Taken When the DTC Sets

cardiagn.com

P0751

- DTC P0751 is a Type B DTC.
- TCM inhibits 1st gear.
- TCM inhibits neutral idle.

P0752

- DTC P0752 is a Type A DTC.
- TCM freezes transmission adaptive functions.
- TCM commands maximum line pressure.
- TCM inhibits Tap Up/Down function.
- TCM inhibits manual shifting of forward gears.
- TCM commands second gear if output is less than 1,350 RPM, or neutral if output speed is 1,350 RPM or greater.
- TCM inhibits neutral idle.

Conditions for Clearing the DTC

- DTC P0751 is a Type B DTC.
- DTC P0752 is a Type A DTC.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**

cardiagn.com

- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **J 21867** Pressure Gauge

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. From a stop, accelerate to 72 km/h (45 mph) with the scan tool Calculated Throttle Position greater than 20 percent. Perform this test 8 times.
4. Verify DTC P0751 or P0752 did not set.
   - **If DTC P0751 or P0752 set**

     Refer to Circuit/System Testing.

   - **If DTC P0751 or P0752 did not set**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

cardiagn.com

Refer to Circuit/System Testing.

- **If the DTC does not set**

7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If line pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If line pressures are within range**
2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur for each solenoid**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If a pressure change does occur for each solenoid**
4. Verify the mechanical conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P0751 or P0752 - Lower Control Valve Body

Clutch select valve 2 stuck - debris, sediment, binding or scored bore or valve damage.

P0751 - Lower Control Valve Body

Bore Plug - Clutch Select Valve 2, Leaking, undersized bore plug, or damaged.

P0751 - Upper Control Valve Body

- Check Ball #2 missing, damaged, or leaking.
- Check Ball #2 Seat damaged or leaking.

P0751 or P0752 - Q8 Control Solenoid Valve Assembly

Shift Solenoid 1:

- O-ring seals leaking.
- Control signal fluid supply leak - valve body filter plate assembly cracked or damaged gasket seal.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0756: SHIFT SOLENOID VALVE 2 PERFORMANCE - STUCK OFF

cardiagn.com

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P0756

Shift Solenoid Valve 2 Performance - Stuck Off - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The shift solenoid valve 2 is part of the control solenoid valve assembly which has no serviceable parts. The control solenoid valve assembly is attached to the lower control valve body. The solenoid operates by the Transmission Control Module opening or closing the ground circuit. With the solenoid circuit grounded (solenoid on), the internal plunger and metering ball block the exhaust fluid creating signal fluid pressure. The signal fluid acts against the clutch select valve 3 to overcome the valve spring force moving it to the apply position, allowing the shift. The shift solenoid 2 is commanded OFF in Reverse, and commanded ON in Park, Neutral, Drive 1 Engine Braking, and Drive 1-6 gear ranges.

Conditions for Running the DTC

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- Ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- High Side Driver 1 is enabled.
- The Throttle Position signal voltage is valid.
- Throttle position is 0.5 percent or greater.
- Transmission fluid temperature is -6.6Â°C (20.12Â°F) or greater.
- The Transmission Output Speed is 67 RPM or greater.

Conditions for Setting the DTC

- Commanded gear is 1st locked.
- Transmission gearbox slip is 400 RPM for 10 s.
- The transmission commands 2nd gear if the above condition exists and detects a ratio of 2.72-3.01 for 1 s.
- The above condition has to occur 3 times.

Action Taken When the DTC Sets

- The TCM freezes the shift adapts function.
- The TCM commands maximum line pressure.

cardiagn.com

- The TCM inhibits neutral idle.
- The TCM inhibits Tap Up/Down function.
- The TCM inhibits Tow/Haul function.
- The TCM commands Neutral if the transmission output speed is 1,350 RPM or greater.
- The TCM commands 2nd gear if the transmission output speed is less than 1,350 RPM.

Conditions for Clearing the DTC

DTC P0756 is a Type A DTC.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission Component and System Description**
- **Transmission General Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

cardiagn.com

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **J 21867** Pressure Gauge

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the Transmission Control Module DTCs with a scan tool.

   NOTE: **During the road test, the Transmission Control Module has to see 3 attempts at a 1 through 6 gear shift change.**

4. Verify the transmission operation performs as indicated in the road test instructions and DTC P0756 did not set. Refer to **Road Test**.
   - **If DTC P0756 is set**

     Refer to Circuit/System Testing.

   - **If DTC P0756 did not set**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

cardiagn.com

Refer to **Fluid Pressure High or Low**.

- **If pressures are within range**

2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If a pressure change does occur**
4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P0756 - Lower Control Valve Body (351)

Clutch select valve 3 stuck off - debris, sediment, binding or scored bore.

P0756 - Lower Control Valve Body (351)

Bore Plug - Clutch Select Valve 3 leaking, undersized bore plug, damaged.

P0756 - Upper Control Valve Body (304)

- Check Ball #3 missing, damaged, leaking.
- Check Ball #3 Spacer plate seat damaged, leaking.

P0756 - Q8 Control Solenoid Valve Assembly (314)

Shift Solenoid (SS) 2:

- O-ring seals leaking.
- Control signal fluid supply leak - valve body filter plate assembly cracked or damaged gasket seal.

P0756 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

1-2-3-4 clutch backing plate retaining ring not seated, causing the piston to over travel and cut the 1-2-3-4 clutch piston seal.

P0756 - Fluid Pump Cover Assembly

Fluid pump cover vanes and fluid pump rotor broken.

P0756 - Low Clutch Sprag Assembly

Broken or incapable of holding torque.

P0756 - Pump Seal

Seal is cut, torn causing a leak due to pump speed and capacity.

Repair Instructions

cardiagn.com

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0776 OR P0777: PRESSURE CONTROL SOLENOID VALVE 2 - STUCK OFF/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P0776

Pressure Control Solenoid Valve 2 - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P0777

Pressure Control Solenoid Valve 2 - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The clutch pressure control solenoid valve 2 is part of the control solenoid valve assembly, which has no serviceable parts. The pressure control solenoid valve 2 regulates transmission fluid pressure to the 3-5-Reverse clutch regulator valve which controls pressure to the 3-5-Reverse clutch. The Transmission Control Module calculates gear ratio based on the RPM signals from the input speed sensor (ISS) and the output speed sensor (OSS). The Transmission Control Module compares the expected transmission gear ratio to the calculated gear ratio for each commanded gear.

Conditions for Running the DTC

P0776

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor is 67 RPM or greater or the accelerator pedal position sensor is 0.5 percent or greater.

cardiagn.com

P0777

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor is 67 RPM or greater or the accelerator pedal position sensor is 0.5 percent or greater.

Conditions for Setting the DTC

P0776

The Transmission Control Module has detected an incorrect gear ratio or neutral condition when the 3-5-R clutch is commanded ON. This condition must occur 3 times.

P0777

The Transmission Control Module has detected an incorrect gear ratio change when the 3-5-R clutch is commanded OFF during a shift or when 3rd gear ratio is detected in 1st gear. This condition must occur 3 times.

Action Taken When the DTC Sets

P0776

- DTC P0776 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM inhibits auto grade braking.
- The TCM limits the transmission to 2nd gear if the output speed sensor signal is less than 1,400 RPM. No upshift will occur.
- The TCM limits the transmission to 4th gear if the output speed sensor signal is 1,400 RPM or greater.

P0777

- DTC P0777 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.

cardiagn.com

- The TCM limits the transmission to Reverse gear and 3rd gear operation.
- The TCM inhibits auto grade braking.

Conditions for Clearing the DIC/DTC

DTCs P0776 and P0777 are Type A DTCs.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

cardiagn.com

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **J 21867** Pressure Gauge

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the Transmission Control Module DTCs with a scan tool.
4. Verify the transmission operation performs as indicated in the road test instructions and DTCs P0776 or P0777 did not set. Refer to **Road Test**.
   - **If DTCs P0776 or P0777 are set**

     Refer to Circuit/System Testing.

   - **If DTCs P0776 or P0777 did not set**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If pressures are within range**
2. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control**

cardiagn.com

Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test.

- **If a pressure change does not occur**

  Replace the Q8 Control Solenoid Valve Assembly.

- **If a pressure change does occur**

4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P0776 - Control Valve Upper Body Assembly (304)

3-5-R Regulator Valve (336) stuck/sticking - debris, binding, damaged valve, or scored bore.

P0776 or P0777 - Q8 Control Solenoid Valve Assembly (314)

- O-ring seals leaking.
- Valve body filter plate assembly cracked, blocked or damaged gasket seal.

P0776 or P0777 - Control Valve Upper Body Assembly (304)

- Actuator feed limit circuit supply fluid to solenoids restricted or not available, debris or sediment blockage.
- B-R-1/4-5-6 clutch regulator valve (327) not in the applied position - debris, binding, damaged valve, or scored bore.
- 4-5-6 clutch boost valve (329) not exhausting - debris, binding, damaged valve, or scored bore.

P0776 or P0777 - Torque Converter (w/Fluid Pump) Housing Assembly (2)

Fluid pump housing vanes/rotor/slide damaged/scored.

P0776 or P0777 - A/Trans Fluid Pump Cover Assembly (219)

Isolator valve (236) stuck/sticking - debris, binding, damaged valve, or scored bore.

P0776 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

3-5-R clutch backing plate retaining ring (400) not seated.

P0776 or P0777 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

1-2-3-4 clutch backing plate retaining ring (429) not seated, causing clutch pack/piston over travel.

P0776 - 4-5-6 Hub/ Shaft Assembly (58)

4-5-6 Hub/Shaft - broken hub weld.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

cardiagn.com

DTC P0796 OR P0797: PRESSURE CONTROL SOLENOID VALVE 3 - STUCK OFF/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P0796

Pressure Control Solenoid Valve 3 - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P0797

Pressure Control Solenoid Valve 3 - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The clutch pressure control solenoid 3 is part of the control solenoid valve assembly, which has no serviceable parts. The Clutch Pressure Control Solenoid 3 regulates transmission fluid pressure to the CBR1/C 4-5-6 clutch regulator valve which controls pressure to the low/reverse clutch and the 4-5-6 clutch. The Transmission Control Module calculates gear ratio based on the RPM signals from the input speed sensor (ISS) and the output speed sensor (OSS). The Transmission Control Module compares the expected transmission gear ratio to the calculated gear ratio for each commanded gear.

Conditions for Running the DTC

P0796

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

P0797

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.

cardiagn.com

- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

Conditions for Setting the DTC

P0796

The Transmission Control Module has detected an incorrect gear ratio or neutral condition when the low and reverse clutch and the 4-5-6 clutch is commanded ON. This condition must occur 3 times.

P0797

The Transmission Control Module has detected an incorrect gear ratio change when the low and reverse clutch and the 4-5-6 clutch is commanded OFF during a shift or when 4th gear ratio is detected in 1st gear. This condition must occur 3 times.

Action Taken When the DTC Sets

P0796

- DTC P0796 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM limits the transmission to Reverse gear and 2nd gear operation.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM limits the transmission to neutral gear if the output speed sensor signal is 1,350 RPM or greater.
- The TCM limits the transmission to 2nd gear if the output speed sensor signal is less than 1,350 RPM. No upshift will occur.

P0797

- DTC P0797 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The ECM/TCM enables torque management.
- The TCM inhibits TAP Up/Down function.

cardiagn.com

- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM limits the transmission to Reverse gear and 4th gear operation.

Conditions for Clearing the DIC/DTC

DTCs P0796 and P0797 are Type A DTCs.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

cardiagn.com

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **J 21867** Pressure Gauge

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the Transmission Control Module DTCs with a scan tool.
4. Verify the transmission operation performs as indicated in the road test instructions and DTCs P0796 or P0797 did not set. Refer to **Road Test**.
   - **If DTC P0796 or P0797 set**

     Refer to Circuit/System Testing.

   - **If DTC P0796 or P0797 did not set**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If pressures are within range**
2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur for each solenoid**

cardiagn.com

Replace the Q8 Control Solenoid Valve Assembly.

- **If a pressure change does occur for each solenoid**

4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P0796 or P0797 - Control Valve Upper Body Assembly (304)

4-5-6 Regulator Valve (327) stuck/sticking - debris, binding, damaged valve, or scored bore.

P0796 - 4-5-6 Clutch Housing Assembly (441)

Turbine Shaft Seals (442) damaged or leaking.

P0796 or P0797 - Q8 Control Solenoid Valve Assembly (314)

- O-ring seals leaking.
- Valve body filter plate assembly cracked, blocked or damaged gasket seal.

P0796 or P0797 - Control Valve Lower Body Assembly (307)

Clutch select valve (352) stuck/ sticking - debris, binding, damaged valve, or scored bore.

P0796 - 4-5-6 Clutch Housing Assembly (441)

4-5-6 Clutch Piston Assembly (439) damaged/ leaking.

P0796 - Transmission Cooling/Lubrication

- Restriction/leak in OAC, oil to air, cooler/radiator.
- Restricted/leaking/kinked/damaged transmission oil cooler lines.
- Restriction/leak in transmission fluid pump assembly.

P0796 - Torque Converter (w/Fluid Pump) Housing Assembly (2)

- Fluid pump housing vanes/rotor/slide damaged/scored.
- Fluid pump or torque converter overstressed due to high temperature.

P0796 - 4-5-6 Hub/Shaft Assembly (58)

4-5-6 Hub/Shaft - broken hub weld.

P0796 - Automatic Transmission Fluid Filter Assembly (26)

Oil filter (26) or filter seal (25) loose or damaged.

P0796 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

1-2-3-4 Clutch Backing Plate Retaining Ring (429) not seated/oriented, causing clutch pack/piston over travel.

P0796 - Control (with body and valve) Valve Assembly (21)

Valve Body to Pump Transfer Seal Assembly (18) damaged/leaking.

cardiagn.com

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0815, P0816, P0826, OR P1876: UPSHIFT/DOWNSHIFT SWITCH AND ENABLE SWITCH

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0815

Upshift Switch Circuit

DTC P0816

Downshift Switch Circuit

DTC P0826

Up and Down Shift Switch Circuit

DTC P1876

Up and Down Shift Enable Switch Circuit Low Voltage

Diagnostic Fault Information

Driver Shift Request

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
Tap Up/Tap Down Switch Signal Circuit	0 V	0 V	5-12 V	-

Circuit/System Description

The driver shift request (DSR) allows the driver to select the desired range of gears for current driving conditions. The DSR shift system is activated when the gear selector is in the manual position. The DSR system is deactivated in all other range positions. Pressing the plus (+) switch once will command the body control module (BCM) to signal the transmission control module (TCM) to upshift to the next high gear. Pressing the minus (-) switch once will command the BCM to signal the TCM to downshift to the next lowest or previous gear. The TCM will not allow a downshift if the transmission is compromised by over-speeding. The automatic transmission manual shift switch is comprised of three different resistors values in series and two switches. The BCM supplies a 12 volt circuit to the automatic transmission manual shift switch. The signal circuit varies the voltage back to the body control module depending on which switch is depressed.

cardiagn.com

Conditions for Running the DTC

P0815, P0816 or P0826

- DTC P0815, P0816, P0826, P182E, P1876, P1877, P1915 or P1761 is not set.
- The ignition voltage is 8.6 volts or greater.
- The engine speed is 400 RPM or greater for 5 seconds.

P1876

- DTC U0100, P0815, P0816, P0826, P1825, P1876 or P1915 is not set.
- The ignition voltage is 8.6 volts or greater.
- The engine speed is 400 RPM or greater for 5 seconds.

Conditions for Setting the DTC

P0815 - Condition 1

The BCM detects a stuck ON Tap Up switch for 1 second in Park or Neutral.

P0815 - Condition 2

The BCM detects a stuck ON Tap Up switch for 10 minutes in any forward gear.

P0816 - Condition 1

The BCM detects a stuck ON Tap Down switch for 1 second in Park or Neutral.

P0816 - Condition 2

The BCM detects a stuck ON Tap Down switch for 10 minutes in any forward gear.

P0826

The BCM detects an invalid voltage on the TAP up/down signal circuit for 1 minute.

P1876

The BCM detects a TAP Enable Switch request 3 times when not in M (D6) range for 2 seconds.

Action Taken When the DTC Sets

- DTCs P0815, P0816, P0826, and P1876 are Type C DTCs.
- The BCM disables TAP shift operation.

Conditions for Clearing the DTC

DTCs P0815, P0816, P0826, and P1876 are Type C DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

cardiagn.com

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference

Control Module References for scan tool information

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Circuit/System Verification

1. Ignition ON, place the S3 Transmission Shift Lever in manual mode range position.
2. Verify with a scan tool, the Driver Shift Control Mode parameter displays Active.
   - **If the parameter does not display Active**

     Refer to Circuit/System Testing.

   - **If the parameter does display Active**
3. Verify with a scan tool, the Driver Shift Request parameter displays Upshift, when momentarily pressing the plus (+) switch.
   - **If the parameter does not display Upshift**

     Refer to Circuit/System Testing.

   - **If the parameter does display Upshift**
4. Verify with a scan tool, the Driver Shift Request parameter displays Downshift, when momentarily pressing the minus (-) switch.
   - **If the parameter does not display Downshift**

     Refer to Circuit/System Testing.

   - **If the parameter does display Downshift**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure records data.
6. Verify the DTC does set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

cardiagn.com

- **If the DTC does not set**

7. All OK.

Circuit/System Testing

1. Ignition OFF and all vehicle systems OFF. Disconnect the harness connector at the S3 Transmission Shift Lever. It may take up to 2 min. for all vehicle systems to power down.
2. Test for less than 5 Ω between the ground circuit terminal C and ground.
   - **If greater than 5 Ω**
   1. Ignition OFF.
   2. Test for less than 2 Ω in the ground circuit wire end to wire end.
      - If 2 Ω or greater, repair the open/high resistance in the wire circuit.
      - If less than 2 Ω, repair the open/high resistance in the ground connection.
   - **If less than 5 Ω**
3. Ignition OFF.
4. Test for less than 1 V on the signal circuit terminal D at the S3 Transmission Shift Lever harness connector.
   - **If greater than 1 V**
   1. Ignition OFF.
   2. Disconnect the X3 harness connector at the K9 Body Control Module. Ignition ON.
   3. Test for less than 1 V on the signal circuit terminal D at the S3 Transmission Shift Lever harness connector and ground.
      - If 1 V or greater, repair the short to B+/Ignition in the signal circuit.
      - If less than 1 V, replace the K9 Body Control Module.
   - **If less than 1 V**
5. Ignition ON.
6. Test for 11.6-12.4 V on the signal circuit terminal D at the S3 Transmission Shift Lever harness connector and ground.
   - **If not between 11.6-12.4 V**
   1. Ignition OFF.
   2. Disconnect the X3 harness connector at the K9 Body Control Module.
   3. Test for less than 2 Ω in the signal circuit wire end to wire end.
      - If greater than 2 Ω, repair the open/high resistance in the wire circuit.
      - If less than 2 Ω, replace the K9 Body Control Module.
   - **If between 11.6-12.4 V**
7. Test or replace the S3 Transmission Shift Lever.

Component Testing

1. Perform the Circuit/System Verification and Circuit/System Testing first.
2. Ignition OFF.
3. Disconnect the S3 Transmission Shift Lever harness connector.
4. Test for 6110-6140 Ω between terminals C and D on the S3 Transmission Shift Lever.

cardiagn.com

- **If not within the specified range**

  Replace the S3 Transmission Shift Lever.

- **If within the specified range**

5. Test for 610-650 Ω between terminals C and D on the S3 Transmission Shift Lever, while holding down the plus (+) switch.
   - **If not within the specified range**

     Replace the S3 Transmission Shift Lever.

   - **If within the specified range**
6. Test for 1990-2020 Ω between terminals C and D on the S3 Transmission Shift Lever, while holding the minus (-) switch.
   - **If not within the specified range**

     Replace the S3 Transmission Shift Lever.

   - **If within the specified range**
7. All OK.

Repair Instructions

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Perform the **Diagnostic Repair Verification** after completing the repair.
- Refer to **Control Module References** for BCM replacement, programming, and setup.
- Replace the RSM shift switch. Refer to **Range Selector Lever Cable Lever Replacement** .

DTC P0842 OR P0843: TRANSMISSION FLUID PRESSURE SWITCH 1

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0842

Transmission Fluid Pressure Switch 1 Circuit Low Voltage

DTC P0843

Transmission Fluid Pressure Switch 1 Circuit High Voltage

Circuit/System Description

The Transmission Fluid Pressure Switch 1 is part of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module supplies a signal circuit to the Transmission Fluid Pressure Switch 1. The Transmission Fluid Pressure Switch 1 has an internal case ground. Transmission Fluid Pressure

cardiagn.com

Switch 1 is normally closed or LOW. When oil pressure is present at the Transmission Fluid Pressure Switch 1, the switch is open or HIGH. The normally high clutch pressure control (PC) solenoid 2 controls pressure to the 3-5 reverse clutch regulator valve. The Transmission Control Module monitors the Transmission Fluid Pressure Switch 1 to determine the position of the 3-5 reverse clutch regulator valve. When the 3-5 reverse clutch is commanded OFF, pressure is present on the Transmission Fluid Pressure Switch 1. When the 3-5 reverse clutch is commanded ON, the 3-5 reverse clutch regulator valve moves and pressure to the Transmission Fluid Pressure Switch 1 is exhausted through the 3-5 reverse clutch regulator valve.

Conditions for Running the DTC

P0842 or P0843

- DTC P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, or P182E is not set.
- Ignition voltage is between 8.6-32 V.
- The transmission fluid temperature is -6.6Â°C (20.12Â°F).
- Engine speed is between 400-7,500 RPM for 5 s.
- The high side driver is commanded ON.
- The engine speed is 550 RPM or greater in Drive 1-6 range.

Conditions for Setting the DTC

P0842

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 1 signal voltage remains LOW after the 3-5-R clutch transitions from a HIGH pressure state to a LOW pressure state. The Transmission Control Module counts each incident. The DTC sets when 25 counts are accumulated.

P0843

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 1 signal voltage remains HIGH after the 3-5-R clutch transitions from a LOW pressure state to a HIGH pressure state. The Transmission Control Module counts each incident. The DTC sets when 24 counts are accumulated.

Action Taken When the DTC Sets

- DTCs P0842 and P0843 are Type C DTCs.
- The Transmission Control Module freezes transmission adaptive functions for the 3-5-Reverse clutch.

Conditions for Clearing the DTC

DTCs P0842 and P0843 are Type C DTCs.

Diagnostic Aids

A Transmission Fluid Pressure Switch may malfunction due to normal debris in the transmission fluid causing a Transmission Fluid Pressure Switch DTC to intermittently set. This type of condition should not be immediately noticeable to a customer, as the switch outputs are used for shift adaptive pressure and do not cause transmission symptoms unless the switch malfunctions continuously for an extended period of time.

Reference Information

cardiagn.com

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tool Reference

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine idling in Park with parking brake applied, and drive wheels chocked.
2. Verify the scan tool Transmission Fluid Pressure Switch 1 parameter displays the correct values for each gear range while placing the gear select lever in Park, Reverse, and Neutral position.
    - **If the correct states are not displayed**

      Refer to Circuit/System Testing.

    - **If the correct states are displayed**
3. Place the gear select lever in Drive range.
4. Verify the scan tool Transmission Fluid Pressure Switch 1 parameter displays the correct states when allowing the transmission to shift from 1 through 6 gears.
    - **If the correct states are not displayed**

cardiagn.com

Refer to Circuit/System Testing.

- **If the correct states are displayed**

5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
2. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
3. Connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 control solenoid valve assembly electrical connector. Ignition ON.
4. Verify the scan tool parameters listed below change states when gently pushing on each Transmission Fluid Pressure Switch with the eraser end of a pencil.
   - Transmission Fluid Pressure Switch 1
   - Transmission Fluid Pressure Switch 3
   - Transmission Fluid Pressure Switch 4
   - Transmission Fluid Pressure Switch 5
   - **If any parameter does not change**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If all parameters change**
5. Verify the channel plate, spacer plate, and filter plate do not have a restricted or blocked orifice. Repair or replace as necessary.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0850-P0852: PARK/NEUTRAL POSITION SWITCH

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.

cardiagn.com

- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0850

Park/Neutral Position Switch Circuit

DTC P0851

Park/Neutral Position Switch Circuit Low Voltage

DTC P0852

Park/Neutral Position Switch Circuit High Voltage

Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
Park/Neutral Signal	P0850/P0851	P0850/P0852	P0850/P0852	-

Typical Scan Tool Data

PNP Switch

Circuit	Short to Ground	Open/High Resistance	Short to Voltage
Operating Conditions: Engine running, normal operating temperature, range selector in Park. **Parameter Normal Range:** 12 Volts = In-Gear, 0 Volts = Park/Neutral			
Park/Neutral Signal	Park/Neutral	In-Gear	In-Gear

Circuit/System Description

The transmission manual shift shaft switch assembly, also known as the internal mode switch, is a sliding contact switch attached to the manual shift shaft inside the transmission case. The park/neutral position switch is integrated into the internal mode switch and connects to the Transmission Control Module lead-frame through a short wire harness. The circuit uses the Transmission Control Module as a pass-through connector only.

The Park/Neutral Signal is sent from the park/neutral switch directly to the engine control module (ECM) and is used for engine start enable.

Conditions for Running the DTC

- Ignition voltage is between 11-18 volts.
- Engine Speed is 1000 RPM or greater.
- TP is 8 percent or greater.
- Engine torque is 75 (55 lb ft) or greater.
- Vehicle speed is 10 km/h (6 mph) or greater.

Conditions for Setting the DTC

P0850 or P0851

cardiagn.com

The ECM detects the Park/Neutral switch signal equals 0 V, Low, when the IMS reports a Drive range.

P0852

The ECM detects the Park/Neutral switch signal equals 12 V, High, when the IMS reports a Park/Neutral range.

Action Taken When the DTC Sets

- DTC P0850, P0851, and P0852 are Type C DTCs.
- The ECM uses IMS Range for engine start-up.

Conditions for Clearing the DTC

DTC P0850, P0851, and P0852 are Type C DTCs.

Reference Information

Schematic Reference

- **Automatic Transmission Controls Schematics**
- **Engine Controls Schematics**

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

cardiagn.com

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Verify the range selector cable is adjusted correctly. Refer to **Range Selector Lever Cable Adjustment** .
    - **If the cable adjustment is not OK**

      Adjust, repair or replace as necessary.

    - **If the cable adjustment is OK**
2. Ignition ON.
3. Verify the scan tool Engine Control Module Park/Neutral Position Switch parameter displays Park/Neutral when in Park or Neutral and In-Gear when in Reverse or Drive Range.
    - **If Park/Neutral or In-Gear is not displayed**

      Refer to Circuit/System Testing.

    - **If Park/Neutral or In-Gear is displayed**
4. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
5. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
6. All OK.

Circuit/System Testing

NOTE: **You must perform Circuit/System Verification first.**

1. Ignition OFF, disconnect the X1 harness connector at the Q8 Control Solenoid Valve Assembly on the automatic transmission.
2. Install the **DT-47825-10** jumper harness to the X1 vehicle harness connector.
3. Test for less than 5 Ω between the ground circuit terminal 5 at the **DT-47825-10** jumper harness and ground at the transmission case.
    - **If 5 Ω or greater**
    1. Ignition OFF.
    2. Test for less than 2 Ω in the ground circuit from wire end to wire end.
    - If 2 Ω or greater, repair the open/high resistance in the circuit.
    - If less than 2 Ω, repair the open/high resistance in the ground connection.
    - **If less than 5 Ω**
4. Ignition ON.
5. Test for 11-13 V between the signal circuit terminal 3 at the **DT-47825-10** jumper harness and ground at the transmission case.
    - **If not between 11-13 V**

cardiagn.com

1. Ignition OFF, disconnect the X1harness connector at the K20 Engine Control Module.
2. Test for infinite resistance between the Park/Neutral signal circuit terminal 3 at the **DT-47825-10** jumper harness and ground at the transmission case.
    - If less than infinite resistance, repair the short to ground in the signal circuit.
    - If infinite resistance.
3. Test for less than 2 Ω in the Park/Neutral signal circuit wire end to wire end.

- If 2 Ω or greater, repair the open/high resistance in the signal circuit.
- If less than 2 Ω, replace the K20 Engine Control Module.
- **If between 11-13 V**

6. Ignition OFF, disconnect the **DT-47825-10** jumper harness from the X1 vehicle harness connector.
7. Connect the **DT-47825-10** jumper harness to the Q8 Control Solenoid Valve Assembly harness connector at the transmission case.
8. Remove the transmission fluid pan.
9. Disconnect the B15 Transmission Internal Mode Switch electrical connector from the Q8 Control Solenoid Valve Assembly.
10. Test for less than 2 Ω between the ground circuit terminal 5 and terminal A at the B15 Transmission Internal Mode Switch connector on the Q8 Control Solenoid Valve Assembly.
    - **If 2 Ω or greater**

      Replace the Q8 control solenoid valve assembly.

    - **If less than 2 Ω**
11. Ignition OFF.
12. Connect the **DT-47825-10** jumper harness to the X1 vehicle harness connector.
13. Ignition ON.
14. Test for 11-13 V between terminal F at the B15 Transmission Internal Mode Switch connector on the Q8 Control Solenoid Valve Assembly and ground at the transmission case.
    - **If not between 11-13 V**

      Replace the Q8 control solenoid valve assembly.

    - **If between 11-13 V**
15. Connect a 3 A fused jumper wire between terminal F at the B15 Transmission Internal Mode Switch on the Q8 Control Solenoid Valve Assembly and ground at the transmission case.
16. Verify the scan tool Engine Control Module Park/Neutral Position Switch parameter displays Park/Neutral.
    - **If Park/Neutral is not displayed**

      Replace the K20 Engine Control Module.

    - **If Park/Neutral is displayed**
17. Replace the B15 Transmission Internal Mode Switch.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

cardiagn.com

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Refer to **Control Module References** for Control Solenoid Valve Assembly replacement, programming, and setup.

NOTE: **If the IMS switch has been replaced, inspect the valve body detent spring to be sure it is centered over the detent lever. This prevents the detent spring from hitting the IMS switch.**

- **Manual Shift Shaft Position Switch Replacement** for IMS replacement.

DTC P0872 OR P0873: TRANSMISSION FLUID PRESSURE SWITCH 3

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0872

Transmission Fluid Pressure Switch 3 Circuit Low Voltage

DTC P0873

Transmission Fluid Pressure Switch 3 Circuit High Voltage

Circuit/System Description

The Transmission Fluid Pressure Switch 3 is part of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module supplies a signal circuit to the Transmission Fluid Pressure Switch 3. The Transmission Fluid Pressure Switch 3 has an internal case ground. Transmission Fluid Pressure Switch 3 is normally closed or LOW. When oil pressure is present at the Transmission Fluid Pressure Switch 3, the switch is open or HIGH. The normally low clutch pressure control (PC) solenoid 4 controls pressure to the 2-6 clutch regulator valve. The Transmission Control Module monitors the Transmission Fluid Pressure Switch 3 to determine the position of the 2-6 clutch regulator valve. When the 2-6 clutch is commanded OFF, pressure is present on the Transmission Fluid Pressure Switch 3. When the 2-6 clutch is commanded ON, the 2-6 clutch regulator valve moves and pressure is exhausted through the 2-6 clutch regulator valve.

Conditions for Running the DTC

P0872 or P0873

- DTC P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, or P182E is not set.
- Ignition voltage is between 8.6-32 V.
- The transmission fluid temperature is -6.6Â°C (20.12Â°F).
- Engine speed is between 400-7,500 RPM for 5 s.
- The high side driver is commanded ON.
- The engine speed is 550 RPM or greater in Drive 1-6 range.

cardiagn.com

Conditions for Setting the DTC

P0872

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 3 signal voltage remains LOW after the 2-6 clutch transitions from a HIGH pressure state to a LOW pressure state. The Transmission Control Module counts each incident. The DTC sets when 10 counts are accumulated.

P0873

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 3 signal voltage remains HIGH after the 2-6 clutch transitions from a LOW pressure state to a HIGH pressure state. The Transmission Control Module counts each incident. The DTC sets when 15 counts are accumulated.

Action Taken When the DTC Sets

- DTCs P0872 and P0873 are Type C DTCs.
- The Transmission Control Module freezes transmission adaptive functions for the 2-6 clutch.

Conditions for Clearing the DTC

DTCs P0872 and P0873 are Type C DTCs.

Diagnostic Aids

A Transmission Fluid Pressure Switch may malfunction due to normal debris in the transmission fluid causing a Transmission Fluid Pressure Switch DTC to intermittently set. This type of condition should not be immediately noticeable to a customer, as the switch outputs are used for shift adaptive pressure and do not cause transmission symptoms unless the switch malfunctions continuously for an extended period of time.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**

cardiagn.com

- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine idling in Park with parking brake applied, and drive wheels chocked.
2. Verify the scan tool Transmission Fluid Pressure Switch 3 parameter displays the correct values for each gear range while placing the gear select lever in Park, Reverse, and Neutral position.
   - **If the correct states are not displayed**

     Refer to Circuit/System Testing.

   - **If the correct states are displayed**
3. Place the gear select lever in Drive range.
4. Verify the scan tool Transmission Fluid Pressure Switch 3 parameter displays the correct states when allowing the transmission to shift from 1 through 6 gears.
   - **If the correct states are not displayed**

     Refer to Circuit/System Testing.

   - **If the correct states are displayed**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
2. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.

cardiagn.com

3. Connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
4. Verify the scan tool parameters listed below change states when gently pushing on each Transmission Fluid Pressure Switch with the eraser end of a pencil.
    - Transmission Fluid Pressure Switch 1
    - Transmission Fluid Pressure Switch 3
    - Transmission Fluid Pressure Switch 4
    - Transmission Fluid Pressure Switch 5
    - **If any parameter does not change**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If all parameters change**
5. Verify the channel plate, spacer plate, and filter plate do not have a restricted or blocked orifice. Repair or replace as necessary.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0877 OR P0878: TRANSMISSION FLUID PRESSURE SWITCH 4

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0877

Transmission Fluid Pressure Switch 4 Circuit Low Voltage

DTC P0878

Transmission Fluid Pressure Switch 4 Circuit High Voltage

Circuit/System Description

The Transmission Fluid Pressure Switch 4 is part of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module supplies a signal circuit to the Transmission Fluid Pressure Switch 4. The Transmission Fluid Pressure Switch 4 has an internal case ground. Transmission Fluid Pressure Switch 4 is normally closed or LOW. When oil pressure is present at the Transmission Fluid Pressure Switch 4, the switch is open or HIGH. The normally LOW pressure control solenoid 5 controls pressure to the 1-2-3-4 clutch regulator valve. The Transmission Control Module monitors the Transmission Fluid Pressure Switch 4 to determine the position of the 1-2-3-4 clutch regulator valve. When the 1-2-3-4 clutch is commanded OFF,

cardiagn.com

pressure is present on the Transmission Fluid Pressure Switch 4. When the 1-2-3-4 clutch is commanded ON, the 1-2-3-4 clutch regulator valve moves and pressure to the Transmission Fluid Pressure Switch is exhausted through the 1-2-3-4 clutch regulator valve.

Conditions for Running the DTC

P0877 or P0878

- DTC P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, or P182E is not set.
- Ignition voltage is between 8.6-32 V.
- The transmission fluid temperature is -6.6Â°C (20.12Â°F).
- Engine speed is between 400-7,500 RPM for 5 s.
- The high side driver is commanded ON.
- The engine speed is 550 RPM or greater in Drive 1-6 range.

Conditions for Setting the DTC

P0877

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 4 signal voltage remains LOW after the 1-2-3-4 clutch transitions from a HIGH pressure state to a LOW pressure state. The Transmission Control Module counts each incident. The DTC sets when 5 counts are accumulated.

P0878

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 4 signal voltage remains HIGH after the 1-2-3-4 clutch transitions from a LOW pressure state to a HIGH pressure state. The Transmission Control Module counts each incident. The DTC sets when 6 counts are accumulated.

Action Taken When the DTC Sets

- DTCs P0877 and P0878 are Type C DTCs.
- The Transmission Control Module freezes transmission adaptive functions for the 1-2-3-4 clutch.

Conditions for Clearing the DTC

DTCs P0877 and P0878 are Type C DTCs.

Diagnostic Aids

A Transmission Fluid Pressure Switch may malfunction due to normal debris in the transmission fluid causing a Transmission Fluid Pressure Switch DTC to intermittently set. This type of condition should not be immediately noticeable to a customer, as the switch outputs are used for shift adaptive pressure and do not cause transmission symptoms unless the switch malfunctions continuously for an extended period of time.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

cardiagn.com

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine idling in Park with parking brake applied, and drive wheels chocked.
2. Verify the scan tool Transmission Fluid Pressure Switch 4 parameter displays the correct values for each gear range while placing the gear select lever in Park, Reverse, and Neutral position.
    - **If the correct states are not displayed**

      Refer to Circuit/System Testing.

    - **If the correct states are displayed**
3. Place the gear select lever in Drive range.
4. Verify the scan tool Transmission Fluid Pressure Switch 4 parameter displays the correct states when allowing the transmission to shift from 1 through 6 gears.
    - **If the correct states are not displayed**

      Refer to Circuit/System Testing.

    - **If the correct states are displayed**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.

cardiagn.com

6. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
2. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
3. Connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
4. Verify the scan tool parameters listed below change states when gently pushing on each Transmission Fluid Pressure Switch with the eraser end of a pencil.
    - Transmission Fluid Pressure Switch 1
    - Transmission Fluid Pressure Switch 3
    - Transmission Fluid Pressure Switch 4
    - Transmission Fluid Pressure Switch 5
    - **If any parameter does not change**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If all parameters change**
5. Verify the channel plate, spacer plate, and filter plate do not have a restricted or blocked orifice. Repair or replace as necessary.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0961-P0963: LINE PRESSURE CONTROL SOLENOID

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0961

cardiagn.com

Line Pressure Control Solenoid Valve Performance

DTC P0962

Line Pressure Control Solenoid Valve Control Circuit Low Voltage

DTC P0963

Line Pressure Control Solenoid Valve Control Circuit High Voltage

Circuit/System Description

The line pressure control solenoid is part of the control solenoid valve assembly which has no serviceable parts. The normally high line pressure control solenoid regulates and directs the pressure control solenoid oil pressure to the isolator/pressure regulator valve. Increasing pressure control solenoid line pressure increases transmission line pressure. The Transmission Control Module varies the current to the line pressure control solenoid through a low side driver. Decreasing the current to the line pressure control solenoid increases line pressure control solenoid oil pressure by closing OFF the solenoid exhaust port. Increasing the current to the line pressure control solenoid decreases line pressure control oil pressure by opening the solenoid exhaust port. Line pressure control solenoid power is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected the high side driver will reset.

Conditions for Running the DTC

P0961, P0962, or P0963

- The engine speed is between 400-7,500 RPM for 5 s.
- The ignition voltage is between 8.6-32 V.

Conditions for Setting the DTC

P0961

The Transmission Control Module detects an internal electrical malfunction of the line pressure control solenoid where the measured line pressure control solenoid current does not equal the commanded line pressure control solenoid current for 5 s.

P0962

The Transmission Control Module detects a short to ground or an open/high resistance on the line pressure control solenoid control circuit for 2 s.

P0963

The Transmission Control Module detects a short to voltage on the line pressure control solenoid control circuit for 5 s.

Action Taken When the DTC Sets

P0961

- DTC P0961 is a Type B DTC.
- The TCM freezes transmission adaptive functions.

cardiagn.com

- The TCM commands maximum line pressure.

P0962

- DTC P0962 is a Type A DTC.
- The TCM turns the high side driver OFF.
- The TCM inhibits the torque converter clutch (TCC).
- The TCM commands maximum line pressure.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits powertrain braking.
- The ECM/TCM request a reduction in engine torque based on input speed.
- The TCM inhibits Tap Up/Down function.
- The TCM inhibits manual shifting or forward gears.
- The TCM inhibits auto grade braking.
- The TCM inhibits neutral idle.

P0963

- DTC P0963 is a Type B DTC.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.

Conditions for Clearing the DIC/DTC

- DTCs P0961 and P0963 are Type B DTCs.
- DTC P0962 is a Type A DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**

cardiagn.com

- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine running in Park position, parking brake applied, place the gear select lever in each gear position for 2-3 s. Return the gear select lever to the Park position.
2. Verify the scan tool parameters listed below do not display Malfunction:
   - Line Pressure Control Solenoid Valve Performance Test Status
   - Line Pressure Control Solenoid Valve Control Circuit High Voltage Test Status
   - Line Pressure Control Solenoid Valve Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

cardiagn.com

- **If not contaminated**

3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
    - **If resistance is not within range**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool the parameters listed below do not display Malfunction:
    - Line Pressure Control Solenoid Valve Performance Test Status
    - Line Pressure Control Solenoid Valve Control Circuit High Voltage Test Status
    - Line Pressure Control Solenoid Valve Control Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0965-P0967: PRESSURE CONTROL SOLENOID VALVE 2

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0965

Pressure Control Solenoid Valve 2 Performance

DTC P0966

Pressure Control Solenoid Valve 2 Control Circuit Low Voltage

DTC P0967

Pressure Control Solenoid Valve 2 Control Circuit High Voltage

cardiagn.com

Circuit/System Description

The pressure control solenoid 2 is part of the control solenoid valve assembly which has no serviceable parts. The normally high pressure control solenoid 2 regulates and directs the pressure control solenoid 2 oil pressure to the 3-5 reverse clutch regulator valve and 3-5 reverse clutch boost valve. Increasing pressure control solenoid 2 pressure increases pressure to the 3-5 reverse clutch. The Transmission Control Module varies the current to the pressure control solenoid 2 through a low side driver. Decreasing the current to the pressure control solenoid 2 increases pressure control solenoid 2 oil pressure by closing OFF the solenoid exhaust port. Increasing the current to the pressure control solenoid 2 decreases pressure control solenoid 2 oil pressure by opening the solenoid exhaust port. Pressure control solenoid 2 power is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected, the high side driver will reset.

Conditions for Running the DTC

- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.

Conditions for Setting the DTC

P0965

The Transmission Control Module detects an internal electrical performance malfunction of the clutch pressure control solenoid 2 control circuit where the measured clutch pressure control solenoid 2 current does not equal the commanded clutch pressure control solenoid 2 current for 5 s.

P0966

The Transmission Control Module detects a short to ground on the clutch pressure control solenoid 2 control circuit for 1 s.

P0967

The Transmission Control Module detects an open or short to voltage on the clutch pressure control solenoid 2 control circuit, for 1 s.

Action Taken When the DTC Sets

P0965

- DTC P0965 is a Type C DTC.
- The TCM freezes transmission adaptive functions on the 3-5 Reverse clutch.

P0966

- DTC P0966 is a Type A DTC.
- The TCM turns OFF the high side driver.
- The TCM forces TCC OFF.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM enables Torque management.

cardiagn.com

- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM limits the transmission to Reverse and 3rd or 5th gear operation.

P0967

- DTC P0967 is a Type A DTC.
- The TCM limits the transmission to 3rd gear or reverse gear operation.
- The TCM forces TCC OFF.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM enables Torque management.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.

Conditions for Clearing the DTC

- DTC P0965 is a Type C DTC.
- DTCs P0966 and P0967 are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

cardiagn.com

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Operate the vehicle in drive range. Allow the vehicle to shift through all forward gear ranges.
2. Verify the scan tool parameters listed below do not display Malfunction
   - Pressure Control Solenoid Valve 2 Performance Test Status
   - Pressure Control Solenoid Valve 2 Control Circuit High Voltage Test Status
   - Pressure Control Solenoid Valve 2 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If resistance is not within range**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If resistance is within range**

cardiagn.com

4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters listed below do not display Malfunction:
    - Pressure Control Solenoid Valve 2 Performance Test Status
    - Pressure Control Solenoid Valve 2 Control Circuit High Voltage Test Status
    - Pressure Control Solenoid Valve 2 Control Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup

DTC P0969-P0971: PRESSURE CONTROL SOLENOID VALVE 3

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0969

Pressure Control Solenoid Valve 3 Performance

DTC P0970

Pressure Control Solenoid Valve 3 Control Circuit Low Voltage

DTC P0971

Pressure Control Solenoid Valve 3 Control Circuit High Voltage

Circuit/System Description

The pressure control solenoid 3 is part of the control solenoid valve assembly which has no serviceable parts. The normally high pressure control solenoid 3 regulates and directs the pressure control solenoid 3 oil pressure to the 4-5-6 clutch regulator valve and 4-5-6 clutch boost valve. Increasing pressure control solenoid 3 oil pressure increases oil pressure to the 4-5-6 clutch assembly. The Transmission Control Module varies the current to the pressure control solenoid 3 through a low side driver. Decreasing the current to the pressure control solenoid 3 increases pressure control solenoid 3 oil pressure by closing OFF the solenoid exhaust port.

cardiagn.com

Increasing the current to the pressure control solenoid 3 decreases pressure control solenoid 3 oil pressure by opening the solenoid exhaust port. Pressure control solenoid 3 power is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected the high side driver will reset.

Conditions for Running the DTC

- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.

Conditions for Setting the DTC

P0969

The Transmission Control Module detects an internal electrical malfunction on the pressure control solenoid 3 control circuit where the measured pressure control solenoid 3 current does not equal the commanded clutch pressure control solenoid 3 current for 5 s.

P0970

The Transmission Control Module detects a short to ground on the pressure control solenoid 3 control circuit for 1 s.

P0971

The Transmission Control Module detects an open or short to voltage on the pressure control solenoid 3 control circuit for 1 s.

Action Taken When the DTC Sets

P0969

- DTC P0969 is a Type C DTCs.
- The TCM freezes transmission adaptive functions to the low and reverse clutch and 4-5-6 clutch.

P0970 and P0971

- DTC P0970 and P0971 are Type A DTCs.
- The TCM limits the transmission to Reverse and 3rd or 5th gear operation.
- The TCM turns the high side driver OFF.
- The TCM forces TCC OFF.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM enables Torque management.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.

Conditions for Clearing the DTC

- DTC P0969 is a Type C DTCs.

cardiagn.com

- DTCs P0970 and P0971 are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Operate the vehicle in drive range. Allow the vehicle to shift through all forward gear ranges.
2. Verify the scan tool parameters listed below do not display Malfunction:
    - Pressure Control Solenoid Valve 3 Performance Test Status
    - Pressure Control Solenoid Valve 3 Control Circuit High Voltage Test Status
    - Pressure Control Solenoid Valve 3 Control Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Refer to Circuit/System Testing.

cardiagn.com

- **If Malfunction is not displayed**

3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If resistance is not within range**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters do not display Malfunction:
   - Pressure Control Solenoid Valve 3 Performance Test Status
   - Pressure Control Solenoid Valve 3 Control Circuit High Voltage Test Status
   - Pressure Control Solenoid Valve 3 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.

cardiagn.com

- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0973 OR P0974: SHIFT SOLENOID VALVE 1

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0973

Shift Solenoid Valve 1 Control Circuit Low Voltage

DTC P0974

Shift Solenoid Valve 1 Control Circuit High Voltage

Circuit/System Description

The shift solenoid 1 is part of the control solenoid valve assembly which has no serviceable parts. The shift solenoid 1 is a normally closed ON/OFF solenoid and is controlled by the Transmission Control Module through a low side driver. When the shift solenoid 1 is energized, shift solenoid 1 fluid pressure is directed to the clutch select valve 2. Power to the shift solenoid 1 is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected, the high side driver will reset.

Conditions for Running the DTC

P0973 or P0974

- DTCs P0973 or P0974 is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.

Conditions for Setting the DTC

P0973

The control solenoid valve assembly detects an internal low voltage electrical malfunction of the shift solenoid 1 control circuit when the shift solenoid 1 is commanded OFF for 2 seconds.

P0974

The control solenoid valve assembly detects an internal high voltage electrical malfunction of the shift solenoid 1 control circuit when the shift solenoid 1 is commanded ON for 2 seconds.

Action Taken When the DTC Sets

P0973

cardiagn.com

- DTC P0973 is a Type A DTC.
- The TCM forces the torque converter clutch (TCC) OFF.
- The TCM commands maximum line pressure.
- The TCM freezes transmission adaptive functions.
- The TCM enables Torque Management.
- The TCM inhibits TAP function.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits Tow/Haul mode.
- The TCM inhibits neutral idle.
- The TCM commands neutral gear if the output speed sensor signal is 1350 RPM or greater.
- The TCM commands 2nd gear if the output speed sensor signal is less than 1350 RPM. No upshift allowed.

P0974

- DTC P0974 is a Type B DTC.
- The TCM inhibits 1st gear.
- The TCM inhibits neutral idle.

Conditions for Clearing the DIC/DTC

- DTC P0973 is a Type A DTC.
- DTC P0974 is a Type B DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

cardiagn.com

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine Running, place the gear selector in Reverse for 5 seconds and then idle the vehicle in Park for 5 seconds.
2. Verify the scan tool parameters listed below do not display Malfunction:
   - Shift Solenoid Valve 1 Control Circuit High Voltage Test Status
   - Shift Solenoid Valve 1 Control Circuit Open Test Status
   - Shift Solenoid Valve 1 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve**

cardiagn.com

and Transmission Control Module Assembly Inspection.

- **If resistance is not within range**

  Replace the Q8 Control Solenoid Valve Assembly.

- **If resistance is within range**

4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters listed below do not display Malfunction:
   - Shift Solenoid Valve 1 Control Circuit High Voltage Test Status
   - Shift Solenoid Valve 1 Control Circuit Open Test Status
   - Shift Solenoid Valve 1 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Before replacing the TCM, perform the **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0976 OR P0977: SHIFT SOLENOID VALVE 2

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0976

Shift Solenoid Valve 2 Control Circuit Low Voltage

DTC P0977

Shift Solenoid Valve 2 Control Circuit High Voltage

Circuit/System Description

The shift solenoid 2 is part of the control solenoid valve assembly which has no serviceable parts. The shift

cardiagn.com

solenoid 2 is a normally closed ON/OFF solenoid and is controlled by the Transmission Control Module through a low side driver. When the shift solenoid 2 is energized, shift solenoid 2 fluid pressure is directed to the clutch select valve 3. Power to the shift solenoid 2 is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected, the high side driver will reset.

Conditions for Running the DTC

P0976 or P0977

- DTCs P0976 or P0977 is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.

Conditions for Setting the DTC

P0976

The Transmission Control Module detects an internal low voltage electrical malfunction of the shift solenoid 2 control circuit when the shift solenoid 2 is commanded OFF for 2 seconds.

P0977

The Transmission Control Module detects an internal high voltage electrical malfunction of the shift solenoid 2 control circuit when the shift solenoid 2 is commanded ON for 2 seconds.

Action Taken When the DTC Sets

P0976

- DTC P0976 is a Type C DTC.
- The TCM freezes transmission adaptive functions.

P0977

- DTC P0977 is a Type A DTC.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM commands maximum line pressure.
- The TCM inhibits powertrain braking.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM inhibits Tow/Haul function.
- The TCM commands neutral gear if the output speed sensor signal is 1,350 RPM or greater.
- The TCM commands 2nd gear if the output speed sensor signal is less than 1,350 RPM. No upshift allowed.

Conditions for Clearing the DIC/DTC

cardiagn.com

- DTC P0976 is a Type C DTC.
- DTC P0977 is a Type A DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine Running, place the gear selector in Reverse for 5 seconds and then idle the vehicle in Park for 5 seconds.
2. Verify the scan tool parameters listed below do not display Malfunction:
    - Shift Solenoid Valve 2 Control Circuit High Voltage Test Status
    - Shift Solenoid Valve 2 Control Circuit Open Test Status
    - Shift Solenoid Valve 2 Control Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

cardiagn.com

Refer to Circuit/System Testing.

- **If Malfunction is not displayed**

3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If resistance is not within range**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters listed below do not display Malfunction:
   - Shift Solenoid Valve 2 Control Circuit High Voltage Test Status
   - Shift Solenoid Valve 2 Control Circuit Open Test Status
   - Shift Solenoid Valve 2 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

cardiagn.com

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Before replacing the TCM, perform the **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P0989 OR P0990: TRANSMISSION FLUID PRESSURE SWITCH 5

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P0989

Transmission Fluid Pressure Switch 5 Circuit Low Voltage

DTC P0990

Transmission Fluid Pressure Switch 5 Circuit High Voltage

Circuit/System Description

The Transmission Fluid Pressure Switch 5 is part of the control solenoid valve assembly which has no serviceable parts. The Transmission Control Module supplies a signal circuit to the Transmission Fluid Pressure Switch 5. The Transmission Fluid Pressure Switch 5 has an internal case ground. Transmission Fluid Pressure Switch 5 is normally closed or LOW. When oil pressure is present at the Transmission Fluid Pressure Switch 5, the switch is open or HIGH. The normally high pressure control solenoid 3 controls pressure to the CBR1/4-5-6 clutch regular valve. The Transmission Control Module monitors the Transmission Fluid Pressure Switch 5 signal circuit to determine the position of the CBR1/4-5-6 clutch regulator valve. When the 4-5-6 clutch is commanded OFF, pressure is present on the Transmission Fluid Pressure Switch 5. When the 4-5-6 clutch is commanded ON, the CBR1/4-5-6 clutch regulator valve moves and pressure to the Transmission Fluid Pressure Switch 5 is exhausted through the CBR1/4-5-6 clutch regulator valve.

Conditions for Running the DTC

P0989 or P0990

- DTC P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The transmission fluid is -6.6Â°C (20.12Â°F) or greater.
- The engine speed is between 400-7,500 RPM for 5 s.
- The high side driver is commanded ON.
- The engine speed is 550 RPM or greater in Drive 1-6 range.

Conditions for Setting the DTC

P0989

cardiagn.com

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 5 signal voltage remains LOW after the 4-5-6 clutch transitions from a HIGH pressure state to a LOW pressure state. The Transmission Control Module counts each incident. The DTC sets when 18 counts are accumulated.

P0990

The Transmission Control Module detects that the Transmission Fluid Pressure Switch 5 signal voltage remains HIGH after the 4-5-6 clutch transitions from a LOW pressure state to a HIGH pressure state. The Transmission Control Module counts each incident. The DTC sets when 15 counts are accumulated.

Action Taken When the DTC Sets

- DTCs P0989 and P0990 are Type C DTCs.
- The Transmission Control Module freezes transmission adaptive functions for the 4-5-6 clutch.

Conditions for Clearing the DTC

DTCs P0989 and P0990 are Type C DTCs.

Diagnostic Aids

A Transmission Fluid Pressure Switch may malfunction due to normal debris in the transmission fluid causing a Transmission Fluid Pressure Switch DTC to intermittently set. This type of condition should not be immediately noticeable to a customer, as the switch outputs are used for shift adaptive pressure and do not cause transmission symptoms unless the switch malfunctions continuously for an extended period of time.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

cardiagn.com

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Engine idling in Park with parking brake applied, and drive wheels chocked.
2. Verify the scan tool Transmission Fluid Pressure Switch 5 parameter displays the correct values for each gear range while placing the gear select lever in Park, Reverse, and Neutral position.
    - **If the correct states are not displayed**

      Refer to Circuit/System Testing.

    - **If the correct states are displayed**
3. Place the gear select lever in Drive range.
4. Verify the scan tool Transmission Fluid Pressure Switch 5 parameter displays the correct states when allowing the transmission to shift from 1 through 6 gears.
    - **If the correct states are not displayed**

      Refer to Circuit/System Testing.

    - **If the correct states are displayed**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
    - **If the DTC sets**

      Refer to Circuit/System Testing.

    - **If the DTC does not set**
7. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
2. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
3. Connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
4. Verify the scan tool parameters listed below change states when gently pushing on each Transmission Fluid Pressure Switch with the eraser end of a pencil.

cardiagn.com

- Transmission Fluid Pressure Switch 1
- Transmission Fluid Pressure Switch 3
- Transmission Fluid Pressure Switch 4
- Transmission Fluid Pressure Switch 5
- **If any parameter does not change**

  Replace the Q8 Control Solenoid Valve Assembly.

- **If all parameters change**

5. Verify the channel plate, spacer plate, and filter plate do not have a restricted or blocked orifice. Repair or replace as necessary.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P1761: UP AND DOWN SHIFT SWITCH SIGNAL MESSAGE COUNTER

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

DTC P1761

Up and Down Shift Switch Signal Message Counter Incorrect

Circuit/System Description

The driver shift request, also known as the TAP Up/Downshift manual shift function, allows the driver to select the desired range of gears for current driving conditions. The driver shift request shift system is activated when the gear selector is in the manual position. The driver shift request system is deactivated in all other range positions. When driver shift request is selected, a signal is sent to the Body Control Module and the also to the Transmission Control Module. Each time a signal is sent, an internal counter in the Body Control Module and Transmission Control Module increments. Both counters must have the same value. This code sets when the rolling count value of the Transmission Control Module does not match the same rolling count value sent from the Body Control Module.

Conditions for Running the DTC

The engine run time is greater than 5 s.

Conditions for Setting the DTC

The TCM detects an error in the rolling count value that does not match with the BCM.

cardiagn.com

Action Taken When the DTC Sets

- DTC P1761 is a Type C DTC.
- The TCM disables TAP Shift operation.

Conditions for Clearing the DTC

DTC P1761 is a Type C DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

COMPONENT CONNECTOR END VIEWS - INDEX

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Description and Operation

Electronic Component Description

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Circuit/System Verification

NOTE:

- **DTC P1761 is an informational DTC.**
- **Diagnose all other K9 Body Control Module DTCs prior to DTC P1761.**

1. Verify there are no other K9 Body Control Module or communication DTCs set.
   - **If a DTC is set**

     Refer to **Diagnostic Trouble Code (DTC) List - Vehicle** .

   - **If a DTC is not set**
2. Complete the diagnosis by looking for a CAN fault. Refer to **Scan Tool Does Not Communicate with High Speed GMLAN Device** .

cardiagn.com

- **If a CAN circuit fault is found**

  Repair as necessary.

- **If a CAN circuit fault is not found**

3. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup

DTC P1762: TRANSMISSION MODE SWITCH SIGNAL MESSAGE COUNTER

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

DTC P1762

Transmission Mode Switch Signal Message Counter Incorrect

Circuit/System Description

The Body Control Module is constantly sending the Engine Control Module and Transmission Control Module serial data messages with information regarding transmission mode switch activation. The Transmission Control Module sets this code when it detects a discrepancy in the structure of the message causing the signal message integrity to be questioned.

Conditions for Running the DTC

- The engine speed is between 400-7,500 RPM for 5 s.
- No other CAN errors are present.

Conditions for Setting the DTC

The TCM detects an error in the rolling count value that does not match with the BCM.

Action Taken When the DTC Sets

- DTC P1762 is a Type C DTC.
- The TCM inhibits TAP Shift operation.

Conditions for Clearing the DTC

DTC P1762 is a Type B DTC.

Reference Information

cardiagn.com

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Circuit/System Verification

NOTE:

- **DTC P1762 is an informational DTC.**
- **Diagnose all other K71 Transmission Control Module or K20 Engine Control Module DTCs prior to DTC P1762.**

1. Verify there are no other K71 Transmission Control Module or K20 Engine Control Module DTCs set.
   - **If a DTC is set**

     Refer to **Diagnostic Trouble Code (DTC) List - Vehicle** .

   - **If a DTC is not set**
2. Complete the diagnosis by looking for a CAN fault. Refer to **Scan Tool Does Not Communicate with High Speed GMLAN Device** .
   - **If a CAN circuit fault is found**

     Repair as necessary.

   - **If a CAN circuit fault is not found**
3. All OK.

DTC P182E OR P1915: INTERNAL MODE SWITCH

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P182E

Internal Mode Switch Indicates - Invalid Range

DTC P1915

Internal Mode Switch Does Not Indicate Park/Neutral During Start

Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
Signal A	P182E	P1915	P1915	P182E, P1915
Signal B	P1915	P182E	P182E	P182E, P1915
Signal C	P1915	P182E	P182E	P182E, P1915

cardiagn.com

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
Signal P	P182E	P1915	P1915	P182E, P1915
Ground	-	P182E	P182E	P182E, P1915

Typical Scan Tool Data

IMS A/B/C/P

Circuit	Short to Ground	Open	Short to Voltage
Operating Conditions: Ignition ON, range selector in Park			
Signal A	LOW	High	High
Signal B	LOW	High	High
Signal C	LOW	High	High
Signal P	LOW	High	High

Circuit/System Description

The manual shift detent lever with shaft position switch assembly or internal mode switch assembly is a sliding contact switch attached to the control valve body within the transmission. The 4 inputs to the Transmission Control Module from the switch indicate which position is selected by the transmission manual shaft. The input voltage at the Transmission Control Module is high when the switch is open and low when the switch is closed to ground. The state of each input is displayed on the scan tool. The input parameters represented are transmission range signal A, Signal B, signal C, and signal P.

The park/neutral position switch is integrated into the transmission internal mode switch. The circuit uses the Transmission Control Module as a pass-through connection only.

The park/neutral signal is sent from the park/neutral switch directly to the engine control module and is used only for engine start enable.

Conditions for Running the DTC

P182E

- DTCs: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E, P0716, P0717, P0722, P0723, P07C0, P07BF, P077C or P077D is not set.
- The engine speed is between 400-7,500 RPM.
- The ignition voltage is between 8.6-32 V.
- Engine torque signal is valid.

P1915

- DTC P0722 or P0723 is not set.
- The transmission output shaft speed is less than 90 RPM.
- The ignition voltage is between 8.6-32 V.

Conditions for Setting the DTC

P182E

cardiagn.com

The IMS does not indicate a valid Park, Reverse, Neutral or Drive Range gear position for 7 seconds.

P1915

The manual shift shaft IMS switch assembly does not indicate Park or Neutral during the following sequence:

- The engine speed is less than 50 RPM for more than 1 second.
- The engine speed is 50-480 RPM for more than 1 second.
- The engine speed is greater than 525 RPM for more than 2 seconds.
- The transmission input shaft speed is 200 RPM or greater.

Action Taken When the DTC Sets

- DTCs P182E and P1915 are Type A DTCs.
- The TCM commands maximum line pressure.
- The TCM turns off the high side driver.
- The TCM freezes transmission adaptive functions.
- The TCM defaults the transmission to third gear if the current gear is 1st, 2nd, or 3rd; or fifth gear if the current gear is 4th, 5th, or 6th gear.
- The TCM inhibits TCC.
- The TCM inhibits Tap up and Tap down functions.

Conditions for Clearing the DTC

DTCs P182E and P1915 are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**

cardiagn.com

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Circuit/System Verification

1. Verify DTC P0850, P0851 or P0852 is set.
   - **If any of the DTCs are set**

     Refer to **DTC P0850-P0852**.

   - **If none of the DTCs are set**
2. Verify the range selector cable is adjusted correctly. Refer to **Range Selector Lever Cable Adjustment** .
   - **If the cable adjustment is not OK**

     Adjust, repair or replace as necessary.

   - **If the cable adjustment is OK**
3. Ignition ON.
4. Verify the scan tool parameter matches the Transmission Internal Mode Switch Logic table for each gear position. Refer to **Transmission Internal Mode Switch Logic** .
   - **If the parameter does not match**

     Refer to Circuit/System Testing.

   - **If the parameter matches**
5. Verify the scan tool engine control module Park/Neutral Switch parameter displays Park/Neutral with the gear shift lever in Park or Neutral and In Gear when in Reverse or Drive.
   - **If Park/Neutral or In Gear is not displayed**

     Refer to Circuit/System Testing.

   - **If Park/Neutral or In Gear is displayed**
6. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
7. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
8. All OK.

Circuit/System Testing

NOTE: **You must perform Circuit/System Verification first.**

cardiagn.com

1. Ignition OFF, remove the automatic transmission fluid pan. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement** .
2. Disconnect the B15 Transmission Internal Mode Switch connector at the Q8 Control Solenoid Valve Assembly. Ignition ON.
3. Verify the scan tool transmission control module Internal Mode Switch A/B/C/P parameter displays High High High High.
    - **If High High High High is not displayed**

      Replace the Q8 Control solenoid Valve Assembly.

    - **If High High High High is displayed**
4. Verify the scan tool Engine Control Module Park/Neutral Position Switch parameter displays In Gear.
    - **If In Gear is not displayed**
    1. Ignition OFF, disconnect the harness connector at the K20 Engine Control Module.
    2. Test for infinite resistance between the neutral start signal circuit and ground at the vehicle harness K20 Engine Control Module connector.
    - If less than infinite resistance, repair the short to ground on the circuit.
    - If infinite resistance, replace the K20 Engine Control Module.
    - **If In Gear is displayed**
5. Install a 3 A fused jumper wire between the low reference circuit terminal A and each signal circuit listed below one at a time at the Q8 Control Solenoid Valve Assembly:
    - Signal A - terminal E
    - Signal B - terminal D
    - Signal C - terminal C
    - Signal P - terminal B
6. Verify the scan tool Transmission Control Module A/B/C/P displays 1 Low and 3 High when a signal circuit is grounded.
    - **If 1 Low and 3 High is not displayed**

      Replace the Q8 control solenoid valve assembly.

    - **If 1 Low and 3 High is displayed**
7. Connect a 3 A fused jumper wire between Park/Neutral switch signal circuit terminal F and low reference circuit terminal A at the Q8 Control Solenoid Valve Assembly.
8. Verify the scan tool engine control module Park/Neutral Position Switch parameter displays Park/Neutral.
    - **If Park/Neutral is not displayed**
    1. Ignition OFF, disconnect the connector at the K20 Engine Control Module.
    2. Test for less than 2 Ω in the signal circuit wire end to wire end.
        - If 2 Ω or greater, repair the open/high resistance in the wire circuit.
        - If less than 2 Ω, replace the K20 Engine Control Module.
    - **If Park/Neutral is displayed**
9. Replace the B15 Transmission Internal Mode Switch.

Repair Instructions

cardiagn.com

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Perform the **Control Solenoid Valve and Transmission Control Module Assembly Inspection** before replacing any internal transmission components.
- **Manual Shift Shaft Position Switch Replacement** for internal mode switch (IMS) replacement
- Refer to **Control Module References** for Control Solenoid Valve Assembly replacement, programming, and setup.

DTC P2714 OR P2715: PRESSURE CONTROL SOLENOID VALVE 4 - STUCK OFF/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P2714

Pressure Control Solenoid Valve 4 - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P2715

Pressure Control Solenoid Valve 4 - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The clutch pressure control solenoid 4 is part of the control solenoid valve assembly, which has no serviceable parts. The Clutch Pressure Control Solenoid 4 regulates transmission fluid pressure to the 2-6 clutch regulator valve which controls pressure to the 2-6 clutch. The Transmission Control Module calculates gear ratio based on the RPM signals from the input speed sensor (ISS) and the output speed sensor (OSS). The Transmission Control Module compares the expected transmission gear ratio to the calculated gear ratio for each commanded gear.

Conditions for Running the DTC

P2714

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.

cardiagn.com

- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

P2715

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

Conditions for Setting the DTC

P2714

The Transmission Control Module has detected an incorrect gear ratio or neutral condition when the 2-6 clutch is commanded ON. This condition must occur 3 times.

P2715

The Transmission Control Module has detected an incorrect gear ratio change when the 2-6 clutch is commanded OFF during a shift or when 2nd gear ratio is detected in 1st gear. This condition must occur 3 times.

Action Taken When the DTC Sets

P2714

- DTC P2714 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM inhibits powertrain braking.
- The TCM inhibits neutral idle.
- The TCM inhibits Tow/Haul mode.
- The TCM limits the transmission to Reverse gear and 3rd gear operation.

P2715

- DTC P2715 is a Type A DTC.

cardiagn.com

- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM inhibits powertrain braking.
- The TCM inhibits neutral idle.
- The TCM inhibits Tow/Haul mode.
- The TCM limits the transmission to neutral gear if the output speed sensor signal is 1,350 RPM or greater.
- The TCM limits the transmission to 2nd gear if the output speed sensor signal is less than 1,350 RPM. No upshift will occur.

Conditions for Clearing the DIC/DTC

DTCs P2714 and P2715 are Type A DTCs.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**
- **Transmission Component and System Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**

cardiagn.com

- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **DT-47825-10** Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the TCM DTCs.
4. Verify the transmission operation performs as indicated in the road test instructions and DTCs P2714 or P2715 did not set. Refer to **Road Test**.
   - **If DTCs P2714 or P2715 are set**

     Refer to Circuit/System Testing.

   - **If DTCs P2714 or P2715 did not set**
5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

cardiagn.com

- **If the DTC does not set**

7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If pressures are within range**
2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for all solenoids when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If a pressure change does occur**
4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P2714 or P2715 - Control Valve Upper Body Assembly (304)

2-6 clutch regulator valve (334) stuck/sticky - debris, binding, damaged valve, or scored bore.

P2714 - Q8 Control Solenoid Valve Assembly (314)

Refer to document PIP 4304A. DTC P2714 may be set with DTC P0878.

P2714 or P2715 - Q8 Control Solenoid Valve Assembly (314)

- Control signal fluid supply leak-valve body filer plate assembly cracked or damage gasket seal.
- O-ring seals leaking.

P2714 or P2715 - Center (w/2-6 and Low/Rev Clutch) Support Assembly (67)

- 2-6 clutch return spring retaining ring (455) not seated in groove.
- 2-6 clutch piston assembly - seal damaged or leaking.
- 2-6 clutch plates (451-453) worn or damaged.
- Center support transfer seal assembly (20) incorrectly installed.

P2714 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

- 1-2-3-4 clutch backing plate retaining ring (429) not seated/oriented correctly.
- 1-2-3-4 clutch piston (414) - seals damaged or leaking.
- 1-2-3-4 clutch piston (414) - cracked or damaged.

P2714 - 4-5-6 (w/turbine shaft) Clutch Assembly (56)

cardiagn.com

- Turbine shaft fluid seal rings (442) damaged or leaking.
- 4-5-6 clutch piston assembly (439) - seals damaged or leaking.

P2714 - A/Trans Fluid Pump Cover Assembly (219)

Pump tower seals (230) damaged or leaking.

P2714 - Torque Converter (w/fluid pump) Housing Assembly (2)

Fluid pump housing/vanes/rotor/slide damaged/scored.

P2714 - A/Trans Fluid Filter Assembly (26)

Oil filter (26) or filter seal (25) loose or damaged.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P2719-P2721: PRESSURE CONTROL SOLENOID 4

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P2719

Pressure Control Solenoid 4 System Performance

DTC P2720

Pressure Control Solenoid 4 Control Circuit Low Voltage

DTC P2721

Pressure Control Solenoid 4 Control Circuit High Voltage

Circuit/System Description

The pressure control solenoid 4 is part of the control solenoid valve assembly which has no serviceable parts. The normally low pressure control solenoid 4 regulates and directs oil pressure to the 2-6 clutch regulator valve. Increasing pressure control solenoid 4 pressure increases pressure to the 2-6 clutch regulator valve. The Transmission Control Module varies the current to the pressure control solenoid 4 through a low side driver. Increasing the current to pressure control solenoid 4 increases oil pressure by closing OFF the solenoid exhaust port. Decreasing the current to pressure control solenoid 4 decreases oil pressure by opening the exhaust port. Pressure control solenoid 4 power is supplied by the Transmission Control Module through a high side driver.

cardiagn.com

The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected the high side driver will reset.

Conditions for Running the DTC

P2719, P2720, or P2721

- DTC P2719, P2720, or P2721 is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The clutch PC solenoid 4 is commanded ON.

Conditions for Setting the DTC

P2719

The Transmission Control Module detects an internal electrical malfunction on the pressure control solenoid 4 control circuit where the measured pressure control solenoid 4 current does not equal the commanded pressure control solenoid 4 current for 5 s.

P2720

The Transmission Control Module detects a short to ground on the pressure control solenoid 4 control circuit for 1 s.

P2721

The Transmission Control Module detects an open or short to voltage on the pressure control solenoid 4 control circuit for 1 s.

Action Taken When the DTC Sets

P2719

- DTC P2719 is a Type C DTC.
- The TCM freezes transmission adaptive functions.

P2720

- DTC P2720 is a Type A DTC.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits engine braking.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM inhibits Tow/Haul function.
- The TCM commands neutral gear when the output speed sensor signal is 1,350 RPM or greater.
- The TCM commands second gear when the output speed sensor signal is less than 1,350 RPM.

cardiagn.com

P2721

- DTC P2721 is a Type A DTC.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits engine braking.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM inhibits Tow/Haul function.
- The TCM commands 3rd gear.

Conditions for Clearing the DTC

- DTC P2719 is a Type C DTC.
- DTCs P2720 and P2721 are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

cardiagn.com

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Operate the vehicle in drive range. Allow the vehicle to shift through all forward gear ranges.
2. Verify the scan tool parameters listed below do not display Malfunction:
   - Pressure Control Solenoid Valve 4 Performance Test Status
   - Pressure Control Solenoid Valve 4 Control Circuit High Voltage Test Status
   - Pressure Control Solenoid Valve 4 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If resistance is not within range**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8

cardiagn.com

Control Solenoid Valve Assembly electrical connector. Ignition ON.

6. Verify the scan tool parameters do not display Malfunction:
   - Pressure Control Solenoid Valve 4 Performance Test Status
   - Pressure Control Solenoid Valve 4 Control Circuit High Voltage Test Status
   - Pressure Control Solenoid Valve 4 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P2723 OR P2724: PRESSURE CONTROL SOLENOID VALVE 5 - STUCK OFF/ON

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

NOTE: **The DTCs listed below set due to a transmission hydraulic/mechanical condition. Perform the Circuit/System Verification and Circuit/System Testing to identify the cause.**

DTC P2723

Pressure Control Solenoid Valve 5 - Stuck Off - Transmission Hydraulic/Mechanical Performance

DTC P2724

Pressure Control Solenoid Valve 5 - Stuck On - Transmission Hydraulic/Mechanical Performance

Circuit/System Description

The clutch pressure control solenoid 5 is part of the control solenoid valve assembly, which has no serviceable parts. The Clutch Pressure Control Solenoid 5 regulates transmission fluid pressure to the 1-2-3-4 clutch regulator valve which controls pressure to the 1-2-3-4 clutch. The Transmission Control Module calculates gear ratio based on the RPM signals from the input speed sensor (ISS) and the output speed sensor (OSS). The Transmission Control Module compares the expected transmission gear ratio to the calculated gear ratio for each commanded gear.

Conditions for Running the DTC

cardiagn.com

P2723

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

P2724

- DTC P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0401, P042E, P0716, P0717, P0722, P0723, or P182E is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The transmission temperature is -6.6Â°C (20.12Â°F) or greater.
- The throttle position signal is valid.
- High side driver is enabled.
- The transmission output speed sensor signal is 67 RPM or greater or the accelerator pedal position sensor signal is 0.5 percent or greater.

Conditions for Setting the DTC

P2723

The Transmission Control Module has detected an incorrect gear ratio or neutral condition when the 1-2-3-4 clutch is commanded ON. This condition must occur 3 times.

P2724

The Transmission Control Module has detected an incorrect gear ratio change when the 1-2-3-4 clutch is commanded OFF during a shift. This condition must occur 3 times.

Action Taken When the DTC Sets

P2723

- DTC P2723 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM inhibits Tow/Haul mode.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.

cardiagn.com

- The TCM inhibits powertrain braking.
- The ECM/TCM request a reduced amount of engine torque based on transmission input speed.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM limits the transmission to Reverse gear and 5th gear operation.

P2724

- DTC P2724 is a Type A DTC.
- The TCM commands maximum line pressure.
- The TCM freezes transmission adaptive functions.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM inhibits powertrain braking.
- The TCM inhibits neutral idle.
- The TCM inhibits auto grade braking.
- The TCM inhibits Tow/Haul function.
- The TCM limits the transmission to 4th gear if the output speed sensor signal is 1,400 RPM or greater.
- The TCM limits the transmission to 2nd gear if the output speed sensor signal is less than 1,400 RPM. No upshift will occur.

Conditions for Clearing the DIC/DTC

DTCs P2723 and P2724 are Type A DTCs.

Diagnostic Aids

Before performing a road test, configure and setup the scan tool for snapshot mode. This will allow you to display, monitor, and verify multiple transmission data parameters at one time, after the road test.

Reference Information

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Description and Operation

- **Electronic Component Description**
- **Transmission General Description**

cardiagn.com

- **Transmission Component and System Description**
- **Park - Engine Running**
- **Reverse**
- **Neutral - Engine Running**
- **Drive Range, First Gear Engine Braking**
- **Drive Range, First Gear**
- **Drive Range, Second Gear**
- **Drive Range, Third Gear**
- **Drive Range, Third Gear Default**
- **Drive Range, Fourth Gear**
- **Drive Range, Fifth Gear**
- **Drive Range, Fifth Gear Default**
- **Drive Range, Sixth Gear**
- **Fluid Passages**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

- **DT-47825** Control Solenoid Test Plate
- **DT-47825-10** Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

NOTE: **If other DTCs are set, diagnose those DTCs first.**

1. Engine idling in Park position, with parking brake applied and drive wheels chocked.
2. Verify the transmission fluid level and condition is correct. Refer to **Transmission Fluid Level and Condition Check**.
   - **If the transmission fluid level and condition is not correct**

     Repair as necessary.

   - **If the transmission fluid level and condition is correct**
3. Ignition ON, clear the Transmission Control Module DTCs with a scan tool.
4. Verify the transmission operation performs as indicated in the road test instructions and DTCs P2723 or P2724 did not set. Refer to **Road Test**.
   - **If DTCs P2723 or P2724 are set**

cardiagn.com

Refer to Circuit/System Testing.

- **If DTCs P2723 or P2724 did not set**

5. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
6. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
7. All OK.

Circuit/System Testing

1. Verify the transmission line pressures are within the specified ranges. Refer to **Line Pressure Check**.
   - **If pressures are not within range**

     Refer to **Fluid Pressure High or Low**.

   - **If pressures are within range**
2. Ignition OFF. Remove the Q8 Control Solenoid Valve Assembly.
3. Verify a pressure change occurs for each solenoid when performing the solenoid test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
   - **If a pressure change does not occur**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If a pressure does occur**
4. Verify the conditions listed below do not exist. Carefully inspect each component for that condition. Repair or replace as necessary.

P2723 or P2724 - Control Valve Upper Body Assembly (304)

1-2-3-4 Clutch Regulator Valve (337) stuck/sticking - debris, binding, damaged valve, or scored bore.

P2723 - Q8 Control Solenoid Valve Assembly (314)

Refer to document PIP 4304A. DTC P2723 may be set with DTC P0878.

P2723 or P2724 - Q8 Control Solenoid Valve Assembly (314)

- O-ring seal leaking.
- Valve body filter plate assembly cracked, blocked, or damaged gasket seal.

P2723 - Control Valve Upper Lower Assembly (351)

Clutch Select Valve 3 (352) stuck/sticking - debris, binding, damaged valve, or scored bore.

P2723 - A/Trans Fluid Pump Cover Assembly (219)

cardiagn.com

Pump Tower Seals (230) damaged/leaking.

P2723 - 1-2-3-4 and 3-5-R Clutch Housing Assembly (51)

- 1-2-3-4 Clutch Piston (414) cracked/damaged/leaking.
- Housing/hub weld cracked/leaking.
- 1-2-3-4 Clutch Backing Plate Retaining Ring (429) not seated/oriented, causing clutch pack/piston over travel.

P2723 - Control (with body and valve) Valve Assembly (21)

Valve Body to Pump Transfer Seal Assembly (19) damaged/leaking.

P2723 - Torque Converter (w/Fluid Pump) Housing Assembly (2)

- Fluid pump housing vanes/rotor/slide damaged/scored.
- Fluid pump or torque converter overstressed due to high temperatures.

P2723 - Automatic Transmission Fluid Filter Assembly (26)

Oil filter (26) or filter seal (25) loose or damaged.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P2728-P2730: PRESSURE CONTROL (PC) SOLENOID VALVE 5

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P2728

Pressure Control (PC) Solenoid Valve 5 Performance

DTC P2729

Pressure Control (PC) Solenoid Valve 5 Control Circuit Low Voltage

DTC P2730

Pressure Control (PC) Solenoid Valve 5 Control Circuit High Voltage

Circuit/System Description

cardiagn.com

The pressure control solenoid 5 is part of the control solenoid valve assembly which has no serviceable parts. The normally low pressure control solenoid 5 regulates and directs oil pressure to the 1-2-3-4 clutch regulator valve and 1-2-3-4 clutch boost valve. Increasing pressure control solenoid 5 pressure increases pressure to the 1-2-3-4 clutch. The Transmission Control Module varies the current to the pressure control solenoid 5 through a low side driver. Increasing the current to pressure control solenoid 5 increases oil pressure by closing OFF the solenoid exhaust port. Decreasing the current to pressure control solenoid 5 decreases oil pressure by opening the exhaust port. Pressure control solenoid 5 power is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected, the high side driver will reset.

Conditions for Running the DTC

P2728, P2729, or P2730

- DTCs P2728, P2729, or P2730 is not set.
- The ignition voltage is between 8.6-32 V.
- The engine speed is between 400-7,500 RPM for 5 s.
- The pressure control solenoid valve 5 is commanded ON.

Conditions for Setting the DTC

P2728

The Transmission Control Module detects an internal electrical performance malfunction of the clutch pressure control solenoid valve 5 control circuit where the measured clutch pressure control solenoid valve 5 current does not equal the commanded clutch pressure control solenoid valve 5 current for 5 s.

P2729

The Transmission Control Module detects a short to ground on the clutch pressure control solenoid valve 5 control circuit for 1 s.

P2730

The Transmission Control Module detects an open or short to voltage on the clutch pressure control solenoid valve 5 control circuit for 1 s.

Action Taken When the DTC Sets

P2728

- DTC P2728 is a Type C DTC.
- The TCM freezes transmission adaptive functions.

P2729

- DTC P2729 is a Type A DTC.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM inhibits TAP Up/Down function.

cardiagn.com

- The TCM inhibits engine braking.
- The TCM inhibits neutral idle.
- The TCM cancels Tow/Haul mode function.
- The TCM inhibits auto grade braking.
- The TCM commands neutral gear if output speed sensor signal is 1,350 RPM or greater.
- The TCM commands 2nd gear if output speed sensor signal is less than 1,350 RPM.

P2730

- DTC P2730 is a Type A DTC.
- The TCM forces TCC OFF.
- The TCM commands maximum line pressure.
- The TCM inhibits TAP Up/Down function.
- The TCM turns OFF the high side driver.
- The TCM inhibits engine braking.
- The ECM commands a reduction in engine torque based on input form the speed sensor.
- The TCM inhibits neutral idle.
- The TCM inhibits manual shifting.
- The TCM inhibits auto grade braking.
- The TCM inhibits Tow/Haul function.

Conditions for Clearing the DTC

- DTC P2728 is a Type C DTC.
- DTCs P2729 and P2730 are Type A DTCs.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**

cardiagn.com

- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Operate the vehicle in drive range. Allow the transmission to shift through all forward gear ranges.
2. Verify the scan tool parameters listed below do not display Malfunction:
   - Pressure Control Solenoid Valve 5 Performance Test Status
   - Pressure Control Solenoid Valve 5 Control Circuit High Voltage Test Status
   - Pressure Control Solenoid Valve 5 Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

cardiagn.com

- **If not contaminated**

3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
    - **If resistance is not within range**

      Replace the Q8 Control Solenoid Valve Assembly

    - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters listed below do not display Malfunction:
    - Pressure Control Solenoid Valve 5 Performance Test Status
    - Pressure Control Solenoid Valve 5 Control Circuit High Voltage Test Status
    - Pressure Control Solenoid Valve 5 Control Circuit Low Voltage Test Status
    - **If Malfunction is displayed**

      Replace the Q8 Control Solenoid Valve Assembly.

    - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P2762, P2763, OR P2764: TORQUE CONVERTER CLUTCH (TCC) PRESSURE CONTROL SOLENOID

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptors

DTC P2762

Torque Converter Clutch (TCC) Pressure Control Solenoid Valve Performance

DTC P2763

Torque Converter Clutch (TCC) Pressure Control Solenoid Valve Control Circuit High Voltage

DTC P2764

cardiagn.com

Torque Converter Clutch (TCC) Pressure Control Solenoid Valve Control Circuit Low Voltage

Circuit/System Description

The torque converter clutch (TCC) pressure control solenoid is part of the control solenoid valve assembly which has no serviceable parts. The normally low TCC pressure control solenoid regulates oil pressure to the TCC regulator valve and TCC control valve. Increasing TCC pressure control solenoid oil pressure increases oil pressure to the torque converter to apply the clutch. The Transmission Control Module varies the current to the TCC pressure control solenoid through a low side driver. Increasing current to the TCC pressure control solenoid increase oil pressure by closing OFF the solenoid exhaust port. Decreasing current to the TCC pressure control solenoid decreases oil pressure by opening up the solenoid exhaust port. The TCC pressure control solenoid power is supplied by the Transmission Control Module through a high side driver. The high side driver protects the circuit and components from excessive current flow. If excessive current flow is detected, the high side driver will turn OFF. When the fault is corrected, the high side driver will reset.

Conditions for Running the DTC

P2762

- DTC P2762 is not set.
- The engine speed is between 400-7,500 RPM for 5 s.
- The ignition voltage is between 8.6-32 V.

P2763

- DTCs P2763, P0658, or P0659 is not set.
- The engine speed is between 400-7,500 RPM for 5 s.
- The ignition voltage is between 8.6-32 V.
- The high side driver is enabled.

P2764

- DTC P2764, P0658, or P0659 is not set.
- The engine speed is between 400-7,500 RPM for 5 s.
- The ignition voltage is between 8.6-32 V.
- The high side driver is enabled.

Conditions for Setting the DTC

P2762

The Transmission Control Module detects an internal electrical performance malfunction of the TCC pressure control solenoid control circuit where the measured TCC pressure control solenoid current does not equal the commanded TCC pressure control solenoid current for 5 s.

P2763

The Transmission Control Module detects an open/high resistance or short to voltage on the TCC pressure control solenoid control circuit for 5 s.

P2764

cardiagn.com

The Transmission Control Module detects a short to ground on the TCC pressure control solenoid control circuit for 1 min.

Action Taken When the DTC Sets

P2762

DTC P2762 is a Type C DTC.

P2763

- DTC P2763 is a Type B DTC.
- The TCM inhibits TCC.
- The TCM commands maximum line pressure.
- The TCM freezes transmission adaptive functions.
- The TCM enables Torque management.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits manual shifting of forward gears.
- The TCM inhibits 6th gear in hot mode operation.

P2764

- DTC P2764 is a Type A DTC.
- The TCM turns off the high side driver.
- The TCM inhibits TCC.
- The TCM freezes transmission adaptive functions.
- The TCM commands maximum line pressure.
- The TCM inhibits TAP Up/Down function.
- The TCM inhibits Manual Up/Down Shift with the shift selector.
- The TCM inhibits neutral idle.
- The ECM reduces engine torque based on input speed.

Conditions for Clearing the DIC/DTC

- DTC P2762 is a Type C DTC.
- DTC P2763 is a Type B DTC.
- DTC P2764 is a Type A DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

cardiagn.com

Description and Operation

- **Transmission General Description**
- **Transmission Component and System Description**
- **Electronic Component Description**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

DT-47825-10 Jumper Harness

For equivalent regional tools, refer to **Special Tools** .

Circuit/System Verification

1. Operate the vehicle in drive range and ensure TCC is commanded ON for 1 minute.
2. Verify the scan tool parameters listed below do not display Malfunction:
   - TCC Pressure Control Solenoid Valve Performance Test Status
   - TCC Pressure Control Solenoid Valve Control Circuit High Voltage Test Status
   - TCC Pressure Control Solenoid Valve Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Refer to Circuit/System Testing.

   - **If Malfunction is not displayed**
3. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observe from the Freeze Frame/Failure Records data.
4. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
5. All OK.

Circuit/System Testing

cardiagn.com

NOTE: **You must perform the Circuit/System Verification first.**

1. Ignition OFF, remove the Q8 Control Solenoid Valve Assembly.
2. Verify the Q8 Control Solenoid Valve Assembly is not contaminated with any debris. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If contaminated**

     Clean as necessary.

   - **If not contaminated**
3. Verify the resistance is within the specified range for each solenoid. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
   - **If resistance is not within range**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If resistance is within range**
4. Place the Q8 Control Solenoid Valve Assembly on a clean work surface near the transmission assembly.
5. Connect **DT-47825-10** jumper harness between the vehicle wire harness electrical connector and the Q8 Control Solenoid Valve Assembly electrical connector. Ignition ON.
6. Verify the scan tool parameters do not display Malfunction:
   - TCC Pressure Control Solenoid Valve Performance Test Status
   - TCC Pressure Control Solenoid Valve Control Circuit High Voltage Test Status
   - TCC Pressure Control Solenoid Valve Control Circuit Low Voltage Test Status
   - **If Malfunction is displayed**

     Replace the Q8 Control Solenoid Valve Assembly.

   - **If Malfunction is not displayed**
7. All OK.

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the repair.

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- **Control Module References** for control solenoid valve assembly replacement, programming, and setup.

DTC P2771: FOUR WHEEL DRIVE (4WD) SWITCH (NQF OR NQH)

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

DTC P2771

cardiagn.com

Four Wheel Drive (4WD) Switch Circuit

Circuit/System Description

On vehicles equipped with 4 wheel drive, the output speed sensor is on the transfer case. The instrument panel mounted transfer case shift control switch consist of a 2HI position, 4HI and 4 Low. The transfer case shift control module continuously monitors the signal to determine the position selected by the vehicle operator. The transfer case shift control module sends the status of the transfer case range out on the serial data line to other control modules. The transmission control module (TCM) monitors the status of the transfer range. When the transfer case is in the 4 Low range, the TCM multiples the transfer case output shaft speed by the transfer case ratio in 4 Low to determine the transmission output shaft speed. The TCM uses this information to provide earlier upshifts and also to prevent an over-speed condition in 4 Low.

Conditions for Running the DTC

- The engine speed is greater than 200 RPM.
- The transmission output speed is greater than 60 RPM.
- The transmission fluid temperature is between 20Â°C (68Â°F) and 130Â°C (266Â°F).
- Shift is complete and range attained is not neutral.
- DTC P0721, P0722, or P2771 is not set.

Conditions for Setting the DTC

Condition 1

Transfer case four wheel drive switch indicates high range and the calculated transfer case range is low for 5 seconds.

Condition 2

Transfer case four wheel drive switch indicates low range and the calculated transfer case range is high for 5 seconds.

Action Taken When the DTC Sets

- DTC P2771 is a Type B DTC.
- The TCM detects four wheel drive high and low range with calculated speed ratios.

Conditions for Clearing the DTC

DTC P2771 is a Type B DTC.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

cardiagn.com

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Circuit/System Verification

1. Ignition ON, transmission in Neutral, place the transfer case shift control switch in the 2 HI position.
2. Verify the 2 high indicator light on the switch is ON and not flashing.
   - **If the 2 high indicator light is flashing or is not ON**

     Refer to Circuit/System Testing.

   - **If 2 high indicator light is ON and not flashing**
3. Verify the scan tool TCM 4WD Low parameter displays Disabled.
   - **If Disabled is not displayed**

     Refer to Circuit/System Testing.

   - **If Disabled is displayed**
4. Place the transfer case shift control switch in the 4 Low position.
5. Verify the 4WD low indicator light is ON and not flashing.
   - **If the 4WD low indicator light is flashing or is not ON**

     Refer to Circuit/System Testing.

   - **If the 4WD low indicator light is ON and not flashing**
6. Operate the vehicle within the Conditions for Running the DTC to verify the DTC does not reset. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records data.
7. Verify the DTC does not set.
   - **If the DTC sets**

     Refer to Circuit/System Testing.

   - **If the DTC does not set**
8. All OK.

Circuit/System Testing

cardiagn.com

1. Verify no other DTCs are set.
    - **If other DTCs are set**

      Refer to **Diagnostic Trouble Code (DTC) List - Vehicle** .

    - **If no other DTCs are set**
2. Refer to **Symptoms - Transfer Case** .

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

- Perform the **FastLearn Procedure** following all transmission repairs
- **Control Module References** for Transmission Control Module replacement, setup, and programming

DTC P2771: FOUR WHEEL DRIVE (4WD) LOW SWITCH (NQG)

Diagnostic Instructions

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor

DTC P2771

Four Wheel Drive (4WD) Low Switch Circuit

Diagnostic Fault Information

Circuit	Short to Ground	Open/High Resistance	Short to Voltage	Signal Performance
4WD Low Signal	P2771	P2771	-	-

Circuit/System Description

Circuit	Description
4WD Low Signal	The control module input circuit has an internal resistance connected to 12 V. When the switch is closed it will pull the signal voltage low.
Components: K20 Engine Control Module M26 Front Axle Engagement Actuator S77 Transfer Case Shift Control Switch	

The S77 Transfer Case Shift Control Switch contains the 4WD Low Signal circuit with its internal ground and the front Axle Actuator - Control circuit with its wired ground.

The NQG Transfer Case uses a dedicated 4WD Low circuit to notify the K20 Engine Control Module (ECM) that the vehicle is in 4WD low range. The ECM supplies 12 volts to the 4WD Low Signal circuit. When the operator selects 4WD Low, the S77 Transfer Case Shift Control Switch grounds the signal circuit. The voltage

cardiagn.com

on the 4WD low signal circuit changes from ignition voltage to zero volts. The ECM detects this voltage change and sends a message to the K71 Transmission Control Module (TCM) that the transfer case is in 4WD Low. The TCM then compensates for transfer case gear reduction in the B14 Transmission Output Shaft Speed (OSS) Sensor signal. The TCM uses the transmission OSS sensor signal to adjust shift points, line pressure and torque converter clutch (TCC) scheduling.

The S77 Transfer Case Shift Control Switch also controls the grounding of the front Axle Actuator - Control circuit which controls the engagement/disengagement of the front axle. When the front Axle Actuator - Control circuit is Open, the plunger on the M26 Front Axle Engagement Actuator is retracted which disengages the front axle. When closed, the plunger on the front axle engagement actuator is extended engaging the front axle.

Conditions for Running the DTC

- No throttle position (TP) sensor DTCs P0122, or P0123.
- No OSS assembly DTCs P0722 or P0723.
- No cam or crank sensor DTCs.
- The system voltage is 9-18 volts.
- The engine speed is 2,000-5,500 RPM for at least 30 seconds.
- Engine torque 80 (8.85 lbf-in).
- The vehicle speed is at least 15 km/h (9 mph).
- The TP angle is 10-40 percent.
- The gear range is not PARK, NEUTRAL or REVERSE.
- The TFT is -7 to +130Â°C (19 to +266Â°F).

Conditions for Setting the DTC

The ECM calculated transfer case ratio is not consistent with the position of the transfer case shift control switch.

Condition 1

The transfer case shift control switch indicates 2WD High or 4WD High and the ECM calculated transfer case range indicates a 4WD Low transfer case ratio of 2.64-2.9, for 2 seconds.

OR

Condition 2

The Transfer Case Shift Control Switch indicates 4WD Low range and the ECM calculated transfer case range indicates a 2WD High OR 4WD High transfer case ratio of 0.8-1.75, for 2 seconds.

Action Taken When the DTC Sets

- DTC P2771 is a Type B DTC.
- The ECM commands a 4WD High shift pattern, not a 4WD Low shift pattern.

Conditions for Clearing the DTC

DTC P2771 is a Type B DTC.

Diagnostic Aids

cardiagn.com

- A malfunctioning speed sensor could cause DTC P2771 to set.
- Verify that the input speed sensor (ISS) and the OSS are functioning properly.
- Road test the vehicle while monitoring the transmission OSS parameter on the scan tool. The transmission OSS parameter should vary with transmission ISS and engine speed. As engine speed increases, transmission ISS and OSS RPM should increase. As engine speed decreases, transmission ISS and OSS RPM should decrease. If not refer to DTC P0716 for the ISS and DTC P0723 for the OSS.
- If the speed sensors pass testing, refer to **Testing for Intermittent Conditions and Poor Connections** .
- A fault on the Front Axle - Control circuit may cause DTC P2771 to set.
- Selecting 4WD Low and then driving the vehicle before the transfer case has time to change range to 4WD Low may set DTC P2771.
- Selecting 2WD High or 4WD High and then driving the vehicle before the transfer case has time to change range to the new range may set DTC P2771.
- **EL-49742** harness is a good source for B+ and ground.
- The transfer case drain plug is a good source for ground.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

COMPONENT CONNECTOR END VIEWS - INDEX

Description and Operation

Transmission General Description

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

DTC Type Reference

Powertrain Diagnostic Trouble Code (DTC) Type Definitions

Scan Tool Reference

Control Module References for scan tool information

Special Tools

EL 49742 Battery Voltage B+ and Ground Source Harness

J 35616 GM-Approved Terminal Test Kit

For equivalent regional tools, refer to **Special Tools** .

cardiagn.com

Circuit/System Verification

1. Verify that the Trans IGN 1 fuse, fuse 19 (Gas)/fuse 13 (Diesel), X50A Fuse Block - Underhood is NOT open.
   - **If the Trans IGN 1 fuse is OPEN**

     Refer to Circuit/System Testing.

   - **If the Trans IGN 1 fuse is NOT OPEN**
2. Parking brake ON. Transmission in Neutral.

   NOTE: **It may be necessary to drive the vehicle slightly forward to engage 4WD Low on the transfer case.**

3. Verify that the, 4WD Low Signal parameter, reads Enabled/Disabled when using the Transfer Case Control Lever to go In/Out of 4WD Low.
   - If the parameter does not perform as specified.

     Refer to Circuit/System Testing.

   - If the parameter does perform as specified.
4. Verify DTC P2771 is only set as a history DTC.
   - **If DTC P2771 is set as current**

     Refer to Circuit/System Testing.

   - **If DTC P2771 is only set as history**

   NOTE: **After inspection, apply Nyogel lubricant 760G to each connector terminal. Ensure each connector and CPA is correctly seated.**

5. Visually inspect each connector terminal of the K20 Engine Control Module X1 connector, the S77 Transfer Case Shift Control Switch connector and the M26 Front Axle Engagement Actuator connector for damage or corrosion. Repair as necessary.
6. Clear DTC P2771 from history.
7. Operate the vehicle within the Conditions for Running the DTC. You may also operate the vehicle within the conditions that you observed from the Freeze Frame/Failure Records data. The DTC should not set.
   - **If DTC P2771 sets**

     Refer to Circuit/System Testing.

   - **If DTC P2771 does not set**
8. All OK.

Circuit/System Testing

1. Ignition OFF, disconnect the harness connector at the S77 Transfer Case Shift Control Switch.
2. Ignition ON, engine OFF. Transfer Case NOT in 4WD Low.

   NOTE:
   - **When test probing harness terminals, it is imperative to use the**

cardiagn.com

proper test probe from the most current version of the J-35616 kit. Use of an improper test probe may deform the terminal, resulting in intermittent open conditions.

- **Testing for steps 3-5 is performed on the S77 Transfer Case Shift Control Switch harness connector using the GY probes J-35616-2A kit.**
  - **To Component Testing - K20 Engine Control Module.**

3. Test for Ignition Voltage between the 4WD Low Signal circuit, terminal B and chassis ground.
   - **If less than Ignition Voltage**
   1. Test for infinite resistance between the 4WD Low Signal circuit, terminal B and chassis ground.
   2. If 10 Ω Ignition OFF, disconnect the X1 harness connector at the K20 Engine Control Module.
   3. Test for less than 10 Ω in the 4WD Low Signal circuit end to end.
      - If 10 Ω or greater, repair the open/high resistance in the circuit.
      - If less than 10 Ω
   4. Test infinite resistance between the 4WD Low Signal circuit and ground.
      - Test less than infinite resistance, repair the short to ground in the circuit.
      - If greater than 10 Ω
   5. Test for infinite resistance between 4WD Low Signal circuit, terminal B and all other terminals of the S77 Transfer Case Shift Control Switch.
      - If 1 Ω or less, repair the short together condition in the affected circuits.
      - If greater than 1 Ω
   6. Ignition ON.
   7. Test for a less than 1.0 V between the 4WD Low Signal circuit, terminal B, and ground.
      - If 1.0 V or greater, repair the short to voltage in the circuit.
      - If less than 1 V, test the K20 Engine Control Module for proper operation.
   - **If Ignition Voltage**

4. Test for less than 10 Ω between the ground circuit, terminal A and chassis ground.
   - **If 10 Ω or greater**
   1. Ignition OFF, disconnect the following grounding bolt. Refer to **Ground Views** .
      - G102 for 4.8L/5.3L/6.0L and 6.2L
      - G103 for Diesel
      - G107 for 4.3L
   2. Test for less than 10 Ω in the ground circuit end to end.
      - If 10 Ω or greater, repair the open/high resistance in the circuit.
      - If less than 10 Ω
   3. Test for infinite resistance between the ground circuit, terminal A and chassis ground.
      - If less than infinite resistance, repair the short to ground in the circuit.
      - If infinite resistance
   4. Test for infinite resistance between ground circuit, terminal A and all other terminals of the S77 Transfer Case Shift Control Switch harness connector.
      - If less than infinite resistance, repair the short together condition in the affected circuits.

cardiagn.com

- If infinite resistance

5. Ignition ON.
6. Test for a less than 1.0 V between the ground circuit, terminal A, and chassis ground.
    - If 1.0 V or greater, repair the short to voltage in the circuit.
    - If less than 1 V, clean the grounding surface and check for intermittent conditions and poor connections.

      Refer to **Testing for Intermittent Conditions and Poor Connections** .

- **If less than 10 Ω**

  Test for Ignition Voltage between the Front Axle Actuator Control circuit, terminal C and the ground circuit, terminal A.

- **If less than Ignition Voltage**

1. Ignition OFF, disconnect the harness connector at the M26 Front Axle Engagement Actuator.
2. Test for less than 10 Ω in the Front Axle Actuator Control circuit end to end.
    - If 10 Ω or greater, repair the open/high resistance in the circuit.
    - If less than 10 Ω
3. Test for infinite resistance between the Front Axle Actuator Control circuit, terminal C and chassis ground.
    - If 10 Ω or less, repair the short to ground in the circuit.
    - If greater than 10 Ω
4. Test for infinite resistance between Front Axle Actuator Control circuit, terminal C and all other terminals of the S77 Transfer Case Shift Control Switch harness connector.
    - If 1 Ω or less, repair the short together condition in the affected circuits.
    - If greater than 1 Ω
5. Ignition ON.
6. Test for a less than 1.0 V between the Front Axle Actuator Control circuit, terminal C, and ground.
    - If 1.0 V or greater, repair the short to voltage in the circuit.
    - If less than 1 V, test the M26 Front Axle Engagement Actuator for proper operation.

      Refer to Component Testing - M26 Front Axle Engagement Actuator.

- **If Ignition Voltage**

NOTE:

- **When test probing harness terminals, it is imperative to use the proper test probe from the most current version of the J-35616 kit. Use of an improper test probe may deform the terminal, resulting in intermittent open conditions.**
- **Testing for steps 6-7 is performed on the M26 Front Axle Engagement Actuator harness connector using the GY probes J-35616-2A kit.**

5. Test for less than 10 Ω between the ground circuit, terminal E and chassis ground.
    - **If 10 Ω or greater**

1. Ignition OFF, disconnect the following grounding bolt. Refer to **Ground Views** .

cardiagn.com

- G102 for 4.8L/5.3L/6.0L and 6.2L
- G103 for Diesel
- G107 for 4.3L

2. Test for less than 10 Ω in the ground circuit end to end.
    - If 10 Ω or greater, repair the open/high resistance in the circuit.
    - If less than 10 Ω
3. Test for infinite resistance between the ground circuit, terminal A and chassis ground.
    - If 10 Ω or less, repair the short to ground in the circuit.
    - If greater than 10 Ω
4. Test for infinite resistance between ground circuit, terminal A and all other terminals of the M26 Front Drive Axle Actuator harness connector.
    - If 10 Ω or less, repair the short together condition in the affected circuits.
    - If greater than 10 Ω
5. Ignition ON.
6. Test for a less than 1.0 V between the ground circuit, terminal E, and ground.
    - If 1.0 V or greater, repair the short to voltage in the circuit.
    - If less than 1 V, clean the grounding surface and check for intermittent conditions and poor connections.

      Refer to **Testing for Intermittent Conditions and Poor Connections** .

- **If less than 10 Ω**

6. Test for Ignition Voltage between the Ignition 1 Voltage circuit, terminal C and the ground circuit, terminal E.
    - **If less than Ignition Voltage**
    1. Ignition OFF, disconnect the X2 harness connector at the X50A Fuse Block - Underhood.
    2. Test for less than 10 Ω in the Ignition 1 Voltage circuit end to end.
        - If 10 Ω or greater, repair the open/high resistance in the circuit.
        - If less than 10 Ω
    3. Test for infinite resistance between the Ignition 1 Voltage circuit, terminal C and chassis ground.
        - If 10 Ω or less, repair the short to ground in the circuit.
        - If greater than 10 Ω
    4. Test for infinite resistance between Ignition 1 Voltage circuit, terminal C and all other terminals of the M26 Front Axle Engagement Actuator harness connector.
        - If 1 Ω or less, repair the short together condition in the affected circuits.
        - If greater than 1 Ω
    5. Ignition ON.
    6. Test for a less than 1.0 V between the Ignition 1 Voltage circuit, terminal C, and ground.
        - If 1.0 V or greater, repair the short to voltage in the circuit.
        - If less than 1 V, test the M26 Front Axle Engagement Actuator for proper operation. Refer to Component Testing - M26 Front Axle Engagement Actuator.
    - **If Ignition Voltage**

cardiagn.com

Refer to Component Testing/ **Testing for Intermittent Conditions and Poor Connections** .

Component Testing

S77 Transfer Case Shift Control Switch

NOTE: **Circuit/System Testing must be performed before Component Testing.**

1. Ignition OFF. Disconnect the connector at the S77 Transfer Case Shift Control Switch.

NOTE:

- **When test probing harness terminals, it is imperative to use the proper test probe from the most current version of the J-35616 kit. Use of an improper test probe may deform the terminal, resulting in intermittent open conditions.**
- **Testing for steps 2-3 is performed on the S77 Transfer Case Shift Control Switch using the GY probes J-35616-3 kit.**

2. Verify the resistance for each of the transfer case positions listed below between the 4WD Low Signal circuit, terminal B and the chassis ground.
   - If the resistance is outside the specified ranges, replace the Transfer Case Shift Control Switch.
   - If the resistance is within the specified ranges.
3. Verify the resistance for each of the transfer case positions listed below between the Front Axle Actuator Control circuit, terminal C and the ground circuit, terminal A.
   - If the resistance is outside the specified ranges, replace the S77 Transfer Case Shift Control Switch.
   - If the resistance is within the specified ranges.
4. Test the K20 Engine Control Module for proper operation.

4WD Low Signal Circuit

Range	Range	Nominal
2WD High	Greater than 10 Ω	∞ Ω
4WD High	Greater than 10 Ω	∞ Ω
4WD Low	Less than 10 Ω	1 Ω
Neutral	Greater than 10 Ω	∞ Ω

Front Axle Actuator Control Circuit

Range	Range	Nominal
2WD High	Greater than 10 Ω	∞ Ω
4WD High	Less than 10 Ω	0.6 Ω
4WD Low	Less than 10 Ω	1 Ω
Neutral	Greater than 10 Ω	∞ Ω

K20 Engine Control Module

NOTE: **Circuit/System Testing must be performed before Component Testing.**

NOTE:

- **When test probing harness terminals, it is imperative to use the proper test probe from the most current version of the J-35616 kit.**

cardiagn.com

Use of an improper test probe may deform the terminal, resulting in intermittent open conditions.

- **Testing for steps 3-5 is performed on the S77 Transfer Case Shift Control Switch using the GY probes J-35616-3 kit.**

1. Ignition OFF. Disconnect the connector at the S77 Transfer Case Shift Control Switch.
2. Ignition ON, Engine OFF. Install a scan tool.
3. Verify the 4WD Low parameter displays DISABLED.
    - **If the 4WD Low parameter displays ENABLED**
    1. Test for Ignition Voltage between the 4WD Low Signal circuit, terminal B and chassis ground.
        - If less than Ignition Voltage
        1. Ignition OFF, disconnect the X1 harness connector at the K20 Engine Control Module.
        2. Test for less than 10 Ω in the 4WD Low Signal circuit end to end.
            - If 10 Ω or greater, repair the open/high resistance in the circuit.
            - If less than 10 Ω
        3. Test infinite resistance between the 4WD Low Signal circuit and ground.
            - Test less the infinite resistance, repair the short to ground in the circuit.
            - If greater than 10 Ω
        4. Test for infinite resistance between 4WD Low Signal circuit, terminal B and all other terminals of the S77 Transfer Case Shift Control Switch.
            - If less than infinite resistance, repair the short together condition in the affected circuits.
            - If infinite resistance, replace the K20 Engine Control Module. Refer to **Control Module References** .
            - If Ignition Voltage
        5. Ignition OFF, disconnect the X1 harness connector at the K20 Engine Control Module.
        6. Ignition ON.
        7. Test for a less than 1.0 V between the 4WD Low Signal circuit, terminal B, and ground.
            - If 1.0 V or greater, repair the short to voltage in the circuit.
            - If less than 1 V
        8. Test for infinite resistance between 4WD Low Signal circuit, terminal B and all other terminals of the S77 Transfer Case Shift Control Switch.
            - If less than infinite resistance, repair the short together condition in the affected circuits.
            - If infinite resistance, replace the K20 Engine Control Module. Refer to **Control Module References** .
4. Using a GY probe **J-35616-3** kit , connect a fused jumper between the 4WD Low Signal circuit, Transfer Case Shift Control Switch terminal B, and chassis ground.
5. Verify the 4WD Low parameter displays ENABLED.
    - **If the 4WD Low parameter displays DISABLED**
    1. Test for Ignition Voltage between the 4WD Low Signal circuit, terminal B and chassis ground.
        - If less than Ignition Voltage

cardiagn.com

1. Ignition OFF, disconnect the X1 harness connector at the K20 Engine Control Module.
2. Test for less than 10 Ω in the 4WD Low Signal circuit end to end.
    - If 10 Ω or greater, repair the open/high resistance in the circuit.
    - If less than 10 Ω
3. Test infinite resistance between the 4WD Low Signal circuit and ground.
    - Test less the infinite resistance, repair the short to ground in the circuit.
    - If greater than 10 Ω
4. Test for infinite resistance between 4WD Low Signal circuit, terminal B and all other terminals of the S77 Transfer Case Shift Control Switch.
    - If less than infinite resistance, repair the short together condition in the affected circuits.
    - If infinite resistance, replace the K20 Engine Control Module. Refer to **Control Module References** .
    - If Ignition Voltage
5. Ignition OFF, disconnect the X1 harness connector at the K20 Engine Control Module.
6. Ignition ON.
7. Test for a less than 1.0 V between the 4WD Low Signal circuit, terminal B, and ground.
    - If 1.0 V or greater, repair the short to voltage in the circuit.
    - If less than 1 V
8. Test for infinite resistance between 4WD Low Signal circuit, terminal B and all other terminals of the S77 Transfer Case Shift Control Switch.
    - If less than infinite resistance, repair the short together condition in the affected circuits.
    - If infinite resistance, replace the K20 Engine Control Module. Refer to **Control Module References** .

M26 Front Axle Engagement Actuator

NOTE: Circuit/System Testing must be performed before Component Testing.

1. Ignition OFF. Disconnect the connector at the M26 Front Axle Engagement Actuator.
2. Remove the M26 Front Axle Engagement Actuator.
3. Connect the M26 Front Axle Engagement Actuator connector. Position the M26 Front Axle Engagement Actuator so that it is visible from the side of the vehicle.
4. Using the Front Axle Engagement Actuator control function of the scan tool, command the front axle to engage and disengage. When commanded to engage, the plunger on the M26 Front Axle Engagement Actuator should extend. When commanded to disengage, the plunger should retract.
    - **If the M26 Front Axle Engagement Actuator does NOT perform as described**

      Replace the M26 Front Axle Engagement Actuator. Refer to **Front Drive Axle Actuator Replacement (1500 Series)** **Front Drive Axle Actuator Replacement (2500/3500 Series)** .

    - **If the M26 Front Axle Engagement Actuator DOES perform as described**
5. Refer to **Front Axle Will Not Engage** , or **Front Axle Will Not Disengage** .

cardiagn.com

Repair Instructions

- Perform the **Reset Transmission Adapts** following all transmission related repairs.
- Perform the **Diagnostic Repair Verification** after completing the repair.
- Refer to **Control Module References** for Control Solenoid Valve Assembly replacement, programming, and setup.

SYMPTOMS - AUTOMATIC TRANSMISSION

Use the symptom tables only if the following conditions are met:

IMPORTANT:

- Refer to **Diagnostic Starting Point - Vehicle** .
- There are no DTCs set.
- The control modules can communicate via the serial data link.
- Review the system operation in order to familiarize yourself with the system functions. Refer to **Transmission General Description** , and **Transmission Component and System Description** .

Visual/Physical Inspection

Inspect the easily accessible or visible system components for obvious damage or conditions which could cause the symptom.

Intermittent

Faulty electrical connections or wiring may be the cause of intermittent conditions. Refer to **Testing for Intermittent Conditions and Poor Connections** .

Symptom List

Refer to a symptom diagnostic procedure from the following list in order to diagnose the symptom:

- Fluid Diagnosis
  - **Transmission Fluid Level and Condition Check**
  - **Fluid Pressure High or Low**
  - **Automatic Transmission Fluid Leaks**
  - **Fluid Leak Diagnosis**
- Noise and Vibration Diagnosis
  - **Whine/Growl Noise That Changes with Vehicle Speed**
  - **Whine/Growl Noise That Changes with Vehicle Speed**
  - **Noise in First or Reverse Gear**
  - **Noise in First, Second, Third, Fourth, Fifth, or Reverse Gear**
  - **Noise in First, Second, Sixth, or Reverse Gear**
  - **Noise in Second or Sixth Gear**
  - **Noise During 3-4 or 4-3 Shifts**
  - **Noise in Fourth, Fifth, or Sixth Gear**
  - **Vibration**

cardiagn.com

    - **Flex Plate/Torque Converter Vibration Test**
    - **Noise and Vibration Analysis**
- Range Performance Diagnosis
    - **No Park or Drive**
    - **No Drive in All Ranges**
    - **No Reverse Gear**
- Shift Quality Feel Diagnosis
    - **Harsh Garage Shift**
    - **Harsh, Soft, Delayed or Slipping First or Reverse Gear**
    - **Harsh, Soft, Delayed or Slipping 1-2-3-4 Shift**
    - **Harsh, Soft, Delayed or Slipping 4-5-6 Shift**
    - **Harsh, Soft, Delayed or Slipping Third, Fifth, or Reverse Gear**
    - **Harsh, Soft, Delayed or Slipping Second or Sixth Gear**
- Shift Pattern
    - **No First Gear**
    - **No First and Reverse Gears**
    - **No First, Second, Third, and Fourth Gear**
    - **No Second and Sixth Gear**
    - **No Fourth, Fifth, and Sixth Gear**
    - **No Third, Fifth, and Reverse Gear**
- Torque Converter Diagnosis
    - **Torque Converter Diagnosis**
    - **No Torque Converter Clutch Apply**
    - **No Torque Converter Clutch Release**
- Symptom Not Found or No Symptom Detected
    - **Transmission Fluid Level and Condition Check**
    - **Road Test**
    - **Line Pressure Check**

CONTROL SOLENOID VALVE AND TRANSMISSION CONTROL MODULE ASSEMBLY INSPECTION

During transmission manufacturing and assembly, small pieces of material may become dislodged. This may also happen after the transmission has been in operation for a period of time. Because the transmission control solenoid valve assembly is continually immersed in transmission oil, material particles or slivers of metallic debris may become deposited on the control solenoid valve assembly. Often this material is very small and can be hard to see. For this reason, it is important that the control solenoid valve assembly be thoroughly inspected.

A thorough inspection of the control solenoid valve assembly should include the following:

- Clean inspection area - Like all transmission service work, cleanliness is very important. Be sure the area where you are inspecting is free of dust and dirt. Have non-glossy white or lightly colored paper down on the inspection surface. This will enhance the lighting and help to see particles that have come from the control solenoid valve assembly.

cardiagn.com

- Lighting - Good lighting is necessary for a thorough inspection. If shop lighting is limited, use natural light. A second source of lighting, such as a penlight, is helpful for close examination. A magnifying glass can also be helpful to see into difficult places.
- Cleaning - Clean shop air may be used for spot cleaning as long as the debris can be removed with out it becoming lodged somewhere else. It is best to rinse or flush particles away with GM Brake Parts Cleaner. Do not use a cloth rag to wipe the control solenoid valve assembly, as it could leave lint behind.

Control Solenoid Valve Assembly Housing and Filter Plate




Fig. 1: View Of Control Solenoid (w/Body & TCM) Valve Assembly Housing & Filter Plate
Courtesy of GENERAL MOTORS COMPANY

NOTE: **At the end of the inspection process where debris is found, it is required the transmission fluid and filter be replaced. Any time the control solenoid valve assembly has been removed, it is mandatory the filter plate assembly (3) be replaced.**

1. Inspect the control solenoid valve assembly housing (1) for damage, cracks, or parting seam (4) separation. Inspect all housing lock tabs (2). Any defect will need to be evaluated for critical operation. Ensure all screws along the control solenoid valve assembly housing are present. Remove and closely examine the filter plate assembly (3) for sediment or debris attached to the screen. If sediment or debris is found on the filter screen, be sure to inspect the solenoid supply or control ports that correspond to location of the debris on the filter plate screen. Inspect the filter plate gasket for proper sealing. If poor sealing is found, be sure to inspect the affected solenoid fluid port entrance and exit for sediment or debris deposits. Thoroughly flush the solenoid cavity with GM Brake Parts Cleaner and replace the filter plate assembly (3). It is not necessary to remove all clutch plate soot from the entire surface of the control solenoid valve assembly housing. Inspect the control solenoid valve assembly filter plate retaining tabs (7). Broken or missing tabs do not require the control solenoid valve assembly be replaced. The filter plate can still be adequately aligned using the bolt hole sleeves. Early design control solenoid valve

cardiagn.com

assembly use four filter plate retaining tabs (7).

2. Examine the 16-way connector (5) cavity for material that could make contact between the electrical pins. Also, look for bent or loose connector pins and ensure the connector lock (6) is functioning and is in good condition.

Control Solenoid Valve Assembly Inspection - Solenoids, Sensors, and Contacts




Fig. 2: View Of Control Solenoid (w/Body & TCM) Valve Assembly Inspection - Solenoids, Sensors & Contacts

Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Pressure Control Solenoid 3 (PCS3)
2	Pressure Control Solenoid 4 (PCS4)
3	Pressure Control Solenoid 2 (PCS2)
4	Shift Solenoid 2 (SS2)
5	Torque Converter Clutch (TCC) Solenoid
6	Pressure Control Solenoid 5 (PCS5)
7	Pressure Control Solenoid 1 (PCS1)
8	Shift Solenoid 1 (SS1)

cardiagn.com

Callout	Component Name
9	Transmission Fluid Temperature (TFT) Sensor
10	Input Speed Sensor/Output Speed Sensor (ISS/OSS) Connector
11	Pressure Control Solenoid 3 (PCS3) Contact Lead
12	Pressure Control Solenoid 4 (PCS4) Contact Lead
13	Pressure Control Solenoid 2 (PCS2) Contact Lead
14	Shift Solenoid 2 (SS2) Contact Lead
15	Torque Converter Clutch (TCC) Solenoid Contact Lead
16	Pressure Control Solenoid 5 (PCS5) Contact Lead
17	Pressure Control Solenoid 1 (PCS1) Contact Lead
18	Shift Solenoid 1 (SS1) Contact Lead
19	Internal Mode Switch (IMS) Connector
20	Metallic Slivers, Debris or Sediment

1. With the filter plate removed, the control solenoid valve assemblies (1-8) can be inspected. Closely examine the solenoid electrical contact lead solder connections (11-18). Look for material that could make contact between the electrical leads. This is where material particles, metallic slivers, debris or sediment (20) can collect. Carefully inspect all sixteen solenoid electrical contact leads (11-18) for build up of material that could form an electrical short. Inspect the solenoid contact leads (11-18) for terminal separation or weak solder joints. Thoroughly flush away all debris with GM Brake Parts Cleaner.
2. Inspect the transmission fluid temperature (TFT) sensor (9), the input speed sensor/output speed sensor (ISS/OSS) connector (10), and the internal mode switch (IMS) connector (19). Look inside the connector cavities for material that could make contact between the electrical pins. Also look for bent or loose electrical pins. If the TFT sensor (9) is heavily coated with clutch soot, rinse with GM Brake Parts Cleaner.
3. Check the resistance of the solenoids at room temperature and verify with the following table. If the resistance is not within the expected range, carefully inspect the solenoid contact leads.

Solenoid Resistance

Solenoid Name	Illustration Number of Solenoid Lead	Expected Resistance (Ohms)
Pressure Control Solenoid 3 (PCS3)	11	4.5-5.5 Ω
Pressure Control Solenoid 4 (PCS4)	12	4.5-5.5 Ω
Pressure Control Solenoid 2 (PCS2)	13	4.5-5.5 Ω
Shift Solenoid 2 (SS2)	14	23.5-24.5 Ω
Torque Converter Clutch (TCC) Solenoid	15	4.5-5.5 Ω
Pressure Control Solenoid 5 (PCS5)	16	4.5-5.5 Ω
Pressure Control Solenoid 1 (PCS1)	17	4.5-5.5 Ω
Shift Solenoid 1 (SS1)	18	23.5-24.5 Ω

Control Solenoid Valve Assembly Supply and Control Fluid Inspection

cardiagn.com




Fig. 3: View Of Control Solenoid (w/Body & TCM) Valve Assembly Supply & Control Fluid Inspection
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Shift Solenoid 1 Supply Port
2	Shift Solenoid 1 Control Port
3	Line Pressure Control Solenoid 1 Control Port
4	Line Pressure Control Solenoid 1 Supply Port
5	Pressure Control Solenoid 5 Supply Port
6	Pressure Control Solenoid 5 Control Port
7	TCC Pressure Control Solenoid Control Port
8	TCC Pressure Control Solenoid Supply Port
9	Shift Solenoid 2 Supply Port
10	Shift Solenoid 2 Control Port
11	Pressure Control Solenoid 2 Control Port
12	Pressure Control Solenoid 2 Supply Port
13	Pressure Control Solenoid 4 Supply Port
14	Pressure Control Solenoid 4 Control Port
15	Pressure Control Solenoid 3 Control Port
16	Pressure Control Solenoid 3 Supply Port
17	Transmission Fluid Pressure (TFP) Switch 5
18	Transmission Fluid Pressure (TFP) Switch 3
19	Transmission Fluid Pressure (TFP) Switch 1
20	Transmission Fluid Pressure (TFP) Switch 4
21	TFP Switch Membrane
22	TFP Switch Gasket

cardiagn.com

1. With the filter plate removed, the control solenoid valve fluid supply and control ports (1-16) can be inspected. Solenoid openings are identified in the illustration. Inspect the following supply and control opening for material particles, metallic slivers, debris, or sediment. Look into solenoid fluid supply openings 1, 4, 5, 8, 9, 12, 13, and 16. Look inside the solenoid fluid control ports 2, 3, 6, 7, 10, 11, 14 and 15. If sediment or debris is found in any one of these port openings, look for holes or tears in the filter plate screen. The filter plate gasket may be leaking caused by a torn gasket, poor sealing, or a deformed plate. As necessary, thoroughly flush away all debris in the supply and control fluid ports with GM Brake Parts Cleaner.
2. Inspect the four transmission fluid pressure (TFP) switches (17-20) for trapped debris or sediment. Any sediment or debris found under a switch membrane requires the control solenoid valve assembly to be replaced. Check all TFP switch membranes (21) for cracks, cuts or pin holes. Ensure all TFP switch gaskets (22) are secure and are not deformed, torn, or improperly seated. As necessary, thoroughly rinse debris and sediment from the top of the switches. It is not necessary to remove the clutch plate soot from the entire surface of the control solenoid valve assembly housing.

CONTROL SOLENOID VALVE AND TRANSMISSION CONTROL MODULE ASSEMBLY INPUT SHAFT SPEED/OUTPUT SHAFT SPEED INPUT TEST

Special Tools

- **DT-47825-10** Jumper Harness
- **J 35616** GM-Approved Terminal Test Kit
- **J 38522** Variable Signal Generator




Fig. 4: Identifying J 35616 And J 38522
Courtesy of GENERAL MOTORS COMPANY

The purpose of this test is to provide a simulated input/output speed sensor (ISS/OSS) signal to the control solenoid valve assembly ISS/OSS input circuits.

cardiagn.com

Transmission Input Speed Sensor

1. Ignition OFF, connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the control solenoid valve assembly electrical connector.
2. Disconnect the ISS/OSS wiring harness connector X3 (1) from the control solenoid valve assembly.
3. Ignition ON, test for 8.3-9.3 volts between the ISS/OSS voltage circuit terminal B on the control solenoid valve assembly and ground at the transmission case.
    - If not within the specified range, replace the control solenoid valve assembly. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
4. Using the **J 35616** terminal test kit , connect the **J 38522** variable signal generator red lead to the ISS signal circuit terminal A on the TCM.
5. Connect the black lead from the **J 38522** variable signal generator to ground at the transmission case.
6. Set the **J 38522** variable signal generator to 5 volts, the frequency to 300, and the percent duty cycle to 50 or the normal position.
7. Ignition ON, verify with a scan tool the Transmission ISS parameter is between 760-785 RPM.
    - If not within the specified range, replace the control solenoid valve assembly. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .

Transmission Output Speed Sensor

1. Ignition OFF, connect the **DT-47825-10** jumper harness between the vehicle wire harness electrical connector, and the control solenoid valve assembly electrical connector.
2. Disconnect the ISS/OSS wiring harness connector X3 (1) from the control solenoid valve assembly.
3. Ignition ON, test for 8.3-9.3 volts between the ISS/OSS voltage circuit terminal B on the control solenoid valve assembly and ground at the transmission case.
    - If not within the specified range, replace the control solenoid valve assembly. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .
4. Using the **J 35616** terminal test kit , connect the **J 38522** variable signal generator red lead to the OSS signal circuit terminal C on the TCM.
5. Connect the black lead from the **J 38522** variable signal generator to ground at the transmission case.
6. Set the **J 38522** variable signal generator to 5 volts, the frequency to 300, and the percent duty cycle to 50 or the normal position.
7. Ignition ON, verify with a scan tool the Transmission OSS parameter is between 495-505 RPM.
    - If not within the specified range, replace the control solenoid valve assembly. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Replacement** .

CONTROL SOLENOID VALVE AND TRANSMISSION CONTROL MODULE ASSEMBLY SOLENOID PERFORMANCE TEST

Special Tools

DT-47825 Control Solenoid Test Plate

The purpose of this procedure is to test the operation of the control solenoid valve assembly for a stuck open or stuck closed solenoid. The **DT-47825** control solenoid test plate bolts to the mounting surface of the control solenoid valve assembly. Pressurized air is routed into the aluminum test block, through the control solenoid valve assembly, and back to the gauge on the test block.

cardiagn.com

A pressure gauge is used to measure the pressurized air through the solenoid control ports. When a solenoid is commanded ON with the scan tool, pressurized air flows through the solenoid control port and displays on the pressure gauge. When the solenoid is commanded OFF with the scan tool, there is no pressurized air flow through the solenoid control port to the pressure gauge. The recommended shop air pressure for this test is 620.5-690.4 Kpa (90-100 psi).

Control Solenoid Valve Assembly with Control Solenoid Test Plate




Fig. 5: View Of Control Solenoid (w/Body & TCM) Valve Assembly With Control Solenoid Test Plate
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Filter Plate Assembly
2	Control Solenoid Valve Assembly
3	DT-47825 Control Solenoid Test Plate
4	Air Connection Port
5	Transmission 16-Way Pass-Through Connector
6	Electrical Connector Slide Lock
7	A/Trans Manual Shift Shaft Position Switch Assembly Electrical Connector
8	A/Trans Manual Shift Shaft Position Switch Assembly
9	Bolt M6 x 14.5

NOTE: **To avoid solenoid overheating and possible internal damage, do not continuously operate the solenoid for more than 2 minutes at a time.**

The TCM will normally cycle some of the transmission solenoids ON and OFF to keep the solenoid passages clean and clear. This is a normal function and may cause the valves to cycle open and closed quickly when the TCM is powered up. This can make the pressure gauge needle flicker or move from high and low as the valves

cardiagn.com

open and close, allowing air to exit the ports where the pressure gauge is not connected.

WARNING: Use of eye goggles is necessary to prevent personal injury.


WARNING: To avoid transmission fluid contact with exposed skin, use shop towels to cover the test plate parts in order to prevent fluid from being released into the air, as any remaining transmission fluid in the control solenoid valve assembly will be forced out, and bodily injury may occur.

It is necessary to drain the control solenoid valve assembly of all remaining transmission fluid before attaching the test plate. Use caution when attaching air to the test plate, as any residual transmission fluid in the control solenoid valve assembly will be forced out. Use shop towels to cover the test plate ports in order to prevent fluid from being released into the air.

Preliminary Procedures

1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
2. Remove the transmission fluid pan and filter. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement** .
3. Remove the transmission electrical connector. Refer to **Automatic Transmission Electrical Connector Passage Sleeve Replacement** .
4. Remove the control solenoid valve assembly from the transmission. Refer to **Control Valve Lower Body and Upper Body Replacement** .
5. Ensure that the manual shift shaft position switch is disconnected and removed before performing the test. Failure to disconnect the switch will cause inaccurate test results and possible misdiagnosis.

Solenoid Testing Procedure



cardiagn.com

Fig. 6: Identifying Solenoid Testing Procedure
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Regulated Air Supply
2	Test Ports
3	Scan Tool
4	Test Pressure Gauge
5	Electrical Connector Sleeve

CAUTION: Do not probe any circuit with a multi-meter. Resistance tests across the serial data bus circuits will damage the TCM.

CAUTION: The TCM connector sleeve allows the test tool harness to be correctly orientated for electrical operation of the TCM. Do not connect the test harness to the TCM without using the connector sleeve. Failure to use the sleeve could allow the test harness to be incorrectly positioned which will result in permanent TCM damage.

1. Align and install the electrical connector sleeve to the control solenoid valve assembly and secure with the connector slide lock.
2. If necessary, clean each side of the filter plate assembly and install the filter plate assembly back on the control solenoid valve assembly. Clean the mounting surface of the **DT-47825** control solenoid test plate.
3. Bolt the **DT-47825** control solenoid test plate to the control solenoid valve assembly mounting surface. Use the bolts and washers supplied with the tool to attach the test block. Tighten the bolts to 5 N.m (44 lb in).
4. Connect the test harness supplied with the **DT-47825** control solenoid test plate to the vehicle harness and to the TCM. Engage the connector locks.
5. Connect shop air to the **DT-47825** control solenoid test plate air inlet. Do not exceed the recommended air pressure of 620.5-689.4 Kpa (90-100 psi).
6. Connect the test pressure gauge to the test port for the solenoid to be tested.
7. With the ignition ON and the scan tool communicating with the vehicle, command the solenoid to be tested ON and OFF. Watch the air pressure gauge for a change as you command the solenoid. Refer to Control Solenoid Valve Assembly Solenoid Performance Test Plate to Component Identification for correct solenoid function and test plate port connections for the solenoid being tested.
8. The solenoid should allow air pressure to flow when commanded ON and prevent air pressure flow when commanded OFF. The test results are read on the pressure gauge.
9. Command the solenoid valve ON and OFF several times to determine the condition of the solenoid in question. Release the test air pressure from the pressure gauge between solenoid tests.

Control Solenoid Valve Assembly Solenoid Performance Test Plate to Component Identification

Solenoid	Test Plate Port	Commanded State	
		ON	OFF
PC Solenoid 2, 3-5 Rev. CL	C	Full pressure to gauge	No pressure to gauge
PC Solenoid 3, 4-5-6 Low Rev CL	A	Full pressure to gauge	No pressure to gauge
PC Solenoid 4, 2-6 CL	B	Full pressure to gauge	No pressure to gauge

cardiagn.com

Solenoid	Test Plate Port	Commanded State	
		ON	OFF
PC Solenoid 5, 1-2-3-4 CL	F	Full pressure to gauge	No pressure to gauge
Shift Solenoid 1	H	Full pressure to gauge	No pressure to gauge
Shift Solenoid 2	D	Full pressure to gauge	No pressure to gauge
TCC PC Solenoid	E	Full pressure to gauge	No pressure to gauge
Line PC Solenoid	G	Command to highest setting, full pressure to gauge	Command to lowest setting, below 620.5 Kpa (90 psi) to gauge

RESET TRANSMISSION ADAPTS

The Reset Transmission Adapts is a procedure for automatic transmissions in which the shift pressure learn values of each individual clutch is reset to zero or a base calibrated value, in the transmission control module (TCM).

Once the transmission adapts are set to zero or a calibrated value, the vehicle is then road test under various drive cycle events for the TCM to relearn shift pressure values for the best possible shift feel in all gear ranges.

The Reset Transmission Adapts procedure must be performed when one of the following repairs have been made to the transmission. Failure to perform the procedure after one of the following repairs may result in poor transmission performance, DTCs being set, or customer dissatisfaction.

- Transmission internal service, repair or overhaul
- Valve body repair or replacement
- Control solenoid valve assembly replacement
- Any service/repair in response to a shift quality concern

1. Install any components or connectors that have been removed or replaced during diagnosis.
2. Perform any adjustments, programming or setup procedures that are required when a component or module is removed or replaced.
3. Clear the DTCs.
4. Ignition OFF, all vehicle systems OFF, this may take up to 2 minutes.

NOTE: **Do not cycle or turn the ignition switch OFF until directed to do so below.**

5. Ignition ON, engine running, with a scan tool Reset Transmission Adapts.
6. Perform the **Road Test**.
7. Ignition OFF for 2 minutes.

TOW/HAUL SWITCH/INDICATOR ALWAYS ON OR INOPERATIVE

cardiagn.com




Fig. 7: View Of Tow/Haul Switch/Indicator
Courtesy of GENERAL MOTORS COMPANY

Circuit/System Description

The Tow/Haul Mode indicator bulb on the instrument cluster is supplied 12 volts and ground by the instrument cluster module. When the Tow/Haul mode is selected, the body control module will send a request on the serial data communication line to the instrument cluster module to turn ON the Tow/Haul indicator. Pressing and releasing the Tow/Haul Switch again will turn OFF the indicator and return the transmission to normal shifting.

Diagnostic Aids

If the electrical circuit checks are OK and the tow/haul shift pattern is not occurring, there may be a mechanical/hydraulic condition that prevents tow/haul operation. Refer to **Symptoms - Automatic Transmission**.

Reference Information

Schematic Reference

Automatic Transmission Controls Schematics

Connector End View Reference

- **COMPONENT CONNECTOR END VIEWS - INDEX**
- **INLINE HARNESS CONNECTOR END VIEWS - INDEX**

Electrical Information Reference

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference

Control Module References for scan tool information

cardiagn.com

Circuit/System Verification

1. Ignition OFF, monitor the instrument cluster.
2. Ignition ON, verify the Tow/Haul mode indicator momentarily illuminates, during the instrument cluster bulb check.
    - **If the Tow/Haul indicator does not illuminate or is always ON**

      Refer to Circuit/System Testing.

    - **If the Tow/Haul indicator does illuminate and is not always ON**
3. Verify with a scan tool the Tow/Haul switch parameter changes from Inactive to Active and back to Inactive with each cycle of the switch.
    - **If the parameter does not change states**

      Refer to Circuit/System Testing.

    - **If the parameter does change states**
4. Verify the Tow/Haul indicator on the instrument cluster turns ON and OFF with each switch activation.
    - **If the indicator does not turn ON and OFF**

      Refer to Circuit/System Testing.

    - **If the indicator turns ON and OFF**
5. All OK.

Circuit/System Testing

1. Ignition OFF and all vehicle systems OFF. Disconnect the harness connector at the S3 Transmission Shift Lever. It may take up to 2 min. for all vehicle systems to power down.
2. Test for less than 5 Ω between the ground circuit terminal 2 and ground.
    - **If greater than 5 Ω**
    1. Ignition OFF.
    2. Test for less than 2 Ω in the ground circuit end to end.
        - If 2 Ω or greater, repair the open/high resistance in the circuit.
        - If less than 2 Ω, repair the open/high resistance in the ground connection.
    - **If less than 5 Ω**
3. Ignition OFF.
4. Test for less than 1 V on the signal circuit terminal 1 at the S3 Transmission Shift Lever harness connector.
    - **If greater than 1 V**
    1. Ignition OFF.
    2. Disconnect the X3 harness connector at the K9 Body Control Module. Ignition ON.
    3. Test for less than 1 V on the signal circuit terminal 1 at the S3 Transmission Shift Lever harness connector and ground.
        - If 1 V or greater, repair the short to B+/Ignition in the signal circuit.
        - If less than 1 V, replace the K9 Body Control Module.

cardiagn.com

- **If less than 1 V**

5. Ignition ON.
6. Test for 11.6-12.4 V on the signal circuit terminal 1 at the S3 Transmission Shift Lever harness connector and ground.
   - **If not between 11.6-12.4 V**
   1. Ignition OFF.
   2. Disconnect the X3 harness connector at the K9 Body Control Module.
   3. Test for less than 2 Ω in the signal circuit end to end.
      - If greater than 2 Ω, repair the open/high resistance in the circuit.
      - If less than 2 Ω, replace the K9 Body Control Module.
   - **If between 11.6-12.4 V**
7. Refer to **Symptoms - Data Communications**

Repair Instructions

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

Body Control Module (BCM) assembly replacement. Refer to **Control Module References** for replacement, setup, and programming.

TRANSMISSION FLUID LEVEL AND CONDITION CHECK

This procedure checks the transmission fluid level, as well as the condition of the fluid itself.

CAUTION: Always use the proper automatic transmission fluid listed. Using incorrect automatic transmission fluid may damage the vehicle.

Before checking the fluid level, perform the following:

1. Start the engine and park the vehicle on a level surface. Keep the engine running.
2. Apply the parking brake and place the shift lever in PARK (P).
3. Depress the brake pedal and move the shift lever through each gear range, pausing for about 3 seconds in each range. Then, move the shift lever back to PARK (P).
4. Allow the engine to idle 500-800 rpm for at least 1 minute. Slowly release the brake pedal.
5. Keep the engine running and observe the transmission fluid temperature (TFT) using the Driver Information Center (DIC) or a scan tool.
6. Using the TFT reading, determine and perform the appropriate check procedure. If the TFT reading is not within the required temperature ranges, allow the vehicle to cool, or operate the vehicle until the appropriate TFT is reached.

Cold Check Procedure

NOTE: Use this procedure only as a reference to determine if the transmission has enough fluid to be operated safely until a hot check procedure can be made. The hot check procedure is the most accurate method to check the fluid level. Perform the hot check procedure at the first opportunity. Use this cold check procedure to check fluid level when the TFT is between 80Â°F and 90Â°F (27Â°C and 32Â°C).

cardiagn.com

1. Locate the transmission dipstick at the rear of the engine compartment, on the passenger's side of the vehicle.
2. Flip the handle up, and then pull out the dipstick and wipe it with a clean rag or paper towel.
3. Install the dipstick by pushing it back in all the way, wait three seconds and then pull it back out again.

NOTE: **Always check the fluid level at least twice. Consistent readings are important to maintaining proper fluid level. If inconsistent readings are noted, inspect the transmission vent assembly to ensure it is clean and unclogged.**

4. Check both sides of the dipstick, and read the lower level. Repeat the check procedure to verify the reading.
5. Inspect the color of the fluid on the dipstick. Refer to Fluid Condition Inspection in this procedure.
6. If the fluid level is below the COLD check band, add only enough fluid as necessary to bring the level into the COLD band. It does not take much fluid, generally less than one pint (0.5L). Do not overfill.
7. If the fluid level is in the acceptable range, push the dipstick back in all the way, then flip the handle down to lock the dipstick in place.
8. Perform a hot check at the first opportunity after the transmission reaches a normal operating temperature between 160Â°F to 200Â°F (71Â°C to 93Â°C).

Hot Check Procedure

NOTE: **Use this procedure to check the transmission fluid level when the TFT is between 160Â°F and 200Â°F (71Â°C and 93Â°C). The hot check procedure is the most accurate method to check the fluid level. The hot check should be performed at the first opportunity in order to verify the cold check. The fluid level rises as fluid temperature increases, so it is important to ensure the transmission temperature is within range.**

1. Locate the transmission dipstick at the rear of the engine compartment, on the passenger's side of the vehicle.
2. Flip the handle up, and then pull out the dipstick and wipe it with a clean rag or paper towel.
3. Install the dipstick by pushing it back in all the way, wait three seconds and then pull it back out again.

NOTE: **Always check the fluid level at least twice. Consistent readings are important to maintaining proper fluid level. If inconsistent readings are noted, inspect the transmission vent assembly to ensure it is clean and unclogged.**

4. Check both sides of the dipstick, and read the lower level. Repeat the check procedure to verify the reading.
5. Inspect the color of the fluid on the dipstick. Refer to Fluid Condition Inspection.
6. A safe operating fluid level is within the HOT crosshatch band on the dipstick. If the fluid level is not within the HOT band, and the TFT is between 160Â°F and 200Â°F (71Â°C and 93Â°C), add or drain fluid as necessary to bring the level into the HOT band. If the fluid level is low, add only enough fluid to bring the level into the HOT band. It does not take much fluid, generally less than one pint (0.5L). Do not overfill. Also, if the fluid level is low, inspect the transmission for leaks. Refer to **Fluid Leak Diagnosis**.
7. If the fluid level is in the acceptable range, push the dipstick back in all the way, then flip the handle

cardiagn.com

down to lock the dipstick in place.

8. If applicable and if the vehicle is equipped, reset the transmission oil life monitor only if the fluid was changed.

Fluid Condition Inspection

Inspect the fluid color. The fluid should be red or dark brown.

- If the fluid color is very dark or black and has a burnt odor, inspect the fluid and inside of the bottom pan for excessive metal particles or other debris. A small amount of "friction" material in the bottom pan is a "normal" condition. If large pieces and/or metal particles are noted in the fluid or bottom pan, flush the oil cooler and cooler lines and overhaul the transmission. If there are no signs of transmission internal damage noted, replace the fluid filter assembly, repair the oil cooler, and flush the cooler lines.
- Fluid that is cloudy or milky or appears to be contaminated with water indicates engine coolant or water contamination. Refer to **Engine Coolant/Water in Transmission**.

LINE PRESSURE CHECK




Fig. 8: View Of Transmission Fluid Pressure Gage
Courtesy of GENERAL MOTORS COMPANY

Special Tools

GE 21867 Pressure Gauge

For equivalent regional tools, refer to **Special Tools** .

WARNING: Keep the brakes applied at all times in order to prevent unexpected vehicle motion. Personal injury may result if the vehicle moves unexpectedly.

cardiagn.com

1. Install a scan tool.
2. Start the engine.
3. Inspect the transmission for the proper fluid level. Refer to **Transmission Fluid Level and Condition Check**.
4. Use the scan tool to inspect for any active or stored diagnostic trouble codes.
5. Inspect the manual linkage at the transmission for proper function.
6. Turn the engine OFF.

NOTE: **You may need to remove or disconnect components in order to gain access to the transmission line pressure test hole plug.**

7. Remove the line pressure test hole plug.
8. Install the **GE 21867** pressure gauge.
9. Access the Scan Tool Transmission Output Controls for the Line PC Solenoid.
10. Start the engine.

NOTE: **In order to achieve accurate line pressure readings, the following procedure should be performed at least three times.**

The values displayed on the scan tool screen will not match the actual pressures indicated on the pressure gauge.

Control the Line PC Solenoid in PARK or NEUTRAL with the engine speed at approximately 1500 RPM and the TFT between 35-55Â°C (95-131Â°F). This protects the clutches from extreme high or low line pressures and ensures a consistent pump capacity.

11. Use the scan tool to increase and decrease line pressure, allowing the pressure to stabilize between increments.
12. Compare the pressure readings on the gauge with the table below.
13. If the pressure readings on the gauge are erratic, or are more than 10% greater or less than the range specified in the table below, refer to **Fluid Pressure High or Low**.
14. Turn the engine OFF.
15. Remove the **GE 21867** pressure gauge.

CAUTION: **Refer to Fastener Caution .**

16. Install the line pressure test hole plug. Tighten the pressure plug to 11 N.m (97 lb in).

Line Pressure

Scan tool Line PC Solenoid Commanded State (KPa)	Approximate line pressure shown on pressure gauge @ 1500 RPM	
	Kpa	PSI
None	310-550	45-80
200	655-900	95-130
400	1100-1310	160-190
600	1520-1725	220-250
800	1860-2070	270-300

cardiagn.com

ROAD TEST

The following test provides a method of evaluating the condition of the automatic transmission. The test is structured so that most driving conditions would be achieved. The test is divided into the following parts:

- Electrical Function Check
- Upshift Control and Torque Converter Clutch (TCC) Apply
- Part Throttle Step-In Downshifts
- Manual Downshifts
- Coasting Downshifts
- Manual Gear Range Selection
    - REVERSE
    - Driver Shift Control

NOTE: **Complete the test in the sequence given. Incomplete testing cannot guarantee an accurate evaluation.**

Before the road test, ensure the following:

- The engine is performing properly.
- Transmission fluid level is correct. Refer to **Transmission Fluid Level and Condition Check**.
- Tire pressure is correct.

During the road test:

- Perform the test only when traffic conditions permit.
- Operate the vehicle in a controlled, safe manner.
- Observe all traffic regulations.
- View the scan tool data while conducting this test.

  Take along qualified help in order to operate the vehicle safely.

- Observe any unusual sounds or smells.

After the road test, check the following:

- Inspect for proper transmission fluid level. Refer to **Transmission Fluid Level and Condition Check**.
- Inspect for any diagnostic trouble codes (DTCs) that may have set during the testing. Refer to the applicable DTC.
- Monitor the scan tool data for any abnormal readings or data.
- Inspect for fluid leaks. Refer to **Fluid Leak Diagnosis**.

Electrical Function Check

Perform this procedure first in order to ensure the electronic transmission components are functioning properly. If these components are not checked, a simple electrical condition could be misdiagnosed.

1. Connect the scan tool.

cardiagn.com

2. Ensure the gear selector is in PARK and set the parking brake.
3. Start the engine.
4. Verify that the following scan tool data can be obtained and is functioning properly.

   Refer to **Control Module References** for typical data values. Data that is questionable may indicate a concern.

   - Engine Speed
   - Transmission ISS
   - Transmission OSS
   - Vehicle Speed
   - IMS
   - Commanded Gear
   - Gear Ratio
   - Line PC Sol. Pressure Cmd.
   - Brake Switch
   - ECT, Engine Data List
   - Trans. Fluid Temp.
   - TCM Temperature
   - Calc. Throttle Position
   - Ignition Voltage
   - TFP Switch 1
   - TFP Switch 3
   - TFP Switch 4
   - TFP Switch 5
   - PC Sol. 2 Pressure Cmd.
   - PC Sol. 3 Pressure Cmd.
   - PC Sol. 4 Pressure Cmd.
   - PC Sol. 5 Pressure Cmd.
   - Shift Solenoid 1
   - Shift Solenoid 2
   - TCC PC Sol. Duty Cycle
   - TCC Slip Speed
5. Check the garage shifts.
   1. Apply the brake pedal and ensure the parking brake is set.
   2. Move the gear selector through the following ranges:
      1. PARK to REVERSE
      2. REVERSE to NEUTRAL
      3. NEUTRAL to DRIVE
      4. DRIVE to REVERSE
      5. REVERSE to DRIVE
   3. Pause 2 to 3 seconds in each gear position.

cardiagn.com

4. Verify the gear engagements are immediate (less than 2 seconds to complete if trans fluid temperature is above 20Â°C) and not harsh. Note that these shifts may be almost imperceptible in some applications. Using the scan tool to monitor Transmission ISS achieving 0 rpm can be used to check delay in these cases.

NOTE: **Harsh engagement may be caused by any of the following conditions:**

- **High engine idle speed-Compare engine idle speed to desired idle speed.**
- **Incorrect line pressure-Investigate Line PC Sol. Pressure Cmd. kPa (psi), also perform Line Pressure Check.**
- **A default condition caused by certain DTCs that result in maximum line pressure to prevent clutch slippage.**
- **Incomplete adapting or incorrect adapting-Repeat maneuver multiple times to see if shift quality improves. If it does not, refer to the service procedures for Harsh Garage Shift, and for Harsh, Soft, Delayed or Slipping First or Reverse Gear.**

NOTE: **Delayed engagement may be caused by any of the following conditions:**

- **Low idle speed-Compare engine idle speed to desired idle speed.**
- **Low fluid level**
- **Incorrect line pressure-Investigate Line PC Sol. Pressure Cmd. kPa (psi), also perform Line Pressure Check.**
- **Cold transmission fluid temperature (TFT)-Use the scan tool to determine TFT.**
- **Selector linkage-Inspect and adjust as necessary.**
- **Incomplete adapting or incorrect adapting-Repeat maneuver multiple times to see if delay improves. If it does not, refer to the service procedures for Harsh, Soft, Delayed or Slipping First or Reverse Gear.**

6. Monitor transmission range on the scan tool, transmission data list.
    1. Apply the brake pedal and ensure the parking brake is set.
    2. Move the gear selector through all ranges.
    3. Pause 2 to 3 seconds in each range.
    4. Return gear selector to PARK.
    5. Verify that all selector positions match the scan tool display.
7. Check throttle position input.
    1. Apply the brake pedal and ensure the parking brake is set.
    2. Ensure the gear selector is in PARK.
    3. Monitor the scan tool Calc. Throttle Position while increasing and decreasing engine speed with the throttle pedal. The scan tool Calc. Throttle Position percentage should increase and decrease with engine speed.

If any of the above checks do not perform properly, record the result for reference after completion of the road

cardiagn.com

test.

Upshift Control and Torque Converter Clutch (TCC) Apply

The TCM calculates the upshift points based primarily on 2 inputs: throttle position and vehicle speed. When the TCM determines that conditions are met for a shift to occur, the TCM commands the shift by varying current to the appropriate PC solenoids to control oncoming and offgoing clutch pressures.

Perform the following steps:

1. Monitor the following scan tool parameters:
    - Calc. Throttle Position
    - Vehicle Speed
    - Engine Speed
    - Transmission ISS
    - Transmission OSS
    - Commanded Gear
    - TCC PC Sol. Pressure Cmd.
    - TCC Slip Speed
    - TFP Switch 1
    - TFP Switch 3
    - TFP Switch 4
    - TFP Switch 5
    - PC Sol. 2 Pressure Cmd.
    - PC Sol. 3 Pressure Cmd.
    - PC Sol. 4 Pressure Cmd.
    - PC Sol. 5 Pressure Cmd.
    - Shift Solenoid 1 and 2
2. Place the gear selector in the DRIVE position.
3. Accelerate the vehicle using a steady throttle position between 15 and 20 percent. Hold the throttle steady.
4. As the transmission upshifts, there should be a noticeable shift feel or engine speed change within 1 to 2 seconds of the commanded gear change. The PC solenoid pressure command should change to "YES" for the oncoming clutch and the PC solenoid pressure command should change to "NO" for the offgoing clutch.
5. Note any harsh, soft or delayed shifts or slipping. Note any noise or vibration.
6. The TCC feel may not be noticeable. In many applications the TCC will apply after the 1-2 shift and TCC events will not be easily detected using engine speed.

NOTE: **This transmission is equipped with an electronically controlled capacity clutch (ECCC), which allows operation of the clutch without fully locking to the torque converter cover. The clutch maintains a small amount of slippage, approximately 20 RPM, in 2nd, 3rd, 4th, 5th, and 6th gears, depending on the vehicle application. ECCC was developed to reduce the possibility of noise, vibration or chuggle caused by TCC apply. Full lockup is available at highway speeds on some applications.**

cardiagn.com

7. Monitor TCC PC solenoid pressure command while driving and check TCC slip speed when the pressure command indicates that the TCC is commanded to apply:

   When the TCC applies, slip speed should be controlled to below 100 RPM when the transmission is not shifting and the throttle is held steady. If the TCC slip exceeds this value for more than 6 seconds after the TCC PC Sol. Pressure Command indicates that the TCC is commanded on:

   - Check for DTCs.
   - Refer to **Torque Converter Diagnosis**.

Part Throttle Step-In Downshifts

1. Place the gear selector in the DRIVE position.
2. Accelerate the vehicle at light throttle (5-15 percent) until 3rd gear is just achieved.
3. Quickly increase throttle angle until commanded gear indicates that a downshift to 2nd gear is commanded.
4. Verify that the transmission downshifts within 2 seconds of the throttle movement.
5. Repeat steps 2 to 4 at higher speed to achieve 4th gear and then step in to command a 4th gear to 3rd gear downshift.
6. Repeat steps 2 to 4 at higher speed to achieve 5th gear and then step in to command a 5th to 4th gear downshift.
7. Repeat steps 2 to 4 at higher speed to achieve 6th gear and then step in to command a 6th gear to 5th gear downshift.
8. Note any harsh, soft or delayed shifts or slipping. Note any noise or vibration.

Manual Downshifts

Manual downshift testing is not required since all vehicles equipped with the 6L45/50/80/90 are also equipped with some form of Driver Shift Control (DSC). The TCM will automatically override DSC downshifts to protect the transmission from damage.

Coasting Downshifts

1. Place the gear selector in the DRIVE position.
2. Accelerate the vehicle to 6th gear with the TCC applied.
3. Release the throttle and apply the brakes.
4. Verify that the downshifts occur as commanded by monitoring gear ratio, which should change after commanded gear changes.

Manual Gear Range Selection

This application does not utilize manual forward gear ranges.

Reverse

Perform the following test using a 10-15 percent throttle position.

1. With the vehicle stopped, move the gear selector to REVERSE.
2. Slowly accelerate the vehicle.
3. Verify that there is no noticeable slip, noise or vibration.

cardiagn.com

Driver Shift Control (DSC)

Refer to the owner's manual for specific instructions on the type of DSC available in this application. Utilize the DSC to ensure that the transmission responds appropriately to driver's commands. The TCM will upshift automatically when maximum engine speed is achieved and will protect from any downshift which may cause excessive engine RPMs.

TORQUE CONVERTER DIAGNOSIS

Torque Converter Stator

The torque converter stator roller clutch can have 2 different malfunctions.

- The stator assembly freewheels in both directions.
- The stator assembly remains locked up in both directions.

Poor Acceleration at Low Speed - Stator Roller Clutch Freewheels at All Times

If the stator is freewheeling at all times, the vehicle tends to have poor acceleration from a standstill and at speeds below 48-55 km/h (30-34 mph). At speeds above 48-55 km/h (30-34 mph), the vehicle may act normally.

For poor acceleration at low speeds, you should first determine that the exhaust system is not blocked, and the transmission is in First gear when starting out. If the engine freely accelerates to high RPM in NEUTRAL, you can assume that the engine and the exhaust system are normal. Check for poor performance in DRIVE and REVERSE to help determine if the stator is freewheeling at all times.

Poor Acceleration at High Speed - Stator Roller Clutch is Locked Up at All Times

If the stator is locked up at all times, performance is normal when accelerating from a standstill. Engine RPM and vehicle speed are limited or restricted at speeds above 48-55 km/h (30-34 mph). Visual examination of the converter may reveal a blue color from overheating.

Torque Converter Bearing Noise

NOTE: **Do not confuse this noise with pump whine noise, which is usually noticeable in all gear ranges. Pump whine will vary with line pressure.**

Torque converter whine is noticed when the vehicle is stopped and the transmission is in DRIVE or REVERSE. This noise will increase as you increase the engine RPM. The noise will stop when the vehicle is moving or when you apply the torque converter clutch, because there is no slip speed across the bearings.

Perform a stall test to verify that the noise is actually coming from the torque converter:

1. Place your foot on the brake.
2. Put the gear selector in DRIVE.

CAUTION: **You may damage the transmission if you depress the accelerator for more than 6 seconds.**

3. Depress the accelerator to approximately 1,200 RPM for no more than six seconds.

A torque converter noise will increase under this load.

cardiagn.com

Torque Converter Clutch

The torque converter clutch (TCC) is applied by fluid pressure, which is controlled by a TCC pressure control (PC) solenoid. This solenoid is part of the control solenoid valve assembly, which is located inside the automatic transmission assembly. The solenoid is controlled through a combination of computer controlled switches and sensors. Electronically controlled capacity clutch (ECCC) is controlled slip across the TCC.

Torque Converter Clutch Shudder

The key to diagnosing torque converter clutch (TCC) shudder is to note when it happens and under what conditions. TCC shudder should only occur during the apply, release, or ECCC conditions of the converter clutch. Shudder should never occur after the TCC is fully locked (approximately 0 RPM slip).

If Shudder Occurs During TCC Apply, Release, and ECCC

If the shudder occurs while the TCC is applying, the problem can be within the transmission or the torque converter. Something is causing one of the following conditions to occur:

- The clutch is not engaging completely.
- The clutch is not releasing completely.
- The clutch is releasing and applying rapidly and continuously.

One of the following conditions may be causing the TCC Shudder to occur:

- Leaking turbine shaft/TCC seals
- A restricted release orifice
- A distorted clutch or converter cover due to long flexplate to converter bolts
- Defective friction material on the TCC plate

If Shudder Occurs After TCC has Locked

Engine problems may go unnoticed under light throttle and load, but they become noticeable after the TCC has locked when going up a hill or accelerating.

Refer to **Symptoms - Engine Controls** , 4.3L or **Symptoms - Engine Controls** 5.3L in order to avoid misdiagnosis of TCC shudder and the unnecessary disassembly of a transmission or the unnecessary replacement of a torque converter.

Torque Converter Vibration Test

NOTE: **The Noise and Vibration Analysis procedure should be performed prior to performing this test.**

Isolating Vibration

NOTE: **Some engine/transmission combinations cannot be balanced in this manner due to restricted access or limited clearances between the torque converter bolts and the engine.**

To isolate and correct a flexplate or torque converter vibration:

1. With the engine at idle speed and the transmission in PARK or NEUTRAL, observe the vibration.

cardiagn.com

2. Turn the engine OFF.
3. Raise and suitably support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
4. Remove the torque converter access cover and the bolts (if equipped).
5. Mark the relationship of the torque converter to the flexplate.
6. Rotate the torque converter to inspect for defects or missing balance weights.
7. Index the converter according to "Indexing Torque Converter" procedure located within this procedure.
8. If the vibration remains, it is most likely caused by the engine.
9. Refer to "Torque Converter Replacement Guide" located within this procedure.

Indexing Torque Converter

To determine and correct a torque converter vibration, the following procedure may have to be performed several times to achieve the best possible torque converter to flexplate balance.

1. Remove the torque converter bolts.
2. Rotate the torque converter one bolt position from the original marked position.




Fig. 9: View Of Torque Converter Hub In Engine Crankshaft

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

CAUTION: **When installing the torque converter to the flexplate, make sure to use specified bolts. DO NOT use longer bolts. Using longer bolts will result in deformation of the torque converter cover and cause internal damage.**

CAUTION: **Refer to Fastener Caution .**

3. Align the torque converter pilot (2) in the engine crankshaft (3). Install the torque converter to flexplate bolts, and tighten according to **Fastener Specifications (On Vehicle)** **Fastener Specifications (Off Vehicle)** .
4. Lower the vehicle.
5. With the engine at idle speed and the transmission in PARK or NEUTRAL, observe the vibration.

   Repeat this procedure until the best possible balance is obtained.

6. Install the torque converter access cover and bolts (if equipped) and tighten according to **Fastener Specifications (On Vehicle)** **Fastener Specifications (Off Vehicle)** .

Torque Converter Replacement Guide

Condition	Action
• Transmission Fluid Oxidized/Discolored • Clutch Fiber Material	Do not replace the torque converter. Refer to **Transmission Fluid Level and Condition Check**.
Transmission Fluid Contaminated with Metal Particles	**NOTE:** **Do not replace the torque converter for clutch system or gearset component damage. Fine metallic debris or clutch plate material that is suspended in the fluid will not cause damage to the internal torque converter components nor any**

cardiagn.com

Condition	Action
	internal transmission components.
Harsh Gear Shifts	Do not replace the torque converter. Refer to **Symptoms - Automatic Transmission**.
Noise-Whine	• Refer to **Symptoms - Automatic Transmission**. • Do not replace the torque converter if noise is present in Neutral/Park. Refer to **Symptoms - Engine Mechanical** , 4.3L or **Symptoms - Engine Mechanical** 5.3L.
Vibration-Out of Balance	Refer to Torque Converter Vibration Test in this procedure.
No Drive/Slips in Drive	Do not replace the torque converter until completing all engine and transmission diagnostics.
Idle Surge/Rough Idle	Do not replace the torque converter. Refer to **Symptoms - Engine Controls** , 4.3L or **Symptoms - Engine Controls** 5.3L.
TCC Apply/Release Shudder	Do not replace the torque converter. Refer to Torque Converter Clutch Shudder in this procedure.
TCC Chuggle	Do not replace the torque converter. Refer to **Symptoms - Engine Controls** , 4.3L or **Symptoms - Engine Controls** 5.3L.
DTC P0741-TCC Stuck OFF/High Slip-Intermittent Only	Do not replace the torque converter. Refer to **DTC P0741 or P0742** diagnostic table.
DTC P0741-TCC Stuck OFF/High Slip	Do not replace the torque converter. Refer to **DTC P0741 or P0742** diagnostic table.
DTC P0742-TCC Stuck ON	Do not replace the torque converter. Refer to **DTC P0741 or P0742** diagnostic table.
Transmission Fluid Contaminated with Sludge/Metal Particles as a result of: • Engine Coolant/Oil • Pump damage • Drive sprocket support damage • Turbine/stator shaft damage • Internal converter damage with no damage found in the transmission	Replace the torque converter.
Poor Acceleration above 48 km/h (30 mph) - Good Launch	Do not replace the torque converter until completing all engine and transmission diagnostics.

cardiagn.com

Condition	Action
	• Refer to Torque Converter Stator in this procedure. • Refer to **Symptoms - Engine Controls** , 4.3L or **Symptoms - Engine Controls** 5.3L.
Poor Launch - Good Acceleration above 48 km/h (30 mph)	Do not replace the torque converter until completing all engine and transmission diagnostics. • Refer to Torque Converter Stator in this procedure. • Refer to **Symptoms - Engine Controls** , 4.3L or **Symptoms - Engine Controls** 5.3L.
Stripped Converter Bolt Holes	• Replace the torque converter. • Inspect flexplate and refer to **Lower Engine Noise, Regardless of Engine Speed** , 4.3L or **Lower Engine Noise, Regardless of Engine Speed** 5.3L.
Torque Converter Pilot Damaged	Replace the torque converter.
Torque Converter Hub surface is damaged - scored, raised/transferred metal.	Replace the torque converter.
External Leaks in the weld areas - hub, lug or closure weld.	Replace the torque converter.
Broken/Cracked Flexplate	Replace the torque converter.
Torque Converter Discolored/Overheated	Replace the torque converter.

FLEX PLATE/TORQUE CONVERTER VIBRATION TEST

Isolating Vibration

CAUTION: Some engine/transaxle combinations cannot be balanced in this manner due to restricted access or limited clearances between the torque converter bolts and the engine. Ensure that the bolts do not bottom out in the lug nuts or the torque converter cover which could dent and cause internal damage.

To isolate and correct a flywheel or torque converter vibration, separate the torque converter from the flywheel to determine if vibration is in the engine or transmission.

1. With the engine at idle speed and the transmission in PARK or NEUTRAL, observe the vibration.
2. Turn the engine OFF.
3. Raise and suitably support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
4. Remove the transmission converter cover bolts and the cover.
5. Mark the relationship of the converter to the flywheel.
6. Remove the bolts attaching the converter to the flywheel.
7. Slide the torque converter away from the flywheel.

cardiagn.com

8. Rotate the flywheel and torque converter to inspect for defects or missing balance weights.
9. Lower the vehicle.
10. With the engine at idle speed and the transmission in PARK or NEUTRAL, observe the vibration. Refer to **Diagnostic System Check - Vehicle** .
11. Turn the engine OFF.

Indexing Torque Converter

To determine and correct a torque converter vibration, the following procedure may have to be performed several times to achieve the best possible torque converter to flywheel balance.

1. Raise and suitably support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
2. Rotate the torque converter one bolt position.




Fig. 10: View Of Torque Converter Hub In Engine Crankshaft
Courtesy of GENERAL MOTORS COMPANY

3. Align the torque converter hub (2) in the engine crankshaft (3) and install the torque converter to flywheel bolts.

cardiagn.com

4. Lower the vehicle.
5. With the engine at idle speed and the transmission in PARK or NEUTRAL, observe the vibration. Refer to **Noise and Vibration Analysis**.

   Repeat this procedure until you obtain the best possible balance.

6. Install the transmission converter cover bolts and the cover.

BUSHING AND MATING SHAFT INSPECTION

NOTE: **Proper bushing and corresponding mating shaft inspection should be performed before replacing the bushing, shaft, and in some cases, the component which houses the bushing. Thoroughly clean and dry the bushing and shaft surfaces before inspecting for damage.**

Any of the following bushing conditions require replacement of the bushing and/or housing:

- Discoloration due to heat distress
- Misalignment or displacement of bushing as a result of spinning in housing
- Medium to heavy scoring that can be easily detected with fingernail. Light scoring is a normal condition.
- Debris embedded into the bushing lining material
- Obvious damage, including excessive and uneven wear
- Excessive polishing. Minor polishing of the bushing is an indication of normal wear and does not require replacement.

Any of the following conditions require replacement of the bushing's mating shaft:

- Discoloration due to heat distress
- Rough surface finish that can be easily detected with finger
- Obvious shaft abnormalities, including warping or uneven surfaces
- Obvious damage or cracking

VIBRATION

Checks	Causes
Lug bolts for the Torque Converter (1)	Inspect for loose torque converter (1) lug bolts.
Input Sun Gear Thrust Washer (55)	Inspect for wear or damage.
Turbine Shaft Thrust Bearing Assembly (57)	Inspect for wear or damage.
2-6 and 3-5-R Clutch Hub Thrust Bearing Assembly (65)	Inspect the bearing for wear or damage.
Output Carrier Assembly (68)	• Inspect the carrier assembly for damaged pinion gears, thrush washers, pins, and rollers. • Inspect for a worn or damaged center support roller bearing assembly (485). • Inspect for damaged thrust bearings (486, 488). • Inspect the carrier assembly for damaged output carrier rear

cardiagn.com

Checks	Causes
	sun gear thrust bearing (captured).
Output Carrier Thrust Bearing Assembly (69)	Inspect the bearing for wear or damage.
Output Shaft Thrust Bearing Assembly (71)	Inspect the bearing for wear or damage.
1-2-3-4 Clutch Hub Thrust Bearing Assembly (63)	Inspect the bearing for wear or damage.
Turbine Shaft Thrust Bearing Assembly (57)	Inspect the bearing for wear or damage.
Clutch Select Solenoid Valve Spring (353)	Inspect for broken spring within the lower valve body in the torque converter clutch regulator apply valve line up (355).

NOISE AND VIBRATION ANALYSIS

A noise or vibration that is noticeable when the vehicle is in motion MAY NOT be the result of the transmission.

If noise or vibration is noticeable in PARK and NEUTRAL with the engine at idle, but is less noticeable as RPM increases, the cause may be from poor engine performance.

- Vibration may also be caused by a small amount of water inside the converter.
- Inspect the tires for the following conditions:
  - Uneven wear
  - Imbalance
  - Mixed sizes
  - Mixed radial and bias ply
- Inspect the suspension components for the following conditions:
  - Alignment wear or damage
  - Loose fasteners
  - Driveline damage or wear
- Inspect the engine and transmission mounts for damage and loose bolts.
- Inspect the transmission case mounting holes for the following conditions:
  - Missing bolts, nuts, and studs
  - Stripped threads
  - Cracks
- Inspect the flywheel for the following conditions:
  - Missing or loose bolts
  - Cracks
  - Imbalance
- Inspect the torque converter for the following conditions:
  - Missing or loose bolts or lugs
  - Missing or loose balance weights
  - Imbalance caused by heat distortion or fluid contamination

cardiagn.com

WHINE/GROWL NOISE THAT CHANGES WITH VEHICLE SPEED

Checks	Causes
2-6 and 3-5-R Clutch Hub Thrust Bearing Assembly (65)	Inspect the bearing for wear or damage.
Output Carrier Assembly (68)	• Inspect the carrier assembly for damaged pinion gears, thrust washers, pins, and rollers. • Inspect for a damaged center support roller bearing assembly (485). • Inspect for damaged thrust bearings (486, 488). • Inspect for damaged sun gears (487, 489). • Inspect the carrier assembly for damaged output carrier rear sun gear thrust bearing (captured). • Inspect for damaged or stripped splines on the output carrier assembly.
Output Carrier Thrust Bearing Assembly (69)	Inspect the bearing for wear or damage.
Output Shaft Assembly (70)	• Inspect for damaged internal gears (495, 497). • Inspect the output carrier bushing (498) for damage or wear.
Output Shaft Thrust Bearing Assembly (71)	Inspect the bearing for wear or damage.
Input Sun Gear Thrust Washer (55)	Inspect the washer for wear or damage.
Input Sun Gear Thrust Bearing (54)	Inspect the bearing for wear or damage.
Input Sun Gear (53)	Inspect for spline wear or damage.
Input Carrier Assembly (52)	Inspect the carrier assembly for damaged pinion gears, thrust washers, pins, and rollers.
1-2-3-4 Clutch Hub Thrust Bearing Assembly (63)	Inspect the bearing for wear or damage.
2-6 and 3-5-R Clutch (with Output Carrier Outer Sun Gear Shaft) Hub Assembly (64)	Inspect the output carrier inner sun gear shaft bushings (60 and 62) for damage or wear.
Turbine Shaft Thrust Bearing Assembly (57)	Inspect the bearing for wear or damage.
Fluid Filter Assembly (26)	• Inspect for damaged or restricted fluid filter assembly (26) • Inspect for damaged fluid filter seal assembly (25) or improper sealing interface (leaks, fluid aeration).
Automatic Transmission Fluid Pump Seal (5)	Inspect for worn or damaged seal.
Transmission Fluid Level	Inspect to ensure the transmission fluid is at the proper level. **Transmission Fluid Level and Condition Check**

WHINE/GROWL NOISE THAT CHANGES WITH ENGINE SPEED

cardiagn.com

Checks	Causes
Transmission Fluid Level	Inspect to ensure the transmission fluid is at the proper level. **Transmission Fluid Level and Condition Check**

NOISE IN FIRST OR REVERSE GEAR

Checks	Causes
Center Support with 2-6 Low and Reverse Clutch Assembly (67)	• Inspect for damaged or worn low and reverse clutch plates (463-465). • Inspect for damaged low and reverse clutch backing plate (462). Inspect for worn splines on backing plate. • Inspect for damaged low and reverse clutch backing plate retaining ring (461). • Inspect for damaged low and reverse clutch piston assembly (470), spring (469), spring retaining ring (466), and center support assembly (459). • Inspect for damaged low clutch sprag assembly (467). Holding the sprag assembly with the retaining ring facing up, and the inner race of the sprag assembly fixed, the outer race should freewheel counterclockwise. • Inspect for cut, worn, or damaged low clutch sprag seal (468).
Output Carrier Assembly (68)	Inspect for damaged or stripped splines on the output carrier assembly.

NOISE IN FIRST, SECOND, THIRD, FOURTH, FIFTH, OR REVERSE GEAR

Checks	Causes
Input Carrier Assembly (52)	Inspect thrust washers, pinion gears, and pins for wear or damage.
Input Sun Gear (53)	Inspect for damaged sun gear.
1-2-3-4 and 3-5-R Clutch Assembly (51)	Inspect for worn or damaged clutch bearing (428).

NOISE IN FIRST, SECOND, SIXTH, OR REVERSE GEAR

Checks	Causes
Center Support with 2-6 Low and Reverse Clutch Assembly (67)	Inspect for worn or damaged output carrier outer sun gear shaft front and rear bushings (458 and 460).
Output Carrier Assembly (68)	Inspect for a worn or damaged center support roller bearing assembly (485).

NOISE IN SECOND OR SIXTH GEAR

Checks	Causes
Center Support with 2-6 Low and Reverse Clutch Assembly (67)	• Inspect for damaged or worn output carrier outer sun gear shaft front bushing (458). • Inspect for damaged or worn output carrier outer sun gear

cardiagn.com

Checks	Causes
	shaft rear bushing (460). • Inspect for damaged 2-6 clutch backing plate (451). Inspect for worn splines on backing plate. • Inspect for damaged 2-6 clutch backing plate retaining ring (450). • Inspect for damaged 2-6 clutch piston assembly (457), spring (456), retaining ring (455), and center support assembly (459).

NOISE DURING 3-4 OR 4-3 SHIFTS

Checks	Causes
4-5-6 Clutch (with Output Carrier Shaft and Dampener) Hub Assembly (58)	• Inspect hub assembly (475), dampener (476), and apply plate (477) for wear or damage. • Inspect for damaged or worn 4-5-6 clutch backing plate (432).

NOISE IN FOURTH, FIFTH, OR SIXTH GEAR

Checks	Causes
Input Sun Gear Thrust Washer (55)	Inspect for wear or damage.
Turbine Shaft Thrust Bearing Assembly (57)	Inspect for wear or damage.
4-5-6 Clutch (with Output Carrier Shaft and Dampener) Hub Assembly (58)	• Inspect for damaged or worn 4-5-6 clutch backing plate (432). • Inspect for improper selective 4-5-6 clutch backing plate retaining ring (431).

CLUTCH PLATE DIAGNOSIS

Composition Plates

Dry the plates and inspect the plates for the following conditions:

- Pitting
- Flaking
- Delamination-splitting or separation of bonded clutch material
- Wear
- Glazing
- Cracking
- Charring
- Chips or metal particles embedded in the lining

Replace a composition plate which shows any of these conditions.

cardiagn.com

Steel Plates

Wipe the plates dry and check the plates for heat discoloration. If the surfaces are smooth, even if color smear is indicated, you can reuse the plate. If the plate is discolored with heat spots or if the surface is scuffed, replace the plate.

Causes of Burned Clutch Plates

The following conditions can result in a burned clutch plate:

- Incorrect usage of clutch or apply plates
- Engine coolant or water in the transmission fluid
- A cracked clutch piston
- Damaged or missing seals
- Low line pressure
- Valve body conditions
    - The valve body face is not flat.
    - Porosity is between channels.
    - The valve bushing clips are improperly installed.
    - The checkballs are misplaced.
- The TeflonÂ® seal rings are worn or damaged.

ENGINE COOLANT/WATER IN TRANSMISSION

CAUTION: The antifreeze or water will deteriorate the seals, gaskets and the glue that bonds the clutch material to the pressure plate. Both conditions may cause damage to the transmission.

If antifreeze or water has entered the transmission, perform the following:

1. Disassemble the transmission.
2. Replace all of the rubber type seals. The coolant will attack the seal material which will cause leakage.
3. Replace the composition-faced clutch plate assemblies. The facing material may separate from the steel center portion.
4. Replace all of the nylon parts - washers.
5. Replace the torque converter.
6. Thoroughly clean and rebuild the transmission, using new gaskets and oil filter.
7. Flush the cooler lines after the transmission cooler has been properly repaired or replaced.

FLUID LEAK DIAGNOSIS

General Method

1. Verify that the leak is transmission fluid.

CAUTION: Do not clean using brake cleaner or other reactive solvents as these solvents can damage rubber gaskets, seals and bushings.

cardiagn.com

2. Thoroughly clean the suspected leak area using a rag.

NOTE: **Do not idle vehicle, this will not actuate transmission systems, and do not drive the vehicle on the freeway as this will splatter oil inhibiting leak diagnosis.**

3. Operate the vehicle for 15-20 minutes under city driving conditions until normal operating temperatures are reached.
4. Park the vehicle over clean paper or cardboard.
5. Shut OFF the engine.
6. Look for fluid spots on the paper.
7. Make the necessary repairs.

Powder Method

CAUTION: **Do not clean using brake cleaner or other reactive solvents as these solvents can damage rubber gaskets, seals and bushings.**

1. Thoroughly clean the suspected leak area using a rag.
2. Apply an aerosol type powder, such as foot powder, to the suspected leak area.

NOTE: **Do not idle vehicle, this will not actuate transmission systems, and do not drive the vehicle on the freeway as this will splatter oil inhibiting leak diagnosis.**

3. Operate the vehicle for 15-20 minutes under city driving conditions until normal operating temperatures are reached.
4. Shut OFF the engine.
5. Inspect the suspected leak area.
6. Trace the leak path through the powder in order to find the source of the leak.
7. Make the necessary repairs.

Dye and Black Light Method

A fluid dye and black light kit is available from various tool manufacturers.

1. Follow the manufacturer's instructions in order to determine the amount of dye to use.
2. Detect the leak with the black light.
3. Make the necessary repairs.

Find the Cause of the Leak

Pinpoint the leak and trace the leak back to the source. You must determine the cause of the leak in order to repair the leak properly. For example, if you replace a gasket, but the sealing flange is bent, the new gasket will not repair the leak. You must also repair the bent flange. Before you attempt to repair a leak, check for the following conditions, and make repairs as necessary:

Gaskets

cardiagn.com

- Fluid level/pressure is too high
- Plugged vent or drain-back holes
- Improperly tightened fasteners
- Dirty or damaged threads
- Warped flanges or sealing surface
- Scratches, burrs, or other damage to the sealing surface
- Damaged or worn gasket
- Cracking or porosity of the component
- Improper sealant used, where applicable
- Incorrect gasket

Seals

- Fluid level/pressure is too high
- Plugged vent or drain-back holes
- Damaged seal bore
- Damaged or worn seal
- Improper installation
- Cracks in component
- Manual or output shaft surface is scratched, nicked, or damaged
- Loose or worn bearing causing excess seal wear

Possible Points of Fluid Leaks

Transmission Oil Pan

- Incorrectly tightened oil pan bolts
- Improperly installed or damaged oil pan gasket
- Damaged oil pan or mounting face
- Incorrect oil pan gasket

Case Leak

- Damaged vehicle speed sensor seal
- Damaged manual shaft seal
- Loose or damaged oil cooler connector fittings
- Worn or damaged propeller shaft oil seal
- Loose line pressure pipe plug
- Porous casting warped torque converter housing

Leak at the Torque Converter End

- Converter leak in the weld area
- Converter seal lip cut. Check the converter hub for damage
- Converter seal bushing moved forward and damaged

cardiagn.com

- Converter seal garter spring missing from the seal
- Porous casting of the transmission case or the oil pump

Leak at the Vent Pipe

- Overfilled system
- Water or coolant in the fluid; The fluid will appear milky
- Transmission case porous
- Incorrect fluid level indicator
- Plugged vent
- Drain-back holes plugged
- Mispositioned oil pump to case gasket, if equipped

Leak Inspection Points




Fig. 11: Leak Inspection Points
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Automatic Transmission Electrical Connector Passage Sleeve

cardiagn.com

Callout	Component Name
2	Line Pressure Test Hole Plug
3	Converter Housing to Case Joint
4	Trans Fluid Cooler Pipe Fitting Seals
5	Manual Shift Shaft Seal
6	Automatic Transmission Vent Pipe
7	Transmission Case Assembly
8	A/Trans Case Extension Seal - 2WD Models
9	Prop Shaft Front Slip Yoke Oil Seal - 2WD Models
10	A/Trans Fluid Pan Gasket
11	Torque Converter Fluid Seal Assembly
12	Torque Converter Assembly
13	Case Extension to Case Joint
14	Output Shaft Seal Assembly - 4WD Models

CASE POROSITY REPAIR

Some external leaks are caused by case porosity in non-pressurized areas. You can usually repair these leaks with the transmission in the vehicle.

1. Thoroughly clean the area to be repaired with a cleaning solvent. Air dry the area.

WARNING: Epoxy adhesive may cause skin irritations and eye damage. Read and follow all information on the container label as provided by the manufacturer.

2. Using instructions from the manufacturer, mix a sufficient amount of an epoxy to make the repair.
3. While the transmission case is still hot, apply the epoxy. You can use a clean, dry soldering acid brush to clean the area and also to apply the epoxy cement. Make certain that the area to be repaired is fully covered.
4. Allow the epoxy cement to cure for three hours before starting the engine.
5. Repeat the fluid leak diagnosis procedures.

AUTOMATIC TRANSMISSION FLUID LEAKS

Checks	Causes
Torque Converter (1)	Inspect for damage, cracks at the lug, hub and seal welds.
Torque Converter Housing (203)	• Verify leak is ATF and not oil from rear of engine. • Inspect for housing porosity or damage. • Inspect for worn or damaged torque converter seal (201). • Inspect for loose line pressure plug. • Inspect cooler line attachment for loose bolt, worn or damaged seal, or leak at line to boss joint. • Inspect vent pipe attachment to housing and hose. • Verify torque of housing to case bolts.

cardiagn.com

Checks	Causes
Automatic Transmission Fluid Pump Seal (5)	Inspect for cut, wear, or damage.
Case Assembly	• Inspect for porosity or damage. • Inspect manual shaft seal. • Inspect control wiring input sleeve seals. • Inspect rear case plugs (12) (4WD/AWD only, 4WD may also be cast over).
Extension Assembly	• Verify oil is from transmission and not transfer case assembly (4WD/AWD). • Inspect extension seal assembly (inner seal behind boot - 2WD only). • Inspect extension to case seal (2WD only).
Pan Assembly	• Inspect the pan assembly for damage. • Inspect gasket for damage or wear. • Inspect case and pan for damage and flatness at gasket interface area.
Cooler Lines/Coolers	• Inspect and follow cooler lines to front radiator and external coolers. • Some vehicles may have rear differential external and internal coolers.

SHIFT INDICATOR INDICATES WRONG GEAR SELECTION

Checks	Causes
Shift Cable	• Inspect for damage. • Verify proper attachment to shifter. • Verify cable is locked into shifter bracket. • Verify cable is properly attached to the transmission. • Verify that the cable is locked into the transmission bracket. • Verify proper shift cable adjustment.
Manual Shaft	• Verify shift lever is properly attached to the manual shaft. • Verify manual shaft is not twisted or damaged.
Manual Shift Detent Lever with Shaft Position Switch Assembly, IMS	Verify proper operation. Refer to **Transmission Internal Mode Switch Logic** .

NO PARK OR DRIVE

cardiagn.com

Checks	Causes
Output Shaft Assembly (70)	Inspect for a broken or damaged output shaft. Inspect for worn splines.
Case Assembly	• Inspect for broken or damaged case. • Inspect for broken or bent park pawl actuator. • Inspect for broken or missing park pawl actuator guide pin or manual shaft pin. • Inspect for broken, loose or misaligned park pawl guide. • Inspect for binding or broken park pawl or actuator assembly.
Manual Shift Detent Lever Assembly (511)	Inspect for broken or disengaged manual valve detent.

HARSH GARAGE SHIFT

Checks	Causes
NOTE: **On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature improves heater performance**	

cardiagn.com

Checks	Causes
by giving quicker vehicle warm-ups.	
Engine	Elevated engine RPM - Verify correct engine operating rpm per application.
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and springs (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure. • Incorrect TCM temperature reporting - Monitor TCM temperature using Tech 2. • Line pressure control solenoid incorrect pressure.
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect for damaged 1-2-3-4 clutch piston (414), piston housing (417), spring (413), and dam assembly (412). • Inspect for cut, worn, or damaged 1-2-3-4 clutch piston seal (416), inner seal (423), and housing seals (424 and 425). • Inspect for improper selective 1-2-3-4 clutch backing plate retaining ring (429). • Inspect for damaged 3-5-R clutch piston (421), apply ring (405), and spring (420). • Inspect for cut, worn, or damaged 3-5-R clutch piston dam O-ring seal (418), inner seal (419), and outer seal (422). • Inspect for improper selective 3-5-R clutch backing plate retaining ring (400).

NO DRIVE IN ALL RANGES

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for damaged or scored pump housing (203), cover (219), rotor (217), slide (212), and vanes (216).
Fluid Filter Assembly (26)	• Inspect for damaged or restricted fluid filter assembly (26). • Inspect for damaged fluid filter seal assembly (25) or improper sealing interface, leaks, and fluid aeration.
Automatic Transmission Fluid Pump Seal (5)	Inspect for worn or damaged seal.

cardiagn.com

Checks	Causes
A/Trans Cooling/Lubrication System	Inspect transmission oil cooler (radiator) and cooler line seals for restrictions, damage, kinks, or leaks.
Torque Converter Assembly (1)	Inspect for overheating (blued), ballooning, leaks, or other damage.
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect clutch pack retaining rings (400 and 429) for proper installation. • Inspect housing and clutch pistons and seals for damage or leaks.
Control Valve Lower Body Assembly (351)	• Inspect for stuck, sticky or damaged clutch select valve (352). • Inspect for stuck checkballs.
Manual Valve (354)	Inspect the manual valve detent lever assembly (505) and connection to the manual valve (354).
A/Trans Manual Shift Shaft Position Switch Assembly (308)	Inspect the switch assembly (308) and connection to the manual valve (354).
A/Trans Manual Shift Shaft Position Switch Assembly (308)	Inspect PRNDL commands to and from vehicle using GDS 2.
Control Solenoid (w/Body and TCM) Valve Assembly (314)	Inspect PRNDL commands to and from vehicle using GDS 2.
A/Trans Fluid Pump (Transfer) Seal Assembly (19)	Inspect for damage or leaks.
Output Shaft Assembly (499)	Inspect for spline wear or damage.
Output Carrier Assembly (490)	• Inspect the carrier assembly for damaged pinion gears, thrust washers, pins, and rollers. • Inspect for damaged thrust bearings (486 and 488). • Inspect for damaged sun gears (487 and 489). • Inspect the carrier assembly for damaged output carrier rear sun gear thrust bearing (captured).
Low Clutch Sprag Assembly (467)	Inspect for excessive wear or damage.
Input Carrier Assembly (52)	Inspect carrier assembly for damaged pinion gears, thrust washers, pins, and rollers.
Input Sun Gear (53)	Inspect for spline wear or damage.
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn 1-2-3-4 clutch regulator valve (337).

NO FIRST GEAR

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Center (with 2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for damaged low clutch sprag assembly (467). Holding the sprag assembly with the retaining ring facing up, and the

cardiagn.com

Checks	Causes
	inner race of the sprag assembly fixed, the outer race should freewheel counterclockwise. • Inspect for damaged low and reverse clutch piston assembly (470), spring (469), spring retaining ring (466), and center support assembly (459). • Inspect for damaged or worn low and reverse clutch plates (463-465). • Inspect for damaged low and reverse clutch backing plate retaining ring (461). • Inspect for cut, worn, or damaged low clutch sprag seal (468).
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 1st/Rev and 4-5-6 clutch regulator valve (327) and spring (326). • Inspect for sticking, damaged, or worn #2 ball check valve. • Inspect for sticking, damaged, or worn #3 ball check valve. • Inspect for sticking, damaged, or worn 1-2-3-4 clutch regulator valve (337).
Control Valve Lower Body Assembly (307)	• Inspect for sticking, damaged, or worn clutch select valve 2 (352) and spring (353). • Inspect for sticking, damaged, or worn clutch select valve 3 (352) and spring (353).
Center Support Fluid Passage Seal Assembly (20)	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80/90E MYC/MYD).

NO FIRST AND REVERSE GEARS

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn 1st/rev and 4-5-6 clutch regulator valve (327) and spring (326).
Control Valve Lower Body Assembly (307)	Inspect for sticking, damaged, or worn clutch select valve 3 (352) and spring (353).
Control Valve Lower Body Assembly (307)	Inspect for sticking, damaged, or worn clutch select valve 2 (352) and spring (353).
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn #2 ball check valve
Center (with 2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for damaged low and reverse clutch piston assembly (470), spring (469), spring retaining ring (466), and center support assembly (459). • Inspect for damaged or worn low and reverse clutch plates

cardiagn.com

Checks	Causes
	(463-465). • Inspect for damage low and reverse clutch backing plate retaining ring (461). • Inspect for damaged low clutch sprag assembly (467). Holding the sprag assembly with the retaining ring facing up, and the inner race of the sprag assembly fixed, the outer race should freewheel counterclockwise. • Inspect for cut, worn, or damaged low clutch sprag seal (468).
Center Support Fluid Passage Seal Assembly (20)	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80/90E MYC/MYD).
Pump Cover (219)	Inspect for sticking or damaged TCC control valve (227).

HARSH, SOFT, DELAYED OR SLIPPING FIRST OR REVERSE GEAR

Checks	Causes
NOTE: **On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature**	

cardiagn.com

Checks	Causes
improves heater performance by giving quicker vehicle warm-ups.	
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 1-R/4-5-6 clutch regulator valve (327) and spring (326). • Inspect for damaged or sticking #2 ball check valve.
Control Valve Lower Body Assembly (307)	Inspect for sticking, damaged, or worn clutch select valve 3 (352) and spring (353).
Control Valve Lower Body Assembly (307)	Inspect for sticking, damaged, or worn clutch select valve 2 (352) and spring (353).
Center (with 2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for damaged low and reverse clutch piston assembly (470), spring (469), spring retaining ring (466), and center support assembly (459). • Inspect for damaged or worn low and reverse clutch plates (463 and 465). • Inspect for damaged low and reverse clutch backing plate retaining ring (461). • Inspect for damaged low clutch sprag assembly (467). Holding the sprag assembly with the retaining ring facing up, and the inner race of the sprag assembly fixed, the outer race should freewheel counterclockwise. • Inspect for cut, worn, or damaged low clutch sprag seal (468).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**. • Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure.
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and spring (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).
Center Support Fluid Passage Seal Assembly (20).	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80.90E MYC/MYD).

cardiagn.com

NO FIRST, SECOND, THIRD, AND FOURTH GEAR

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn 1-2-3-4 clutch regulator valve (337) and spring (326).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Inspect for contamination or debris. • Pressure control solenoid 5 commanded/failed LOW (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect clutch pack retaining ring (429) for proper installation. If the retaining ring is out of the groove the following parts must be replaced: 1-2-3-4 and 3-5-R clutch housing (427), 1-2-3-4 and 3-5-R clutch bearing assembly (428) and the 1-2-3-4 clutch backing plate retaining ring. • Inspect for a cracked or damaged 1-2-3-4 clutch piston (414), piston housing (417), spring (413), and dam assembly (412). • Inspect for cut, worn, or damaged 1-2-3-4 clutch piston seal (416), inner seal (423), and housing seals (424 and 425). • Inspect for improper selective 1-2-3-4 clutch backing plate retaining ring (429).
Fluid Filter Assembly (26)	• Inspect for damaged or restricted fluid filter assembly (26). • Inspect for damaged fluid filter seal assembly (25) or improper sealing interface, leaks, and fluid aeration.
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for damaged or scored pump housing (203), cover (219), rotor (217), slide (212) and vanes (216).
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for damaged or leaking 1-2-3-4 and 3-5-R clutch fluid seal rings (230).
Center (w/2-6 Low and Reverse Clutch) Support Assembly (67)	Inspect for worn or damaged low clutch sprag assembly (467).
A/Trans Fluid Pump (Transfer) Seal Assembly (19)	Inspect for damage or leaks.
1-2-3-4 Clutch (with Output Carrier Inner Sun Gear Shaft) Hub Assembly (61)	Inspect for damaged splines on the hub assembly.

HARSH, SOFT, DELAYED OR SLIPPING 1-2-3-4 SHIFT

Checks	Causes
NOTE:	

cardiagn.com

Checks	Causes
On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature improves heater performance by giving quicker vehicle warm-ups.	
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 1-2-3-4 clutch regulator valve (337) and spring (326). • Inspect for damaged or stuck #1 ball check valve.
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Inspect for contamination or debris. • Pressure control solenoid 5 commanded/failed LOW (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**. • Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure.

cardiagn.com

Checks	Causes
	• Line pressure control solenoid incorrect pressure.
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect for damaged 1-2-3-4 clutch piston (414), piston housing (417), spring (413), and dam assembly (412). • Inspect for cut, worn, or damaged 1-2-3-4 clutch piston seal (416), inner seal (423), and housing seals (424 and 425). • Inspect 3-5 reverse clutch housing for cracked weld. • Inspect for improper selective 1-2-3-4 clutch backing plate retaining ring (429). • Inspect for damaged 3-5-R clutch piston (421), apply ring (405), and spring (420). • Inspect for cut, worn, or damaged 3-5-R clutch piston dam O-ring seal (418), inner seal (419), and outer seal (422). • Inspect for improper selective 3-5-R clutch backing plate retaining ring (400).
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for damaged or leaking 1-2-3-4 and 3-5-R clutch fluid seal rings (230).
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and springs (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for damaged or scored pump housing (203), cover (219), rotor (217), slide (212) and vanes (216).
Fluid Filter Assembly (26)	• Inspect for damaged or restricted fluid filter assembly (26). • Inspect for damaged fluid filter seal assembly (25) or improper sealing interface, leaks, and fluid aeration.
A/Trans Fluid Pump (Transfer) Seal Assembly (19)	Inspect for damage or leaks.

NO SECOND AND SIXTH GEAR

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn 2-6 clutch regulator valve (334) and spring (326).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	Pressure control solenoid 4 commanded/failed LOW (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
Center (with 2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for proper installation of the 2-6 clutch return spring retaining ring (455).

cardiagn.com

Checks	Causes
	• Inspect for damaged 2-6 clutch piston assembly (457), spring (456), retaining ring (455), and center support housing (459). • Inspect for worn or damaged 2-6 clutch plates (451-453).
Center Support Fluid Passage Seal Assembly (20)	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80/90E MYC/MYD).

HARSH, SOFT, DELAYED OR SLIPPING SECOND OR SIXTH GEAR

Checks	Causes
NOTE: **On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature improves heater performance by giving quicker vehicle warm-ups.**	

cardiagn.com

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged or worn 2-6 clutch regulator valve (334) and spring (326). • Inspect for damaged or sticking #6 ball check valve.
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Pressure Control Solenoid 4 commanded/failed LOW (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**. • Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure.
Center (with 2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for proper installation of the 2-6 clutch return spring retaining ring (455). • Inspect for damaged 2-6 clutch piston assembly (457), spring (456), retaining ring (455), and center support assembly (459). • Inspect for worn or damaged 2-6 clutch plates (451-453).
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and springs (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).
Center Support Fluid Passage Seal Assembly (20)	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80/90E MYC/MYD).

NO THIRD, FIFTH, AND REVERSE GEAR

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 3-5-R regulator valve (336) and valve spring (326). • Inspect for damaged or stuck #7 ball check valve.
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking clutch select solenoid valve 3 (352) and valve spring (353).
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect for proper installation of 3-5-R clutch backing plate retaining ring (400). • Inspect for worn, damaged, or leaking clutch bearing seal assembly (428). • Inspect for damaged or worn 3-5-R clutch plates (401-404).

cardiagn.com

Checks	Causes
	• Inspect for damaged 3-5-R clutch piston (421), apply ring (405), and spring (420). • Inspect for cut, worn, or damaged 3-5-R clutch piston dam O-ring seal (418), inner seal (419), and outer seal (422). • Inspect for improper selective 3-5-R clutch backing plate retaining ring (400).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	Pressure control solenoid 2 commanded/failed HIGH (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
A/Trans Fluid Pump (Transfer) Seal Assembly (19)	Inspect for damage or leaks.

HARSH, SOFT, DELAYED OR SLIPPING THIRD, FIFTH, OR REVERSE GEAR

Checks	Causes
NOTE: **On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature improves heater**	

cardiagn.com

Checks	Causes
performance by giving quicker vehicle warm-ups.	
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 3-5-R regulator valve (336) and valve spring (326). • Inspect for damaged or stuck #7 ball check valve.
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking clutch select solenoid valve 3 (352) and valve spring (353).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Pressure control solenoid 2 commanded/failed HIGH (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**. • Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure.
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect for proper installation of 3-5-R clutch backing plate retaining ring (400). • Inspect for worn, damaged, or leaking clutch bearing seal assembly (428). • Inspect for damaged or worn 3-5-R clutch plates (401-404). • Inspect for damaged 3-5-R clutch piston (421), apply ring (405), and spring (420). • Inspect 3-5 reverse clutch housing for cracked weld. • Inspect for cut, worn, or damaged 3-5-R clutch piston dam O-ring seal (418), inner seal (419), and outer seal (422). • Inspect for improper selective 3-5-R clutch backing plate retaining ring (400).
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and springs (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).
A/Trans Fluid Pump (Transfer) Seal Assembly (19)	Inspect for damage or leaks.

NO FOURTH, FIFTH, AND SIXTH GEAR

Checks	Causes
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission

cardiagn.com

Checks	Causes
	assembly for leaks.
Control Valve Upper Body Assembly (304)	Inspect for sticking, damaged, or worn R-1/4-5-6 clutch regulator valve (327) and spring (326).
4-5-6 (with Turbine Shaft) Clutch Assembly (56)	• Inspect for cut, worn, or damaged turbine shaft fluid seal rings (442). • Inspect for damaged piston (439), piston dam (437), dam retaining ring (436), and clutch spring (438). • Inspect for worn or damaged 4-5-6 clutch plates (432-435). • Inspect for damaged or leaking clutch housing (441). • Inspect for improper selective 4-5-6 clutch backing plate retaining ring (431). • Inspect for damaged or distorted turbine shaft.
A/Trans Fluid Pump Seal Assembly (18)	Inspect for cut, leaking, or damaged seal.
4-5-6 Clutch (with Output Carrier Shaft and Dampener) Hub Assembly (58)	• Inspect the shaft for damage or wear. • Inspect the hub assembly (475), dampener (476), and apply plate (477) for wear or damage.
A/Trans Cooling/Lubrication System	Inspect transmission oil cooler (radiator) and cooler lines/seals for restrictions, damage, kinks or leaks.
Control Solenoid (w/Body and TCM) Valve Assembly (314)	Pressure control solenoid 3 commanded/failed HIGH (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**.
Torque Converter (with Fluid Pump) Housing Assembly (2)	• Inspect for damaged or scored pump housing (203), cover (219), rotor (217), slide (212), and vanes (216). • Inspect for damaged or porous pump cover assembly (219). Inspect pump surfaces for flatness. • Inspect for excessive fluid pump rotor (217) clearance or damage. Ensure proper selective rotor is being utilized.
Output Shaft Assembly (70)	Inspect for damaged or stripped splines on the output shaft.

HARSH, SOFT, DELAYED OR SLIPPING 4-5-6 SHIFT

Checks	Causes
NOTE: **On cold days, approximately 32Â°F (0Â°C) or colder, the transmission is designed to shift**	

cardiagn.com

Checks	Causes
differently. The transmission uses a warm-up mode shift schedule until the engine reaches normal operating temperature. While the transmission is in warm-up mode, it is normal for transmission upshifts to be delayed or held longer. This feature improves heater performance by giving quicker vehicle warm-ups.	
A/Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 1-R/4-5-6 clutch regulator valve (327) and spring (326). • Inspect for damaged or sticking #3 and #4 ball check valves.
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking clutch select solenoid valve 2 (352) and valve spring (353).
Control Solenoid (w/Body and TCM) Valve Assembly (314)	• Pressure Control Solenoid 3 commanded/failed HIGH (off) or leaking - Perform solenoid valve assembly function test. Refer to **Control Solenoid Valve and Transmission Control Module Assembly Solenoid Performance Test**. • Incorrect or inadequate adapt activity - Perform **Reset Transmission Adapts** procedure.
4-5-6 (with Turbine Shaft) Clutch Assembly (56)	• Inspect for cut, worn, or damaged turbine shaft fluid seal rings (442). • Inspect for damaged piston (439), piston dam (437), dam retaining ring (436), and clutch spring (438).

cardiagn.com

Checks	Causes
	• Inspect for damaged or worn 4-5-6 clutch plates (432-435). • Inspect for damage or leaking clutch housing (441). • Inspect for improper selective 4-5-6 clutch backing plate retaining ring (431). • Inspect for damaged or distorted turbine shaft.
A/Trans Fluid Pump Seal Assembly (18)	Inspect for cut, leaking, or damaged seal.
4-5-6 Clutch (with Output Carrier Shaft and Dampener) Hub Assembly (58)	• Inspect shaft for damage or wear. • Inspect hub assembly (475), dampener (476), and apply plate (477) for wear or damage.
A/Trans Fluid Pump Cover Assembly (219)	• Inspect for damaged, stuck, sticky pressure regulator valve (233) and springs (234 and 235). • Inspect for damaged, stuck, sticky isolator valve (236) and sleeve (237).

NO TORQUE CONVERTER CLUTCH APPLY

Checks	Causes
Torque Converter Assembly (1)	Diagnose torque converter for possible internal damage. Refer to **Torque Converter Diagnosis**.
Fluid Pump Cover Assembly (219)	• Inspect for worn, damaged, or sticking converter feed limit valve (220) and spring (221). • Inspect for worn, damaged, or sticking TCC control valve (227) and spring (226). • Inspect for damaged stator shaft.
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking torque converter clutch (TCC) regulator apply valve (355). Refer to **Control Solenoid Valve and Transmission Control Module Assembly Inspection**.
4-5-6 (with Turbine Shaft) Clutch Assembly (56)	• Inspect for damaged turbine shaft. • Inspect for damaged turbine shaft O-ring seal.
Torque Converter (with Fluid Pump) Housing Assembly (2)	Inspect for leaking or damaged torque converter fluid seal assembly (201), torque converter bushing (206), turbine shaft o-ring seal (443) and torque converter (with fluid pump) housing assembly (2).

NO TORQUE CONVERTER CLUTCH RELEASE

Checks	Causes
Torque Converter Assembly (1)	Diagnose torque converter for possible internal damage. Refer to **Torque Converter Diagnosis**.

cardiagn.com

Checks	Causes
Fluid Pump Cover Assembly (219)	• Inspect for worn, damaged, or sticking converter feed limit valve (220) and spring (221). • Inspect for worn, damaged, or sticking torque converter clutch (TCC) control valve (227) and spring (226).
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking TCC regulator apply valve (355).

NO REVERSE GEAR

Checks	Causes
A//Trans Fluid Pan Assembly (29)	Verify proper fluid level and condition, inspect transmission assembly for leaks.
Control Valve Upper Body Assembly (304)	• Inspect for sticking, damaged, or worn 3-5-R regulator valve (336) and valve spring (326). • Inspect for damaged or missing #5 ball check valve.
Control Valve Lower Body Assembly (307)	Inspect for worn, damaged, or sticking clutch select solenoid valve 3 (352) and valve spring (353).
1-2-3-4 and 3-5-R Clutch Assembly (51)	• Inspect for proper installation of 3-5-R clutch backing plate retaining ring (400). • Inspect for worn, damaged, or leaking clutch bearing seal assembly (428). • Inspect for damaged or worn 3-5-R clutch plates (401-404). • Inspect for damaged 3-5-R clutch piston (421), apply ring (405), and spring (420). • Inspect for cut, worn, or damaged 3-5-R clutch piston dam O-ring seal (418), inner seal (419), and outer seal (422). • Inspect for improper selective 3-5-R clutch backing plate retaining ring (400).
Torque Converter (with Fluid Pump) Housing Assembly (2)	• Inspect for worn or damaged 1-2-3-4 and 3-5-R clutch fluid seal rings (230). • Inspect for damaged or scored pump housing (203), cover (219), rotor (217), slide (212), and vanes (216). • Inspect for damaged or porous pump cover assembly (219). Inspect pump surfaces for flatness. • Inspect for excessive fluid pump rotor (217) clearance or damage. Ensure proper selective rotor is being utilized.
Center Support Fluid Passage Seal Assembly (20), A/Trans Fluid Pump Seal Assemblies (18 and 19)	• Inspect for worn, cut, or damaged seals. • Inspect for proper seal (20) size (6L45/50E MYA/MYB) vs (6L80/90E MYC/MYD).

cardiagn.com

Checks	Causes
Center (w/2-6 Low and Reverse Clutch) Support Assembly (67)	• Inspect for damaged or leaking low and reverse clutch piston assembly (470). • Inspect for damaged or worn low and reverse clutch plates (462-465). • Inspect for damaged low clutch sprag assembly (467). Holding the sprag assembly with the retaining ring facing up, and the inner race of the sprag assembly fixed, the outer race should freewheel counterclockwise.
2-6 and 3-5-R Clutch (with Output Carrier Outer Sun Gear Shaft) Hub Assembly (64)	Inspect for damaged or distorted shaft on hub assembly.
Output Shaft Assembly (70)	Inspect for damaged or stripped splines on the output shaft.

FLUID PRESSURE HIGH OR LOW

Checks	Causes
Torque Converter Housing with Fluid Pump Assembly (2)	• Inspect for worn, sticking, or damaged pressure regulator valve (233). • Inspect for worn, sticking, or damaged pressure regulator valve outer spring (234). • Inspect for worn, sticking, or damaged pressure regulator valve inner spring (235). • Inspect for worn, sticking, or damaged isolator valve (236) and sleeve (237). • Inspect for worn, sticking, or damaged pressure relief ball valve (225). • Inspect for worn, sticking, or damaged pressure relief ball valve spring (224). • Inspect for damaged or porous pump cover assembly (219). Inspect for pump surfaces not flat. • Inspect for excessive fluid pump rotor (217) clearance or damage. Ensure proper selective rotor is being utilized. • Inspect for damaged fluid pump slide (212). Ensure proper selective slide is being utilized. • Inspect for worn, sticking, or damaged fluid pump slide outer spring (211). • Inspect for worn or damaged fluid pump slide seal (213), seal support (214), pivot pin (215), fluid seal ring (209), and O-ring seal (210). • Inspect for worn or damaged fluid pump vane rings (207) and rotor guide (208). • Inspect fluid filter assembly (26) for torque converter friction material.

cardiagn.com

Checks	Causes
Control Valve Upper Body Assembly (321)	• Inspect for worn, sticking, or damaged actuator feed limit valve (325) and spring (324). • Inspect for worn, sticking, or damaged clutch boost valve (329) and spring (330).
Control Valve (w/Body and TCM) Valve Assembly	Inspect for leaking or damaged filter plate assembly seals (16). Verify VBS operation in not stuck high or low.
Fluid Filter Assembly (26)	• Inspect for damaged or restricted fluid filter assembly (26). • Inspect for damaged fluid filter seal assembly (25).

NO TORQUE CONVERTER CLUTCH SLIP WITH TORQUE CONVERTER CLUTCH ENGAGED

Checks	Causes
Clutch Select Solenoid Valve Spring (353)	Inspect for broken spring within the lower valve body in the torque converter clutch regulator apply valve line up (355).

Article GUID: A00854526

cardiagn.com

Automatic Transmission - 6L80 (MYC) or 6L90 (MYD) - Repair Instructions - Off Vehicle - Sierra, Silverado

REPAIR INSTRUCTIONS - OFF VEHICLE

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

TORQUE CONVERTER REMOVAL AND HOLDING FIXTURE INSTALLATION





Fig. 1: Torque Converter And Holding Fixture
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Torque Converter Assembly
2	Transmission Case Assembly **NOTE:** **1. Rotate the transmission so that the**

cardiagn.com

Callout	Component Name
	converter housing is up and secure with locking pin. 2. Allow any remaining transmission fluid to drain from the case extension. **Special Tools** • **DT 47605** Holding Fixture Adapter • **DT 47605** Holding Fixture • **J 3289-20** Holding Fixture Base Assembly • **J 8763-B** Holding Fixture For equivalent regional tools, refer to **Special Tools** .

CASE EXTENSION ASSEMBLY REMOVAL



cardiagn.com

Fig. 2: Case Extension
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Bolt M10 x 40 (Quantity: 6)
2	Case Extension
3	Case Extension Seal

PROPELLER SHAFT OIL SEAL SLEEVE REMOVAL (2WD)




Fig. 3: Propeller Shaft Oil Seal Sleeve (2WD)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Propeller Shaft Oil Seal Sleeve **CAUTION:** **Do not attempt to remove or install the propeller shaft oil seal sleeve by striking or hitting the sleeve. Transmission**

cardiagn.com

Callout	Component Name
	internal bearing damage could result. **NOTE:** • Discard the propeller shaft oil seal sleeve. The sleeve cannot be reused and must be replaced. • Use the 3/8 x 24 in threaded rods for propeller shaft oil seal sleeve removal. **Special Tools** • **DT-22912-B** Split Plate Bearing Puller • **DT-50802** Threaded Rod Kit • **GE-8433-1** Puller Bar For equivalent regional tools, refer to **Special Tools** .

TRANSMISSION FLUID PAN, FILTER AND ELECTRICAL CONNECTOR PASSAGE SLEEVE REMOVAL

cardiagn.com




Fig. 4: Fluid Pan, Fluid Filter And Electrical Connector Passage Sleeve
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Bolt M6 x 20 (Qty: 18)
2	Fluid Pan Assembly
3	Fluid Pan Gasket **NOTE:** **The fluid pan gasket is reusable. Inspect the gasket to determine if it may be reused. If the gasket is stuck to the case or pan, it should be**

cardiagn.com

Callout	Component Name
	replaced.
4	Fluid Filter Assembly **CAUTION:** **Pull the fluid filter assembly straight out to avoid damage. Do not bend or twist the filter neck.**
5	Fluid Filter Seal Assembly **CAUTION:** **Do not damage the case sealing surface when removing the filter seal assembly.** **NOTE:** **Use a screwdriver or snap ring pliers.**
6	Electrical Connector Slide Lock **CAUTION:** **Pull up on the electrical connector slide lock to avoid damage to the connector.**
7	Electrical Connector Passage Sleeve **NOTE:** **Engage DT 47715 electrical connector**

cardiagn.com

Callout	Component Name
	passage sleeve remover/installer on sleeve and pull straight out. **Special Tools** • **DT 47715** Electrical Connector Passage Sleeve Remover/Installer • **J 42183** Driver Handle For equivalent regional tools, refer to **Special Tools** .

CONTROL VALVE BODY ASSEMBLY REMOVAL




Fig. 5: Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Bolt M5 x 73 (Qty: 6)

cardiagn.com

Callout	Component Name
	NOTE: **Do not remove all the bolts in the control valve body assembly. Remove only the bolts indicated.** **Special Tool** **DT-48285** Valve Body Torx Plus Socket (if applicable) For equivalent regional tools, refer to **Special Tools** .
2	Control Valve Body Assembly **CAUTION:** **Use care when handling the control valve body assembly. If dropped, damage to the internal components of the control solenoid valve assembly, including the transmission control module (TCM), may result.**
3	Fluid Pump Seal Assembly **CAUTION:** **Use care when removing the seal assemblies to avoid**

cardiagn.com

Callout	Component Name
	damaging the valve body seal bores. CAUTION: Refer to Seal Reuse Caution .
4	Fluid Pump Seal Assembly CAUTION: Use care when removing the seal assemblies to avoid damaging the valve body seal bores. CAUTION: Refer to Seal Reuse Caution .
5	Center Support Fluid Passage Seal Assembly CAUTION: Use care when removing the seal assemblies to avoid damaging the case seal bores. CAUTION: Refer to Seal Reuse Caution .

TORQUE CONVERTER HOUSING WITH FLUID PUMP REMOVAL

cardiagn.com




Fig. 6: Torque Converter Housing with Fluid Pump
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: **The valve body assembly must be removed prior to removing the torque converter (with fluid pump) housing assembly. Failure to ensure this will cause**	

cardiagn.com

Callout	Component Name
severe damage to both fluid pump seal assemblies. Also, the load of the valve body pushing on the seals, which in turn push on the pump, may prevent proper pump installation into the case. Refer to control valve body assembly removal.	
1	Turbine Shaft (O-ring) Seal
2	Bolt M10 x 50 (Qty: 9)
3	Torque Converter (With Fluid Pump) Housing Assembly
4	Fluid Pump Seal

1-2-3-4 AND 3-5 REVERSE CLUTCH ASSEMBLY AND 4-5-6 CLUTCH ASSEMBLY REMOVAL (6L80/6L90)

cardiagn.com




Fig. 7: 1-2-3-4 and 3-5 Reverse Clutch Assembly and 4-5-6 Clutch Assembly (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	1-2-3-4 and 3-5 Reverse Clutch Assembly and 4-5-6 (With Turbine Shaft) Clutch Assembly
2	Turbine Shaft Thrust Bearing Assembly
3	4-5-6 Clutch (With Output Carrier Shaft and Dampener) Hub Assembly
4	4-5-6 Clutch Hub Thrust Bearing Assembly
5	1-2-3-4 Clutch (With Output Carrier Inner Sun Gear Shaft) Hub Assembly
6	1-2-3-4 Clutch Hub Thrust Bearing Assembly
7	2-6 and 3-5 Reverse Clutch (With Output Carrier Outer Sun Gear Shaft) Hub Assembly
8	2-6 and 3-5 Reverse Clutch Hub Thrust Bearing Assembly
9	1-2-3-4 and 3-5 Reverse Clutch Assembly
10	Input Carrier Assembly
11	Input Sun Gear
12	Input Sun Gear Thrust Bearing
13	Input Sun Gear Thrust Washer
14	4-5-6 (With Turbine Shaft) Clutch Assembly

CENTER SUPPORT, OUTPUT CARRIER AND OUTPUT SHAFT REMOVAL (6L80/6L90)

cardiagn.com




Fig. 8: Center Support, Output Carrier and Output Shaft (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Center Support Retaining Ring **WARNING:** **Use care when removing or installing the retaining ring. Ensure the J 45126 and DT 47773 are installed properly onto the retaining ring or bodily injury may occur.** **NOTE:** **To release tension on the retaining**

cardiagn.com

Callout	Component Name
	ring, place the retaining ring flat on the floor and step on it, then remove the tool. **Special Tools** • **DT 47773** Snap Ring Pliers Adapter Set • **J 45126** Snap Ring Pliers For equivalent regional tools, refer to **Special Tools** .
2	Center (with 2-6 Low and Reverse Clutch) Support Assembly
3	Output Carrier Assembly and Output Shaft Assembly **CAUTION:** **Ensure the DT 47786 is completely threaded into the output shaft assembly. Due to the weight of the assembly, incomplete threading may cause the assembly to break free from the DT 47786, causing component damage.** **Special Tool** **DT 47786** Output Carrier/Shaft Lifting Tool For equivalent regional tools, refer to **Special Tools** .
4	Output Shaft Thrust Bearing Assembly

MANUAL SHIFT SHAFT AND PARKING SYSTEM COMPONENTS OVERHAUL (6L80/6L90)

cardiagn.com




Fig. 9: Manual Shift Shaft and Parking System (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Manual Shaft Detent Lever Hub Pin **CAUTION:** **Refer to Pin Reuse Caution .**
2	Manual Shift Shaft Pin **CAUTION:** **Refer to Pin Reuse Caution .**
3	Manual Shift Shaft **CAUTION:**

cardiagn.com

Callout	Component Name
	Ensure the manual shift shaft seal is replaced before installing the shaft. Installing the seal after the shaft may cause damage to the seal, resulting in fluid leaks and transmission damage. **NOTE:** **Refer to Manual Shift Shaft Seal Replacement.**
4	Manual Shaft Detent Lever Assembly
5	Park Pawl Actuator Assembly
6	Park Pawl Actuator Guide Pin **CAUTION:** **Refer to Pin Reuse Caution .** **NOTE:** **Use a large pair of side cutters to "walk" the pin out.**
7	Park Pawl Actuator Guide
8	Park Pawl Actuator Guide (O-ring) Seals **CAUTION:** **Refer to Seal Reuse Caution .**

cardiagn.com

Callout	Component Name
9	Park Pawl **NOTE:** **Inspect for damage only. Do not remove. The park pawl is not a serviceable component.**
10	Park Pawl Spring **NOTE:** **Inspect for damage only. Do not remove. The park pawl spring is not a serviceable component.**

MANUAL SHIFT SHAFT SEAL REPLACEMENT




Fig. 10: Manual Shift Shaft Seal

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

Callout	Component Procedure
1	Manual Shift Shaft Seal **CAUTION:** **Do not damage the case bore during removal of the manual shift shaft seal.** **CAUTION:** **When installing the seal, ensure the seal lip is firmly seated against the case bore surface. Do not allow the seal lip to be crushed, or a leak may result.** **CAUTION:** **Refer to Seal Reuse Caution .** **Special Tools** • **DT 47770** Seal Installer • **DT 45201** Cooler Line Seal Remover For equivalent regional tools, refer to **Special Tools** .

OUTPUT SHAFT SEAL REPLACEMENT (AWD)

cardiagn.com




Fig. 11: Output Shaft Seal (AWD)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
	Output Shaft Seal Assembly **CAUTION:** **Refer to Seal Reuse Caution .**
1	**Special Tool** • **EN 37212** Front Output Shaft Seal Installer (6L50) • **DT 38693** Seal Installer (6L80) • **EN 45000** Seal Remover For equivalent regional tools, refer to **Special Tools** .

CASE INSPECTION

cardiagn.com




Fig. 12: Inspecting Case
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure. CAUTION: Do not reuse cleaning solvents. Previously	

cardiagn.com

Callout	Component Name
used solvents may deposit sediment which may damage the component. **Preliminary Procedures** 1. Thoroughly clean the transmission case assembly, including case threads, with clean solvent. 2. Clean gasket sealing surfaces. Remove all residual gasket material. 3. Inspect all threaded holes. If necessary, repair any thread damage.	
1	Front Case Sealing Surface
2	Manual Shift Shaft Seal **NOTE:** **Refer to Manual Shift Shaft Seal Replacement.**
3	Center Support Fluid Passage Seal Bores
4	Fluid Pan Sealing Surface
5	Case Plugs
6	Output Shaft Bushing or Bearing (model specific)
7	Rear Case Sealing Surface
8	Fill Tube Bore
9	Electrical Connector Passage Sleeve Bore

OUTPUT INTERNAL GEAR DISASSEMBLE (6L80/6L90)

cardiagn.com




Fig. 13: Output Internal Gear (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
NOTE: **Inspect each component and replace as necessary.**	
1	Output Carrier Assembly
2	Output Carrier Thrust Bearing Assembly
3	Output Internal Gear Assembly

OUTPUT CARRIER ASSEMBLY OVERHAUL (6L80)

cardiagn.com




Fig. 14: Output Carrier Components (6L80)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Carrier Front Sun Gear Thrust Bearing Assembly
2	Center Support Roller Bearing **CAUTION:** **Do not reuse the center support roller bearing. Install a NEW center support roller bearing. Reusing an old bearing may result in damage to the output carrier.** **NOTE:**

cardiagn.com

Callout	Component Name
	The thick side of the bearing shell faces up. **Special Tools** • **DT 47857** Bearing Installer • **J 6125-B** Slide Hammer • **J 8092** Driver Handle • **J 23129** Universal Seal Remover For equivalent regional tools, refer to **Special Tools** .
3	Output Carrier Front Sun Gear **CAUTION:** **Install the gear chamfer side up. Failure to install the gear chamfer side up may result in transmission damage.**
4	Output Carrier Front Sun Gear Rear Thrust Bearing Assembly
5	Output Carrier Rear Sun Gear **CAUTION:** **Install the gear chamfer side up. Failure to install the gear chamfer side up may result in transmission damage.**
6	Output Carrier Rear Sun Gear Bearing Assembly **NOTE:**

cardiagn.com

Callout	Component Name
	Inspect for damage only. Do not remove. The bearing assembly is not a serviceable component.

OUTPUT CARRIER ASSEMBLY OVERHAUL (6L90)




Fig. 15: Output Carrier Assembly (6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Carrier Front Sun Gear Thrust Bearing Assembly
2	Center Support Roller Bearing **CAUTION:** **Do not reuse the center support roller bearing. Install a NEW center**

cardiagn.com

Callout	Component Name
	support roller bearing. Reusing an old bearing may result in damage to the output carrier. **NOTE:** **The thick side of the bearing shell faces up.** **Special Tools** • **DT 47857** Bearing Installer • **J 8092** Driver Handle • **J 45124** Removal Bridge • **DT 47865** Bearing Remover For equivalent regional tools, refer to **Special Tools** .
3	Output Carrier Front Sun Gear **CAUTION:** **Install the gear chamfer side up. Failure to install the gear chamfer side up may result in transmission damage.**
4	Output Carrier Front Sun Gear Rear Thrust Bearing Assembly
5	Output Carrier Rear Sun Gear **CAUTION:** **Install the gear chamfer side up. Failure**

cardiagn.com

Callout	Component Name
	to install the gear chamfer side up may result in transmission damage.
6	Output Carrier Rear Sun Gear Bearing Assembly **NOTE:** **Inspect for damage only. Do not remove. The bearing assembly is not a serviceable component.**

OUTPUT CARRIER TO OUTPUT SHAFT ASSEMBLE (6L80/6L90)




Fig. 16: Output Carrier To Output Shaft (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Carrier Thrust Bearing Assembly

cardiagn.com

Callout	Component Name
2	Output Carrier Internal Front Gear **CAUTION:** **Install the gear flat side down. Failure to install the gear flat side down may result in transmission damage.**
3	Output Shaft Assembly
4	Output Carrier Internal Gear Retaining Ring **NOTE:** **Grasp the output shaft and carrier with both hands to turn over.**

OUTPUT CARRIER TO OUTPUT INTERNAL GEAR ASSEMBLE (6L80/6L90)




Fig. 17: Output Carrier Components & Internal Gear (6L80/6L90)

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Carrier Thrust Bearing Assembly
2	Output Carrier Assembly
3	Output Internal Gear Assembly **NOTE:** **Grasp the output shaft and carrier with both hands to turn over.**

2-6 CLUTCH OVERHAUL

2-6 Clutch Plates Removal




Fig. 18: Identifying 2-6 Clutch Plate Components
Courtesy of GENERAL MOTORS COMPANY

2-6 Clutch Plates Removal

Callout	Component Name
1	2-6 Clutch Backing Plate Retaining Ring
2	2-6 Clutch Backing Plate
3	2-6 Clutch Plate Assembly (Qty: 5)
4	2-6 Clutch Plate (Qty: 5)

cardiagn.com

Callout	Component Name
5	2-6 Clutch (Waved) Plate

2-6 Clutch Piston Replacement




Fig. 19: 2-6 Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

2-6 Clutch Piston Replacement

Callout	Component Name
1	2-6 Clutch Spring Retaining Ring (Tapered) **NOTE:** **Ensure the DT 47761 spring compressor is centered over the clutch spring.** **Special Tool** **DT 47761** Clutch Spring Compressor For equivalent regional tools, refer to **Special Tools** .
2	2-6 Clutch Spring

cardiagn.com

Callout	Component Name
	CAUTION:
3	2-6 Clutch Piston Assembly **Ensure the spring tabs** **NOTE:** ing **down during installation, and that the tabs fit between the teeth on the piston. Failure to do so may cause damage to**

2-6 Clutch Plates Installation




Fig. 20: 2-6 Clutch Plates
Courtesy of GENERAL MOTORS COMPANY

2-6 Clutch Plates Installation

Callout	Component Name
1	2-6 Clutch (Waved) Plate
2	2-6 Clutch Plates (Qty: 5) **NOTE:** **Alternate between**

cardiagn.com

Callout	Component Name
	steel and fiber clutch plates.
3	2-6 Clutch Plate Assembly (Qty: 5) **NOTE:** **Alternate between steel and fiber clutch plates.**
4	2-6 Clutch Backing Plate
5	2-6 Clutch Backing Plate Retaining Ring (Flat) **CAUTION:** **When installed, the open end of the snap ring must orient away from the slotted and scalloped areas of the center support assembly. Ideal orientation location should be at the 3 o'clock or 9 o'clock position of the center support, when facing the pan side of the case. Orienting the snap ring opening with either the scalloped or slotted areas of the center support may**

cardiagn.com

Callout	Component Name
	cause transmission damage. **Procedure** Be sure to install the retaining ring gap at the 9 o'clock or 3 o'clock position, as indicated by the arrows.
6	2-6 Clutch Apply Passage **NOTE:** **Apply air to verify proper installation of all 2-6 clutch components.**

LOW AND REVERSE CLUTCH OVERHAUL

Low and Reverse Clutch Plate Removal




Fig. 21: Low And Reverse Clutch Plate
Courtesy of GENERAL MOTORS COMPANY

Low and Reverse Clutch Plate Removal

Callout	Component Name

cardiagn.com

Callout	Component Name
1	Low and Reverse Clutch Backing Plate Retaining Ring
2	Low and Reverse Clutch Backing Plate
3	Low and Reverse Clutch Plate Assembly (Qty: 5)
4	Low and Reverse Clutch Plate (Qty: 5)
5	Low and Reverse Clutch (Waved) Plate

Low and Reverse Clutch Piston Removal




Fig. 22: Low And Reverse Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

Low and Reverse Clutch Piston Removal

Callout	Component Name
1	Low and Reverse Clutch Spring Retaining Ring **CAUTION:** **Ensure the DT 47779 contacts the sprag assembly and not the sprag retaining ring. Damage to the sprag**

cardiagn.com

Callout	Component Name
	may result. **Special Tool** **DT 47779** Clutch Spring Compressor For equivalent regional tools, refer to **Special Tools** .
2	Low Clutch Sprag Assembly **NOTE:** **A blue colored ring may be present on the outer splines of the low clutch sprag assembly. This is a normal condition caused by heat treating during manufacturing and does not indicate need for replacement.**
3	Low and Reverse Clutch Spring
4	Low and Reverse Clutch Piston Assembly **NOTE:** **It may be necessary to apply air to the apply passage in order to unseat the piston.**
5	Low Clutch Sprag Seal **CAUTION:** **Refer to Seal Reuse Caution .**

Low and Reverse Clutch Piston Installation

cardiagn.com




Fig. 23: Low And Reverse Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

Low and Reverse Clutch Piston Installation

Callout	Component Name
1	Low and Reverse Clutch Piston Assembly **NOTE:** **Lubricate the inner and outer sealing surfaces of the piston assembly with automatic transmission fluid (ATF) in order to ease installation into the center support assembly.**

cardiagn.com

Callout	Component Name
2	Low Clutch Sprag Seal **CAUTION:** **Refer to Seal Reuse Caution .** **NOTE:** **Apply ATF to the DT 47780 low clutch sprag seal cone to ease seal installation.** **Special Tool** **DT 47780** Low Clutch Sprag Seal Cone For equivalent regional tools, refer to **Special Tools** .
3	Low and Reverse Clutch Spring **CAUTION:** **Ensure the spring tabs are facing up during installation. Failure to do so may cause damage to the clutch assembly.**
4	Low Clutch Sprag Assembly **NOTE:** • **Verify that the low clutch sprag is operating correctly. Refer to the illustration for proper freewheel**

cardiagn.com

Callout	Component Name
	direction. • Ensure the missing splines on the sprag assembly are aligned with the missing splines on the center support hub.
5	Low and Reverse Clutch Spring Retaining Ring **CAUTION:** **Ensure the DT 47779 contacts the sprag assembly and not the sprag retaining ring. Damage to the sprag may result.** **CAUTION:** **The retaining ring gap must be aligned with the 3 missing splines on the center support hub. Failure to do so may cause damage to the clutch**

cardiagn.com

Callout	Component Name
	assembly. **Special Tools** • **DT 47778-1** Low Clutch Sprag Retaining Ring Cone • **DT 47778-2** Low Clutch Sprag Retaining Ring Pusher • **DT 47779** Clutch Spring Compressor For equivalent regional tools, refer to **Special Tools** .

Low and Reverse Clutch Plate Installation




Fig. 24: Low And Reverse Clutch Plate
Courtesy of GENERAL MOTORS COMPANY

Low and Reverse Clutch Plate Installation

Callout	Component Name
1	Low and Reverse Clutch (Waved) Plate
2	Low and Reverse Clutch Plate (Qty: 5)
3	Low and Reverse Clutch Plate Assembly (Qty: 5)
4	Low and Reverse Clutch Backing Plate
5	Low and Reverse Clutch Backing Plate Retaining Ring **NOTE:**

cardiagn.com

Callout	Component Name
	Apply air to verify proper installation of all low and reverse clutch components.

LOW AND REVERSE CLUTCH BACKING PLATE RETAINING RING MEASUREMENT




Fig. 25: Low & Reverse Clutch Backing Plate Retaining Ring
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name

cardiagn.com

Callout	Component Name
Preliminary Procedures 1. Install **DT-47868-1** pack travel weight and **DT-47868-4** travel weight adapter onto the low and reverse clutch backing plate. 2. Attach the **GE 8001** dial indicator set to the **GE 26900-13** magnetic base and zero out the dial indicator on the **DT-47868-1** pack travel weight. **Special Tools** • **DT-47868-1** Pack Travel Weight • **DT-47868-4** Clutch Travel Weight Adapter • **GE 8001** Dial Indicator Set • **GE 26900-13** Magnetic Base For equivalent regional tools, refer to **Special Tools** .	
1	Low and Reverse Backing Plate Retaining Ring **NOTE:** **Apply compressed air to the apply passage hole, at least 3 times and observe the dial indicator measurement each time. This action"fluffs" the clutch plates to ensure an accurate measurement. Refer to Clutch Backing Plate Retaining Ring Specifications .**

4-5-6 CLUTCH DAMPENER OVERHAUL (6L80/6L90)

cardiagn.com




Fig. 26: 4-5-6 Clutch Dampener Components
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
NOTE: **6L45 models DO NOT include a 4-5-6 clutch dampener.**	
1	4-5-6 Clutch Dampener Retaining Ring **CAUTION:** **Ensure the retaining ring is fully seated when installed.** **Using a screwdriver, fully seat the retaining ring into the groove by pushing on the inside diameter**

cardiagn.com

Callout	Component Name
	around the whole circumference. If the retaining ring is not fully seated, transmission damage will result.
2	4-5-6 Clutch Dampener Apply Plate
3	4-5-6 Clutch Dampener **NOTE:** Dry and inspect the clutch dampener for the following conditions: • Pitting • Flaking • Delamination • Wear • Glazing • Cracking If any of these conditions are found, replace the dampener.

4-5-6 CLUTCH OVERHAUL

4-5-6 Clutch Plates Removal

cardiagn.com




Fig. 27: View Of 4-5-6 Clutch Plates (6L80/6L90)
Courtesy of GENERAL MOTORS COMPANY

4-5-6 Clutch Plates Removal

Callout	Component Name
1	4-5-6 Clutch Backing Plate Retaining Ring
2	4-5-6 Clutch Backing Plate
3	4-5-6 Clutch Plate Assembly (Qty: 6)
4	4-5-6 Clutch Plate (Qty: 6)
5	4-5-6 Clutch (Waved) Plate

4-5-6 Clutch Piston Removal

cardiagn.com




Fig. 28: 4-5-6 Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

4-5-6 Clutch Piston Removal

Callout	Component Name
1	4-5-6 Clutch Piston Dam Retaining Ring **CAUTION:** **Use care when compressing the 4-5-6 clutch piston assembly, spring and dam assembly. Compressing the dam assembly too much may damage it.** **CAUTION:** **Refer to Retaining**

cardiagn.com

Callout	Component Name
	Ring Reuse Caution . **Special Tool** **J 43074** Clutch Spring Compressor
2	4-5-6 Clutch Piston Dam Assembly **NOTE:** **It may be necessary to apply air pressure to remove the dam and piston.**
3	4-5-6 Clutch Spring
4	4-5-6 Clutch Piston Assembly **NOTE:** **It may be necessary to apply air pressure to remove the piston.**

Turbine Shaft Fluid Seal Ring Replacement

cardiagn.com




Fig. 29: Turbine Shaft Fluid Seal Ring
Courtesy of GENERAL MOTORS COMPANY

Turbine Shaft Fluid Seal Ring Replacement

Callout	Component Name
Preliminary Procedures • Inspect the turbine shaft fluid passages and splines. • Clean any plugged passages.	
1	Turbine Shaft Fluid Seal Ring (Qty: 3) **CAUTION:** **Do not use old seal rings. Install NEW seal rings. Reusing old seal rings may cause internal transmission leaks and transmission damage.**

cardiagn.com

Callout	Component Name
	CAUTION: Size the fluid NOTE: gs for at least 5 minutes after installation to obtain proper seal ring size. Failure to do so may cause internal transmission leaks and transmission damage. Special Tools • DT 47768-1 Seal Protector • DT 47768-2 Seal Pusher • DT 47768-3 Seal Sizer

Adjust the turn screw on DT 47768-1 seal protector and install the bottom seal ring first.

4-5-6 Clutch Piston Installation




Fig. 30: 4-5-6 Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

4-5-6 Clutch Piston Installation

cardiagn.com

Callout	Component Name
1	4-5-6 Clutch Piston Assembly
2	4-5-6 Clutch Spring **CAUTION:** **Ensure the spring tabs are facing up during installation. Failure to do so may cause damage to the clutch assembly.**
3	4-5-6 Clutch Piston Dam Assembly **NOTE:** **Lubricate the inner and outer sealing surfaces of the dam assembly with automatic transmission fluid (ATF) in order to ease installation into the piston.**
4	4-5-6 Clutch Piston Dam Retaining Ring **CAUTION:** **Use care when compressing the 4-5-6 clutch piston assembly, spring and dam assembly. Compressing the dam**

cardiagn.com

Callout	Component Name
	assembly too much may damage it. **CAUTION:** Refer to Retaining Ring Reuse Caution . **NOTE:** Apply air to verify proper installation of all 4-5-6 clutch components. The piston should apply and release smoothly. **Special Tool** **J 43074** Clutch Spring Compressor

4-5-6 Clutch Plates Installation

cardiagn.com




Fig. 31: 4-5-6 Clutch Plates
Courtesy of GENERAL MOTORS COMPANY

4-5-6 Clutch Plates Installation

Callout	Component Name
1	4-5-6 Clutch (Waved) Plate
2	4-5-6 Clutch Plate (Qty: 6)
3	4-5-6 Clutch Plate Assembly (Qty: 6)
4	4-5-6 Clutch Backing Plate
5	4-5-6 Clutch Backing Plate Retaining Ring **NOTE:** **After the retaining ring is installed, determine clutch piston travel in order to verify if the correct selective retaining ring is being used. Refer to 4-5-6 Clutch Backing Plate Retaining**

cardiagn.com

Callout	Component Name
	Ring Measurement.

4-5-6 CLUTCH BACKING PLATE RETAINING RING MEASUREMENT




Fig. 32: Measuring 4-5-6 Clutch Backing Plate Retaining Ring
Courtesy of GENERAL MOTORS COMPANY


Callout	Component Name
Preliminary Procedures 1. Install the clutch assembly into a hole in the workbench 2. Zero out the dial indicator on the **DT 47868-1** pack travel weight. **Special Tools** • **DT 47868-1** Pack Travel Weight • **GE 8001** Dial Indicator Set • **GE 26900-13** Magnetic Base For equivalent regional tools, refer to Special Tools .	
1	4-5-6 Clutch Apply Passage **NOTE:**

cardiagn.com

Callout	Component Name
	While using one finger to block the top passage hole on the turbine shaft, apply compressed air to the opposite top passage hole, and observe the dial indicator measurement. Refer to Clutch Backing Plate Retaining Ring Specifications to determine the correct retainer.

1-2-3-4 AND 3-5 REVERSE CLUTCH OVERHAUL (6L80/6L90)

1-2-3-4 and 3-5 Reverse Clutch Plates Removal



cardiagn.com

Fig. 33: 1-2-3-4 And 3-5 Reverse Clutch Plates
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 and 3-5 Reverse Clutch Plates Removal

Callout	Component Name
1	3-5 Reverse Clutch Backing Plate Retaining Ring
2	3-5 Reverse Clutch Backing Plate
3	3-5 Reverse Clutch Plate Assembly **Procedure** • Remove Qty: 4 plates - 6L80 • Remove Qty: 4 or 5 plates - Model Dependent - 6L90
4	3-5 Reverse Clutch Plate **Procedure** • Remove Qty: 4 plates - 6L80 • Remove Qty: 4 or 5 plates - Model Dependent - 6L90
5	3-5 Reverse Clutch (Waved) Plate
6	3-5 Reverse Clutch Apply Ring
7	1-2-3-4 Clutch Backing Plate Retaining Ring
8	1-2-3-4 Clutch Backing Plate
9	1-2-3-4 Clutch Plate Assembly **Procedure** • Remove Qty: 5 plates - 6L80 • Remove Qty: 5 or 6 plates - Model Dependent - 6L90
10	1-2-3-4 Clutch Plate **Procedure** • Remove Qty: 5 plates - 6L80 • Remove Qty: 5 or 6 plates - Model Dependent - 6L90
11	1-2-3-4 Clutch (Waved) Plate

1-2-3-4 Clutch Piston Removal

cardiagn.com




Fig. 34: 1-2-3-4 Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 Clutch Piston Removal

Callout	Component Name

cardiagn.com

Callout	Component Name
1	1-2-3-4 Clutch Piston Dam Retaining Ring **CAUTION:** **Use care when compressing the 1-2-3-4 clutch spring and dam assembly. Compressing the dam assembly too much may damage it.** **CAUTION:** **Refer to Retaining Ring Reuse Caution .** **Special Tool** **DT 38734** Intermediate Spring Compressor Adapter For equivalent regional tools, refer to **Special Tools** .
2	1-2-3-4 Clutch Piston Dam Assembly
3	1-2-3-4 Clutch Spring
4	1-2-3-4 Clutch Piston **Procedure** Inspect the 1-2-3-4 clutch piston for cracking and replace if damaged. **NOTE:** • **It may be necessary to apply air to the apply passage in order to remove the piston. Install the 1-2-3-4 clutch housing**

cardiagn.com

Callout	Component Name
	onto the torque converter (with fluid pump) housing assembly in order to apply air. • After air is applied, it may be necessary to turn the housing assembly upside down and carefully tap the housing against a flat surface in order to release the piston.

3-5 Reverse Clutch Piston Removal

cardiagn.com




Fig. 35: 3-5 Reverse Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

3-5 Reverse Clutch Piston Removal

Callout	Component Name
Preliminary Procedures 1. Install the 1-2-3-4 and 3-5 reverse clutch housing assembly onto the torque converter (with fluid pump) housing assembly. 2. Apply hand pressure on the 1-2-3-4 clutch piston housing while applying compressed air to the apply passage in order to unseat the 3-5 reverse clutch piston.	
1	1-2-3-4 Clutch Piston Housing Retaining Ring **CAUTION:** **Refer to Retaining Ring Reuse Caution .** **Special Tool** **DT 47867** Adjustable Clutch Spring Compressor For equivalent regional tools, refer to **Special Tools** .
2	1-2-3-4 Clutch Piston Housing
3	3-5 Reverse Clutch Spring

cardiagn.com

Callout	Component Name
4	3-5 Reverse Clutch Piston **NOTE:** **It may be necessary to turn the housing assembly upside down and carefully tap the housing against a flat surface in order to release the piston.**

3-5 Reverse Clutch Air Bleed Inspection (6L80/6L90)




Fig. 36: Using Compressed Air To Ensure Unblocked Bleed Passage
Courtesy of GENERAL MOTORS COMPANY

3-5 Reverse Clutch Air Bleed Inspection (6L80/6L90)

Callout	Component Name
1	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly **Procedure**

cardiagn.com

Callout	Component Name
	Ensure the air bleed passage is clear and free from obstructions by using a fine wire and also compressed air.

3-5 Reverse Clutch Housing Inspection Disassembled




Fig. 37: 3-5 Reverse Clutch Housing
Courtesy of GENERAL MOTORS COMPANY

3-5 Reverse Clutch Housing Inspection Disassembled

Callout	Component Name
1	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly **Procedure** 1. Apply soap compound to weld area of housing. 2. Hold thumb over the air bleed passage. 3. For disassembled 1-2-3-4 and 3-5 reverse clutch housing spray compressed air onto the housing / hub joint and inspect weld area for bubbles. 4. If bubbles are detected a new housing is required.

3-5 Reverse Clutch Housing Inspection Assembled

cardiagn.com




Fig. 38: 3-5 Reverse Clutch Housing
Courtesy of GENERAL MOTORS COMPANY

3-5 Reverse Clutch Housing Inspection Assembled

Callout	Component Name
1	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly **Procedure** 1. Apply soap compound to weld area of housing. 2. Hold thumb over the air bleed passage. 3. For fully assembled 1-2-3-4 and 3-5 reverse clutch housing spray compressed air into the 3-5R clutch feed hole and inspect weld area for bubbles. 4. If bubbles are detected a new housing is required.

1-2-3-4 and 3-5 Reverse Clutch Piston Seals Replacement

cardiagn.com




Fig. 39: 1-2-3-4 and 3-5 Reverse Clutch Piston Seals
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 and 3-5 Reverse Clutch Piston Seals Replacement

Callout	Component Name
CAUTION: Refer to Seal Reuse Caution . **Preliminary Procedure** Lubricate all seals with automatic transmission fluid (ATF) prior to installation.	
1	1-2-3-4 Clutch Piston Seal
2	3-5 Reverse Clutch Piston Dam (O-Ring) Seal
3	3-5 Reverse Clutch Piston Inner Seal
4	1-2-3-4 Clutch Piston Housing
5	3-5 Reverse Clutch Piston Outer Seal
6	3-5 Reverse Clutch Piston
7	1-2-3-4 Clutch Piston Inner Seal **CAUTION:** **Do not install a NEW 1-2-3-4 clutch piston inner seal yet. A**

cardiagn.com

Callout	Component Name
	special tool used to install the 1-2-3-4 clutch piston housing retaining ring may damage the seal if the seal is installed prior to installing the retaining ring. Refer to 3-5 Reverse Clutch Piston Installation.
8	1-2-3-4 Clutch Piston Housing Seal
9	1-2-3-4 Clutch Piston Housing Seal

3-5 Reverse Clutch Piston Installation




Fig. 40: Installing 3-5 Reverse Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

cardiagn.com

3-5 Reverse Clutch Piston Installation

Callout	Component Name
1	3-5 Reverse Clutch Piston
2	3-5 Reverse Clutch Spring **CAUTION:** **Ensure the clutch spring is centered on the piston with the tabs facing up. Failure to do so may cause damage to the clutch assembly.**
3	1-2-3-4 Clutch Piston Housing
4	1-2-3-4 Clutch Piston Housing Retaining Ring **CAUTION:** **Before using the DT 47782-2, push the retaining ring over the DT 47782-1 by hand so that the ring is positioned below the tapered area of the DT 47782-1. If the ring is positioned above the tapered area when it is being installed, the ring will become lodged between both tools**

cardiagn.com

Callout	Component Name
	and damage to the tools, retaining ring, and piston housing will result. CAUTION: Refer to Retaining Ring Reuse Caution . CAUTION: Push the retaining ring down over the cone until the ring seats firmly in the retaining ring groove. The retaining ring will make a distinctive click sound when it seats. Failure to properly seat the retaining ring may cause damage to the 3-5 reverse clutch assembly. NOTE:

cardiagn.com

Callout	Component Name
	Use a screwdriver in order to verify the retaining ring is fully seated into the groove. It may appear as though the retaining ring is not fully seated, since the groove is shallow by design. However, this shallow interface is normal. **Special Tools** • **DT 47782-1** Retaining Ring Cone • **DT 47782-2** Retaining Ring Installer For equivalent regional tools, refer to **Special Tools** .
5	1-2-3-4 Clutch Piston Inner Seal **CAUTION:** **Install a NEW seal and orientate as shown. Failure to do so may cause internal transmission leaks and damage to the transmission.**

1-2-3-4 Clutch Piston Installation

cardiagn.com




Fig. 41: 1-2-3-4 Clutch Piston
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 Clutch Piston Installation

Callout	Component Name
1	1-2-3-4 Clutch Piston
2	1-2-3-4 Clutch Spring **CAUTION:** **Ensure the clutch spring is centered on the piston with the tabs facing up. Failure to do so may cause damage to the clutch assembly.**
3	1-2-3-4 Clutch Piston Dam Assembly **NOTE:**

cardiagn.com

Callout	Component Name
	Lubricate the inner and outer surfaces of the dam assembly with ATF in order to ease installation into the piston. Install the tabs facing up.
4	1-2-3-4 Clutch Piston Dam Retaining Ring **CAUTION:** **Use care when compressing the 1-2-3-4 clutch spring and dam assembly. Compressing the dam assembly too much may damage it.** **CAUTION:** **Refer to Retaining Ring Reuse Caution .** **Special Tool** **DT 38734** Intermediate Spring Compressor Adapter For equivalent regional tools, refer to **Special Tools** .

1-2-3-4 Clutch Plate Installation

cardiagn.com




Fig. 42: 1-2-3-4 Clutch Plate
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 Clutch Plate Installation

Callout	Component Name
1	1-2-3-4 Clutch (Waved) Plate **CAUTION:** **Ensure an opening between the external splines of the waved plate is centered over the missing snap ring groove punch in the housing. Failure to do so may cause damage to the clutch assembly.**

cardiagn.com

Callout	Component Name
2	1-2-3-4 Clutch Plate **CAUTION:** **Ensure all clutch plates are centered in the housing. When installing the first steel clutch plate, ensure an opening between the external splines is centered over the missing snap ring groove punch in the housing. Align the external splines of each remaining steel clutch plate with the first steel clutch plate. Failure to do so may cause damage to the clutch assembly.** **Procedure** • Install Qty: 5 plates - 6L80 • Install Qty: 5 or 6 plates - Model Dependent - 6L90
3	1-2-3-4 Clutch Plate Assembly **Procedure**

cardiagn.com

Callout	Component Name
	• Install Qty: 5 plates - 6L80 • Install Qty: 5 or 6 plates - Model Dependent - 6L90
4	1-2-3-4 Clutch Backing Plate **CAUTION:** **Align the external splines of the backing plate with the external splines of the steel clutch plates. Failure to do so may cause damage to the clutch assembly.** **CAUTION:** **Ensure the 1-2-3-4 Clutch Backing Plate is installed correctly to prevent mechanical damage.** **Procedure** If the plate has UP stamped on it, install that side up. If the plate has 3 circle marks spaced 120 degrees apart stamped on it, install that side up. If no identification marks are present, install sharp edge up, chamfer side down.
5	1-2-3-4 Clutch Backing Plate Retaining Ring **CAUTION:** **Depending on the housing configuration, align the retaining ring**

cardiagn.com

Callout	Component Name
	gap with the missing snap ring groove punch in the housing or the offset punch in the housing. Failure to do so may cause damage to the clutch assembly. **Procedure** After the retaining ring is installed, determine clutch piston travel in order to verify if the correct selective retaining ring is being used. Refer to **1-2-3-4 Clutch Backing Plate Retaining Ring Measurement**.

3-5 and Reverse Clutch Plate Installation




Fig. 43: 3-5 and Reverse Clutch Plate
Courtesy of GENERAL MOTORS COMPANY

3-5 and Reverse Clutch Plate Installation

Callout	Component Name

cardiagn.com

Callout	Component Name
1	3-5 Reverse Clutch Apply Ring **CAUTION:** **Ensure apply ring legs are positioned into the 3-5 reverse clutch piston. Failure to do so may cause damage to the 3-5 reverse clutch assembly.**
2	3-5 Reverse Clutch (Waved) Plate
3	3-5 Reverse Clutch Plate **Procedure** • Install Qty: 4 plates - 6L80 • Install Qty: 4 or 5 plates - Model Dependent - 6L90
4	3-5 Reverse Clutch Plate Assembly **Procedure** • Install Qty: 4 plates - 6L80 • Install Qty: 4 or 5 plates - Model Dependent - 6L90
5	3-5 Reverse Clutch Backing Plate
6	3-5 Reverse Clutch Backing Plate Retaining Ring **CAUTION:** **Depending on the housing configuration, align the retaining ring gap with the missing snap ring groove punch in the housing or**

cardiagn.com

Callout	Component Name
	the offset punch in the housing. Failure to do so may cause damage to the clutch assembly. **Procedure** 1. After retaining ring is installed check 1-2-3-4 and 3-5 reverse clutch housing for weld leak. Refer to 3-5 Reverse Clutch Housing Inspection Assembled earlier in this procedure. 2. After the retaining ring is installed, determine clutch piston travel in order to verify if the correct selective retaining ring is being used. Refer to **3-5 Reverse Clutch Backing Plate Retaining Ring Measurement (6L80/6L90)**.

1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly Replacement




Fig. 44: 1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly
Courtesy of GENERAL MOTORS COMPANY

1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly Replacement

Callout	Component Name
1	3-5 Reverse Clutch Bearing

cardiagn.com

Callout	Component Name
	CAUTION: Install the NEW bearing assembly with the seal side up. Improper installation of the bearing may cause damage to the transmission. CAUTION: Do not use a hammer or other striking tool that may cause damage to the bearing and housing. Use care to ensure the bearing is installed slowly and evenly using an arbor press supporting the inner hub. Do not support by the housing or fracture will result. CAUTION: Do not reuse the bearing. Install a NEW bearing. Reusing an old bearing may cause

cardiagn.com

Callout	Component Name
	damage to the transmission. **Procedure** Install the bearing flush to 0.3 mm (0.012 in) below the thrust surface. **Special Tools** • **DT 47865** Bearing Remover • **DT 47866** Bearing Installer • **DT 45124** Removal Bridge For equivalent regional tools, refer to **Special Tools** .

1-2-3-4 CLUTCH BACKING PLATE RETAINING RING MEASUREMENT

Fluid Passage Plug Kit Installation




Fig. 45: Fluid Passage Plug Kit
Courtesy of GENERAL MOTORS COMPANY

Fluid Passage Plug Kit Installation

Callout	Component Name
Special Tools **DT-49291** Clutch Travel Air Passage Plug Kit	

cardiagn.com

Callout	Component Name
1	Compensator Feed Fluid Passage - Outer **Procedure** Install the tapered oval fluid passage plug DT-49291-4 which is part of **DT-49291** clutch travel air passage plug kit , into the compensator feed fluid passage hole on the 1-2-3-4 and 3-5 reverse clutch support assembly. **NOTE:** **The compensator feed fluid passage hole is the top outer hole on the 1-2-3-4 and 3-5 reverse clutch support assembly.**
2	Compensator Feed Fluid Passage - Inner **Procedure** Install the round fluid passage plug DT-49291-5 which is part of **DT-49291** clutch travel air passage plug kit , into the compensator feed fluid passage hole inside the 1-2-3-4 and 3-5 reverse clutch support assembly. **NOTE:** **The compensator feed fluid passage hole is the middle inner hole in the 1-2-3-4 and 3-5 reverse clutch support assembly.**
3	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly **Procedure** 1. Ensure that the 1-2-3-4 clutch plates, backing plate and retaining ring are installed. 2. Install the 1-2-3-4 and 3-5 reverse clutch housing onto the torque converter (with fluid pump) housing assembly. 3. Install the applicable plug kit sleeve DT-49291-2 (6L80/6L90) or DT-49291-3 (6L45/6L50), cap DT-49291-1, bolt, washer and nut which are all part of **DT-49291** clutch travel air passage plug kit.

cardiagn.com

Apply Compressed Air and Measurement




Fig. 46: 1-2-3-4 Clutch Backing Plate Retaining Ring
Courtesy of GENERAL MOTORS COMPANY

Apply Compressed Air and Measurement

Callout	Component Name
Preliminary Procedures 1. Install the **DT 47868-2** base adapter onto the torque converter housing. 2. Install **DT 47868-1** travel weight and **DT-47868-3** travel weight adapter onto the 1-2-3-4 clutch backing plate. 3. Install the **GE 26900-13** magnetic base onto **DT 47868-2** base adapter. 4. Attach the **GE 8001** dial indicator set to the **GE 26900-13** magnetic base. **Special Tools** • **DT 47868-1** Clutch Pack Travel Weight • **DT 47868-2** Magnetic Base Adapter • **DT-47868-3** Clutch Travel Weight Adapter • **GE 8001** Dial Indicator Set • **GE 26900-13** Magnetic Base For equivalent regional tools, refer to **Special Tools** .	
1	Compensator Feed Fluid Passage **Procedure**

cardiagn.com

Callout	Component Name
	1. Apply compressed air to the compensator feed fluid passage. 2. Zero out the dial indicator **J 8001** dial indicator set.
2	1-2-3-4 Clutch Apply Passage **Procedure** While Applying compressed air to the compensator feed fluid passage, simultaneously apply compressed air to the 1-2-3-4 clutch apply passage. Do this at least 3 times and observe the dial indicator measurement each time. Refer to **Clutch Backing Plate Retaining Ring Specifications** .

3-5 REVERSE CLUTCH BACKING PLATE RETAINING RING MEASUREMENT (6L80/6L90)




Fig. 47: 3-5 Reverse Clutch Backing Plate Retaining Ring
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Install the 1-2-3-4 and 3-5 reverse clutch housing with the 1-2-3-4 and 3-5 reverse clutch plates installed, onto the torque converter housing. 2. Install the **DT 47868-2** magnetic base adapter onto the torque converter housing. 3. Install **DT 47868-1** clutch pack travel weight onto the 3-5 reverse clutch backing plate. 4. Install the **J 26900-13** magnetic base onto **DT 47868-2** magnetic base adapter. 5. Attach the **J 8001** dial indicator set to the **J 26900-13** magnetic base and zero out the dial indicator on the **DT 47868-1** clutch pack travel weight.	

cardiagn.com

Callout	Component Name
Special Tools • **DT 47868-1** Clutch Pack Travel Weight • **DT 47868-2** Magnetic Base Adapter • **J 8001** Dial Indicator Set • **J 26900-13** Magnetic Base For equivalent regional tools, refer to **Special Tools** .	
1	3-5 Reverse Clutch Apply Passage **NOTE:** **Apply compressed air to the apply passage hole, and observe the dial indicator measurement. Refer to Clutch Backing Plate Retaining Ring Specifications .**

TORQUE CONVERTER HOUSING WITH FLUID PUMP DISASSEMBLE

cardiagn.com





Fig. 48: Torque Converter Housing with Fluid Pump
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: Do not loosen or remove the 6 bolts securing the clutch support to the pump cover assembly. These bolts have been installed and torqued only after specific clutch support rotational requirements have been met. If the clutch	

cardiagn.com

Callout	Component Name
support is not installed properly, damage to the transmission will occur.	
1	1-2-3-4 and 3-5 Reverse Clutch Housing Thrust Washer
2	Bolt M6 x 40 (Qty: 13)
3	Fluid Pump Cover Assembly
4	Fluid Pump Vane Ring
5	Fluid Pump Rotor
6	Fluid Pump Vanes (Qty: 13)
7	Fluid Pump Rotor Guide
8	Fluid Pump Vane Ring
9	Fluid Pump Slide Outer Spring
10	Fluid Pump Slide
11	Fluid Pump Slide (O-Ring) Seal
12	Fluid Pump Slide Fluid Seal Ring
13	Fluid Pump Slide Seal
14	Fluid Pump Slide Seal Support
15	Fluid Pump Slide Pivot Pin

FLUID PUMP COVER CLEANING AND INSPECTION



cardiagn.com

Fig. 49: Fluid Pump Cover
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
WARNING: Valve springs can be tightly compressed. Use care when removing retainers and plugs. Personal injury could result. **Preliminary Procedure** Clean and inspect all components and machined surfaces.	
1	Pressure Regulator Valve Train
2	Converter Feed Limit Valve Train
3	Pressure Relief Ball Valve and Spring
4	TCC Control Valve and Spring
5	A/Trans Fluid Pump Locator Pin

1-2-3-4 AND 3-5 REVERSE CLUTCH FLUID SEAL RING INSTALLATION (6L80/6L90)




Fig. 50: 1-2-3-4 And 3-5 Reverse Clutch Fluid Seal Ring

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: **Do not use old seal rings. Install NEW seal rings. Reusing old seal rings may cause internal transmission leaks and transmission damage.**	
1	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Rings - Inner O-ring (Qty: 3)
2	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Rings - Outer (Qty: 3)

TORQUE CONVERTER HOUSING CLEANING AND INSPECTION




Fig. 51: Torque Converter Housing
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures	

cardiagn.com

Callout	Component Name
1. Thoroughly clean the torque converter housing assembly, including threads, with clean solvent. 2. Clean sealing surfaces. 3. Inspect all threaded holes. If necessary, repair any thread damage.	
1	Line Pressure Test Hole Plug **CAUTION:** **Use care when tightening the line pressure test hole plug. Do not use a socket extension, which could cause side-loading and potentially crack the transmission case assembly.** **CAUTION:** **Refer to Fastener Caution .** **Tighten** 11 N.m (97 lb in)
2	A/Trans Vent Pipe
3	Trans Fluid Cooler Pipe Fitting Seal **CAUTION:** **Refer to Seal Reuse Caution .** **NOTE:** **Refer to Transmission Fluid Cooler Pipe Seal Replacement.**

cardiagn.com

Callout	Component Name
4	Torque Converter Bushing

TORQUE CONVERTER FLUID SEAL REPLACEMENT




Fig. 52: Torque Converter Fluid Seal
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Torque Converter Fluid Seal Retaining Ring
2	Torque Converter Fluid Seal Assembly **NOTE:** **The seal can be installed by hand.** **Special Tool** **EN 45000** Seal Remover For equivalent regional tools, refer to **Special Tools** .

TRANSMISSION FLUID COOLER PIPE SEAL REPLACEMENT

cardiagn.com




Fig. 53: Transmission Fluid Cooler Pipe Seal
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Trans Fluid Cooler Pipe Fitting Seals (Qty: 2) **Special Tools** • **DT 47770** Seal Installer • **DT 45201** Cooler Line Seal Remover For equivalent regional tools, refer to **Special Tools** .

FLUID PUMP SELECTIVE MEASUREMENT

cardiagn.com




Fig. 54: Fluid Pump Selective & Bolt Tightening Sequence
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Clean and inspect all components and machined surfaces. 2. After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components.	
1	Fluid Pump Slide **Procedure** 1. Install an existing and/or undamaged pump slide. 2. Place gauging plastic in three locations on the pump slide surface facing the pump cover, up.
2	Fluid Pump Slide Pivot Pin
3	Fluid Pump Rotor Guide **NOTE:** **Align the rotor guide tabs to the notches on the bottom**

cardiagn.com

Callout	Component Name
	of the rotor.
4	Fluid Pump Rotor **Procedure** 1. Install an existing and/or undamaged pump rotor. 2. Place gauging plastic in three locations on the pump rotor surface facing the pump cover, up.
5	Fluid Pump Cover Assembly
6	Fluid Pump Cover Bolts M6 x 40 (Qty: 13) **CAUTION:** **Refer to Fastener Caution .** **Procedure** 1. Hand tighten the bolts. 2. Tighten the fluid pump cover bolts in the sequence shown. 3. Remove the pump cover bolts and the pump cover. 4. Using the measuring device provided with the gauging plastic kit, measure the gauging plastic on the rotor and the slide, see inset drawings. Choose the correct selective rotor and or slide, based on the slide and rotor to fluid pump body end play specifications. Refer to **Fluid Pump Selective Specifications** . 5. Remove the gauging plastic and clean the rotor and slide surfaces. **Tighten** 11 N.m (97 lb in)

TORQUE CONVERTER HOUSING WITH FLUID PUMP ASSEMBLE

cardiagn.com




Fig. 55: Torque Converter Housing with Fluid Pump
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Fluid Pump Slide Fluid Seal Ring
2	Fluid Pump Slide (O-Ring) Seal
3	Fluid Pump Slide Pivot Pin
4	Fluid Pump Slide Seal Support **NOTE:** **The seal support is circular. The seal is rectangular.**
5	Slide Seal
6	Fluid Pump Slide **NOTE:** **If installing a NEW pump slide into the torque converter housing, ensure to**

cardiagn.com

Callout	Component Name
	properly select the correct rotor and slide before performing this procedure. Refer to Fluid Pump Selective Measurement, and Fluid Pump Selective Specifications .
7	Fluid Pump Slide Outer Spring
8	Fluid Pump Vane Ring
9	Fluid Pump Rotor Guide **CAUTION:** **Align the rotor guide tabs to the notches on the bottom of the rotor. Failure to do so may cause transmission damage.**
10	Fluid Pump Rotor **NOTE:** **If installing a NEW pump rotor into the torque converter housing, ensure to properly select the correct rotor and slide before**

cardiagn.com

Callout	Component Name
	performing this procedure. Refer to Fluid Pump Selective Measurement, and Fluid Pump Selective Specifications .
11	Fluid Pump Vanes (Qty: 13)
12	Fluid Pump Vane Ring

FLUID PUMP COVER INSTALLATION




Fig. 56: Fluid Pump Cover
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure NOTE:	

cardiagn.com

Callout	Component Name
Do not use abrasive cleaning pads that can remove material or leave abrasive residue in the parts. **NOTE:** **Do not immerse the pump cover in a parts cleaner with used solvent that can leave dirt / grit / residue in the parts.** Inspect the service pump cover and pressure regulator valve for signs of rust inhibitor (RI) that may prevent the pressure regulator from operating properly before installing the pump cover. Excessive RI can be removed with solvent, light penetrating oil or carburetor cleaner.	
1	Fluid Pump Cover Assembly
2	Fluid Pump Cover Bolts M6 x 40 (Qty: 13) **NOTE:** **Hand tighten only.**
3	Alignment Tool and Bolt **CAUTION:** **Refer to Fastener Caution .** **Procedure** 1. Center the **DT 46664** pump cover alignment tool around the fluid pump cover assembly in the 9 o'clock position and tighten the alignment bolt. 2. Tighten the fluid pump cover bolts in the sequence shown. **Tighten**

cardiagn.com

Callout	Component Name
	11 N.m (97 lb in) **Special Tools** **DT 46664** Pump Cover Alignment Tool For equivalent regional tools, refer to **Special Tools** .
4	1-2-3-4 and 3-5 Reverse Clutch Housing Thrust Washer **NOTE:** **Install a NEW washer. Do NOT reuse the old washer.**

CONTROL VALVE BODY ASSEMBLY DISASSEMBLE

Input and Output Speed Sensor Assembly Removal




Fig. 57: Input And Output Speed Sensor Assembly
Courtesy of GENERAL MOTORS COMPANY

Input and Output Speed Sensor Assembly Removal

Callout	Component Name
1	Bolt M6 x 20 (Qty: 2)
2	Speed Sensor Electrical Connector

cardiagn.com

Callout	Component Name
	NOTE:
3	A/Trans Input and Output Speed Sensor Assembly
4	A/Trans Input and Output Speed Sensor Wiring Harness Clip (Qty: 2) **Release the connector lock before disconnecting.** **NOTE:** **Inspect the clips and replace if damaged.**

Manual Shaft Detent Assembly and Manual Shift Shaft Position Switch Removal




Fig. 58: Manual Shaft Detent Assembly and Manual Shift Shaft Position Switch
Courtesy of GENERAL MOTORS COMPANY

Manual Shaft Detent Assembly and Manual Shift Shaft Position Switch Removal

Callout	Component Name
1	Bolt M6 x 14.5
2	Manual Shaft Detent Assembly
3	Bolt M5 x 55
4	A/Trans Manual Shift Shaft Position Switch Assembly Electrical Connector **NOTE:**

cardiagn.com

Callout	Component Name
	Release the connector lock before disconnecting.
5	A/Trans Manual Shift Shaft Position Switch Assembly

Control Solenoid Valve Assembly Removal




Fig. 59: Control Solenoid Valve Assembly
Courtesy of GENERAL MOTORS COMPANY

Control Solenoid Valve Assembly Removal

Callout	Component Name
1	Bolt M5 x 53 (Qty: 2)
2	Bolt M5 x 55 (Qty: 4)
3	Bolt M5 x 45 (Qty: 5)
4	Control Solenoid (w/Body and TCM) Valve Assembly **CAUTION:** **Use care when handling the control valve body assembly. If dropped,**

cardiagn.com

Callout	Component Name
	damage to the control solenoid valve body assembly internal components, including the transmission control module (TCM), may result.
5	Filter Plate Assembly **CAUTION:** **Use care when removing or installing the filter plate assembly. A broken or missing retaining tab may not adequately secure the filter plate to the control solenoid valve assembly, resulting in possible damage or contamination.** **CAUTION:** **Discard the filter plate. Replace with a NEW filter plate. Reusing an old filter plate may cause damage to the control**

cardiagn.com

Callout	Component Name
	solenoid valve assembly.

Upper and Lower Valve Bodies Disassemble




Fig. 60: Upper and Lower Valve Bodies
Courtesy of GENERAL MOTORS COMPANY

Upper and Lower Valve Bodies Disassemble

Callout	Component Name
1	Bolt M5 x 36 (Qty: 12)
2	Bolt M5 x 45 (Qty: 5)
3	Bolt M5 x 55
4	Control Valve Lower Body Assembly **Procedure** Separate the upper and lower valve bodies by carefully prying at the point indicated. **Control Valve Lower Body Assembly Cleaning and Inspection**
5	Control Valve Body Spacer (w/Gasket) Plate Assembly **CAUTION:** **Do not use the old spacer plate. Install a NEW spacer**

cardiagn.com

Callout	Component Name
	plate. Reusing an old spacer plate may cause internal transmission leaks and transmission damage.
6	Control Valve Body Ball Check Valve (Qty: 8) **NOTE:** Note the position of the ball check valves.
7	Control Valve Upper Body Assembly **NOTE:** For additional information regarding the control valve upper body assembly. Control Valve Upper Body Assembly Cleaning and Inspection

CONTROL VALVE LOWER BODY ASSEMBLY CLEANING AND INSPECTION

cardiagn.com




Fig. 61: Cleaning Control Valve Lower Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
WARNING: Valve springs can be tightly compressed. Use care when removing retainers and plugs. Personal injury could result. **CAUTION:** After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any	

cardiagn.com

Callout	Component Name
transmission components. Lint from the towels can cause component failure. **CAUTION:** **Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.** **Preliminary Procedure** Clean and inspect all valve components and the valve body. The control valve lower body is replaceable only as an assembly.	
1	Clutch Piston Dam Feed Regulator Valve Train
2	Clutch Select Solenoid Valve 3 Train
3	Clutch Select Solenoid Valve 2 Train
4	Manual Valve
5	TCC Regulator Apply Valve Train

CONTROL VALVE UPPER BODY ASSEMBLY CLEANING AND INSPECTION

cardiagn.com




Fig. 62: Cleaning Control Valve Upper Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
WARNING: Valve springs can be tightly compressed. Use care when removing retainers and plugs. Personal injury could result. **CAUTION:** Do not remove the exhaust backfill pressure relief retainer, spring, or	

cardiagn.com

Callout	Component Name
ball valve (refer to arrow in above illustration for location). The retainer is set to a precise depth. Replacement of this retainer could cause internal transmission damage. CAUTION: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure. CAUTION: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the	

cardiagn.com

Callout	Component Name
component. **Preliminary Procedure** Clean and inspect all valve components, locating pins, and the valve body. The control valve upper body is replaceable only as an assembly.	
1	Clutch Boost Valve Train
2	1-2-3-4 Clutch Regulator Valve Train
3	3-5 Reverse Clutch Regulator Valve Train
4	Clutch Boost Valve Train
5	2-6 Clutch Regulator Valve Train
6	Clutch Boost Valve Train
7	CBR1/4-5-6 Clutch Regulator Valve Train
8	Actuator Feed Limit Valve Train
9	Control Valve Body Locator Pin
10	Control Valve Body Locator Pin
11	Control Valve Body Locator Pin

CONTROL VALVE BODY ASSEMBLY ASSEMBLE

Upper to Lower Control Valve Body Assembly Assemble




Fig. 63: Upper to Lower Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Upper to Lower Control Valve Body Assembly Assemble


cardiagn.com

Callout	Component Name
1	Control Valve Body Ball Check Valve (Qty: 8) **CAUTION:** **Do not use any type of grease or other material to hold the check ball valves in place during assembly. Grease will cause the valves to not operate properly, resulting in damage to the transmission.** **NOTE:** **For additional information regarding ball check valve location. Ball Check Valve Locations**
2	Control Valve Body Spacer (w/Gasket) Plate Assembly **CAUTION:** **Do not use the old spacer plate. Install a NEW spacer plate. Reusing an old spacer plate may cause internal transmission**

cardiagn.com

Callout	Component Name
	leaks and transmission damage.
3	Control Valve Lower Body Assembly **NOTE:** **Turn the valve body assembly over after installing to upper body.**
4	Bolt M5 x 36 (Qty: 12) **CAUTION:** **Refer to Fastener Caution .** **Procedure** Tighten the bolts in the sequence shown. **Tighten** 8 N.m (71 lb in).

Filter Plate Installation



cardiagn.com

Fig. 64: Filter Plate
Courtesy of GENERAL MOTORS COMPANY

Filter Plate Installation

Callout	Component Name
1	Filter Plate Assembly **CAUTION:** **Use care when handling the control valve body assembly. If dropped, damage to the control solenoid valve body assembly internal components, including the transmission control module (TCM), may result.** **CAUTION:** **Discard the filter plate. Replace with a NEW filter plate. Reusing an old filter plate may cause damage to the control solenoid valve assembly.** **NOTE:** **Use care when removing or**

cardiagn.com

Callout	Component Name
	installing the filter plate assembly. However, if a retaining tab is broken or missing, do not replace the control solenoid valve assembly. The filter plate assembly can still be adequately aligned.

Control Solenoid Valve Assembly Installation




Fig. 65: Control Solenoid Valve Assembly
Courtesy of GENERAL MOTORS COMPANY

Control Solenoid Valve Assembly Installation

Callout	Component Name
1	Control Solenoid (w/Body and TCM) Valve Assembly

cardiagn.com

Callout	Component Name
	NOTE: **Note the locator pin on the control valve lower body assembly while aligning the control solenoid valve assembly.**
2	Bolt M5 x 53 (Qty: 2) **NOTE:** **Hand tighten only.**
3	Bolt M5 x 55 (Qty: 4) **NOTE:** **Hand tighten only.**
4	Bolt M5 x 45 (Qty: 5) **NOTE:** **Hand tighten only.**

Manual Shift Shaft Position Switch Installation

cardiagn.com




Fig. 66: Manual Shift Shaft Position Switch
Courtesy of GENERAL MOTORS COMPANY

Manual Shift Shaft Position Switch Installation

Callout	Component Name
1	A/Trans Manual Shift Shaft Position Switch Assembly
2	Manual Valve Link **NOTE:** **Align the switch activator slide with the manual valve link.**
3	Bolt M5 x 55 **NOTE:** **Hand tighten only.**
4	A/Trans Manual Shift Shaft Position Switch Harness Clip **NOTE:** **The wiring harness clip on the manual**

cardiagn.com

Callout	Component Name
	shift shaft position switch does not need to be replaced if damaged or missing. The clip functions only as a manufacturing assembly aid to keep the harness clear during an automated bolt installation process. If the clip is damaged, simply remove and discard.
5	A/Trans Manual Shift Shaft Position Switch Electrical Connector **NOTE:** Connect and lock the manual shift shaft position switch electrical connector to the control solenoid valve assembly.

Valve Body, Control Solenoid Torque Sequence

cardiagn.com




Fig. 67: Control Solenoid Torque Sequence
Courtesy of GENERAL MOTORS COMPANY

Valve Body, Control Solenoid Torque Sequence

Callout	Component Name
CAUTION: **Bolt torque sequencing is critical to the proper function of the control solenoid valve assembly. Failure to follow the required sequencing may result in transmission malfunction.**	
Preliminary Procedure	
1. Hand tighten the last 6 bolts before final torque sequence.	
2. The 2 "heat sink" bolts must be tightened last.	

cardiagn.com

Callout	Component Name
1	Bolts M5 x 45 (Qty: 5)
2	Bolt M5 x 55 **CAUTION:** **Refer to Fastener Caution .** **Procedure** Tighten all 18 bolts in the sequence shown. **Tighten** 8 N.m (71 lb in).

Control Solenoid Valve Assembly Contact Gap Inspection




Fig. 68: Inspecting Control Solenoid Valve Assembly Contact Gap
Courtesy of GENERAL MOTORS COMPANY

Control Solenoid Valve Assembly Contact Gap Inspection

Callout	Component Name
1	Control Solenoid (w/Body and TCM) Valve Assembly **NOTE:**

cardiagn.com

Callout	Component Name
	Inspect the contact area between the "heat sink" area of the control solenoid valve assembly and the valve body. There should be no visible gap. If a gap exists, loosen all 18 bolts and retighten in the required sequence.

Input and Output Speed Sensor Assembly Installation




Fig. 69: Input and Output Speed Sensor Assembly
Courtesy of GENERAL MOTORS COMPANY

cardiagn.com

Input and Output Speed Sensor Assembly Installation

Callout	Component Name
1	A/Trans Input and Output Speed Sensor Wiring Harness Clip (Qty: 2)
2	A/Trans Input and Output Speed Sensor Assembly
3	Bolt M6 x 20 (Qty: 2) **CAUTION:** **Refer to** **Fastener Caution** . **Tighten** 12 N.m (106 lb in)

CENTER SUPPORT, OUTPUT CARRIER AND OUTPUT SHAFT INSTALLATION (6L80/6L90)




Fig. 70: Center Support, Output Carrier and Output Shaft
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Shaft Thrust Bearing Assembly
2	Output Carrier Assembly and Output Shaft Assembly **CAUTION:**

cardiagn.com

Callout	Component Name
	Apply automatic transmission fluid (ATF) to the inside diameter of the output shaft seal before installing the output shaft assembly into the case. Failure to lube the seal may cause the seal to roll during output shaft installation, which will result in transmission damage. CAUTION: Ensure the DT 47786 is completely threaded into the output shaft assembly. Due to the weight of the assembly, incomplete threading may cause the assembly to break free from the DT 47786, causing component damage.

cardiagn.com

Callout	Component Name
	Special Tools **DT 47786** Output Carrier/Shaft Lifting Tool
3	Center Support Assembly **NOTE:** • **When the center support assembly is properly installed, the fluid passages should align with the fluid passage seal bores in the case assembly.** • **It may be necessary to rotate the output shaft by hand in order to fully install the center support assembly.**
4	Center Support Retaining Ring **WARNING:** **Use care when removing or installing the retaining ring. Ensure the J 45126 and DT 47773 are**

cardiagn.com

Callout	Component Name
	installed properly onto the retaining ring or bodily injury may occur. **CAUTION:** **Ensure the retaining ring is installed with the tapered side up, and in the 9 o'clock position from the pan side of the case. Failure to properly install the retaining ring will cause transmission damage.** **Special Tools** • **DT 47773** Snap Ring Pliers Adapter Set • **J 45126** Snap Ring Pliers

1-2-3-4 AND 3-5 REVERSE CLUTCH ASSEMBLY AND 4-5-6 CLUTCH ASSEMBLY INSTALLATION (6L80/6L90)

cardiagn.com




Fig. 71: 1-2-3-4 And 3-5 Reverse Clutch Assembly And 4-5-6 Clutch Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	2-6 and 3-5 Reverse Clutch Hub Thrust Bearing Assembly
2	2-6 and 3-5 Reverse Clutch (with Output Carrier Outer Sun Gear Shaft) Hub Assembly
3	1-2-3-4 Clutch Hub Thrust Bearing Assembly
4	1-2-3-4 Clutch (with Output Carrier Inner Sun Gear Shaft) Hub Assembly
5	4-5-6 Clutch Hub Thrust Bearing Assembly
6	4-5-6 Clutch (with Output Carrier Shaft and Dampener) Hub Assembly **NOTE:** **Refer to 4-5-6 Clutch Dampener Overhaul (6L50/80/90) for complete inspection.**
7	Turbine Shaft Thrust Bearing Assembly
8	4-5-6 (with Turbine Shaft) Clutch Assembly
9	Input Sun Gear Thrust Bearing **NOTE:**

cardiagn.com

Callout	Component Name
	Thrust bearing snaps onto input carrier assembly.
10	Input Sun Gear Thrust Washer
11	Input Carrier Assembly **NOTE:** **The spline on the input carrier installs up into the 1-2-3-4 and 3-5 reverse clutch housing.**
12	Input Sun Gear
13	1-2-3-4 and 3-5 Reverse Clutch Assembly **NOTE:** **Wiggle the DT 47781 clutch assembly installer in order to align the 1-2-3-4 and 3-5 reverse clutch plates with the external splines of the 4-5-6 clutch assembly. To verify that the 1-2-3-4 and 3-5 reverse clutch assembly is fully installed, lift up on the turbine**

cardiagn.com

Callout	Component Name
	shaft. There should not be any noticeable slack. **Special Tool** **DT 47781** C1234 35R Clutch Assembly Installer For equivalent regional tools, refer to **Special Tools** .

TORQUE CONVERTER HOUSING WITH FLUID PUMP INSTALLATION




Fig. 72: Torque Converter Housing & Fluid Pump
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	NEW Fluid Pump Seal
2	Torque Converter (with Fluid Pump) Housing Assembly **CAUTION:** **Ensure the turbine shaft (O-ring) seal is not installed**

cardiagn.com

Callout	Component Name
	prior to installing the torque converter housing assembly. The seal may become cut or damaged during installation of the torque converter housing assembly.
3	Bolts M10 x 50 (Qty: 9) **CAUTION:** **Refer to Fastener Caution .** **Procedure** Tighten in the sequence shown. **Tighten** 72 N.m (53 lb ft)
4	NEW Turbine Shaft (O-Ring) Seal

PROPELLER SHAFT FRONT SLIP YOKE OIL SEAL REPLACEMENT

cardiagn.com




Fig. 73: Propeller Shaft Front Slip Yoke Oil Seal
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Output Shaft Seal Assembly **Special Tools** • **DT-48021** Seal Installer (6L90) • **J 8092** Driver Handle (6L90) • **J 38869** Output Shaft Seal Installer (6L80) • **J 45000** Seal Remover

CONTROL VALVE BODY ASSEMBLY INSTALLATION

cardiagn.com




Fig. 74: Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	NEW Fluid Pump Seal Assembly
2	NEW Fluid Pump Seal Assembly
3	NEW Center Support Fluid Passage Seal Assembly **NOTE:** **There are two different designs for the Center Support Fluid Passage Seal. The design for 6L45/50 (MYA/MYB) models**

cardiagn.com

Callout	Component Name
	utilizes tabs. The design for 6L80/90 (MYC/MYD) models does not have tabs.
4	Control Valve Body Assembly **CAUTION:** **The control valve body assembly needs to be lowered into place vertically, with no lateral movement. Lateral movement can damage the pass through connector pins and/or the oil transfer seals.** **NOTE:** **Align the manual shift shaft position switch activator slide with the detent lever guide pin.**

cardiagn.com

Callout	Component Name
5	Bolts M5 x 73 (Qty: 6) **CAUTION:** **Refer to** **Fastener Caution** . **Procedure** Tighten in the sequence shown. **Tighten** 8 N.m (71 lb in). **Special Tool** **DT-48285** Valve Body Torx Plus Socket (if applicable) For equivalent regional tools, refer to **Special Tools** .

AUTOMATIC TRANSMISSION ELECTRICAL CONNECTOR PASSAGE SLEEVE INSTALLATION





Fig. 75: Automatic Transmission Electrical Connector Passage Sleeve
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	NEW Automatic Transmission Wiring Connector Seal
2	NEW Automatic Transmission Wiring Connector Seal - O-Ring (Qty: 2)
3	Electrical Connector Passage Sleeve

cardiagn.com

Callout	Component Name
	CAUTION: Orientate the alignment tab inside the passage sleeve with the slot in the electrical connector of the control solenoid valve assembly. Push the sleeve into the bore and the electrical connector. Do NOT overtighten the latch to prevent damage to the connector. Ensure that the latch is fully seated into the case. When a fluid leak
4	Specification 14.16 mm Special Tools • DT 47715 Electrical Connector Passage Sleeve Remover/Installer • FN 42183 Driver Handle For equivalent regional tools, refer to **Special Tools** . Electrical Connector Slide Lock **NOTE:** Push down on the electrical connector slide lock to release at any time. Ensure that the latch is fully seated into the case. When

FLUID FILTER AND MANUAL SHIFT DETENT ASSEMBLY INSTALLATION



cardiagn.com

Fig. 76: Fluid Filter And Manual Shift Detent Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Manual Shaft Detent Spring **CAUTION:** **Ensure the manual shaft detent assembly roller is centered over the manual shaft detent lever assembly. Failure to center the roller may cause hard or no shift lever operation.**
2	Manual Shaft Detent Spring Bolt M6 x 14.5 **CAUTION:** **Refer to Fastener Caution .** **Tighten** 12 N.m (106 lb in).
3	Fluid Filter Seal **NOTE:** **Install a NEW seal.** **Special Tools** • **DT 47848** Seal Installer • **EN 42183** Driver Handle For equivalent regional tools, refer to **Special Tools** .
4	Fluid Filter

cardiagn.com

Callout	Component Name
	NOTE: Install a NEW filter.

TRANSMISSION FLUID PAN INSTALLATION




Fig. 77: Transmission Fluid Pan And Bolt Tightening Sequence
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Fluid Pan Gasket **NOTE:** **The fluid pan gasket is reusable. Inspect the gasket to determine if it may be reused. If the gasket is stuck to the case or pan, it should be replaced.**
2	Fluid Pan Assembly

cardiagn.com

Callout	Component Name
3	Fluid Pan Bolts M6 x 20 (Qty: 18) **CAUTION:** **Refer to Fastener Caution .** **Procedure** Tighten in sequence shown. **Tighten** 9 N.m (80 lb in)

PROPELLER SHAFT OIL SEAL SLEEVE INSTALLATION (2WD)




Fig. 78: Propeller Shaft Oil Seal Sleeve (2WD)
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
1	Propeller Shaft Oil Seal Sleeve **CAUTION:** **Do not attempt to remove or install the propeller**

cardiagn.com

Callout	Component Name
	shaft oil seal sleeve by striking or hitting the sleeve. Transmission internal bearing damage could result. **NOTE:** • Ensure the propeller shaft oil seal is in place inside the sleeve prior to installation. • Always install a NEW propeller shaft oil seal sleeve. The sleeve cannot be reused and must be replaced. • The DT-50802 threaded rods must be situated 180 degrees apart. • Use the M10 x 1.5 mm threaded rods for propeller shaft oil

cardiagn.com

Callout	Component Name
	seal sleeve installation. • The nut on GE-8433-1 should be tightened until DT-50802-1 bottoms out on the output shaft. **Special Tools** • **DT-50802** Threaded Rod Kit • **DT-50802-1** Sleeve Installer • **GE-8433-1** Puller Bar For equivalent regional tools, refer to **Special Tools** .

CASE EXTENSION ASSEMBLY INSTALLATION




Fig. 79: Case Extension Assembly & Bolt Tightening Sequence
Courtesy of GENERAL MOTORS COMPANY

cardiagn.com

Callout	Component Name
1	NEW Case Extension Seal
2	Case Extension
3	Bolts M10 x 40 (Qty: 6) **CAUTION:** **Refer to** **Fastener Caution** . **Procedure** Tighten in sequence shown. **Tighten** 55 N.m (41 lb ft)

TORQUE CONVERTER INSTALLATION AND HOLDING FIXTURE REMOVAL




Fig. 80: Torque Converter And Holding Fixture
Courtesy of GENERAL MOTORS COMPANY

Callout	Procedure
Preliminary Procedure Rotate the transmission so that the fluid pan assembly is down.	
1	Transmission Case Assembly **Special Tools**

cardiagn.com

Callout	Procedure
	• **DT 47605** Holding Fixture • **J 3289-20** Holding Fixture Base Assembly • **J 8763-B** Holding Fixture For equivalent regional tools, refer to **Special Tools** .
2	Torque Converter Assembly

Article GUID: A00854694

cardiagn.com

REPAIR INSTRUCTIONS - ON VEHICLE

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

CONNECTOR RECONNECTION - AUTOMATIC TRANSMISSION

Special Tools

EL-35616 Terminal Test Probe Kit

For equivalent regional tools, refer to **Special Tools** .

When the condition is not currently present, but is indicated in DTC history, the cause may be intermittent. An intermittent may also be the cause when there is a customer complaint, but the symptom cannot be duplicated. Refer to the Symptom Table of the system that is suspect of causing the condition before trying to locate an intermittent condition.

Most intermittent conditions are caused by faulty electrical connections or wiring. Inspect for the following items:

- Loose, corroded, or painted terminal stud/fastener
- Wiring broken inside the insulation
- Poor connection between the male and female terminal at a connector
- A terminal not seated all the way into the connector body
- Poor terminal to wire connection - Some conditions which fall under this description are poor crimps, poor solder joints, crimping over the wire insulation rather than the wire itself, and corrosion in the wire to terminal contact area, etc.
- Pierced or damaged insulation can allow moisture to enter the wiring causing corrosion. The conductor can corrode inside the insulation, with little visible evidence. Look for swollen and stiff sections of wire in the suspect circuits.
- Wiring which has been pinched, cut, or its insulation rubbed through may cause an intermittent open or short as the bare area touches other wiring or parts of the vehicle.
- Wiring that comes in contact with hot or exhaust components
- Refer to **Inducing Intermittent Fault Conditions** in order to duplicate the conditions required, in order to verify the customer concern.
- Refer to **Testing for Electrical Intermittents** for test procedures to detect intermittent open, high resistance, short to ground, and short to voltage conditions.
- Refer to **Scan Tool Snapshot Procedure** for advanced intermittent diagnosis and Vehicle Data Recorder

cardiagn.com

operation.

Testing for Terminal Fretting

Some intermittent conditions can be caused by wire terminal fretting corrosion. Fretting corrosion is a build-up of insulating, oxidized wear debris that can form when there is a small motion between electrical contacts. The oxidized wear debris can pile up enough at the electrical contact spots that the electrical resistance across the connection increases. Movement between the contacting surfaces as small as 10 to 100 microns can cause fretting. To put this in perspective, a sheet of paper is about 100 microns thick, so fretting motion is small and hard to see. Vibration and thermal expansion/contraction are the main sources that create fretting motion. Since vehicles vibrate and can experience large temperature swings, they are a good source for fretting motion. Tin, copper, nickel, and iron surfaces are all susceptible to fretting corrosion. Fretting corrosion can be difficult to see but it looks like small, dark smudges on the terminals contact surface.

To correct a fretting condition disconnect the suspect connector and add dielectric grease / lubricant (Nyogel 760G or equivalent, meeting GM specification 9986087) to both sides of the connector terminals. Then reconnect the connector and wipe away any excess lubricant. This will correct the additional terminal contact resistance due to the terminal fretting corrosion.

Testing for Proper Terminal Contact

It is important to test terminal contact at the component and any inline connectors before replacing a suspect component. Mating terminals must be inspected to ensure good terminal contact. A poor connection between the male and female terminal at a connector may be the result of contamination or deformation.

Contamination may be caused by the connector halves being improperly connected. A missing or damaged connector seal, damage to the connector itself, or exposing the terminals to moisture and dirt can also cause contamination. Contamination, usually in the underhood or underbody connectors, leads to terminal corrosion, causing an open circuit or intermittently open circuit.

Deformation is caused by probing the mating side of a connector terminal without the proper adapter. Always use the **EL-35616** kit when probing connectors. Other causes of terminal deformation are improperly joining the connector halves, or repeatedly separating and joining the connector halves. Deformation, usually to the female terminal contact tang, can result in poor terminal contact causing an open or intermittently open circuit.

cardiagn.com

Testing for Proper Terminal Contact in Bussed Electrical Centers

It is very important to use the correct test adapter when testing for proper terminal contact of fuses and relays in a bussed electrical center. Use the **EL-35616** kit to test for proper terminal contact. Failure to use the **EL-35616** kit can result in improper diagnosis of the bussed electrical center.

Follow the procedure below in order to test terminal contact:

1. Separate the connector halves.
2. Visually inspect the connector halves for contamination. Contamination may result in a white or green build-up within the connector body or between terminals. This causes high terminal resistance, intermittent contact, or an open circuit. An underhood or underbody connector that shows signs of contamination should be replaced in its entirety: terminals, seals, and connector body.
3. Using an equivalent male terminal/terminated lead, verify that the retention force is significantly different between a known good terminal and the suspect terminal. Replace the female terminal in question.

Flat Wire Connectors

There are no serviceable parts for flat wire connectors on the harness side or the component side.

Follow the procedure below in order to test terminal contact:

1. Remove the component in question.
2. Visually inspect each side of the connector for signs of contamination. Avoid touching either side of the connector as oil from your skin may be a source of contamination as well.
3. Visually inspect the terminal bearing surfaces of the flat wire circuits for splits, cracks, or other imperfections that could cause poor terminal contact. Visually inspect the component side connector to ensure that all of the terminals are uniform and free of damage or deformation.
4. Insert the appropriate adapter into the flat wire harness connector in order to test the circuit in question.

Control Module/Component Voltage and Grounds

Poor voltage or ground connections can cause widely varying symptoms.

- Test all control module voltage supply circuits. Many vehicles have multiple circuits supplying voltage to a control module. Other components in the system may have separate voltage supply circuits that may also need to be tested. Inspect connections at the module/component connectors, fuses, and any intermediate connections between the voltage source and the module/component. A test lamp or a DMM may indicate that voltage is present, but neither tests the ability of the circuit to carry sufficient current. Operate the component to test the ability of the circuit to carry sufficient current. Refer to **Circuit Testing** , and **Power Distribution Schematics (1500)** **Power Distribution Schematics (2500/3500)** .
- Test all control module ground and system ground circuits. The control module may have multiple ground circuits. Other components in the system may have separate grounds that may also need to be tested. Inspect grounds for clean and tight connections at the grounding point (screw or stud). Inspect the connections at the component and in splice packs, where applicable. Operate the component to test the ability of the circuit to carry sufficient current. Refer to **Circuit Testing** , and **Ground Distribution Schematics (1500)** **Ground Distribution Schematics (2500/3500)** .

Temperature Sensitivity

- An intermittent condition may occur when a component/connection reaches normal operating temperature. The condition may occur only when the component/connection is cold, or only when the component/connection is hot.
- Freeze Frame, Failure Records, Snapshot, or Vehicle Data Recorder data may help with this type of intermittent condition, where applicable.
- If the intermittent is related to heat, review the data for a relationship with the following:
  - High ambient temperatures
  - Underhood/engine generated heat
  - Circuit generated heat due to a poor connection, or high electrical load
  - Higher than normal load conditions, towing, etc.
- If the intermittent is related to cold, review the data for the following:
  - Low ambient temperatures - In extremely low temperatures, ice may form in a connection or component. Inspect for water intrusion.
  - The condition only occurs on a cold start.
  - The condition goes away when the vehicle warms up.
- Information from the customer may help to determine if the trouble follows a pattern that is temperature

cardiagn.com

related.

- If temperature is suspected of causing an intermittent fault condition, attempt to duplicate the condition. Refer to **Inducing Intermittent Fault Conditions** in order to duplicate the conditions required.

Electromagnetic Interference and Electrical Noise

Some electrical components/circuits are sensitive to electromagnetic interference or other types of electrical noise. Inspect for the following conditions:

- A mis-routed harness that is too close to high voltage/high current devices such as secondary ignition components, motors, generator etc. - These components may induce electrical noise on a circuit that could interfere with normal circuit operation.
- Electrical system interference caused by a malfunctioning relay, or a control module driven solenoid or switch - These conditions can cause a sharp electrical surge. Normally, the condition will occur when the malfunctioning component is operating.
- Installation of non-factory or aftermarket add on accessories such as lights, 2-way radios, amplifiers, electric motors, remote starters, alarm systems, cell phones, etc. - These accessories may create interference in other circuits while operating and the interference would disappear when the accessory is not operating. Refer to **Checking Aftermarket Accessories** .
- Test for an open diode across the A/C compressor clutch and for other open diodes. Some relays may contain a clamping diode.
- The generator may be allowing AC noise into the electrical system.

Incorrect Control Module

- There are only a few situations where reprogramming a control module is appropriate:
  - A new service control module is installed.
  - A control module from another vehicle is installed.
  - Revised software/calibration files have been released for this vehicle.

NOTE: **DO NOT re-program the control module with the SAME software/calibration files that are already present in the control module. This is not an effective repair for any type of concern.**

- Verify that the control module contains the correct software/calibration. If incorrect programming is found, reprogram the control module with the most current software/calibration. Refer to **Control Module References** for replacement, setup, and programming.

TRANSMISSION FLUID FILLER TUBE AND SEAL REPLACEMENT

Removal Procedure

cardiagn.com




Fig. 1: Removing The Transmission Oil Level Indicator
Courtesy of GENERAL MOTORS COMPANY

1. Unlock the transmission oil level indicator.
2. Remove the transmission oil level indicator.

NOTE: **Tie the engine wiring harness, between the oil level indicator tube and engine, to the engine, so when installing the new oil level indicator tube the harness will not get caught on the oil level indicator tube.**

3. Raise the vehicle.
4. Support the transmission with a suitable jack.
5. Remove the transmission crossmember. Refer to **Transmission Support Crossmember Replacement (2WD - Light Duty)** **Transmission Support Crossmember Replacement (2WD - Heavy Duty)** **Transmission Support Crossmember Replacement (4WD - Light Duty)** **Transmission Support Crossmember Replacement (4WD - Heavy Duty)** .
6. Remove the transmission oil level indicator tube bracket nut.
7. Remove the exhaust heat shield from the transmission. Refer to **Transmission Heat Shield Replacement**.
8. Lower rear of transmission to allow for clearance to remove transmission oil level indicator tube.

cardiagn.com

9. Remove the transmission oil level indicator tube from the transmission.
10. Raise rear of transmission to allow for clearance to remove transmission oil level indicator tube from vehicle.




Fig. 2: View Of Oil Level Indicator Tube & Transmission Seal
Courtesy of GENERAL MOTORS COMPANY

11. Remove the oil level indicator tube (1) and seal (2) assembly.
12. Remove the seal (2) from the oil level indicator tube (1).

Installation Procedure

cardiagn.com




Fig. 3: View Of Oil Level Indicator Tube & Transmission Seal
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Lightly oil the seal to aid in the installation into the transmission case.**

1. Install a seal (2) to the indicator tube (1).
2. Install the oil level indicator tube (1) and seal (2) assembly.
3. Lower rear of transmission to allow for clearance to install transmission oil level indicator tube into the transmission.
4. Seat the oil level indicator tube seal into the transmission, then seat the oil level indicator tube.

CAUTION: **Refer to Fastener Caution .**

5. While holding the oil level indicator tube down into the transmission, Install transmission oil level indicator tube bracket nut. Tighten the nut to 18 N.m (13 lb ft).
6. Install the exhaust heat shield to the transmission. Refer to **Transmission Heat Shield Replacement**.
7. Raise rear of transmission to install transmission crossmember.
8. Install the transmission crossmember. Refer to **Transmission Support Crossmember Replacement (2WD - Light Duty)** **Transmission Support Crossmember Replacement (2WD - Heavy Duty)**

cardiagn.com

Transmission Support Crossmember Replacement (4WD - Light Duty) Transmission Support Crossmember Replacement (4WD - Heavy Duty) .

9. Remove the jack.
10. Lower the vehicle.




Fig. 4: Removing The Transmission Oil Level Indicator
Courtesy of GENERAL MOTORS COMPANY

11. Install the transmission oil level indicator.
12. Lock the transmission oil level indicator.

RANGE SELECTOR LEVER CABLE REPLACEMENT

Removal Procedure

cardiagn.com




Fig. 5: View Of Steering Cable Retainer On Steering Column
Courtesy of GENERAL MOTORS COMPANY

WARNING: **The automatic transaxle range selector cable is made out of two cable sections. After initial connection never separate the two metal couplings from one another. Integrity of the connection of the two metal couplings will be lost if separation of the two metal couplings occurs. When servicing the transaxle remove the cable at the automatic transaxle range selector lever and at the automatic transaxle range selector cable bracket. If either section of the cable needs to be replaced, replace both of the cable sections. Loss of connection integrity of the two metal couplings can cause loss of transaxle shift control which could result in personal injury.**

1. Position the steering column shift lever to the park position.
2. Remove the instrument panel knee bolster. **Instrument Panel Knee Bolster Replacement** .
3. Remove the left front side door sill garnish molding. **Front Side Door Sill Garnish Molding Replacement (Crew Cab, Extended Cab)** **Front Side Door Sill Garnish Molding Replacement (Regular Cab)** .
4. Pull back the carpet and insulation around the driver area.

cardiagn.com

5. Remove the retainer securing the cable to the steering column.




Fig. 6: View Of Cable, Steering Column Ball Stud & Steering Column Bracket
Courtesy of GENERAL MOTORS COMPANY

6. Remove the cable end from the steering column ball stud.
7. Depress the tangs and remove the cable from the steering column bracket.

cardiagn.com




Fig. 7: View Of Range Selector Cable
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Avoid unnecessary twisting/bending of the range selector cable when removing the cable from the support.**

8. Remove the range selector cable from the support.

cardiagn.com




Fig. 8: Removing The Cable Grommet From The Floor Panel
Courtesy of GENERAL MOTORS COMPANY

9. Remove the cable grommet from the floor panel.
10. Raise and suitably support the vehicle. **Lifting and Jacking the Vehicle** .

cardiagn.com




Fig. 9: Removing The Cable Clips From The Floor Panel Reinforcement
Courtesy of GENERAL MOTORS COMPANY

11. Remove the clips on the cable from the floor panel reinforcement.
12. Ensure the transmission manual shaft is positioned in mechanical park.
13. Remove the cable clip on the transfer case, if equipped.

cardiagn.com




Fig. 10: Range Selector Cable And Retainer
Courtesy of GENERAL MOTORS COMPANY

NOTE: **DO NOT pry the cable end from the lever ball stud. Replacement of the range selector cable requires a NEW control lever.**

14. Remove the range selector cable (2) and the transmission range selector lever as an assembly.
15. Remove the retainer (1) that secures the cable to the bracket.
16. Depress the tangs and remove the cable from the bracket.
17. Remove the transmission range selector cable from the vehicle.

Installation Procedure

1. Install the transmission range selector cable to the vehicle.




Fig. 11: Range Selector Cable And Retainer
Courtesy of GENERAL MOTORS COMPANY

2. Ensure that the transmission manual shaft lever is in the mechanical park position.

cardiagn.com

3. Align and install the range selector cable (2) to the bracket.
4. Install the retainer (1) that secures the cable to the bracket.
5. Install the NEW range selector lever to the transmission. **Automatic Transmission Range Selector Lever Replacement**

WARNING: After installing the transmission range selector shift cable, pull up and push down on ALL connections to verify that the connections are fully seated and properly engaged. Failure to perform this task can result in the vehicle not being able to shift into PARK causing potential vehicle damage and bodily injury.

6. Install the range selector cable end to the transmission range selector lever ball stud.
7. Install the cable clip on the transfer case, if equipped.




Fig. 12: Removing The Cable Clips From The Floor Panel Reinforcement
Courtesy of GENERAL MOTORS COMPANY

8. Install the clips on the cable to the floor panel reinforcement.
9. Lower the vehicle and ensure that the steering column shift lever is still in the park position.

cardiagn.com




Fig. 13: Removing The Cable Grommet From The Floor Panel
Courtesy of GENERAL MOTORS COMPANY

10. Install the cable grommet to the floor panel.

cardiagn.com




Fig. 14: View Of Range Selector Cable
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Avoid unnecessary twisting/bending of the range selector cable when installing the cable to the support.**

11. Install the range selector cable to the support.

cardiagn.com




Fig. 15: View Of Cable, Steering Column Ball Stud & Steering Column Bracket
Courtesy of GENERAL MOTORS COMPANY

12. Install the cable to the steering column bracket.
13. Ensure the tangs fully engage into the steering column bracket.
14. Install the cable end to the steering column ball stud.

cardiagn.com




Fig. 16: View Of Steering Cable Retainer On Steering Column
Courtesy of GENERAL MOTORS COMPANY

15. Install the retainer securing the cable to the steering column.
16. Position the carpet and insulation around the driver area.
17. Install the left front side door sill garnish molding. **Front Side Door Sill Garnish Molding Replacement (Crew Cab, Extended Cab)** **Front Side Door Sill Garnish Molding Replacement (Regular Cab)** .
18. Install the instrument panel knee bolster. **Instrument Panel Knee Bolster Replacement** .
19. Test the transmission for proper shift operation.
20. If all of the gear positions cannot be achieved, adjust the cable. **Range Selector Lever Cable Adjustment**.

RANGE SELECTOR LEVER CABLE ADJUSTMENT

cardiagn.com




Fig. 17: Aligning The Outside Diameter Of The Transmission End With The Inside Diameter Of The Shifter End
Courtesy of GENERAL MOTORS COMPANY

1. Ensure that the steering column shift lever is in the park (P) position.
2. Raise and suitably support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
3. Ensure that the transmission manual shaft lever is in the park (P) position.
4. Grasp the shift cable shifter end (1) in the left hand and the shift cable transmission end (2) in the right hand.
5. Align the outside diameter of the transmission end (2) with the inside diameter of the shifter end (1).

cardiagn.com




Fig. 18: Engaging The Inner Wire And Lock Both Wires Together
Courtesy of GENERAL MOTORS COMPANY

6. Push the end of the transmission cable (3) inside the shifter end until the blue spring (2) on the transmission end (3) is fully compressed, this will engage the inner wire and lock both wires together.

cardiagn.com




Fig. 19: Tension/Adjust The Cable System
Courtesy of GENERAL MOTORS COMPANY

NOTE: **DO NOT hold the transmission end (1) during this operation, this will result in a mis-adjusted cable.**

7. Release the transmission end (3) and allow the spring (2) to tension/adjust the cable system.
8. Pull the white cover (5) on the shifter end (1) back.
9. Push the natural colored lock button (4) down to engage the locking teeth on the transmission end (3).

cardiagn.com




Fig. 20: View Of White Cover & Natural Colored Lock
Courtesy of GENERAL MOTORS COMPANY

10. Release the white cover (1).
11. Verify the white cover (1) conceals the natural colored lock (2).
12. If the white cover (1) does not conceal the natural colored lock (2), the shift cable must be re-adjusted. Refer to cable re-adjustment below.
13. Lower the vehicle.
14. Test the transmission for proper shift operation.
15. If all of the gear positions cannot be achieved, the shift cable must be re-adjusted. Refer to cable re-adjustment below.

Cable Re-Adjustment

cardiagn.com




Fig. 21: View Of White Cover & Natural Colored Lock
Courtesy of GENERAL MOTORS COMPANY

1. Place the steering column shift lever back into the park (P) position.
2. Raise the vehicle.
3. Ensure that the transmission manual shaft lever is in the park (P) position.
4. Pull the white cover (1) back to expose the natural colored lock (2). Under the lock (2), insert a flat-bladed screwdriver under the lock ramp located at the top of the lock. The lock will pop up, and the transmission end will move slightly away from the shifter end.

cardiagn.com




Fig. 22: Engaging The Inner Wire And Lock Both Wires Together
Courtesy of GENERAL MOTORS COMPANY

5. Push the end of the transmission end (3) inside the shifter end (1) until the blue spring (2) on the transmission end (3) is fully compressed, this will engage the inner wire and lock both wires together.

cardiagn.com




Fig. 23: Tension/Adjust The Cable System
Courtesy of GENERAL MOTORS COMPANY

NOTE: **DO NOT hold the transmission end (1) during this operation, this will result in a mis-adjusted cable.**

6. Release the transmission end (3) and allow the spring (2) to tension/adjust the cable system.
7. Pull the white cover (5) on the shifter end (1) back.
8. Push the natural colored lock button (4) down to engage the locking teeth on the transmission end (3).

cardiagn.com




Fig. 24: View Of White Cover & Natural Colored Lock
Courtesy of GENERAL MOTORS COMPANY

9. Release the white cover (1).
10. Verify the white cover (1) conceals the natural colored lock (2).

RANGE SELECTOR LEVER CABLE BRACKET REPLACEMENT

cardiagn.com




Fig. 25: View Of Transmission Range Selector Cable Bracket & Bolts
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Apply the park brake. 2. Shift the transmission into neutral. 3. Raise the vehicle. Refer to **Lifting and Jacking the Vehicle** . 4. Remove the transmission range selector cable from the range selector cable bracket. Refer to **Range Selector Lever Cable Replacement**.	
1	Transmission Range Selector Cable Bracket Bolt (Qty: 2) **CAUTION:** **Refer to Fastener Caution** . **Tighten** 22 N.m (16 lb ft)
2	Transmission Range Selector Cable Bracket

AUTOMATIC TRANSMISSION RANGE SELECTOR LEVER REPLACEMENT

cardiagn.com




Fig. 26: Automatic Transmission Range Selector Lever
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name

Preliminary Procedures

1. Apply the park brake.
2. Shift the transmission into neutral.
3. Raise the vehicle. **Lifting and Jacking the Vehicle** .

WARNING:
After installing the transmission range selector shift cable, pull up and push down on ALL connections to verify that the connections are fully seated and properly

cardiagn.com

Callout	Component Name
	engaged. Failure to perform this task can result in the vehicle not being able to shift into PARK causing potential vehicle damage and bodily injury. **NOTE:** **DO NOT pry the cable end from the lever ball stud. Replacement of the range selector lever requires a NEW cable assembly.** 4. Remove the transmission range selector cable and the range selector lever as a assembly by removing the lever nut.
1	Transmission Range Selector Cable Lever Nut **WARNING:** **Hold the transmission range selector lever while removing or installing the lever retaining nut. Failure to hold the lever can cause damage to**

cardiagn.com

Callout	Component Name
	the transmission internal park system components which could allow the vehicle to roll when placed in the park position. **CAUTION:** Refer to Fastener Caution . **Tighten** 25 N.m (18 lb ft)
2	Transmission Range Selector Cable Lever and Cable Assembly

TRANSMISSION HEAT SHIELD REPLACEMENT




Fig. 27: View Of Transmission Heat Shield & Bolts
Courtesy of GENERAL MOTORS COMPANY


cardiagn.com

Callout	Component Name
Preliminary Procedures Raise the vehicle. Refer to **Lifting and Jacking the Vehicle** .	
1	Transmission Heat Shield Bolt (Qty: 2) **CAUTION:** **Refer to** **Fastener Caution** . **Tighten** 17 N.m (13 lb ft)
2	Transmission Heat Shield

AUTOMATIC TRANSMISSION FLUID PRESSURE TEST HOLE PLUG REPLACEMENT

Removal Procedure

1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** .



cardiagn.com

Fig. 28: View Of Oil Pressure Test Plug
Courtesy of GENERAL MOTORS COMPANY

2. Clean the surrounding area of the oil pressure test plug.
3. Remove the oil pressure test plug.

Installation Procedure




Fig. 29: View Of Oil Pressure Test Plug
Courtesy of GENERAL MOTORS COMPANY

CAUTION: Refer to Fastener Caution .

1. Install the oil pressure test plug and tighten to 11 N.m (97 lb in).
2. Check the transmission fluid level (fill if necessary). Refer to **Transmission Fluid Level and Condition Check** .
3. Lower the vehicle.

AUTOMATIC TRANSMISSION ELECTRICAL CONNECTOR PASSAGE SLEEVE REPLACEMENT

cardiagn.com




Fig. 30: Automatic Transmission Electrical Connector Passage Sleeve Component View
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: Orientate the alignment tab inside the passage sleeve with the slot in the electrical connector of the control solenoid valve assembly. Push the sleeve straight into the case bore and connector. Do NOT rotate the sleeve at any time. Ensure the sleeve is	

cardiagn.com

Callout	Component Name
fully seated into the case. When the sleeve is properly installed, the distance from the case surface to the end of the sleeve should be 14-16 mm. Even though the correct electrical connections may still be maintained, failure to ensure proper installation of the sleeve may result in a fluid leak around the sleeve lip seal and into the sleeve cavity. **Preliminary Procedures** 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Remove the transmission oil pan. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**. 3. Remove the transmission heat shield. Refer to **Transmission Heat Shield Replacement**. 4. Disconnect the vehicle wire harness electrical connector from the transmission electrical connector passage sleeve.	
1	Electrical Connector Slide Lock **NOTE:** **Pull down on the slide lock to remove the**

cardiagn.com

Callout	Component Name
	sleeve. Push up on the slide lock after sleeve installation.
2	Electrical Connector Passage Sleeve **NOTE:** • **Use the DT-47715 electrical connector passage sleeve remover/installer and J-42183 driver handle to remove and install the electrical connector passage sleeve.** • **The distance (a) from the case surface to the end of the sleeve should be 14-16 mm.** **Special Tools** • **DT-47715** Electrical Connector Passage Sleeve Remover/Installer • **J-42183** Driver Handle Equivalent regional tools:**Special Tools**
3	O-Ring Seal (Qty: 2) **NOTE:** **Use a NEW O-ring seal.**
4	Lip Seal **NOTE:** **Use a NEW lip seal.**

cardiagn.com

AUTOMATIC TRANSMISSION FLUID, FLUID PAN AND/OR FILTER REPLACEMENT




Fig. 31: Fluid, Fluid Pan and/or Filter Component View
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
CAUTION: Use DexronÂ® VI transmission fluid only. Failure to use the proper fluid may result in transmission internal damage.	
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Disconnect and lower the three-way catalytic converter. Refer to **Three-Way Catalytic Converter Replacement (LC8, L96)** **Three-Way Catalytic Converter Replacement (LV3, L83, L8B, or L86)** . 3. Place a suitable drain pan under the transmission.	

cardiagn.com

Callout	Component Name
1	Transmission Fluid Pan Bolt (Qty: 18) **CAUTION:** **Refer to Fastener Caution .** **Procedure** Tighten the bolts in the sequence shown. **Tighten** 9 N.m (80 lb in)
2	Transmission Fluid Pan Assembly **Procedure** 1. Check the condition of the draining fluid. Refer to **Transmission Fluid Level and Condition Check** . 2. Fill the transmission with the proper fluid. Refer to **Transmission General Specifications** . 3. Fill the transmission with the proper amount of transmission fluid. Refer to **Approximate Fluid Capacities** , and **Transmission Fluid Level and Condition Check** .
3	Transmission Fluid Pan Gasket **Procedure** The fluid pan gasket is reusable. Inspect the gasket to determine if it may be reused.
4	NEW Fluid Filter Assembly **Procedure** Pull the fluid filter assembly straight out. Do not bend or twist the filter neck.
5	NEW Fluid Filter Seal Assembly **CAUTION:** **Do not damage the case sealing surface when removing the filter seal assembly.** **Procedure** 1. Use a screwdriver or snap ring pliers to remove the filter seal. 2. Use the **DT 47848** seal installer and the **J 42183** driver handle to install the filter seal. 3. Lubricate the filter seal with transmission fluid before installing the filter.

cardiagn.com

Callout	Component Name
	Special Tools • **DT 47848** Seal Installer • **J 42183** Driver Handle Driver Handle For equivalent regional tools, refer to **Special Tools** .

TRANSMISSION MOUNT INSPECTION

CAUTION: To prevent transmission oil pan damage and possible transmission failure, insert a block of wood that completely covers the bottom of the transmission oil pan surface, between the transmission oil pan and the jack support. If the inserted block of wood does not completely cover the bottom of the transmission oil pan, this may result in damage to the transmission oil pan and possible transmission failure.

1. Raise the transmission in order to remove the weight from the transmission mount and create slight tension in the rubber.
2. Observe the transmission mount while raising the transmission. Replace the transmission/transaxle mount if the transmission mount exhibits any of the following conditions:

   NOTE: Black paint on the rubber will crack with time, this does no constitute a failure.

   - The hard rubber surface is covered with heat check cracks.
   - The rubber is separated from the metal plate of the transmission mount.
   - The rubber is split through the center of the transmission mount.
3. If there is movement between the metal plate of the transmission mount and its attaching points, lower the transmission on the transmission mount. Tighten the bolts or nuts attaching the transmission mount to the frame or transmission mount bracket.

TRANSMISSION MOUNT REPLACEMENT (TWO WHEEL DRIVE)

cardiagn.com




Fig. 32: View Of Transmission Mount, Crossmember Nut & Bolts
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Support the transmission with a transmission jack.	
1	Transmission Mount to Crossmember Nut **CAUTION:** **Refer to** **Fastener Caution** . **Tighten** • For light duty, 55 N.m (40 lb ft) • For heavy duty, 107 N.m (79 lb ft)
2	Transmission Mount Bolt (Qty: 2) **Tighten** 67 N.m (50 lb ft)
3	Transmission Mount **Procedure** Raise the transmission with the transmission jack just enough to remove the transmission

cardiagn.com

Callout	Component Name
	mount.

TRANSMISSION MOUNT REPLACEMENT (FOUR WHEEL DRIVE)




Fig. 33: View Of Transmission Mount, Crossmember Nut & Bolts
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Support the transmission with a transmission jack.	
1	Transmission Mount to Crossmember Nut (Qty: 2) **CAUTION:** **Refer to** **Fastener** **Caution** . **Tighten** • For light duty, 55 N.m (40 lb ft) • For heavy duty, 107 N.m (79 lb ft)

cardiagn.com

Callout	Component Name
2	NEW Transmission Mount Bolt (Qty: 2) **CAUTION:** **This vehicle is equipped with torque-to-yield or single use fasteners. Install a NEW torque-to-yield or single use fastener when installing this component. Failure to replace the torque-to-yield or single use fastener could cause damage to the vehicle or component.** **Tighten** • 45 N.m (33 lb ft) • Plus 50 degrees
3	Transmission Mount **Procedure** Raise the transmission with the transmission jack just enough to remove the transmission mount.

CASE EXTENSION AND GASKET REPLACEMENT

cardiagn.com




Fig. 34: Case Extension Housing And Seal
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
NOTE: **The extension housing and drive shaft flange (yoke) on this vehicle are serviced as a complete assembly. The drive shaft flange seal is a dust shield used to protect the sealed drive shaft flange bearing that is pressed into the extension housing. The drive shaft**	

cardiagn.com

Callout	Component Name
flange is pressed into the drive shaft flange bearing, and is not serviceable. The extension housing should NOT contain any transmission fluid. If transmission fluid is present in the extension housing, replacement of the output shaft seal is necessary. Refer to Transmission Output Shaft Seal Replacement (Four Wheel Drive).	
	Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Remove the propeller shaft. Refer to **One-Piece Propeller Shaft Replacement** , or **Two-Piece Propeller Shaft Replacement (MYC, M5U, MSX)** **Two-Piece Propeller Shaft Replacement (MW7)** . 3. Support the transmission with a suitable jack. 4. Remove the transmission mount assembly. Refer to **Transmission Mount Replacement (Two Wheel Drive)** **Transmission Mount Replacement (Four Wheel Drive)**.
1	Case Extension Housing Bolt (Qty: 6) **CAUTION:** Refer to Fastener Caution .

cardiagn.com

Callout	Component Name
	Tighten 55 N.m (41 lb ft)
2	Case Extension Housing Assembly **NOTE:** • **Serviced as a complete assembly as shown.** • **There is no gasket or seal between the extension housing and transmission case.**

TRANSMISSION OUTPUT SHAFT SEAL REPLACEMENT (FOUR WHEEL DRIVE)





Fig. 35: Transmission Output Shaft Seal Replacement
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure	

cardiagn.com

Callout	Component Name
Remove the transfer adapter from the transmission. Refer to the appropriate procedure: • **Transfer Case Adapter Replacement (Heavy Duty)** **Transfer Case Adapter Replacement (Light Duty)** for the MP 1222/1225/1226-NQG transfer case • **Transfer Case Adapter Replacement (With Allison Transmission)** **Transfer Case Adapter Replacement (Except Allison Transmission)** for the MP 1625/1626-NQF transfer case • **Transfer Case Adapter Replacement** for the MP 3023/3024-NQH transfer case	
1	Output Shaft Seal **Procedure** 1. Use the **J-6125-B** hammer and **J-36825-A** remover to remove the seal. Use care in order to avoid damaging the output shaft bushing. 2. Lubricate the seal with clean transmission fluid. 3. Use the **DT-50648** installer to install the seal. **Special Tools** • **DT-50648** Case Seal Installer • **J-6125-B** Slide Hammer with Adaptor • **J-36825-A** Output Shaft Oil Seal Remover For equivalent regional tools, refer to **Special Tools** .

PROPELLER SHAFT FRONT SLIP YOKE OIL SEAL REPLACEMENT (TWO WHEEL DRIVE)



cardiagn.com

Fig. 36: View Of Output Shaft Seal Assembly
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Remove the propeller shaft. Refer to **One-Piece Propeller Shaft Replacement** , or **Two-Piece Propeller Shaft Replacement (MYC, M5U, MSX)** **Two-Piece Propeller Shaft Replacement (MW7)** .	
1	Propeller Shaft Front Slip Yoke Oil Seal **Special Tools** • **DT-48021** Seal Installer (6L90) • **J 8092** Driver Handle (6L90) • **J 38869** Output Shaft Seal Installer (6L80) • **J 45000** Seal Remover For equivalent regional tools, refer to **Special Tools** .

MANUAL SHIFT SHAFT AND SEAL REPLACEMENT




Fig. 37: Manual Shift Shaft & Seal
Courtesy of GENERAL MOTORS COMPANY

cardiagn.com

Callout	Component Name
Preliminary Procedures 1. Remove the automatic transmission range select lever. Refer to **Automatic Transmission Range Selector Lever Replacement**. 2. If equipped with four wheel drive, remove the front propeller shaft. Refer to **Front Axle Propeller Shaft Replacement** . 3. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 4. Remove the transmission fluid pan. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**. 5. Remove the control valve body. Refer to **Control Valve Lower Body and Upper Body Replacement**.	
1	Manual Shift Shaft Pin **Procedure** 1. Discard the pin. Replace with NEW pin. 2. "Walk" the pin out using side cutters.
2	Manual Shaft Detent Lever Hub Pin **Procedure** 1. Discard the pin. Replace with NEW pin. 2. "Walk" the pin out using side cutters.
3	Manual Shift Shaft **NOTE:** **The manual shaft must be removed to replace the manual shaft seal.**
4	Manual Shift Shaft Seal **Procedure** 1. Use the **J-45201** cooler line seal remover to remove the seal from the transmission case. 2. Use the **DT-47770** seal installer to install the seal into the transmission case. **Special Tools** • **DT-47770** Seal Installer • **J-45201** Cooler Line Seal Remover

cardiagn.com

Callout	Component Name
	For equivalent regional tools, refer to **Special Tools** .

MANUAL SHIFT DETENT LEVER AND PARK PAWL ACTUATOR REPLACEMENT





Fig. 38: Manual Shift Detent Lever And Park Pawl Actuator
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Remove the automatic transmission range select lever. Refer to **Automatic Transmission Range Selector Lever Replacement**. 2. Remove the valve body. Refer to **Control Valve Lower Body and Upper Body Replacement**.	
1	Manual Shaft Detent Lever Hub Pin **NOTE:** • **Discard the pin. Replace with NEW pin.** • **"Walk" the pin**

cardiagn.com

Callout	Component Name
	out using side cutters.
2	Manual Shift Shaft Pin **NOTE:** • **Discard the pin. Replace with NEW pin.** • **"Walk" the pin out using side cutters.**
3	Manual Shift Shaft
4	Manual Shaft Detent Lever Assembly
5	Park Pawl Actuator Assembly

MANUAL SHIFT SHAFT POSITION SWITCH REPLACEMENT



cardiagn.com

Fig. 39: Manual Shift Shaft Position Switch Component View
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Remove the transmission fluid pan and filter. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**.	
1	Manual Shift Shaft Position Switch Assembly Electrical Connector **NOTE:** • **Release the connector lock before disconnecting. Engage the connector lock after connecting.** • **The wiring harness clip near the connector does not need to be replaced if broken or missing. The clip is used during manufacturing to keep the wire harness clear during an automated bolt installation process. If the clip is damaged, simply remove and discard.**
2	Manual Shift Shaft Position Switch Assembly Bolts **CAUTION:** **Refer to Fastener**

cardiagn.com

Callout	Component Name
	Caution . **Tighten** 12 N.m (106 lb in) **Special Tool** **DT-48285** Valve Body Torx Plus Socket For equivalent regional tools, refer to **Special Tools** .
3	Manual Shift Shaft Position Switch Assembly **Procedure** Align the switch activator slide with the manual valve link.

CONTROL SOLENOID VALVE AND TRANSMISSION CONTROL MODULE ASSEMBLY REPLACEMENT

Removal Procedure




Fig. 40: View Of Transmission Oil Pan And Filter

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

NOTE: **The valve body must be removed from the transmission to replace the control solenoid valve and transmission control module assembly.**

1. Remove the upper and lower control valve body assembly. Refer to **Control Valve Lower Body and Upper Body Replacement**.
2. Remove the transmission oil pan and filter. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**.
3. Remove the electrical connector passage sleeve. Refer to **Automatic Transmission Electrical Connector Passage Sleeve Replacement**.




Fig. 41: View Of Speed Sensor Electrical Connector
Courtesy of GENERAL MOTORS COMPANY

4. Disconnect the speed sensor electrical connector (2) from the control solenoid valve assembly.
5. Turn the control valve body assembly over.

cardiagn.com




Fig. 42: Manual Shift Shaft Position Switch Connector
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Release the connector lock before disconnecting.**

6. Disconnect the manual shift shaft position switch connector (4) from the control solenoid valve assembly.
7. Remove the bolt (3) and remove the manual shift shaft position switch assembly.

cardiagn.com




Fig. 43: View Of Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

8. Remove the 2 bolts (1) from the "heat sink" side of the control solenoid valve assembly.

cardiagn.com




Fig. 44: View Of Bolts
Courtesy of GENERAL MOTORS COMPANY

9. Remove the 5 bolts (2) and the 4 bolts (1) securing the control solenoid valve assembly to the control valve body assembly.

cardiagn.com




Fig. 45: View Of Control Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

10. Remove the control valve body assembly.

CAUTION: Use care when removing or installing the filter plate assembly. A broken or missing retaining tab may not adequately secure the filter plate to the control solenoid valve assembly, resulting in possible damage or contamination.

11. Carefully remove and discard the filter plate assembly (5).

Installation Procedure

cardiagn.com




Fig. 46: View Of Filter Plate Assembly
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Inspect the 4 filter plate retaining tabs on the control solenoid valve assembly. A broken or missing tab may not adequately secure the filter plate to the control solenoid valve assembly.**

1. Install a NEW filter plate assembly (1).

cardiagn.com




Fig. 47: View Of Control Solenoid Valve Assembly Bolts
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Note the locator pin on the control valve lower body assembly.**

2. Align the control solenoid valve assembly (1) to the control valve lower body assembly.
3. Install the 2 bolts (2), through the "heat sink" side of the control solenoid valve assembly (1). Hand tighten only.

cardiagn.com




Fig. 48: View Of Bolts
Courtesy of GENERAL MOTORS COMPANY

4. Install the 4 bolts (1) and 5 bolts (2) securing the control solenoid valve assembly to the control valve lower body assembly. Hand tighten only.

cardiagn.com




Fig. 49: View Of Manual Shift Shaft Position Switch Assembly
Courtesy of GENERAL MOTORS COMPANY

5. Install the manual shift shaft position switch assembly (1). Align the switch activator slide with the manual valve link. Secure with 1 bolt (3). Hand tighten only.

NOTE: **The wiring harness clip (4) on the manual shift shaft position switch does not need to be replaced if damaged or missing. The clip functions only as a manufacturing assembly aid to keep the harness clear during an automated bolt installation process. If the clip is damaged, simply remove and discard.**

6. Connect and lock the manual shift shaft position switch electrical connector (5) to the control solenoid valve assembly and attach the wiring harness clip (4).

cardiagn.com




Fig. 50: Control Solenoid Valve Assembly Bolt Tightening Sequence
Courtesy of GENERAL MOTORS COMPANY

CAUTION: **Bolt torque sequencing is critical to the proper function of the control solenoid valve assembly. Failure to follow the required sequencing may result in transmission malfunction.**

CAUTION: **Refer to Fastener Caution .**

NOTE: **When following the tightening sequence, skip over bolts 10, 11, 12, 13 and 15. These bolts are not removed for this procedure.**

7. Tighten all bolts in the sequence shown. The 2 "heat sink" bolts (17,18) must be tightened last.

   Tighten bolts to 8 N.m (71 lb in).

cardiagn.com




Fig. 51: View Of Control Solenoid Valve Assembly
Courtesy of GENERAL MOTORS COMPANY

8. Inspect the contact area between the "heat sink" area of the control solenoid valve assembly (1) and the valve body. There should be no visible gap. If a gap exists, loosen all 18 bolts and retighten in the sequence shown.

cardiagn.com




Fig. 52: View Of Output Speed Sensor Wiring Harness
Courtesy of GENERAL MOTORS COMPANY

9. Inspect the 2 input and output speed sensor wiring harness clips (1) for damage. Replace if damaged.

cardiagn.com




Fig. 53: View Of Speed Sensor Electrical Connector
Courtesy of GENERAL MOTORS COMPANY

10. Connect the speed sensor electrical connector (2) to the control solenoid valve assembly.

cardiagn.com




Fig. 54: Valve Body Assembly
Courtesy of GENERAL MOTORS COMPANY

11. Install the upper and lower control valve body assembly. Refer to **Control Valve Lower Body and Upper Body Replacement**.
12. Install the electrical connector passage sleeve. Refer to **Automatic Transmission Electrical Connector Passage Sleeve Replacement**.

cardiagn.com




Fig. 55: View Of Transmission Oil Pan And Filter
Courtesy of GENERAL MOTORS COMPANY

13. Install the transmission oil pan and filter. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**.
14. If a NEW TCM has been installed into the vehicle, the NEW module needs to be reprogrammed. Refer to **Service Programming System (SPS)** .

NOTE: **The Service Fast Learn Adapts procedure must be performed when one of the following repairs have been made to the vehicle. Failure to perform the procedure after one of the following repairs may result in poor transmission performance, as well as transmission DTCs being set:**

- **Transmission internal service/overhaul**
- **Valve body repair or replacement**
- **Control solenoid valve assembly replacement**
- **TCM software/calibration update**
- **Any service in response to a shift quality concern**

cardiagn.com

15. Perform the Reset Transmission Adapts. Refer to **Reset Transmission Adapts** .

CONTROL VALVE LOWER BODY AND UPPER BODY REPLACEMENT




Fig. 56: View Of Control Valve Lower & Upper Body
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure Remove the transmission electrical connector. Refer to **Automatic Transmission Electrical Connector Passage Sleeve Replacement**.	
1	Manual Shaft Detent Bolt **CAUTION:** **Refer to** **Fastener Caution** . **Tighten** 12 N.m (106 lb in)
2	Manual Shaft Detent Assembly
3	Control Valve Assembly Bolt (Qty: 6) **Procedure** 1. Use **DT-48285** valve body torx plus socket. 2. Do not remove all the bolts in the control valve body assembly. Remove only the bolts

cardiagn.com

Callout	Component Name
	indicated. 3. Tighten in specified sequence. **Tighten** 8 N.m (71 lb in) **Special Tool** **DT-48285** Valve Body Torx Plus Socket (if applicable) For equivalent regional tools, refer to **Special Tools** .
4	Control Valve Assembly
5	Fluid Pump Seal **Procedure** Discard seal and replace with new.
6	Fluid Pump Seal **Procedure** Discard seal and replace with new.
7	Center Support Fluid Passage Seal **Procedure** 1. Discard seal and replace with new. 2. It is recommended that transmission adaptive pressure (TAP) information be reset. Transmission performance may be affected as new TAP values are learned. Refer to **Reset Transmission Adapts** . 3. If replacing the control valve body assembly, remove the **Control Solenoid Valve and Transmission Control Module Assembly Replacement**, and the **Manual Shift Shaft Position Switch Replacement**.

INPUT AND OUTPUT SPEED SENSOR REPLACEMENT

cardiagn.com




Fig. 57: Input And Output Speed Sensor
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedures 1. Raise and support the vehicle. Refer to **Lifting and Jacking the Vehicle** . 2. Remove the transmission fluid pan and filter. Refer to **Automatic Transmission Fluid, Fluid Pan and/or Filter Replacement**. 3. Remove the upper and lower valve body assembly. Refer to **Control Valve Lower Body and Upper Body Replacement**.	
1	Speed Sensor Electrical Connector
2	Input and Output Speed Sensor Assembly Bolt (Qty: 2) **CAUTION:** **Refer to Fastener Caution .** **Tighten** 12 N.m (106 lb in)
3	Input and Output Speed Sensor Assembly Clip (Qty: 2) **Procedure** Inspect the wiring harness clips for damage replace if necessary.
4	Input and Output Speed Sensor Assembly

cardiagn.com

TRANSMISSION CONVERTER COVER REPLACEMENT




Fig. 58: View Of Torque Converter Covers & Bolts
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure Raise the vehicle. Refer to **Lifting and Jacking the Vehicle** .	
1	Torque Converter Cover Bolt **CAUTION:** **Refer to** **Fastener Caution** . **Tighten** 12 N.m (106 lb in)
2	Torque Converter Cover **Procedure** Remove the starter. Refer to **Starter Replacement (L96, LC8)** **Starter Replacement (L83, L8B)** **Starter Replacement (LV3)** .
3	Torque Converter Cover Bolt **Tighten** 12 N.m (106 lb in)
4	Torque Converter Cover

TRANSMISSION REPLACEMENT

cardiagn.com

Special Tools

J-21366 Converter Holding Strap

For equivalent regional tools, refer to **Special Tools** .

Removal Procedure

1. Disconnect the negative battery cable. Refer to **Battery Negative Cable Disconnection and Connection (L96 LC8)** **Battery Negative Cable Disconnection and Connection (L83, L8B, LV3)** .
2. Raise and suitably support the vehicle. Refer to **Lifting and Jacking the Vehicle** .
3. Remove the rear propeller shaft. Refer to **One-Piece Propeller Shaft Replacement** , or **Two-Piece Propeller Shaft Replacement (MYC, M5U, MSX)** **Two-Piece Propeller Shaft Replacement (MW7)** .
4. If the vehicle is equipped with a transfer case, remove the front propeller shaft. Refer to **Front Axle Propeller Shaft Replacement** .




Fig. 59: Identifying Torque Converter Access Plug
Courtesy of GENERAL MOTORS COMPANY

5. Remove the torque converter access plug.

cardiagn.com




Fig. 60: View Of Left Flywheel Inspection Cover
Courtesy of GENERAL MOTORS COMPANY

6. Remove the left flywheel inspection cover.
7. Remove the starter motor. Refer to **Starter Replacement (L96, LC8)** **Starter Replacement (L83, L8B)** **Starter Replacement (LV3)** .

cardiagn.com




Fig. 61: View Of Right Flywheel Inspection Cover
Courtesy of GENERAL MOTORS COMPANY

8. Remove the right flywheel inspection cover.
9. Remove the steering gear skid shield. Refer to **Steering Gear Skid Shield Replacement** .
10. Mark the relationship of the flywheel to the torque converter for reassembly.

cardiagn.com




Fig. 62: View Of Flywheel To Torque Converter Bolts
Courtesy of GENERAL MOTORS COMPANY

11. Remove the flywheel to torque converter bolts.
12. Support the transmission with a transmission jack.
13. Remove the transmission crossmember. Refer to **Transmission Support Crossmember Replacement (2WD - Light Duty)** **Transmission Support Crossmember Replacement (2WD - Heavy Duty)** **Transmission Support Crossmember Replacement (4WD - Light Duty)** **Transmission Support Crossmember Replacement (4WD - Heavy Duty)** .
14. Remove the transmission mount. Refer to **Transmission Mount Replacement (Two Wheel Drive)** **Transmission Mount Replacement (Four Wheel Drive)**.
15. Remove the catalytic converter pipe. Refer to **Three-Way Catalytic Converter Replacement (LC8, L96)** **Three-Way Catalytic Converter Replacement (LV3, L83, L8B, or L86)** .
16. Lower the transmission to gain access to the top and sides of the transmission.
17. Remove the transfer case, if equipped. Refer to **Transfer Case Assembly Replacement** MP 1222/1225/1226 (NQG), or **Transfer Case Assembly Replacement** MP 3023/3024 (NQH), or **Transfer Case Assembly Replacement** MP 1625/1626 (NQF).

cardiagn.com




Fig. 63: View Of Transmission Heat Shield & Bolts
Courtesy of GENERAL MOTORS COMPANY

18. Remove the 2 bolts securing the heat shield to the transmission.
19. Remove the transmission heat shield.

cardiagn.com




Fig. 64: View Of Range Selector Cable & Cable Bracket Retainer
Courtesy of GENERAL MOTORS COMPANY

20. Remove the range selector cable retaining clip (1) from the transmission range selector cable.
21. Remove the range selector cable (2) from the range selector lever ball stud and the range selector cable bracket.

cardiagn.com




Fig. 65: View Of Transmission Vent Hose
Courtesy of GENERAL MOTORS COMPANY

22. Disconnect the transmission vent hose.
23. Disconnect the transmission electrical connector by pulling the white plastic tab, located on the connector circular ring (approximately 15 x 15 mm), outward and then rotate the circular ring of the connector counterclockwise. When the circular ring is disengaged, pull the connector straight out. Outward means away from transmission centerline, counterclockwise is looking at connector from rear of transmission.
24. Remove the wire harness from the transmission.

cardiagn.com




Fig. 66: View Of Bolt Securing Fuel Line Bracket To Left Side Of Transmission
Courtesy of GENERAL MOTORS COMPANY

25. Remove the bolt that secures the fuel line bracket to the left side of the transmission.

cardiagn.com




Fig. 67: View Of Oil Cooling Lines & Bolt
Courtesy of GENERAL MOTORS COMPANY

26. Disconnect the transmission oil cooler lines (1) from the transmission. Refer to **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LV3)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L83, L86 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LC8, L96 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L86 with M5U)** .
27. Plug the transmission oil cooler line connectors in the transmission case.
28. Remove the transmission dipstick tube retaining nut.
29. Reposition the transmission dipstick tube.
30. Remove the vent tube bracket retaining nut on the back of the transmission at the engine.
31. Reposition the vent tube bracket.
32. Remove the transmission cooler line bracket retaining nut and reposition.
33. Remove the fuel line bracket nut on the back of the transmission at the engine and reposition the fuel line bracket.
34. Secure the transmission to the jack using the appropriate strap.

cardiagn.com




Fig. 68: View Of Transmission Bolts
Courtesy of GENERAL MOTORS COMPANY

35. Remove the 8 bolts securing the transmission to the engine.
36. Pull the transmission straight back.
37. Install the **J-21366** converter holding strap onto the transmission bell housing to retain the torque converter.
38. Remove the transmission from the vehicle while simultaneously removing the fluid level indicator tube.
39. Flush the transmission cooler lines. Refer to **Transmission Fluid Cooler Flow Test and Flushing (6L80 or 6L90)** **Transmission Fluid Cooler Flow Test and Flushing (Allison)** **Transmission Fluid Cooler Flow Test and Flushing (8L90)** .

Installation Procedure

1. Install the **J-21366** converter holding strap onto the transmission bell housing to retain the torque converter.
2. Support the transmission with a transmission jack.
3. Raise the transmission into place while simultaneously installing the fluid indicator tube.
4. Remove the **J-21366** converter holding strap from the transmission.
5. Slide the transmission straight onto the locating pins while lining up the marks on the flywheel and the

cardiagn.com

torque converter.

The torque converter must rotate freely by hand.




Fig. 69: View Of Transmission Bolts
Courtesy of GENERAL MOTORS COMPANY

CAUTION: Refer to Fastener Caution .

6. Install the 8 bolts securing the transmission to the engine and tighten to 50 N.m (37 lb ft).
7. Unstrap the transmission from the jack.
8. Position the fuel line bracket to the back of the engine at the transmission and install the nut. Tighten the nut to 10 N.m (89 lb in).
9. Position the vent tube bracket to the back of the engine at the transmission.
10. Install the vent tube bracket retaining nut and tighten to 10 N.m (89 lb in).
11. Position the transmission dipstick tube and seal into the transmission.
12. Install the dipstick tube retaining fastener and tighten to 10 N.m (89 lb in).
13. Remove the plugs in the oil cooler lines in the transmission case.

cardiagn.com




Fig. 70: View Of Oil Cooling Lines & Bolt
Courtesy of GENERAL MOTORS COMPANY

14. Connect the oil cooler lines (1) to the transmission. Refer to **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LV3)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L83, L86 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (LC8, L96 with MYD)** **Transmission Fluid Cooler Inlet and Outlet Pipe Replacement (L86 with M5U)** .
15. Install the bolt that secures the fuel line bracket to the transmission and tighten to 10 N.m (89 lb in).
16. Install the wire harness to the transmission.
17. Connect the transmission electrical connector to the transmission.

cardiagn.com




Fig. 71: View Of Transmission Vent Hose
Courtesy of GENERAL MOTORS COMPANY

18. Connect the transmission vent hose.

cardiagn.com




Fig. 72: View Of Range Selector Cable & Cable Bracket Retainer
Courtesy of GENERAL MOTORS COMPANY

19. Install the range selector cable (2) to the range selector cable bracket and the range selector lever ball stud.
20. Install the range selector cable retaining clip (1) to the transmission range selector cable.

cardiagn.com




Fig. 73: View Of Transmission Heat Shield & Bolts
Courtesy of GENERAL MOTORS COMPANY

21. Install the transmission heat shield.
22. Install the 2 bolts securing the heat shield to the transmission and tighten to 17 N.m (13 lb ft).
23. Install the transfer case, if equipped. Refer to **Transfer Case Assembly Replacement** , or **Transfer Case Assembly Replacement** , or **Transfer Case Assembly Replacement** .
24. Raise the transmission in place using the jack.
25. Install the catalytic converter pipe. Refer to **Three-Way Catalytic Converter Replacement (LC8, L96) Three-Way Catalytic Converter Replacement (LV3, L83, L8B, or L86)** .
26. Install the transmission mount. Refer to **Transmission Mount Replacement (Two Wheel Drive)Transmission Mount Replacement (Four Wheel Drive)**.
27. Install the transmission crossmember. Refer to **Transmission Support Crossmember Replacement (2WD - Light Duty) Transmission Support Crossmember Replacement (2WD - Heavy Duty) Transmission Support Crossmember Replacement (4WD - Light Duty) Transmission Support Crossmember Replacement (4WD - Heavy Duty)** .
28. Remove the transmission jack.

cardiagn.com




Fig. 74: View Of Flywheel To Torque Converter Bolts
Courtesy of GENERAL MOTORS COMPANY

29. From the torque converter access hole, push the torque converter forward to seat the converter pilot in the crank bore.
30. If reusing the torque converter bolts, clean the bolt threads and apply sealant. Refer to **Adhesives, Fluids, Lubricants, and Sealers** .
31. Install the flywheel to torque converter bolts and tighten to 65 N.m (48 lb ft).
32. Install the steering gear skid shield. Refer to **Steering Gear Skid Shield Replacement** .

cardiagn.com




Fig. 75: View Of Right Flywheel Inspection Cover
Courtesy of GENERAL MOTORS COMPANY

33. Install the right flywheel inspection cover and bolt. Tighten the bolt to 12 N.m (106 lb in).
34. Install the starter motor. Refer to **Starter Replacement (L96, LC8)** **Starter Replacement (L83, L8B)** **Starter Replacement (LV3)** .

cardiagn.com




Fig. 76: View Of Left Flywheel Inspection Cover
Courtesy of GENERAL MOTORS COMPANY

35. Install the left flywheel inspection cover and bolt. Tighten the bolt to 12 N.m (106 lb in).

cardiagn.com




Fig. 77: Identifying Torque Converter Access Plug
Courtesy of GENERAL MOTORS COMPANY

36. Install the torque converter access plug.
37. If the vehicle is equipped with a transfer case, install the front propeller shaft. Refer to **Front Axle Propeller Shaft Replacement** .
38. Install the rear propeller shaft. Refer to **One-Piece Propeller Shaft Replacement** , or **Two-Piece Propeller Shaft Replacement (MYC, M5U, MSX)** **Two-Piece Propeller Shaft Replacement (MW7)** .
39. Lower the vehicle.
40. Connect the negative battery cable. Refer to **Battery Negative Cable Disconnection and Connection (L96 LC8)** **Battery Negative Cable Disconnection and Connection (L83, L8B, LV3)** .
41. Check the transmission fluid level and fill if necessary. Refer to **Transmission Fluid Level and Condition Check** .
42. If a NEW TCM has been installed into the vehicle, the NEW module needs to be reprogrammed. Refer to **Service Programming System (SPS)** .

NOTE: **The Service Fast Learn Adapts procedure must be performed when one of the following repairs have been made to the vehicle. Failure to perform the**

cardiagn.com

procedure after one of the following repairs may result in poor transmission performance, as well as transmission DTCs being set:

- **Transmission internal service/overhaul**
- **Valve body repair or replacement**
- **Control solenoid valve assembly replacement**
- **TCM software/calibration update**
- **Any service in response to a shift quality concern**

43. Perform the Reset Transmission Adapts. Refer to **Reset Transmission Adapts** .

TORQUE CONVERTER REPLACEMENT




Fig. 78: Torque Converter
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure Remove the transmission. Refer to **Transmission Replacement**.	
1	Converter Holding Strap **WARNING:** **The torque converter must be held to the torque**

cardiagn.com

Callout	Component Name
	converter housing by a retaining device such as shipping brackets. Without the retaining device, the torque converter may slide forward, disengaging the oil pump, or may fall completely out of the transmission causing personal injury and/or property damage. **Special Tools** **DT-21366** Converter Holding Strap For equivalent region tools, refer to **Special Tools** .
2	Torque Converter Assembly **Procedure** 1. Place a drain pan under the front of the transmission. 2. Use care not to damage the torque converter seal during the installation procedure. 3. Spin the torque converter to engage the turbine shaft splines in the torque converter hub, the stator shaft splines in the stator race and to engage the drive flats on the converter pump hub with the oil pump drive gear. **NOTE:** **Lubricate the converter pump hub OD and the torque converter seal with clean**

cardiagn.com

Callout	Component Name
	transmission fluid.

TORQUE CONVERTER FLUID SEAL REPLACEMENT




Fig. 79: Torque Converter Fluid Seal
Courtesy of GENERAL MOTORS COMPANY

Callout	Component Name
Preliminary Procedure Remove the torque converter. Refer to **Torque Converter Replacement**.	
1	Torque Converter Fluid Seal Assembly **NOTE:** **The seal can be installed by hand.** **Special Tools** • **EN-23129** Seal Remover • **J-6125-1B** Slide Hammer For equivalent regional tools, refer to **Special Tools** .

cardiagn.com

Article GUID: A00854522

cardiagn.com

Automatic Transmission - 6L80 (MYC) or 6L90 (MYD) - Schematic Wiring Diagrams - Sierra, Silverado

SCHEMATIC WIRING DIAGRAMS

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

AUTOMATIC TRANSMISSION CONTROLS WIRING SCHEMATICS

Module Power, Ground, Data Communication and MIL




Fig. 1: Module Power, Ground, Data Communication and MIL
Courtesy of GENERAL MOTORS COMPANY

ISS, OSS, TFP, and TFT Sensors, Pressure and Shift Controls

cardiagn.com




Fig. 2: ISS, OSS, TFP, and TFT Sensors, Pressure and Shift Controls
Courtesy of GENERAL MOTORS COMPANY

IMS and Tap Up/Tap Down

cardiagn.com




Fig. 3: IMS and Tap Up/Tap Down
Courtesy of GENERAL MOTORS COMPANY

Article GUID: A00854590

cardiagn.com

SPECIAL TOOLS AND EQUIPMENT


APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500


SPECIAL TOOLS

Illustration	Tool Number/Description
	DT-22912-B Split Plate Bearing Puller


cardiagn.com

Illustration	Tool Number/Description
	DT-47605 Holding Fixture Adapter

cardiagn.com

Illustration	Tool Number/Description
	DT-47715 Electrical Connector Passage Sleeve Remover/Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-47731 1/2 Inch Quick Connect Release Tool


cardiagn.com

Illustration	Tool Number/Description
	DT-47761 Clutch Spring Compressor


cardiagn.com

Illustration	Tool Number/Description
	DT-47768-1 Seal Protector

cardiagn.com

Illustration	Tool Number/Description
	DT-47768-2 Seal Protector

cardiagn.com

Illustration	Tool Number/Description
	DT-47768-3 Seal Sizer


cardiagn.com

Illustration	Tool Number/Description
	DT-47770 Seal Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-47773 Retaining Ring Pliers Adapter Set

cardiagn.com

Illustration	Tool Number/Description
	DT-47778-1 Low Clutch Sprag Retaining Ring Cone


cardiagn.com

Illustration	Tool Number/Description
	DT-47778-2 Low Clutch Sprag Retaining Ring Pusher


cardiagn.com

Illustration	Tool Number/Description
	DT-47779 Low Clutch Spring Compressor


cardiagn.com

Illustration	Tool Number/Description
	DT-47780 Low Clutch Sprag Seal Cone


cardiagn.com

Illustration	Tool Number/Description
	DT-47781 C1234 and 35R Clutch Assembly Installer

cardiagn.com

Illustration	Tool Number/Description
	DT-47782-1 Retaining Ring Cone


cardiagn.com

Illustration	Tool Number/Description
	DT-47782-2 Retaining Ring Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-47786 Output Carrier/Shaft Lifting Tool


cardiagn.com

Illustration	Tool Number/Description
	DT-47825 Solenoid Performance Test Block

cardiagn.com

Illustration	Tool Number/Description
	DT-47825-10 Jumper Harness


cardiagn.com

Illustration	Tool Number/Description
	DT-47848 Filter Neck Seal Installer

cardiagn.com

Illustration	Tool Number/Description
	DT-47857 Bearing Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-47865 Bearing Remover


cardiagn.com

Illustration	Tool Number/Description
	DT-47866 Bearing Installer


cardiagn.com

Illustration	Tool Number/Description
	DT 47867 Adjustable Clutch Spring Compressor


cardiagn.com

Illustration	Tool Number/Description
	DT-47868-1 Pack Travel Weight


cardiagn.com

Illustration	Tool Number/Description
	DT-47868-2 Magnetic Base Adapter


cardiagn.com

Illustration	Tool Number/Description
	DT-47868-3 Clutch Travel Weight Adapter


cardiagn.com

Illustration	Tool Number/Description
	DT-47868-4 Clutch Travel Weight Adapter


cardiagn.com

Illustration	Tool Number/Description
	DT-48021 Seal Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-48285 Valve Body Torx Plus Socket

cardiagn.com

Illustration	Tool Number/Description
	DT-49291 Clutch Travel Air Passage Plug Kit


cardiagn.com

Illustration	Tool Number/Description
	DT-50648 Case Seal Installer


cardiagn.com

Illustration	Tool Number/Description
	DT-50802 Threaded Rod Kit


cardiagn.com

Illustration	Tool Number/Description
	DT-50802-1 Sleeve Installer

cardiagn.com

Illustration	Tool Number/Description
	EL-49742 Battery Voltage B+ and Ground Source Harness


cardiagn.com

Illustration	Tool Number/Description
	GE-8433-1 Puller Bar


cardiagn.com

Illustration	Tool Number/Description
	J-3289-20 Holding Fixture Base Assembly


cardiagn.com

Illustration	Tool Number/Description
	J-6125-B Slide Hammer


cardiagn.com

Illustration	Tool Number/Description
	J-8001 Dial Indicator Set


cardiagn.com

Illustration	Tool Number/Description
	J-8092 Driver Handle


cardiagn.com

Illustration	Tool Number/Description
	J-8763-B Holding Fixture

cardiagn.com

Illustration	Tool Number/Description
	J-21366 Converter Holding Strap


cardiagn.com

Illustration	Tool Number/Description
	J-21867 Pressure Gauge


cardiagn.com

Illustration	Tool Number/Description
	J-23129 Universal Seal Remover


cardiagn.com

Illustration	Tool Number/Description
	J-26900-13 Magnetic Base


cardiagn.com

Illustration	Tool Number/Description
	J-35616 GM Approved Terminal Test Kit

cardiagn.com

Illustration	Tool Number/Description
	J-36825-A Output Shaft Oil Seal Remover (4WD Models Only)

cardiagn.com

Illustration	Tool Number/Description
	J-38522 Variable Signal Generator

cardiagn.com

Illustration	Tool Number/Description
	J-38693 Seal Installer


cardiagn.com

Illustration	Tool Number/Description
	J-38734 Intermediate Spring Compressor Adapter

cardiagn.com

Illustration	Tool Number/Description
	J-38869 Output Shaft Seal Installer

cardiagn.com

Illustration	Tool Number/Description
	J-41623-B Cooler Quick Connect Tool


cardiagn.com

Illustration	Tool Number/Description
	J-42183 Driver Handle

cardiagn.com

Illustration	Tool Number/Description
	J-43074 Clutch Spring Compressor


cardiagn.com

Illustration	Tool Number/Description
	J-45000 Seal Remover


cardiagn.com

Illustration	Tool Number/Description
	J-45096 Transmission Oil Cooler System Flush and Flow Test Tool


cardiagn.com

Illustration	Tool Number/Description
	J-45096-30 Transmission Cooler Flusher Adapters

cardiagn.com

Illustration	Tool Number/Description
	J-45124 Remover Bridge

cardiagn.com

Illustration	Tool Number/Description
	J-45126 Snap Ring Pliers

cardiagn.com

Illustration	Tool Number/Description
	J-45201 Cooler Line Seal Remover

cardiagn.com

Illustration	Tool Number/Description
	J-46664 Pump Cover Alignment Tool

Article GUID: A00854524

cardiagn.com

SPECIFICATIONS

APPLICATION

- 4.3L LV3 H 6L80 (MYC) 1500
- 5.3L L83 C 6L80 (MYC) 1500
- 6.0L LC8 B Gas/CNG 6L90-E (MYD) 2500/3500
- 6.0L L96 G Gas/Ethanol 6L90-E (MYD) 2500/3500

FASTENER SPECIFICATIONS (ON VEHICLE)

Single Use Non-Threaded Fasteners/Components

NOTE: *All fasteners/components listed in this table MUST BE DISCARDED and replaced with NEW after removal.*
Application
Case Extension Gasket
Transmission Output Shaft Seal
Propeller Shaft Front Slip Yoke Oil Seal
Torque Converter Fluid Seal

Single Use Threaded Fastener/Component Tightening Specifications

NOTE: *All fasteners/components listed in this table MUST BE DISCARDED and replaced with NEW after removal.*	
Application	**Specification** **Metric (English)**
Transmission Mount to Transmission Bolts- 4WD HD	
• First Pass:	45 N.m (33 lb ft)
• Final Pass:	50 Degrees

cardiagn.com

Reusable Threaded Fastener Tightening Specifications

NOTE:
All fasteners listed in this table can be reused after removal.

Application	Specification Metric (English)
Auxiliary Fluid Cooler Bolts	12 N.m (106 lb in)
Case Extension Housing Bolts	55 N.m (41 lb ft)
Control Valve Assembly Bolts	8 N.m (71 lb in)
Control Solenoid Valve and Transmission Control Module Assembly Bolts	8 N.m (71 lb in)
Floor Shift Control Indicator Screw	2.5 N.m (22 lb in)
Floor Shift Control Lever Bolt	9 N.m (80 lb in)
Floor Shift Control Lever Knob Screw	6 N.m (53 lb in)
Fluid Filler Tube Nut	18 N.m (13 lb ft)
Fuel Pipe Bracket Screw	9 N.m (80 lb in)
Flywheel Inspection Cover Bolts- Left	12 N.m (106 lb in)
Flywheel Inspection Cover Bolts- Right	12 N.m (106 lb in)
Heat Shield to Transmission Bolts	17 N.m (13 lb ft)
Input and Output Speed Sensor Assembly Bolts	12 N.m (106 lb in)
Manual Shaft Detent Bolt	12 N.m (106 lb in)
Manual Shift Shaft Position Switch Assembly Bolts	12 N.m (106 lb in)
Oil Level Indicator Tube Bracket Nut	22 N.m (17 lb ft)
Oil Pressure Test Plug	11 N.m (97 lb in)
Torque Converter Cover Bolts	12 N.m (106 lb in)
Torque Converter to Flex Plate Bolts	65 N.m (48 lb ft)
Transmission to Engine Bolts	50 N.m (37 lb ft)
Transmission Electrical Harness Retaining Screw	9 N.m (80 lb in)
Transmission Fluid Cooler Pipe Bracket Bolt	22 N.m (17 lb ft)
Transmission Fluid Pan Bolts	9 N.m (80 lb in)
Transmission Mount to Crossmember Nuts- HD	107 N.m (79 lb ft)
Transmission Mount to Crossmember Nuts- LD	55 N.m (40 lb ft)
Transmission Mount to Transmission Bolts- LD and 2WD HD	67 N.m (50 lb ft)
Transmission Range Selector Cable Bracket Bolt	22 N.m (17 lb ft)
Transmission Range Selector Cable Lever Nut	25 N.m (18 lb ft)

FASTENER SPECIFICATIONS (OFF VEHICLE)

Single Use Non-Threaded Fasteners/Components

Application
NOTE:

cardiagn.com

Application
All fasteners/components listed in this table MUST BE DISCARDED and replaced with NEW after removal.
1-2-3-4 and 3-5-Reverse Clutch Housing Thrust Washer
Automatic Transmission Fluid Filter
Automatic Transmission Fluid Filter Seal
Automatic Transmission Fluid Pump Seal
Automatic Transmission Fluid Pump Seals
Center Support Fluid Passage Seal
Filter Plate Assembly
Turbine Shaft Seal

Reusable Threaded Fastener Tightening Specifications

Application	Ref No.*	Quantity	Size	Specification	
				Metric	English
Automatic Transmission Case Extension@Automatic Transmission Case	16	6	M10x1.5x40	55 N.m	41 lb ft
Automatic Transmission Fluid Pan@Automatic Transmission Case	30	18	M6x1.0x20	9 N.m	80 lb in
Automatic Transmission Fluid Pump Cover Bolt @ Torque Converter Housing	231	13	M6 1.0x40	11 N.m	97 lb in
Control Solenoid Valve@Control Valve Upper Body	310	6	M5x0.8x55	8 N.m	71 lb in
Control Solenoid Valve@Control Valve Upper Body	309	10	M5x0.8x45	8 N.m	71 lb in
Control Solenoid Valve Heat Sink @ Valve Body	312	2	M5x0.8x53	8 N.m	71 lb in
Control Valve Assembly @ Control Valve Body	22	6	M5x0.8x73	8 N.m	71 lb in
Control Valve Upper Body Assembly @ Control Valve Lower Body Assembly	301	12	M5x0.8x36	8 N.m	71 lb in
Input and Output Speed Sensor Assembly @ Control Valve Upper Body Assembly	302	2	M6x1.0x20	12 N.m	106 lb in
Line Pressure Test Hole Plug @ Torque Converter Housing	202	1	1/8-27 NPTF	11 N.m	97 lb in

cardiagn.com

Application	Ref No.*	Quantity	Size	Specification	
				Metric	English
Manual Shaft Detent Assembly @ Control Valve Body	23	1	M6x1.0x14.5	12 N.m	106 lb in
Torque Converter Housing @ Automatic Transmission Case	3	9	M10x1.5x50	72 N.m	53 lb ft
*Reference number refers to the component callout number in Disassembled Views					

APPROXIMATE FLUID CAPACITIES

Application	Specification	
	Metric	English
Pan Removal and Filter Replacement - Approximate Capacity (6L80/6L90)	5.7 liters	6.0 quarts
Overhaul - Approximate Capacity (6L80/6L90)	9.9 liters	10.5 quarts
Complete Trans System - Approximate Capacity (6L80)	11.5 liters	12.2 quarts
Complete Trans System (Heavy Duty Cooling) - Approximate Capacity (6L80/6L90)	11.7 liters	12.4 quarts

TRANSMISSION GENERAL SPECIFICATIONS

Name	6L80	6L90
RPO Codes	MYC	MYD
Production Location	Silao, Mexico; Strasbourg, France; Toledo, OH (USA)	Silao, Mexico; Strasbourg, France; Toledo, OH (USA)
Transmission Drive	Rear Wheel Drive	Rear Wheel Drive
1st Gear Ratio	4.027	4.027
2nd Gear Ratio	2.364	2.364
3rd Gear Ratio	1.532	1.532
4th Gear Ratio	1.152	1.152
5th Gear Ratio	0.852	0.852
6th Gear Ratio	0.667	0.667
Reverse	3.064	3.064
Torque Converter Size - Diameter of Torque Converter Turbine	258/300 mm	300 mm
Pressure Taps	Line Pressure	Line Pressure
Transmission Fluid Type	DEXRON VIÂ®	DEXRON VIÂ®
Transmission Type: 6	Six Forward Gears	Six Forward Gears
Transmission Type: L	Longitude Mount	Longitude Mount
Transmission Type: 50	Product Series	Product Series
Position Quadrant	P, R, N, D, S	P, R, N, D, M
Case Material	Die Cast Aluminum	Die Cast Aluminum
Transmission Net Weight (Approximate)	95.1-103.7 kg (209.7-228.6 lb)	110 kg (243 lb)
Maximum Trailer Towing Capacity	N/A	Refer to applicable owner's manual

cardiagn.com

ADHESIVES, FLUIDS, LUBRICANTS, AND SEALERS

Application	Type of Material	GM Part Number	
		United States	Canada
Automatic Transmission Fluid	DEXRONÂ®VI	88861037	19264717

FLUID PUMP SELECTIVE SPECIFICATIONS

Size Classification	Thickness (mm)	Thickness (in)
NOTE: • **Rotor and slide must be chosen from the same size classification as the oil pump body.** • **Allowable rotor and slide to fluid pump body end play is as follows:** **Specification** • **Slide to Fluid Pump Body End Play - 0.020-0.051 mm (0.0008-0.0020 in)** • **Rotor to Fluid Pump Body End Play - 0.020-0.051 mm (0.0008-0.0020 in)**		
The fluid pump assembly has selective rotor and slide components. These components are chosen based on pump body dimensions. Fluid pump rotor and slide components are available in three size classifications (1, 2, 3) with the following tolerances:		
Rotor Selection		
1	17.948-17.961	0.7066-0.7071
2	17.961-17.974	0.7071-0.7076
3	17.974-17.987	0.7076-0.7081
Slide Selection		
1	17.948-17.961	0.7066-0.7071
2	17.961-17.974	0.7071-0.7076

cardiagn.com

Size Classification	Thickness (mm)	Thickness (in)
3	17.974-17.987	0.7076-0.7081

CLUTCH BACKING PLATE RETAINING RING SPECIFICATIONS

3-5 Reverse Clutch

Clutch Pack Travel Specification - 1.21-1.79 mm (0.048-0.070 in)		
Retaining Ring Thickness		
Metric	English	O.D. Color
NOTE: **After measuring clutch pack travel, determine if the measurement is within the specification. If the measurement is not within the specification, measure the thickness of the existing retaining ring, and then choose a thicker or thinner retaining ring that will bring the measurement within specification.**		
1.61-1.71 mm	0.063-0.067 in	Gray
1.88-1.98 mm	0.074-0.078 in	Light Green
2.15-2.25 mm	0.085-0.089 in	Yellow
2.42-2.52 mm	0.095-0.099 in	None
2.69-2.79 mm	0.106-0.110 in	Purple

1-2-3-4 Clutch

Clutch Pack Travel Specification - 1.53-1.99 mm (0.060-0.078 in)		
Retaining Ring Thickness		
Metric	English	O.D. Color

cardiagn.com

Clutch Pack Travel Specification - 1.53-1.99 mm (0.060-0.078 in)		
Retaining Ring Thickness		
Metric	English	O.D. Color
NOTE:		
2.42-2.52 mm	0.095-0.099 in	None
2.69-2.79 mm	0.106-0.110 in	Purple
2.96-3.06 mm	0.117-0.120 in	Light Blue
3.23-3.33 mm	0.127-0.131 in	Orange
3.50-3.60 mm	0.138-0.142 in	White

After measuring clutch pack travel, determine if the measurement is within the specification. If the measurement is within the specification, measure the thickness of the existing retaining ring, and then choose a thicker or thinner retaining ring that will bring the measurement within specification.

4-5-6 Clutch

Clutch Pack Travel Specification - 1.28-1.89 mm (0.050-0.074 in)		
Retaining Ring Thickness		
Metric	English	O.D. Color
NOTE:		
1.60-1.70 mm	0.063-0.067 in	Yellow
2.02-2.12 mm	0.080-0.083 in	None
2.44-2.54 mm	0.096-0.100 in	Purple

Low/Reverse Clutch

cardiagn.com

Clutch Pack Travel Specification - 1.30-2.07 mm (0.051-0.081 in)		
Retaining Ring Thickness		O.D. Color
Metric	English	
NOTE: **After measuring clutch pack travel, determine if the measurement is within the specification. If the measurement is not within the specification, measure the thickness of the existing retaining ring, and then choose a thicker or thinner retaining ring that will bring the measurement within specification.**		
1.85-1.95 mm	0.073-0.077 in	Yellow
2.26-2.36 mm	0.089-0.093 in	None
2.67-2.77 mm	0.105-0.109 in	Purple

RANGE REFERENCE

Range Reference Table

Range	Park	Reverse	Neutral	Drive						
				1st Braking	1st	2nd	3rd	4th	5th	6th
1-2-3-4 Clutch	-	-	-	Applied	Applied	Applied	Applied	Applied	-	-
3-5 Reverse Clutch	-	Applied	-	-	-	-	Applied	-	Applied	-
4-5-6 Clutch	-	-	-	-	-	-	-	Applied	Applied	Applied

cardiagn.com

Range	Park	Reverse	Neutral	Drive						
				1st Braking	1st	2nd	3rd	4th	5th	6th
2-6 Clutch	-	-	-	-	-	Applied	-	-	-	Applied
Low and Reverse Clutch	Applied*	Applied	Applied*	Applied	-	-	-	-	-	-
Low Clutch Sprag	-	-	-	Holding	Holding	-	-	-	-	-
* = Applied with NO load										

SHIFT SOLENOID VALVE STATE AND GEAR RATIO

Gear	Shift SOL 1	Shift SOL 2	1-2-3-4 CL PC SOL 5 N.L.	2-6 CL PC SOL 4 N.L.	3-5 REV CL PC SOL 2 N.H.	LOW REV 4-5-6 CL PC SOL 3 N.H.	6L45 6L50 Gear Ratio	6L80 6L90 Gear Ratio
Park	ON	ON	OFF	OFF	OFF	ON	-	-
Reverse	ON	OFF	OFF	OFF	ON	ON	3.200	3.064
Neutral	ON	ON	OFF	OFF	OFF	ON	-	-
1st Braking	ON	ON	ON	OFF	OFF	ON	4.065	4.027
1st	OFF	ON	ON	OFF	OFF	OFF	4.065	4.027
2nd	OFF	ON	ON	ON	OFF	OFF	2.371	2.364
3rd	OFF	ON	ON	OFF	ON	OFF	1.551	1.532
4th	OFF	ON	ON	OFF	OFF	ON	1.157	1.152
5th	OFF	ON	OFF	OFF	ON	ON	0.853	0.852
6th	OFF	ON	OFF	ON	OFF	ON	0.674	0.667
For shift solenoids 1 and 2, "ON" = Solenoid Energized (Pressurized) "OFF" = Solenoid De-energized (No Pressure). For pressure control solenoids, "ON" = Pressurized, "OFF" = No Pressure								

TRANSMISSION INTERNAL MODE SWITCH LOGIC

Gear Selector Position	Signal A	Signal B	Signal C	Signal P
Park	LOW	HI	HI	LOW
Park/Reverse	LOW	LOW	HI	LOW
Reverse	LOW	LOW	HI	HI
Reverse/Neutral	HI	LOW	HI	HI
Neutral	HI	LOW	HI	LOW
Neutral/Drive 6	HI	LOW	LOW	LOW
Drive 6	HI	LOW	LOW	HI
Drive 6/Drive 4	LOW	LOW	LOW	HI
Drive 4	LOW	LOW	LOW	LOW
Drive 4/Drive 3	LOW	HI	LOW	LOW

cardiagn.com

Gear Selector Position	Signal A	Signal B	Signal C	Signal P
Drive 3	LOW	HI	LOW	HI
Drive 3/Drive 2	HI	HI	LOW	HI
Drive 2	HI	HI	LOW	LOW
Open	HI	HI	HI	HI
Invalid	HI	HI	HI	LOW
Invalid	LOW	HI	HI	HI
HI = Ignition voltage LOW = 0 volts				

TRANSMISSION PARTS KIT SPECIFICATIONS

A/Trans Fluid Filter Kit




Fig. 1: Automatic Transmission Fluid Filter Kit
Courtesy of GENERAL MOTORS COMPANY

A/Trans Fluid Filter Kit

Callout	Quantity	Component Name
25	1	A/Trans Fluid Filter Seal Assembly
26	1	A/Trans Fluid Filter Assembly

A/Trans Fluid Pump Rotor Package

cardiagn.com




Fig. 2: Automatic Transmission Fluid Pump Rotor Package
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

A/Trans Fluid Pump Rotor Package

Callout	Quantity	Component Name
5	1	A/Trans Fluid Pump Seal
9	1	A/Trans Connector Seal
10	2	A/Trans Connector (O-Ring) Seal
18	1	A/Trans Fluid Pump Seal Assembly
19	1	A/Trans Fluid Pump Seal Assembly
20	1	Center Support Fluid Passage Seal Assembly
201	1	Torque Converter Fluid Seal Assembly
205	2	A/Trans Fluid Cooler Pipe Fitting
207	1	A/Trans Fluid Pump Vane Ring
208	1	A/Trans Fluid Pump Rotor Guide
209	1	A/Trans Fluid Pump Slide Fluid Seal Ring
210	1	A/Trans Fluid Pump Slide (O-Ring) Seal

cardiagn.com

Callout	Quantity	Component Name
211	1	A/Trans Fluid Pump Slide Outer Spring
213	1	A/Trans Fluid Pump Slide Seal
214	1	A/Trans Fluid Pump Slide Seal Support
215	1	A/Trans Fluid Pump Slide Pivot Pin
216	13	A/Trans Fluid Pump Vane
217	1	A/Trans Fluid Pump Rotor
230	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
238	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
443	1	Turbine Shaft (O-Ring) Seal

A/Trans Service Seal Kit




Fig. 3: Automatic Transmission Service Seal Kit
Courtesy of GENERAL MOTORS COMPANY

A/Trans Service Seal Kit

Callout	Quantity	Component Name
5	1	A/Trans Fluid Pump Seal
9	1	A/Trans Connector Seal

cardiagn.com

Callout	Quantity	Component Name
10	2	A/Trans Connector (O-Ring) Seal
18	1	A/Trans Fluid Pump Seal Assembly
19	1	A/Trans Fluid Pump Seal Assembly
20	1	Center Support Fluid Passage Seal Assembly
33	1	A/Trans Case Extension Seal
36	1	Prop Shaft Front Slip Yoke Oil Seal
201	1	Torque Converter Fluid Seal Assembly
205	2	A/Trans Fluid Cooler Pipe Fitting Seal
209	1	A/Trans Fluid Pump Slide Fluid Seal Ring
210	1	A/Trans Fluid Pump Slide (O-Ring) Seal
213	1	A/Trans Fluid Pump Slide Seal
214	1	A/Trans Fluid Pump Slide Seal Support
230	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
306	7	Control Valve Body Ball Check Valve
311	1	Control Solenoid Valve Filter Plate Assembly
411	1	1-2-3-4 Clutch Piston Dam Retaining Ring
415	1	1-2-3-4 Clutch Piston Housing Retaining Ring
418	1	3-5 Reverse Clutch Piston Dam (O-Ring) Seal
419	1	3-5 Reverse Clutch Piston Inner Seal
423	1	1-2-3-4 Clutch Piston Inner Seal
424	1	1-2-3-4 Clutch Piston Housing Seal
425	1	1-2-3-4 Clutch Piston Housing Seal
442	3	Turbine Shaft Fluid Seal Ring
443	1	Turbine Shaft (O-Ring) Seal
468	1	Low Clutch Sprag Seal
478	1	4-5-6 Clutch Dampener Retaining Ring
507	1	Manual Shift Shaft Seal
510	2	Park Pawl Actuator Guide (O-Ring) Seal

Clutch Plate Package

cardiagn.com




Fig. 4: Clutch Plate Package
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

Clutch Plate Package

Callout	Quantity	Component Name
402	4	3-5 Reverse Clutch Plate Assembly
408	5	1-2-3-4 Clutch Plate Assembly
433	6	4-5-6 Clutch Plate Assembly
434	6	4-5-6 Clutch Plate
452	5	2-6 Clutch Plate Assembly
453	5	2-6 Clutch Plate
463	5	Low and Reverse Clutch Plate Assembly

A/Trans Electrical Connector Passage Sleeve Seal Kit

cardiagn.com




Fig. 5: Automatic Transmission Electrical Connector Passage Sleeve Seal Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

A/Trans Electrical Connector Passage Sleeve Seal Kit

Callout	Quantity	Component Name
9	1	A/Trans Connector Seal
10	2	A/Trans Connector (O-Ring) Seal

A/Trans Control Solenoid Valve Assembly Seal Kit

cardiagn.com




Fig. 6: Automatic Transmission Control Solenoid Valve Assembly Seal Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

A/Trans Control Solenoid Valve Assembly Seal Kit

Callout	Quantity	Component Name
9	1	A/Trans Connector Seal
10	2	A/Trans Connector (O-Ring) Seal
18	1	A/Trans Fluid Pump Seal Assembly
19	1	A/Trans Fluid Pump Seal Assembly
20	1	Center Support Fluid Passage Seal Assembly

A/Trans Clutches Seal Kit

cardiagn.com




Fig. 7: Automatic Transmission Clutches Seal Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

A/Trans Clutches Seal Kit

Callout	Quantity	Component Name
418	2	3-5 Reverse Clutch Piston Dam (O-Ring) Seal
419	2	3-5-Reverse Clutch Piston Inner Seal
423	1	1-2-3-4 Clutch Piston Inner Seal
424	1	1-2-3-4 Clutch Piston Housing Seal
425	1	1-2-3-4 Clutch Piston Housing Seal
468	1	Low Clutch Sprag Seal

A/Trans Fluid Pump Cover Package

cardiagn.com




Fig. 8: Automatic Transmission Fluid Pump Cover Package
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

A/Trans Fluid Pump Cover Package

Callout	Quantity	Component Name
5	1	A/Trans Fluid Pump Seal
9	1	A/Trans Connector Seal
10	2	A/Trans Connector (O-Ring) Seal
18	1	A/Trans Fluid Pump Seal Assembly
19	1	A/Trans Fluid Pump Seal Assembly
20	1	Center Support Fluid Passage Seal Assembly
201	1	Torque Converter Fluid Seal Assembly
205	2	A/Trans Fluid Cooler Pipe Fitting
219	1	A/Trans Fluid Pump Cover Assembly
229	1	1-2-3-4 and 3-5 Reverse Clutch Housing Thrust Washer
230	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
443	1	Turbine Shaft (O-Ring) Seal

cardiagn.com

Low Clutch Sprag Kit




Fig. 9: Low Clutch Sprag Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

Low Clutch Sprag Kit

Callout	Quantity	Component Name
466	1	Low Clutch Sprag Seal
467	1	Low Clutch Sprag Assembly
468	1	Low Clutch Sprag Seal

Control Solenoid Valve Filter Plate Kit

cardiagn.com




Fig. 10: Control Solenoid Valve Filter Plate Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

Control Solenoid Valve Filter Plate Kit

Callout	Quantity	Component Name
9	1	A/Trans Connector Seal
10	2	A/Trans Connector (O-Ring) Seal
18	1	A/Trans Fluid Pump Seal Assembly
19	1	A/Trans Fluid Pump Seal Assembly
20	1	Center Support Fluid Passage Seal Assembly
306	7	Control Valve Body Ball Check Valve
311	1	Filter Plate Assembly

Retaining Ring Package

cardiagn.com




Fig. 11: Retaining Ring Package
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

Retaining Ring Package

Callout	Quantity	Component Name
411	1	1-2-3-4 Clutch Piston Dam Retaining Ring
415	1	1-2-3-4 Clutch Piston Housing Retaining Ring
478	1	4-5-6 Clutch Dampener Retaining Ring

1-2-3-4& 3-5 Reverse Clutch Fluid Seal Ring Kit

cardiagn.com




Fig. 12: 1-2-3-4 And 3-5 Reverse Clutch Fluid Seal Ring Kit
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

1-2-3-4& 3-5 Reverse Clutch Fluid Seal Ring Kit

Callout	Quantity	Component Name
230	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring
238	3	1-2-3-4 and 3-5 Reverse Clutch Fluid Seal Ring

1-2-3-4& 3-5 Reverse Clutch Kit




Fig. 13: 1-2-3-4 And 3-5 Reverse Clutch Kit

cardiagn.com

Courtesy of GENERAL MOTORS COMPANY

1-2-3-4& 3-5 Reverse Clutch Kit

Callout	Quantity	Component Name
427	1	1-2-3-4 and 3-5 Reverse Clutch Housing Assembly
428	1	1-2-3-4 and 3-5 Reverse Clutch Bearing Assembly

Manual Shift Shaft Hole Plug




Fig. 14: Manual Shift Shaft Hole Plug
Courtesy of GENERAL MOTORS COMPANY

NOTE: **Callouts with boxes around them indicate part is included in the service kit. Callouts without boxes are shown for relationship purposes only.**

Manual Shift Shaft Hole Plug

Callout	Quantity	Component Name
11	1	Manual Shift Shaft Hole Plug

Article GUID: A00854529

cardiagn.com