2008.50 Mondeo

Workshop Manual

Table of Contents

GROUP 1 General Information

Service Information

General Information 100-00
Identification Codes 100-01
Jacking and Lifting 100-02
Noise, Vibration and Harshness 100-04

GROUP 2 Chassis

Suspension

Suspension System - General Information 204-00
Front Suspension 204-01
Rear Suspension 204-02
Wheels and Tires 204-04
Vehicle Dynamic Suspension 204-05

Driveline

Front Drive Halfshafts 205-04

Brake System

Brake System - General Information 206-00
Front Disc Brake 206-03
Rear Disc Brake 206-04
Parking Brake and Actuation 206-05
Hydraulic Brake Actuation 206-06
Power Brake Actuation 206-07
Anti-Lock Control 206-09

Steering System

Steering System - General Information 211-00
Power Steering 211-02
Steering Linkage 211-03
Steering Column 211-04
Steering Column Switches 211-05

GROUP 3 Powertrain

Engine

Engine - 2.3L Duratec-HE (MI4) 303-01
Engine Cooling - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-03
Fuel Charging and Controls - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-04
Accessory Drive - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-05
Starting System - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-06
Engine Ignition - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-07
Engine Emission Control - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-08
Intake Air Distribution and Filtering - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 303-12
Evaporative Emissions 303-13
Electronic Engine Controls - 2.3L Duratec-HE (MI4) 303-14

Automatic Transmission/Transaxle

Automatic Transmission/Transaxle - Vehicles With: 6-Speed Automatic Transaxle (AWF21) 307-01
Transmission/Transaxle Cooling - Vehicles With: 6-Speed Automatic Transaxle (AWF21) 307-02
Automatic Transmission/Transaxle External Controls - Vehicles With: 6-Speed Automatic Transaxle (AWF21) 307-05

Exhaust System

Exhaust System - 2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4) 309-00

Fuel System

Fuel System - General Information 310-00

Fuel Tank and Lines 310-01
Acceleration Control 310-02
Speed Control 310-03

GROUP 4 Electrical

Climate Control System
Climate Control System - General Information 412-00
Climate Control 412-01
Auxiliary Climate Control 412-02
Instrumentation and Warning Systems
Instrument Cluster and Panel Illumination 413-00
Instrument Cluster 413-01
Horn 413-06
Clock 413-07
Information and Message Center 413-08
Warning Devices 413-09
Parking Aid 413-13
Battery and Charging System
Charging System - General Information 414-00
Battery, Mounting and Cables 414-01
Generator and Regulator 414-02
Information and Entertainment Systems
Information and Entertainment System - General Information 415-00
Information and Entertainment System 415-01
Lighting
Exterior Lighting 417-01
Interior Lighting 417-02
Electrical Distribution
Module Communications Network 418-00
Module Configuration 418-01
Electronic Feature Group
Anti-Theft - Active 419-01A
Anti-Theft - Passive 419-01B
Multifunction Electronic Modules 419-10

GROUP 5 Body and Paint

Body and Paint
Front End Body Panels 501-02
Body Closures 501-03
Interior Trim and Ornamentation 501-05
Rear View Mirrors 501-09
Seating 501-10
Glass, Frames and Mechanisms 501-11
Instrument Panel and Console 501-12
Handles, Locks, Latches and Entry Systems 501-14
Wipers and Washers 501-16
Roof Opening Panel 501-17
Bumpers 501-19
Safety Belt System 501-20A
Supplemental Restraint System 501-20B
Body Repairs - General Information 501-25
Body Repairs - Vehicle Specific Information and Tolerance Checks 501-26
Front End Sheet Metal Repairs 501-27
Roof Sheet Metal Repairs 501-28
Side Panel Sheet Metal Repairs 501-29
Rear End Sheet Metal Repairs 501-30
Paint - General Information 501-36
Frame and Mounting
Uni-Body, Subframe and Mounting System 502-00

To the best of our knowledge, the illustrations, technical information, data and descriptions in this issue were correct at the time of going to print. The right to change prices, specifications, equipment and maintenance instructions at any time without notice is reserved as part of FORD policy of continuous development and improvement for the benefit of our customers.

No part of this publication may be reproduced, stored in a data processing system or transmitted in any form, electronic, mechanical, photocopy, recording, translation or by any other means without prior permission of Ford-Werke Aktiengesellschaft. No liability can be accepted for any inaccuracies in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Copyright ©

FORD-WERKE AKTIENGESELLSCHAFT

Service training programs D-F/GT-1

Printed in Germany - rewi druckhaus, Wissen
-

Printed on environmentally friendly chlorine-free paper. (GB)

GROUP

1

General Information

SECTION TITLE PAGE

Service Information
General Information.....100-00
Identification Codes.....100-01
Jacking and Lifting.....100-02
Noise, Vibration and Harshness.....100-04

GROUP

2 Chassis

SECTION TITLE PAGE

Suspension
- Suspension System - General Information....204-00
- Front Suspension....204-01
- Rear Suspension....204-02
- Wheels and Tires....204-04
- Vehicle Dynamic Suspension....204-05

Driveline
- Front Drive Halfshafts....205-04

Brake System
- Brake System - General Information....206-00
- Front Disc Brake....206-03
- Rear Disc Brake....206-04
- Parking Brake and Actuation....206-05
- Hydraulic Brake Actuation....206-06
- Power Brake Actuation....206-07
- Anti-Lock Control....206-09

Steering System
- Steering System - General Information....211-00
- Power Steering....211-02
- Steering Linkage....211-03
- Steering Column....211-04
- Steering Column Switches....211-05

GROUP

3

Powertrain

SECTION TITLE PAGE

Engine

Engine2.3L Duratec-HE (MI4).....303-01
Engine Cooling2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-03
Fuel Charging and Controls2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-04
Accessory Drive2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-05
Starting System2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-06
Engine Ignition2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-07
Engine Emission Control2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-08
Intake Air Distribution and Filtering2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....303-12
Evaporative Emissions.....303-13
Electronic Engine Controls2.3L Duratec-HE (MI4).....303-14

Automatic Transmission/Transaxle

Automatic Transmission/TransaxleVehicles With: 6-Speed Automatic Transaxle (AWF21).....307-01
Transmission/Transaxle CoolingVehicles With: 6-Speed Automatic Transaxle (AWF21).....307-02
Automatic Transmission/Transaxle External ControlsVehicles With: 6-Speed Automatic Transaxle (AWF21).....307-05

Exhaust System

Exhaust System2.0L Duratec-HE (MI4)/2.3L Duratec-HE (MI4).....309-00

Fuel System

Fuel System - General Information.....310-00
Fuel Tank and Lines.....310-01
Acceleration Control.....310-02
Speed Control.....310-03

GROUP

4

Electrical

SECTION TITLE PAGE

Climate Control System
Climate Control System - General Information....412-00
Climate Control....412-01
Auxiliary Climate Control....412-02

Instrumentation and Warning Systems
Instrument Cluster and Panel Illumination....413-00
Instrument Cluster....413-01
Horn....413-06
Clock....413-07
Information and Message Center....413-08
Warning Devices....413-09
Parking Aid....413-13

Battery and Charging System
Charging System - General Information....414-00
Battery, Mounting and Cables....414-01
Generator and Regulator....414-02

Information and Entertainment Systems
Information and Entertainment System - General Information....415-00
Information and Entertainment System....415-01

Lighting
Exterior Lighting....417-01
Interior Lighting....417-02

Electrical Distribution
Module Communications Network....418-00
Module Configuration....418-01

Electronic Feature Group
Anti-Theft - Active....419-01A
Anti-Theft - Passive....419-01B
Multifunction Electronic Modules....419-10

GROUP

5

Body and Paint

SECTION TITLE PAGE

Body and Paint

Front End Body Panels....501-02
Body Closures....501-03
Interior Trim and Ornamentation....501-05
Rear View Mirrors....501-09
Seating....501-10
Glass, Frames and Mechanisms....501-11
Instrument Panel and Console....501-12
Handles, Locks, Latches and Entry Systems....501-14
Wipers and Washers....501-16
Roof Opening Panel....501-17
Bumpers....501-19
Safety Belt System....501-20A
Supplemental Restraint System....501-20B
Body Repairs - General Information....501-25
Body Repairs - Vehicle Specific Information and Tolerance Checks....501-26
Front End Sheet Metal Repairs....501-27
Roof Sheet Metal Repairs....501-28
Side Panel Sheet Metal Repairs....501-29
Rear End Sheet Metal Repairs....501-30
Paint - General Information....501-36

Frame and Mounting

Uni-Body, Subframe and Mounting System....502-00