2007 WQ Fiesta
(including XR4)

Repair Manual

NOTE: ***All references to "gasoline" or "gas" (US terminology) in this manual should be read as "petrol" and NOT as "LPG".***

PART No. WSM 110

Registered at the National Library, Canberra, ACT Australia

ISBN 1 921140 151 (Set)
ISBN 1 921140 16X (Volume 1)
ISBN 1 921140 178 (Volume 2)
ISBN 1 921140 186 (Volume 3)

© 2007 Ford Motor Company of Australia Ltd.
Registered Office: CAMPBELLFIELD, VICTORIA
A.B.N. 30 004 116 223

Reproduction in whole or in part is prohibited without written approval.

PRINTED IN AUSTRALIA. May 2007

CONTENTS

TITLE	SECTION
VOLUME 1	
GENERAL INFORMATION	**Group 1**
General Information	100
CHASSIS	**Group 2**
Suspension	204
Driveline	205
Brake System	206
Steering System	211
POWERTRAIN	**Group 3**
Engine	303
Transmission / Transaxle, Clutch and Transfer Case	308
Exhaust System	309
Fuel System	310
VOLUME 2	
ELECTRICAL	**Group 4**
Climate Control System	412
Instrumentation and Warning Systems	413
Battery and Charging System	414
Entertainment Systems	415
Lighting	417
Electrical Distribution	418
Electronic Feature Group	419
BODY AND PAINT	**Group 5**
VOLUME 3	
Body	501
Frame and Mounting	502
WIRING DIAGRAMS	**APPENDICES**

2006.0 Fiesta

Workshop Manual

Table of Contents

GROUP 1 General Information

Service Information

General Information	100-00
Identification Codes	100-01
Jacking and Lifting	100-02
Noise, Vibration and Harshness	100-04

GROUP 2 Chassis

Suspension

Suspension System - General Information	204-00
Front Suspension	204-01
Rear Suspension	204-02
Wheels and Tires	204-04

Driveline

Front Drive Halfshafts	205-04

Brake System

Brake System - General Information	206-00
Drum Brake	206-02
Front Disc Brake	206-03
Rear Disc Brake	206-04
Parking Brake and Actuation	206-05
Hydraulic Brake Actuation	206-06
Power Brake Actuation	206-07
Anti-Lock Control	206-09A
Anti-Lock Control - Traction Control	206-09B
Anti-Lock Control - Stability Assist	206-09C

Steering System

Steering System - General Information	211-00
Power Steering	211-02
Steering Linkage	211-03
Steering Column	211-04
Steering Column Switches	211-05

GROUP 3 Powertrain

Engine

Engine System - General Information	303-00
Engine - 1.25L Duratec-16V (Sigma)/1.4L Duratec-16V (Sigma)/1.6L Duratec-16V (Sigma)	303-01A
Engine - 2.0L Duratec-HE (MI4)	303-01B
Engine Cooling - 1.3L Duratec-8V (Rocam)/1.25L Duratec-16V (Sigma)/1.4L Duratec-16V (Sigma)/1.6L Duratec-16V (Sigma)	303-03A
Engine Cooling - 2.0L Duratec-HE (MI4)	303-03B
Fuel Charging and Controls - 1.25L Duratec-16V (Sigma)/1.4L Duratec-16V (Sigma)/1.6L Duratec-16V (Sigma)	303-04A
Fuel Charging and Controls - 2.0L Duratec-HE (MI4)	303-04B
Accessory Drive	303-05
Starting System	303-06
Engine Ignition	303-07A
Engine Ignition - 2.0L Duratec-HE (MI4)	303-07B
Engine Emission Control - 1.3L Duratec-8V (Rocam)/1.25L Duratec-16V (Sigma)/1.4L Duratec-16V (Sigma)/1.6L Duratec-16V (Sigma)	303-08A
Engine Emission Control - 2.0L Duratec-HE (MI4)	303-08B

Intake Air Distribution and Filtering 303-12
Evaporative Emissions 303-13
Electronic Engine Controls 303-14

Automatic Transmission/Transaxle

Automatic Transmission/Transaxle - Vehicles With: 4-Speed Automatic Transmission (AW81-40) 307-01
Transmission/Transaxle Cooling - Vehicles With: 4-Speed Automatic Transmission (AW81-40) 307-02
Automatic Transmission/Transaxle External Controls - Vehicles With: 4-Speed Automatic Transmission (AW81-40) 307-05

Manual Transmission/Transaxle, Clutch and Transfer Case

Manual Transmission/Transaxle and Clutch - General Information 308-00
Clutch 308-01
Clutch Controls 308-02
Manual Transmission/Transaxle 308-03
Manual Transmission/Transaxle External Controls 308-06

Exhaust System

Exhaust System 309-00

Fuel System

Fuel System - General Information 310-00
Fuel Tank and Lines 310-01
Acceleration Control - 1.3L Duratec-8V (Rocam)/1.25L Duratec-16V (Sigma)/1.4L Duratec-16V (Sigma)/1.6L Duratec-16V (Sigma) 310-02A
Acceleration Control - 2.0L Duratec-HE (MI4) 310-02B

GROUP 4 Electrical

Climate Control System

Climate Control System - General Information 412-00
Air Distribution and Filtering 412-01
Heating and Ventilation 412-02
Air Conditioning 412-03
Control Components 412-04

Instrumentation and Warning Systems

Instrument Cluster and Panel Illumination 413-00
Instrument Cluster 413-01
Horn 413-06
Information and Message Center 413-08
Warning Devices 413-09
Parking Aid 413-13

Battery and Charging System

Charging System - General Information 414-00
Battery, Mounting and Cables 414-01
Generator and Regulator 414-02

Information and Entertainment Systems

Information and Entertainment System - General Information 415-00
Audio Unit 415-01
Antenna 415-02

Lighting

Exterior Lighting 417-01
Interior Lighting 417-02

Electrical Distribution

Module Communications Network 418-00
Module Configuration 418-01

Electronic Feature Group

Anti-Theft - Active 419-01A
Anti-Theft - Passive 419-01B
Cellular Phone 419-08
Multifunction Electronic Modules 419-10

GROUP 5 Body and Paint

Body and Paint

Body System - General Information 501-00
Front End Body Panels 501-02
Body Closures 501-03
Interior Trim and Ornamentation 501-05
Exterior Trim and Ornamentation 501-08
Rear View Mirrors 501-09
Seating 501-10
Glass, Frames and Mechanisms 501-11
Instrument Panel and Console 501-12

Handles, Locks, Latches and Entry Systems 501-14
Wipers and Washers 501-16
Bumpers 501-19
Safety Belt System 501-20A
Supplemental Restraint System 501-20B
Body Repairs - General Information 501-25
Body Repairs - Vehicle Specific Information and Tolerance Checks 501-26
Front End Sheet Metal Repairs 501-27
Roof Sheet Metal Repairs 501-28
Side Panel Sheet Metal Repairs 501-29
Rear End Sheet Metal Repairs 501-30
Paint - General Information 501-36

Frame and Mounting

Uni-Body, Subframe and Mounting System 502-00

To the best of our knowledge, the illustrations, technical information, data and descriptions in this issue were correct at the time of going to print. The right to change prices, specifications, equipment and maintenance instructions at any time without notice is reserved as part of FORD policy of continuous development and improvement for the benefit of our customers.

No part of this publication may be reproduced, stored in a data processing system or transmitted in any form, electronic, mechanical, photocopy, recording, translation or by any other means without prior permission of Ford-Werke Aktiengesellschaft. No liability can be accepted for any inaccuracies in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Copyright ©

FORD-WERKE AKTIENGESELLSCHAFT

Service training programs D-F/GT-1

Printed in Germany - rewi druckhaus, Wissen
-

Printed on environmentally friendly chlorine-free paper. (GB)

GROUP

1

General Information

SECTION TITLE PAGE

Service Information

General Information.....100-00
Identification Codes.....100-01
Jacking and Lifting.....100-02
Noise, Vibration and Harshness.....100-04

GROUP

2

Chassis

SECTION TITLE	PAGE
Suspension	
Suspension System - General Information	204-00
Front Suspension	204-01
Rear Suspension	204-02
Wheels and Tires	204-04
Driveline	
Front Drive Halfshafts	205-04
Brake System	
Brake System - General Information	206-00
Drum Brake	206-02
Front Disc Brake	206-03
Rear Disc Brake	206-04
Parking Brake and Actuation	206-05
Hydraulic Brake Actuation	206-06
Power Brake Actuation	206-07
Anti-Lock Control	206-09A
Anti-Lock Control - Traction Control	206-09B
Anti-Lock Control - Stability Assist	206-09C
Steering System	
Steering System - General Information	211-00
Power Steering	211-02
Steering Linkage	211-03
Steering Column	211-04
Steering Column Switches	211-05