
HOW TO READ THE WIRING DIAGRAMS

CONTENTS

MODELS	2	ABBREVIATION SYMBOLS	2
--------------	---	----------------------------	---



1-2 HOW TO READ THE WIRING DIAGRAMS – Models/Abbreviation Symbols

MODELS

Model code		Engine model	Transmission model	Fuel supply system		
K96WG	NHEL6	6G72-SOHC (2,972 mL)	V5MT1 (4WD-5M/T)	MPI		
	NHER6		V4A51 (4WD-4A/T)			
	RHEL6					
	RHER6					
K94W	NUFL6	4D56 (2,477 mL) <Emission regulation- step III>	V5MT1 (4WD-5M/T)	Fuel injection		
	NUFR6					
	NUPFL6	4D56 (2,477 mL) <Emission regulation- step II>				
	NUPFR6					
K94WG	NHFL6	4D56 (2,477 mL) <Emission regulation- step III>				
	NHFR6					
	NHPFL6	4D56 (2,477 mL) <Emission regulation- step II>				
	NHPFR6					

ABBREVIATION SYMBOLS

Abbreviation symbols	Meaning
VG	Variable geometry
VGT	Variable geometry turbocharger