

## List of components 1:6

|       |                                                      |          |                                            |
|-------|------------------------------------------------------|----------|--------------------------------------------|
| 1/1   | Battery                                              | 3/111    | Light Switch Module (LSM)                  |
|       |                                                      | 3/112    | Climate Control Module (CCM)               |
| 2/16  | Relay, rear window wiper                             | 3/117    | Switch unit, ceiling light                 |
| 2/17  | Relay, horn                                          | 3/126    | Driver Door Module (DDM)                   |
| 2/22  | Relay, climate control system                        | 3/127    | Passenger Door Module (PDM)                |
| 2/23  | Relay, fuel pump                                     | 3/128    | Rear Left Door Module (LDM)                |
| 2/32  | Main relay, engine management system                 | 3/129    | Rear Right Door Module (RDM)               |
|       |                                                      | 3/155    | Program selector, automatic transmission   |
| 2/34  | Relay, front fog lights                              |          |                                            |
| 2/35  | Relay, starter motor                                 | 3/156    | Gear Selector Module (GSM)                 |
| 2/63  | Relay, high beam                                     | 3/157    | Switch, passenger side airbag              |
| 2/64  | Relay, auxiliary lights (accessory)                  | 3/173    | Switch, trunk lid/tailgate private lock    |
| 2/80  | Relay, reversing light                               | 3/174    | Switch, reduced alarm                      |
| 2/82  | Relay, heated rear window                            | 3/217    | Belt buckle contact, rear left             |
| 2/89  | Relay, interior lighting                             | 3/218    | Belt buckle contact, center rear           |
| 2/92  | Relay, windshield washer motor                       | 3/219    | Belt buckle contact, rear right            |
| 2/93  | Relay, rear window washer motor                      | 3/254    | Steering Wheel Module (SWM)                |
| 2/142 | Fuel filter preheater relay                          | 3/255    | Position sensor, driver's seat             |
| 2/157 | Relay, subwoofer control module                      | 3/256    | Position sensor, passenger seat            |
| 2/159 | Relay, infotainment                                  | 3/258    | Contact, locking front left                |
| 2/182 | Relay, headlight washer motor                        | 3/259    | Contact, locking, front right              |
| 2/192 | Relay, electric engine heater, 4-cyl.                | 3/260    | Contact, locking, rear left                |
| 2/192 | Relay, electric engine heater, 5-cyl.                | 3/261    | Contact, locking, rear right               |
| 2/193 | Relay, comfort functions                             | 3/262    | Contact, unlocking, front left             |
| 2/238 | Relay, audio disconnection                           | 3/263    | Contact, unlocking, front right            |
|       |                                                      | 3/264    | Contact, unlocking, rear left              |
| 3/1   | Ignition switch                                      | 3/265    | Contact, unlocking, rear right             |
| 3/4   | Switch unit, cruise control (SWS)                    | 3/267    | Switch unit, telematics                    |
| 3/6   | Switch, hazard warning flashers                      | 3/268    | Load assistance switch                     |
| 3/8   | Switch, heated rear window/exterior rearview mirrors | 3/271    | Contact, immobilizer, clutch pedal         |
|       |                                                      | 3/286    | BLIS switch                                |
| 3/9   | Contact brake light                                  |          |                                            |
| 3/10  | Reversing light contact                              | 4/7      | Combustion Preheater Module (CPM)          |
| 3/25  | Switch, power sunroof                                | 4/9      | Supplemental Restraint System Module (SRS) |
| 3/25  | Switch, power roof, C70                              |          |                                            |
| 3/26  | Switch unit, power driver's seat                     | 4/16     | Brake Control Module (BCM)                 |
| 3/27  | Switch unit, power passenger seat                    | 4/28     | Transmission Control Module (TCM)          |
| 3/35  | Switch, handle, trunk lid/tailgate                   | 4/31     | Fan control module                         |
| 3/37  | Contact horn                                         | 4/33     | Sunroof control module                     |
| 3/39  | Clutch pedal contact                                 | 4/46.1   | Engine Control Module (ECM), 5-cyl         |
| 3/46  | Seat contact, passenger seat                         | 4/46.2   | Engine Control Module (ECM), 5-cyl. Turbo  |
| 3/47  | Parking brake contact                                | 4/46.3   | Engine Control Module (ECM), 5-cyl. 2.4l D |
| 3/60  | Switch, auxiliary lights                             | 4/46.4   | Engine Control Module (ECM), 4-cyl. 2.0l D |
| 3/62  | Hood alarm contact                                   | 4/46.5   | Engine Control Module (ECM), 4-cyl. 1.6l D |
| 3/74  | Lock unit, driver's door                             | 4/46.6   | Engine Control Module (ECM), 4-cyl. 1.8l   |
| 3/75  | Lock unit, passenger door                            | 4/46.7   | Engine Control Module (ECM), 4-cyl. 1.6l   |
| 3/76  | Lock unit, rear left door                            | 4/52     | Power Seat Module (PSM)                    |
| 3/77  | Lock unit, rear right door                           | 4/56     | Central Electronic Module (CEM)            |
| 3/78  | Lock unit, trunk lid/tailgate                        | 4/56 A-H | Central Electronic Module (CEM)            |
| 3/80  | Switch, central locking driver's door                | 4/59     | Convertible Roof Module (CRM)              |
| 3/81  | Power window switches, driver's door                 | 4/71     | Cooling fan control module                 |
| 3/82  | Switch, central locking passenger door               | 4/78     | Accessory Electronic Module (AEM)          |
| 3/83  | Switch, power window passenger door                  | 4/82     | Differential Electronic Module (DEM)       |
| 3/85  | Power window switch, rear left door                  | 4/83     | Control module fuel pump                   |
| 3/86  | Power window switch, rear right door                 | 4/86     | Parking Assistance Module (PAM)            |
| 3/93  | Belt buckle contact, driver's seat                   | 4/93     | Keyless Vehicle Module (KVM)               |
| 3/94  | Belt buckle contact, passenger seat                  |          |                                            |

## List of components 2:6

|       |                                                   |       |                                                   |
|-------|---------------------------------------------------|-------|---------------------------------------------------|
| 4/102 | Steering Column Lock Module (SCL)                 | 6/103 | Damper Motor Module (DMM), floor/ventilation      |
| 4/103 | Remote Receiver Module (RRX)                      | 6/104 | High pressure headlight washer motor              |
| 4/103 | Signal receiver, keyless vehicle (RKE)            | 6/114 | Vacuum pump                                       |
| 4/109 | Glow plug control module                          | 6/117 | Interior temperature sensor                       |
| 4/110 | Trailer Module (TRM)                              | 6/118 | Regulator motor, swirl throttle                   |
| 4/111 | Additive Dosing Module (ADM)                      | 6/120 | Engine throttle body                              |
| 4/112 | Control module, gas discharge lamp master, left   | 6/143 | Regulator motor, Turbo                            |
| 4/113 | Control module, gas discharge lamp slave, right   | 6/149 | Electric catch motor                              |
| 4/126 | Left Camera Module (LCM)                          | 6/155 | Pump unit, roof operation                         |
| 4/127 | Right Camera Module (RCM)                         | 7/4   | Brake fluid level sensor                          |
| 5/1   | Driver Information Module (DIM)                   | 7/5   | Washer fluid level sensor                         |
| 6/1   | Wiper Motor Module (WMM)                          | 7/6   | Oil pressure monitor, 4-cyl                       |
| 6/2   | Washer pump                                       | 7/6   | Oil pressure monitor, 5-cyl                       |
| 6/16  | Motor driver's seat, backrest angle               | 7/6   | Oil pressure monitor, Turbo                       |
| 6/17  | Motor driver's seat, up/down front edge           | 7/6   | Oil pressure monitor, Diesel                      |
| 6/18  | Motor driver's seat, up/down rear edge            | 7/8   | Pressure sensor, climate control system           |
| 6/19  | Motor driver's seat, fore/aft                     | 7/12  | Solar sensor, twilight sensor and indicator alarm |
| 6/20  | Motor passenger seat, fore/aft                    | 7/15  | Heated oxygen sensor, front                       |
| 6/25  | Starter motor                                     | 7/16  | Sensor, coolant temperature                       |
| 6/26  | Alternator                                        | 7/17  | Mass air flow sensor (MAF), 5-cyl                 |
| 6/28  | Motor, passenger compartment fan                  | 7/17  | Mass air flow sensor (MAF), Turbo                 |
| 6/29  | Motor, electric cooling fan                       | 7/21  | Camshaft position sensor                          |
| 6/32  | Rear window wiper motor                           | 7/24  | Front knock sensor, 4-cyl                         |
| 6/33  | Fuel pump                                         | 7/24  | Front knock sensor, 5-cyl                         |
| 6/35  | Fuel pump, auxiliary heater                       | 7/24  | Front knock sensor, Turbo                         |
| 6/37  | Lock motor, fuel filler flap                      | 7/25  | Impulse sensor, 4-cyl                             |
| 6/38  | Motor, left headlight adjustment                  | 7/25  | Impulse sensor, 5-cyl                             |
| 6/39  | Motor, right headlight adjustment                 | 7/25  | Impulse sensor, Turbo                             |
| 6/48  | Damper Motor Module (DMM), recirculation          | 7/25  | Impulse sensor, Diesel                            |
| 6/62  | Power rear-view mirror driver's door              | 7/31  | Sensor ABS, front left                            |
| 6/63  | Power passenger door mirror                       | 7/32  | Sensor ABS, front right                           |
| 6/64  | Motor, passenger seat backrest angle              | 7/41  | Temperature sensor evaporator                     |
| 6/65  | Motor, passenger seat, front edge up/down         | 7/51  | Accelerator pedal sensor                          |
| 6/66  | Motor passenger seat, up/down rear edge           | 7/56  | Sensor ABS, rear left                             |
| 6/67  | Pump, fuel leakage control                        | 7/57  | Sensor ABS, rear right                            |
| 6/71  | Electrical Power Steering Module (EPS)            | 7/61  | Sensor input speed                                |
| 6/73  | Coolant pump, auxiliary heater                    | 7/62  | Sensor output speed                               |
| 6/95  | Damper Motor Module (DMM), temperature, left side | 7/69  | Sensor outdoor temperature                        |
| 6/96  | Damper Motor Module (DMM), right-hand side        | 7/71  | Sensor boost pressure                             |
| 6/99  | Engine EGR                                        | 7/74  | Sensor oil temperature, automatic transmission    |
| 6/102 | Damper Motor Module (DMM), defroster              | 7/77  | Temperature sensor, intake air 1                  |
|       |                                                   | 7/77  | Temperature sensor, intake air 2                  |
|       |                                                   | 7/81  | Pressure sensor, intake manifold                  |
|       |                                                   | 7/82  | Heated oxygen sensor, rear                        |
|       |                                                   | 7/86  | Intake air temperature sensor, Diesel             |
|       |                                                   | 7/93  | Occupant Weight Sensor (OWS)                      |

## List of components 3:6

|        |                                                                 |        |                                                |
|--------|-----------------------------------------------------------------|--------|------------------------------------------------|
| 7/100  | Level sensor alarm, S40                                         | 8/3    | Electromagnetic clutch, climate control system |
| 7/100  | Level sensor alarm, V50                                         |        |                                                |
| 7/100  | Level sensor, alarm, C70                                        | 8/6-10 | Injection valves                               |
| 7/108  | Side impact sensor, rear left                                   | 8/18   | EVAP valve                                     |
| 7/109  | Side impact sensor, rear right                                  | 8/19   | Solenoid, variable valve timing, intake        |
| 7/110  | Sensor temperature driver's seat                                | 8/28   | Turbocharger control valve                     |
| 7/111  | Sensor temperature passenger seat                               | 8/30   | Airbag igniter, driver's side                  |
| 7/115  | Side impact sensor, left B-post                                 | 8/31   | Airbag igniter, passenger side                 |
| 7/116  | Side impact sensor, right B-post                                | 8/32   | Igniter, airbag stage 2, passenger side        |
| 7/120  | Angle sensor, Bi-Xenon rear                                     | 8/33   | Igniter, belt tensioner, driver's side         |
| 7/121  | Angle sensor, Bi-Xenon front                                    | 8/34   | Igniter, belt tensioner, passenger side        |
| 7/122  | Mass Movement Sensor module (MMS), front, S40/V50               | 8/36   | Solenoid shift lock                            |
| 7/122  | Mass Movement Sensor module (MMS), front, C70                   | 8/37   | Automatic transmission                         |
| 7/123  | Clutch pedal sensor                                             | 8/38   | Shift solenoid 1                               |
| 7/124  | Sensor brake pedal                                              | 8/39   | Shift solenoid 2                               |
| 7/130  | Fuel level sensor, ejector side                                 | 8/40   | Lock-up solenoid                               |
| 7/131- |                                                                 | 8/41   | Pressure solenoid                              |
| 7/134  | Rear parking assistance sensor                                  | 8/45   | Solenoid, variable valve timing, intake        |
| 7/143  | Sensor fuel level, pump side                                    | 8/48   | Auto-dimming rearview mirror                   |
| 7/149  | Rain Sensor Module (RSM)                                        | 8/51   | Igniter side airbag, driver's side             |
| 7/154  | Sensor fuel temperature                                         | 8/52   | Igniter side airbag, passenger side            |
| 7/156  | Fuel pressure and temperature sensor, 5-cyl                     | 8/55   | Igniter, rear left belt tensioner              |
| 7/156  | Pressure and temperature sensor fuel, Turbo                     | 8/56   | Igniter, rear right belt tensioner             |
| 7/158  | Rear mass movement sensor, S40/V50                              | 8/57   | Igniter, left anti-roll bar                    |
| 7/158  | Rear mass movement sensor, C70                                  | 8/58   | Igniter, right anti-roll bar                   |
| 7/159  | Air Quality Sensor (AQS)                                        | 8/61   | Igniter, airbag stage 2, driver's side         |
| 7/162  | Pressure sensor, fuel line                                      | 8/65   | Pressure monitor, power steering, S40-V50      |
| 7/163  | Camshaft position sensor 2                                      | 8/66   | Igniter, left inflatable curtain, S40/V50      |
| 7/164  | Body Sensor Cluster Stability Sensor (BSC)                      | 8/66   | Igniter, left inflatable curtain, C70          |
| 7/165  | Pressure and temperature sensor, intake manifold                | 8/67   | Igniter, right inflatable curtain, S40/V50     |
| 7/166  | Oil level sensor                                                | 8/67   | Igniter, right inflatable curtain, C70         |
| 7/172  | Position sensor camshaft, intake side                           | 8/71   | Throttle solenoid                              |
| 7/173  | Position sensor camshaft, exhaust side                          | 8/72   | Shift solenoid 3                               |
| 7/174  | Differential pressure sensor, particle filter                   | 8/73   | Shift solenoid 4                               |
| 7/178  | Front impact sensor, right                                      | 8/74   | Shift solenoid 5                               |
| 7/179  | Front impact sensor, left                                       | 8/77   | Control valve, fuel volume                     |
| 7/182  | Remote control IR sensor, RTI                                   | 8/81   | Solenoid, variable valve timing outlet         |
| 7/186  | Heated oxygen sensor, rear                                      | 8/82   | Solenoid, variable turbo geometry              |
| 7/187  | Center heated oxygen sensor                                     | 8/84   | Switch, vacuum pump                            |
| 7/190  | Temperature sensor, exhaust gases upstream of particle filter   | 8/92   | Lap belt tensioner, driver                     |
| 7/191  | Temperature sensor, exhaust gases downstream of particle filter | 8/98   | Control valve fuel pressure                    |
| 7/192  | Water detection sensor                                          | 8/99   | Igniter, steering column                       |
| 7/193  | Position sensor turbo                                           | 8/111  | High-pressure solenoid valve, Diesel           |
| 7/194  | Sensor belt roller, driver                                      | 8/113  | Bypass valve, EGR cooling                      |
| 7/195  | Sensor belt roller, passenger                                   | 8/114  | Valve mixing air/fuel                          |
| 7/198  | Detector, windshield frame                                      | 8/119  | Pressure monitor, climate control system       |
| 7/204- |                                                                 | 8/120  | EGR valve                                      |
| 7/207  | Front parking assistance sensor                                 | 8/121  | Valve coolant                                  |
| 7/208  | Side impact sensor, left door, C70                              | 8/122  | Bypass valve, intercooler                      |
| 7/209  | Side impact sensor, right door, C70                             | 8/127  | Pressure switch, climate control system        |
| 7/220  | Hall sensor, cargo compartment, C70                             | 8/128  | Driver's belt force limiter                    |
| 7/221  | Position sensor, rear roof section, C70                         | 8/129  | Passenger belt force limiter                   |
| 7/222  | Position sensor, front roof section, C70                        | 8/132  | Control valve inlet                            |
| 7/223  | Cargo compartment detector, C70                                 | 8/133  | Control valve fuel pressure                    |
| 7/224  | Hall sensor, roof, C70                                          | 8/134  | Solenoid, reverse interlock, manual            |
| 7/230  | Sensor, folding of backrest                                     | 8/137  | Lock motor, left door compartment              |
| 7/231  | Sensor, folding of backrest                                     | 8/138  | Lock motor, right door compartment             |
|        |                                                                 | 8/139  | Lock motor, ski hatch                          |
|        |                                                                 | 8/140  | Lock motor, rear left seat compartment         |
|        |                                                                 | 8/141  | Lock motor, rear right seat compartment        |

## List of components 4:6

|        |                                                      |        |                                           |
|--------|------------------------------------------------------|--------|-------------------------------------------|
| 9/1    | Front 12V outlet                                     | 10/25  | Cargo compartment lighting                |
| 9/2    | Heated rear window                                   | 10/26  | Reading light, rear left                  |
| 9/12   | Seat Heating Module (SHM), driver's side             | 10/27  | Reading light, rear right                 |
| 9/13   | Seat Heating Module (SHM), passenger side            | 10/29  | Glove compartment lighting                |
| 9/16   | Heating element, driver's seat backrest              | 10/43  | Right brake light, S40/V50                |
| 9/17   | Heating element, passenger seat backrest             | 10/43  | Right brake light, C70                    |
| 9/18   | Heating element, driver's seat cushion               | 10/44  | Right tail light 1, S40/V50               |
| 9/19   | Heating element, passenger seat cushion              | 10/44  | Right tail light 1, C70                   |
| 9/25   | Rear 12V outlet                                      | 10/45  | Right tail light 2, S40/V50               |
| 9/30   | Auxiliary heater                                     | 10/45  | Right tail light 2, C70                   |
| 9/32   | PTC resistor, oil trap                               | 10/46  | Rear right fog light, S40/V50             |
| 9/33   | Electrically heated rear-view mirror, driver's door  | 10/46  | Rear right fog light, C70                 |
| 9/34   | Electrically heated rear-view mirror, passenger door | 10/47  | Rear right direction indicator, S40/V50   |
| 9/38   | Electrically heated fuel filter                      | 10/47  | Rear right direction indicator, C70       |
| 9/41   | PTC-element                                          | 10/48  | Right reversing light, S40/V50            |
| 9/41.1 | Electric engine heater                               | 10/48  | Right reversing light, C70                |
| 10/1   | Lamp housing, front left                             | 10/50  | Left brake light, S40/V50                 |
| 10/2   | Lamp housing, front right                            | 10/50  | Left brake light, C70                     |
| 10/3   | License plate lighting                               | 10/51  | Left tail light 1, S40/V50                |
| 10/5   | Fog light, front left                                | 10/51  | Left tail light 1, C70                    |
| 10/6   | Fog light, front right                               | 10/52  | Left tail light 2, S40/V50                |
| 10/11  | Position/parking light, front left                   | 10/52  | Left tail light 2, C70                    |
| 10/12  | Position/parking light, front right                  | 10/53  | Rear left fog light, S40/V50              |
| 10/13  | Direction indicator, front left                      | 10/53  | Rear left fog light, C70                  |
| 10/14  | Direction indicator, front right                     | 10/54  | Rear left direction indicator, S40/V50    |
| 10/15  | Direction indicator, rear-view mirror driver's door  | 10/54  | Rear left direction indicator, C70        |
| 10/16  | Direction indicator, passenger door mirror           | 10/55  | Left reversing light, S40/V50             |
| 10/17  | Lamp housing, rear right, S40/V50                    | 10/55  | Left reversing light, C70                 |
| 10/17  | Lamp housing, rear right, C70                        | 10/64  | High beam, right                          |
| 10/18  | Lamp housing, rear left, S40/V50                     | 10/65  | Auxiliary light, front right              |
| 10/18  | Lamp housing, rear left, C70                         | 10/66  | Low beam, right                           |
| 10/19  | Auxiliary brake light, S40/V50                       | 10/68  | High beam, left                           |
| 10/19  | Auxiliary brake light, C70                           | 10/69  | Auxiliary light, front left               |
| 10/22  | Ceiling light, S40/V50                               | 10/70  | Low beam, left                            |
| 10/22  | Ceiling light, C70                                   | 10/97  | Courtesy lighting, left                   |
| 10/24  | Cargo compartment lighting, S40                      | 10/102 | Courtesy lighting, right                  |
| 10/24  | Cargo compartment lighting, C70                      | 10/114 | Vanity mirror lighting, left              |
|        |                                                      | 10/115 | Vanity mirror lighting, right             |
|        |                                                      | 10/148 | Lighting, rear-view mirror driver's door  |
|        |                                                      | 10/149 | Lighting, rear-view mirror passenger door |
|        |                                                      | 10/150 | Rear reading light                        |
|        |                                                      | 10/245 | Lock indicator, left door                 |
|        |                                                      | 10/246 | Lock indicator, right door                |
|        |                                                      | 15/31  | Distribution box in engine compartment    |

## List of components 5:6

|         |                                          |          |                                                 |
|---------|------------------------------------------|----------|-------------------------------------------------|
| 16/1    | Integrated Audio Module (IAM)            | 16/145   | Remote Digital Audio Receiver (RDAR)            |
| 16/1.2  | Infotainment Control Module (ICM)        | 16/150   | AM/FM antenna and amplifier, rear right fender  |
| 16/3    | Speaker, passenger door                  | 16/151   | Distribution filter, front left door            |
| 16/4    | Speaker, driver's door                   | 16/152   | Distribution filter, front right door           |
| 16/5    | Speaker, rear right door                 |          |                                                 |
| 16/6    | Speaker, rear left door                  |          |                                                 |
| 16/9    | Window antenna                           | 17/13    | Data link connector                             |
| 16/9.1  | TMC antenna                              | 17/19    | 12V outlet, cargo compartment                   |
| 16/10   | Horn 1                                   | 17/37    | 4-pin outlet, tow hitch cable harness           |
| 16/11   | Horn 2                                   | 17/38    | 7-pin outlet, tow hitch cable harness           |
| 16/16   | Window antenna amplifier                 | 17/39    | 13-pin outlet, tow hitch cable harness          |
| 16/26   | Speaker, dashboard middle                | 17/40    | External equipment input (AUX)                  |
| 16/35   | Siren Control Module (SCM), S40          |          |                                                 |
| 16/35   | Siren Control Module (SCM), V50          |          |                                                 |
| 16/35   | Siren Control Module (SCM), C70          | 18/4     | Contact reel                                    |
| 16/45   | Road Traffic Information module (RTI)    |          |                                                 |
| 16/46   | RTI Display                              | 20/3-7   | Spark plug and ignition coil                    |
| 16/46.1 | RTI Display                              | 20/17    | Transformer, ignition coils                     |
| 16/47   | GSM/GPS/RDAR antenna, S40/V50            | 20/22-26 | Glow plug                                       |
| 16/47   | GSM/GPS/RDAR antenna, C70                | 26/5     | DC/AC converter, fuel tank                      |
| 16/49   | Traffic Message Channel Module (TMC)     |          |                                                 |
| 16/49.1 | Traffic Message Channel Module (TMC)     | 31/3     | Ground connection, left MacPherson strut tower  |
| 16/55   | Treble speaker, driver's door            | 31/4     | Ground connection, engine                       |
| 16/56   | Treble speaker, passenger door           | 31/6     | Ground connection, A-post, driver's side        |
| 16/60   | Phone Module (PHM)                       | 31/10    | Ground connection, A-post, passenger side       |
| 16/62   | Hand unit, cellular phone                | 31/11    | Ground connection, rear left side               |
| 16/64   | Cellular phone antenna, S40/V50          | 31/12    | Ground connection, rear right side              |
| 16/64   | Cellular phone antenna, C70              | 31/52    | Ground connection, left MacPherson strut tower  |
| 16/67   | Antenna amplifier, bumper                |          |                                                 |
| 16/68   | TMC and FM subantenna, bumper            | 31/66    | Ground connection, front left seat riser        |
| 16/79   | Subwoofer Module (SUB), S40/V50          | 31/67    | Ground connection, front right seat riser       |
| 16/79   | Subwoofer Module (SUB), C70              | 31/80    | Ground connection, left MacPherson strut tower  |
| 16/93   | Control module, cellular phone handsfree |          |                                                 |
| 16/98   | Microphone                               | 31/83    | Ground connection, A-post, driver's side        |
| 16/105  | Audio Module (AUD)                       | 31/84    | Ground connection, A-post, passenger side       |
| 16/108  | Multimedia Module (MMM)                  | 31/88    | Ground connection, engine                       |
| 16/126  | Holder, handsfree cellular phone         | 31/89    | Ground connection, engine                       |
| 16/127  | Microphone, handsfree cellular phone     | 31/102   | Ground connection, front member, 4-cyl.         |
| 16/128  | Antenna, front left door lock            | 31/102   | Ground connection, front member, 5-cyl.         |
| 16/129  | Antenna, door lock, front right          | 31/107   | Ground connection, tailgate (V50)               |
| 16/130  | Antenna, rear left door lock             | 31/110   | Ground connection, right MacPherson strut tower |
| 16/131  | Antenna, rear right door lock            | 31/112   | Ground connection, right MacPherson strut tower |
| 16/132  | Antenna, door lock, bumper               | 31/114   | Ground connection, left MacPherson strut tower  |
| 16/133  | Antenna, rear door lock cabin 1, S40/V50 |          |                                                 |
| 16/133  | Antenna door lock cabin 1 rear, C70      | 31/115   | Ground connection, left A-post                  |
| 16/134  | Antenna, door lock cabin 2, S40/V50      | 31/116   | Ground connection, right A-post                 |
| 16/134  | Antenna door lock cabin 2, C70           | 31/119   | Ground connection, left MacPherson strut tower  |
| 16/135  | Antenna, door lock cabin 3, S40/V50      |          |                                                 |
| 16/135  | Antenna door lock cabin 3, C70           |          |                                                 |
| 16/136  | Treble speaker, rear left door           |          |                                                 |
| 16/137  | Treble speaker, rear right door          |          |                                                 |
| 16/138  | Rear window antenna, right               |          |                                                 |
| 16/139  | Global Positioning System module (GPS)   |          |                                                 |
| 16/140  | SIM card reader                          |          |                                                 |
| 16/141  | Interference filter, rear window, left   |          |                                                 |
| 16/142  | Interference filter, rear window, right  |          |                                                 |

## List of components 6:6

|        |                    |          |                                   |
|--------|--------------------|----------|-----------------------------------|
| 63/no. | Branching point    | 64/599   | Connector                         |
| 64/25G | Connector          | 64/600   | Connector                         |
| 64/30  | Connector          | 64/660   | Connector                         |
| 64/31  | Connector          | 64/661   | Connector                         |
| 64/34  | Connector          | 64/662   | Connector                         |
| 64/40  | Connector          | 64/663   | Connector                         |
| 64/41  | Connector          | 64/707   | Connector                         |
| 64/43  | Connector          | 64/708   | Connector                         |
| 64/45  | Connector          | 64/816   | Connector                         |
| 64/47  | Connector          | 64/817   | Connector                         |
| 64/48  | Connector, S40/V50 | 64/861   | Connector                         |
| 64/49  | Connector          | 64/862   | Connector                         |
| 64/50  | Connector          | 64/978   | Connector                         |
| 64/51  | Connector          | 64/979   | Connector                         |
| 64/53  | Connector          | 64/1300  | Connector                         |
| 64/60  | Connector          | 64/1400  | Connector                         |
| 64/70  | Connector          |          |                                   |
| 64/79V | Connector          | F/no.    | Fuse, passenger compartment       |
| 64/80  | Connector          | F/no.    | Fuse, engine compartment          |
| 64/80A | Connector          |          |                                   |
| 64/90  | Connector          | FH/no.   | Fuse in holder                    |
| 64/111 | Connector          |          |                                   |
| 64/112 | Connector          | PF/no.   | Main fuse by battery              |
| 64/113 | Connector          |          |                                   |
| 64/114 | Connector          | R/no.    | Relay, passenger compartment      |
| 64/120 | Connector          | R/no.    | Relay, soldered                   |
| 64/179 | Connector          | R/no.    | Relay, engine compartment         |
| 64/233 | Connector          | 10X/17C  | Connector interface, original car |
| 64/245 | Connector          | 10X/18C  | Connector interface, original car |
| 64/246 | Connector          | 16X/1A   | Connector interface, original car |
| 64/250 | Connector          | 16X/105A | Connector interface, original car |
| 64/322 | Connector          | 16X/105B | Connector interface, original car |
| 64/425 | Connector          | 17X/19   | Connector interface, original car |
| 64/545 | Connector          | 64X/322  | Connector interface, original car |
| 64/596 | Connector          |          |                                   |