

1 Fitting locations: vehicle underbody


♦ ⇒ ["1.1 Underbody", page 1](#)

Component	Chapter	Comment
Rear right vehicle inclination sender -G77-	⇒ "1.1 Underbody", page 1	
Exhaust gas temperature sender 3 -G495-	⇒ "1.1 Underbody", page 1	
Exhaust gas temperature sender 4 -G648-	⇒ "1.1 Underbody", page 1	
Exhaust flap control unit -J883-	⇒ "1.1 Underbody", page 1	
Driver's side aerial for entry and start system -R134-	⇒ "1.1 Underbody", page 1	
Passenger side aerial for entry and start system -R135-	⇒ "1.1 Underbody", page 1	

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.1 Underbody

- 1 - Passenger side aerial for entry and start system -R135-
☐ For left-hand drive models
- 1 - Driver's side aerial for entry and start system -R134-
☐ For right-hand drive models
- 2 - Exhaust gas temperature sender 4 -G648-
- 3 - Exhaust gas temperature sender 3 -G495-
- 4 - Driver's side aerial for entry and start system -R134-
☐ For left-hand drive models
- 4 - Passenger side aerial for entry and start system -R135-
☐ For right-hand drive models
- 5 - Exhaust flap control unit -J883-
- 6 - Rear right vehicle inclination sender -G77-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

[Back to overview](#) ⇒ [page 1](#)