


POWER SEATS

Component Index

- [Dash Fuse Box](#)
- Power Seat Switch
 - [Driver's](#)
 - [Passenger's](#)
- Recline Motor
 - [Driver's](#)
 - [Passenger's](#)
- Slide Motor
 - [Driver's](#)
 - [Passenger's](#)


POWER SEATS

Circuit Schematic



POWER SEATS

Circuit Schematic



POWER SEATS

Circuit Schematic

(Refer to Section 201 for photographs.)

Component		Photo No.
Dash Fuse Box	Left side of I/P, behind panel	58
Power Seat Switch		
Driver's	Left side of driver's seat	144
Passenger's	Left side of passenger's seat	144
Recline Motor		
Driver's	Left side of driver's seat	144
Passenger's	Left side of passenger's seat	144
Slide Motor		
Driver's	Under driver's seat	143
Passenger's	Under passenger's seat	143
Connector		
B-38	Under driver's seat	143
B-39	Under passenger's seat	143
H-32	Behind left kick panel	62
Ground		
B-7	Below center console	81