

SECTION 3


WIRING DIAGRAM FOR POWER SUPPLIES

CONTENTS


1. 30 TER BAT+ POWER SUPPLY CIRCUIT	3-4
2. IGNITION SWITCH CIRCUIT	3-6
3. 15C ACC , 15A IGN 2 POWER SUPPLY CIRCUIT (PASSENGER ROOM FUSE BOX)	3-6
4. 15 TER IGN 1 POWER SUPPLY CIRCUIT (PASSENGER ROOM FUSE BOX)	3-7

3-2 WIRING DIAGRAM FOR POWER SUPPLIES


1. 30 Ter BAT+ POWER SUPPLY CIRCUIT(ENGINE ROOM FUSE BOX)




30 Ter BAT+ POWER SUPPLY CIRCUIT(ENGINE ROOM FUSE BOX)




30 Ter BAT+ POWER SUPPLY CIRCUIT(ENGINE ROOM FUSE BOX)




30 Ter BAT+ POWER SUPPLY CIRCUIT(ENGINE ROOM FUSE BOX)



2. IGNITION SWITCH CIRCUIT



4. 15 Ter **IGN 1** POWER SUPPLY CIRCUIT(PASSENGER ROOM FUSE BOX)



15 Ter **IGN 1** POWER SUPPLY CIRCUIT(PASSENGER ROOM FUSE BOX)

