

ARTICLE BEGINNING 

DEFOGGERS 




Fig. 1: Defogger Circuit

HORN




Fig. 2: Horn Circuit

POWER DOOR LOCKS





Fig. 3: Power Door Lock Circuit, 2 Door

POWER WINDOWS



RADIO



Fig. 5: 2-Speaker System Circuit



STARTING/CHARGING




Fig. 7: Charging Circuit




Fig. 8: Starting Circuit

TRUNK, TAILGATE, FUEL DOOR 




Fig. 9: Trunk, Tailgate, Fuel Door Circuits

WIPER/WASHER




Fig. 10: Wiper/Washer Circuit


© 2008 Mitchell Repair Information Co., LLC.

ARTICLE BEGINNING **IDENTIFICATION** **COMPONENT LOCATION MENU** **COMPONENT LOCATIONS**

Component	(Figure No.) Location
A/C RELAY	(1) B 3
A/C SELECT SW	(3) A 11
ALDL CONNECTOR (4 CYL)	(1) B 1
ALDL CONNECTOR (V6)	(2) B 9
ALTERNATOR	(1) B 2
ASHTRAY LIGHT	(5) F 22
BACK-UP LT SW	(5) D 20
BEAM SELECT SW	(4) F 16
BLOWER SW	(3) A 9
CIGAR LIGHTER	(5) F 20
CLUTCH START INTERLOCK	(1) A 4
CONTROL RELAY	(5) C 20
CRUISE CONTROL	(2) E-F 4-5
CNVNC CENTER	(5) D-E 21
DEFOGGER SW	(5) C-D 19
DIRECTIONAL FLASHER	(3) F 12
DIR/HAZ SW	(4) D-E 14
DISTRIBUTOR CONN	(1) B 1
DOME LT	(5) B 22
DOOR SWITCHES	(5) B 20-22
ENGINE SYSTEM (ECM 4 CYL)	(1) C-F 4
ENGINE SYSTEM (ECM V6)	(2) A 5-8
EVAPOR PRES CTRL SW	(3) B 13
FUEL PUMP RELAY (4 CYL)	(1) C 1
FUEL PUMP RELAY (V6)	(2) B 4
FUSE BLOCK	(2, 3) C-F 9-13
FUEL PUMP & SENSOR	(5) D 22
4WD INDICATOR	(5) C-E 19
GEAR SELECT SW	(5) C 22
GLOVE BOX LT	(5) F 20
HADLT SW	(4) F 14
HI BLOWER RELAY	(3) A 12
HORN	(1) C 1

Component	(Figure No.) Location
IGNITION SW	(3) B-C 9-10
INSTRUMENT CLSTR CONNS	(4) A-C 16
INST PANEL CTSY LTS	(3) A-B 13
JUNCTION BLOCK	(1) A 3
LIFTGATE SW	(5) C 21
OIL PRES SW (4 CYL)	(2) F 7
OIL PRES SW (V6)	(2) D 5
OIL PRES SW (V6)	(2) D 8
OIL PRES RELAY	(2) D 6
PANEL DIMMER SW	(4) F 16
POWER DOOR LOCKS	(5) A 18-21
POWER WINDOWS	(5) B 18-21
STOP LT SW	(5) E 22
TACH FILTER	(1) B 2
TCC SOLENOID	(2) E 8
TIMER RELAY	(5) C 19
TRAILER CONN	(5) F 19
VEHICLE SPEED SENSOR (VSS)	(2) E 8
WATER TEMP SW (4 CYL)	(2) F 8
WATER TEMP SW (V6)	(2) E 6
WATER TEMP TRANSDUCER	(2) F 7
W/SHIELD WIPER SYS	(4) E-F 17-18

WIRING DIAGRAM




200508 1 2 3 4

[Fig. 1: Engine Compartment & Headlights](#)




12/1/2009



96476

Fig. 3: Fuse Block & Underdash



96477

Fig. 4: Instrument Panel



12/1/2009

© 2008 Mitchell Repair Information Co., LLC.

cardiagn.com