TRANSAXLE

CONTENTS

page

NV T350 (A-578) MANUAL TRANSAXLE 1

NV T350 (A-578) MANUAL TRANSAXLE

GENERAL INFORMATION

GEAR RATIOS

All transaxles have a torque capacity of 184 N·m. The gear ratios of each transaxle are shown in the following chart.

ENGINE GEAR	2.0 SOHC and DOHC	2.0 SOHC- RIGHT HAND DRIVE ONLY
1st	3.54	3.54
2nd	2.13	2.13
3rd	1.36	1.36
4th	1.03	1.03
5th	0.72	0.72
FINAL DRIVE	3.55	3.55
REVERSE BRAKE	NO	NO
CLUTCH RELEASE SYSTEM	CABLE	HYDRAULIC