

READING INSTRUCTION

1. NO. of relay circuit:

30: Coming from storage battery

15: Controlling by ignition switch

ACC: Ignition switch radio set

31: Ground

58b: Luminous regulating line

2. This circuit diagram is suitable to configuration of A21 1.6 and 2.0.
Considering the time limit, it is liable to mistakes or omissions. Please
contact with Service Technology Dep. of sales company if any
unconformity is found.

TEL: 0553-5922392

FAX: 0553-5840795

