

INSPECTION

INSPECT ACCELERATOR PEDAL POSITION SENSOR ([See page DI-31](#))