


PREPARATION

SST (SPECIAL SERVICE TOOLS)

ST008-1D

	09201-41020	Valve Stem Oil Seal Replacer	Armature front bearing for 2.0 kW for LN Thailand
	09285-76010	Injection Pump Camshaft Bearing Cone Replacer	Armature front bearing for 2.7 kW
	09286-46011	Injection Pump Spline Shaft Puller	Armature bearing (Except rear bearing for 2.0 kW for LN Thailand)
	09810-38140	Starter Magnet Switch Nut Wrench 14	2.0 kW
	09810-38170	Starter Magnet Switch Nut Wrench 17	2.7 kW
	09820-00030	Alternator Rear Bearing Replacer	Armature front bearing for 2.0 kW for Except LN Thailand
	09950-00020	Bearing Remover	Armature rear bearing for 2.0 kW for LN Thailand

ST

RECOMMENDED TOOLS

ST007-14

	09082-00040	TOYOTA Electrical Tester.	
---	-------------	---------------------------	--

EQUIPMENT

ST000-0W

Dial indicator	Commutator
Heater	Water temperature Sensor
Magnetic finger	
Pull scale	Brush spring
Sandpaper	Commutator
Thermometer	Water temperature Sensor
Torque wrench	
V-block	
Vernier calipers	Commutator, Brush