

CHERY T21

Service Manual

2014

01

FOREWORD

This manual contains on-vehicle diagnosis and service procedures for Chery T21.

It is very important to read and be familiar with this manual thoroughly for proper repair and maintenance. This manual should be kept in a handy place for quick and easy reference.

The contents in this manual, including all illustrations and specifications, are current at the time of printing. Any modifications involving with repair and maintenance occur, relevant information supplementary to this volume will be made available at Chery dealers.

Chery Automobile Co., Ltd. reserves all rights. Specifications and contents in this manual are subject to change without notification, and Chery Automobile Co., Ltd. takes no legal obligations and responsibilities.

All rights reserved. Any unit or individual shall not reproduce or copy this manual in any form or by any means, or transmit it on the network by any form for any purpose without written permission of Chery Automobile Co., Ltd.

This manual only applies to the models listed below:

T21 2.0L MT

T21 2.0L CVT

CAUTION:

This manual is only for specialized technicians. If non-specialized or uncertified individuals privately perform repairs or maintenance only referring to this manual or without proper equipment and tools, it may damage the customer's vehicle and hurt you and other persons nearby.

In order to prevent dangerous operation and damage to the vehicle, be sure to follow the instructions shown below:

- The contents in this manual must be read thoroughly. Have a good understanding of all the contents written in the PRECAUTION of "INTRODUCTION" section.
- Before performing the repair procedures, be sure to wear safety equipment properly to avoid personal injury.
- When performing the repair procedures, be sure to use specified and recommended tools to prevent damage to the customer's vehicle. Be sure to confirm the safety of technicians before operating to avoid personal injury.
- If a part needs to be replaced, use Chery genuine part with the same part number. Do not use any inferior quality part.
- Observe the "WARNING" and "CAUTION" in this manual carefully in order to reduce the risk of personal injury and vehicle damage due to improper operation during service and maintenance.

FOREWORD	01
INTRODUCTION	02
PREPARATION	03
SERVICE SPECIFICATIONS	04
MAINTENANCE	05
SQR484F ENGINE MANAGEMENT SYSTEM	06
SQR484F ENGINE MECHANICAL	07
SQR484F FUEL SUPPLY SYSTEM	08
SQR484F EMISSION CONTROL SYSTEM	09
SQR484F INTAKE SYSTEM	10
SQR484F EXHAUST SYSTEM	11
SQR484F COOLING SYSTEM	12
SQR484F LUBRICATION SYSTEM	13
SQR484F IGNITION SYSTEM	14
SQR484F STARTING SYSTEM	15
SQR484F CHARGING SYSTEM	16
QR525MHE TRANSMISSION	17
QR019CHB CVT	18
CLUTCH	19
DRIVE SHAFT	20
DIFFERENTIAL	21
AXLE	22
SUSPENSION	23
TIRE AND WHEEL	24
BRAKE CONTROL SYSTEM	25
BRAKE	26
PARKING BRAKE	27

STEERING COLUMN	28
HYDRAULIC ASSIST STEERING	29
ELECTRONIC POWER STEERING	30
AIR CONDITIONING	31
SUPPLEMENTAL RESTRAINT SYSTEM	32
SEAT BELT	33
ENGINE IMMOBILIZER	34
LIGHTING SYSTEM	35
WIPER AND WASHER	36
DOOR LOCK	37
INSTRUMENT CLUSTER	38
AUDIO SYSTEM	39
REVERSING RADAR SYSTEM	40
HORN	41
OTHER SYSTEM	42
WINDSHIELD/WINDOW GLASS	43
REAR VIEW MIRROR	44
INSTRUMENT PANEL	45
SEAT	46
ENGINE HOOD/DOOR	47
EXTERIOR	48
INTERIOR	49
BODY DIMENSIONS	50
WIRE HARNESS	51

