


2007-08 ELECTRICAL

Relay and Control Unit Locations - TL

ENGINE COMPARTMENT

**Fig. 1: Identifying Engine Compartment Relay And Control Locations**

DASHBOARD




Fig. 2: Identifying Dashboard Relay And Control Locations (1 Of 3)




Fig. 3: Identifying Dashboard Relay And Control Locations (2 Of 3)




Fig. 4: Identifying Dashboard Relay And Control Locations (3 Of 3)

ROOF AND TRUNK




Fig. 5: Identifying Roof And Trunk Relay And Control Locations

DOOR AND SEAT

Driver's Door




Fig. 6: Identifying Door And Seat Relay And Control Locations - Dirver's Door



Driver's Seat**Front Passenger's Seat**

Fig. 7: Identifying Door And Seat Relay And Control Locations - Driver's Seat