



2009 Audi A4 Cabriolet • S4 Cabriolet

Quick Reference Guide



Fuel filler flap

Opening:

Press on the right side of the fuel filler flap.


Closing:

Press the fuel filler flap in until it latches.



Fuel

(see label)




Engine oil

The engine oil specification is in the "Checking and filling" chapter and the engine oil capacity is in the "Data" chapter.

Tire pressures

(driver's side B-pillar)
Visible when the door is open or inside the fuel filler flap.





Dear Driver,

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the owner's manual with its important explanations and warnings.

The owner's manual provides detailed information about your vehicle. You can find information on the radio, CD player, navigation system, and telephone in the radio system or navigation system owner's manual.

We hope you enjoy driving your new Audi and we wish you safe and pleasant motoring.

Sincerely, AUDI AG

Cockpit

1 Memory seat buttons

2 Power windows

Setting the desired position:
Press/pull as far as the first
level and hold.

Automatic up/down function:
Briefly press/pull as far as the
second level.

⚠ WARNING

Be careful when closing the
windows. Check to see that no one
is in the way, or serious personal
injury could result.

3 Hood release

4 Steering wheel position adjuster

⚠ WARNING

The column should only be
adjusted when the vehicle is
at a complete standstill.

5 Door handle and central locking switch



unlocked



locked

6 Adjusting the exterior mirrors

Adjust the knob:



Left exterior mirror



Neutral




Right exterior mirror



Folding the exterior
mirror

The mirror glass moves in
the direction that the knob
is pressed.





- 7 Cruise control
- 8 Coming home/leaving home activation
- 9 Light switch
- 10 Turn signal and high beam lever
- 11 Multifunction steering wheel controls
- 12 tiptronic shift buttons
- 13 Instruments and indicator lights

- 14 Windshield wiper controls and trip computer buttons
- 15 Buttons and indicator lights for:
 - ESP Electronic stabilization program
 - PASS AIR BAG OFF Passenger airbag
 - Emergency flashers
- 16 Storage compartment
- 17 Radio system or navigation system
- 18 Climate control system
- 19 Driver's seat heating

- 20 Passenger's seat heating
- 21 Selector lever with automatic transmission or shift lever
- 22 Parking brake
- 23 Power top
- 24 Power outlet

Adjusting the seats

① Upper thigh support

② Adjusting seat height and forward/back position

- Front of the seat cushion up/down
- Back of the seat cushion up/down
- Seat up/down
- Seat forward/back

③ Adjusting backrest/headrest:

- Backrest forward/back
- Headrest higher/lower

④ Adjusting the lumbar support:

Press on the respective area of the switch.

⑤ Entry assistance:

Pull the lever up and tilt the backrest forward or back.



Adjusting the headrests:

Hold the sides of the headrest with both hands and slide it. The top edge of the headrest should be at eye level or higher.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.



Automatic climate control switch

-  **Left buttons:** Driver's side temperature selection
-  **Right buttons:** Passenger's side temperature selection
-  **Center buttons:** Adjusts fan speed
-  **Automatic mode**
Set the desired temperature and press the button.
-  **Recirculation mode**
Circulate and filter the air inside the passenger compartment
-  **ECON mode**
Activate/deactivate the air conditioning system
-  **Deactivating the climate control system**
-  **Air directed to the windows**
-  **Air from dashboard outlets**
-  **Air directed to the footwells**

Automatic transmission



Selector lever positions

- P** Park
- R** Reverse
- N** Neutral (*Idle*)
- D** Drive
- S** Sport


Releasing the selector lever lock and engaging a gear: Switch the ignition

on, press the brake pedal and press the lock button on the selector lever. Place the selector lever in the **D** or **S** position to drive forward.

tiptronic: To shift manually, move the selector lever to the right out of the **D** position. The driver information system displays the gears.

Shifting up/down: Press the selector lever forward/back.

Power top



Opening the power top

Switch the ignition on:

Pull and hold the  switch until the power top opens and the covers close completely.

Closing the power top

Switch the ignition on:

Press and hold the  switch until the top has closed completely.

Wind deflector



Installing:

- Remove the wind screen from the compartment (luggage compartment).
- Fold both side pieces upward.
- Fold brace **A** (left/right) out and position the wind screen horizontally on the rear seat backrest upholstery.
- Slide the brace **A** (left right) into the retainers as far as the stop.
- Press the locking knob **B** (left/right) and slide the pins into the side openings **C**.
- Align the upper part of the wind screen to the stop.


Removing:

Perform the steps in reverse order.

WARNING

The two rear seats must not be occupied when the wind deflector is installed. Do not place any objects on the horizontal surface of the wind deflector.

Variable convertible top compartment



Raise the convertible top compartment to increase the size of the luggage compartment.

The convertible top must be closed.

Raising: Slide the lever to the **A** position.

Lowering: Slide the lever to the **B** position.



Cruise control

The **CRUISE**/ indicator light appears in the instrument cluster when the system is switched on.

Switching on/off: Pull/push the lever **2**.

Storing the speed: Press the button **1**.

Changing the stored speed: Press the lever up (*faster*) or down (*slower*).

WARNING

Improper use of the Cruise control can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Audi navigation system plus

Components

- ❶ Driver information system
- ❷ Multifunction steering wheel

Roll the **left menu thumbwheel** to mark a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system and telephone.

Roll the **right menu thumbwheel** to control the volume. Press the right thumbwheel to repeat the last navigation announcement.





3 Display

4 Function buttons

Press the desired button (such as FM/AM) to activate that mode.

5 On/Off knob

Switching on: Press briefly.

Adjusting the volume: Rotate.

Muting: Tap.

Switching off: Press and hold.

6 Control buttons

To call up one of the functions shown in the four corners of the display, press the corresponding control button that is assigned to that corner of the display.

7 Control knob

Marking a menu item in the display 3:

Rotate the control knob.

Confirming the selection:

Press the control knob.

Operation

Operation is the same in all functions.



⚠ WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!

A Calling up menus in the display corners:

Press the corresponding button.

B Marking:

Rotate the knob.

C Confirming:

Press the knob.



- 1 Press the FM/AM function button.



- 2 Rotate the control knob and mark the desired station.



- 3 Press the control knob to confirm.



- 4 Press the "Presets" control button.
- 5 Rotate the control knob and mark "Store station <station name>".



- 6 Press the control knob. The next free memory preset is marked.



- 7 Rotate the control knob and mark the desired preset.
- 8 Press the control knob to confirm.



- 1 Press the NAV function button.




- 2 Rotate the control knob and mark "City/ZIP".
- 3 Press the control knob to confirm.



- 4 Rotate the control knob to mark the first letter of the destination.
- 5 Press the control knob to confirm.



- 6 Enter the remaining letters of the destination using the same procedure until the desired location name is displayed.



- 7 When you have entered the destination, rotate the control knob and mark "OK".
- 8 Press the control knob to confirm.



- 9 Mark the menu item "Start route guidance".
- 10 Press the control knob to confirm. The route is calculated.

Functions

Establishing a Bluetooth™ cell phone connection

You can connect a Bluetooth™ capable cell phone quickly to the navigation system cell phone preparation.

- Switch on the ignition, the navigation system and the cell phone.
- On the cell phone, select the menu that searches for Bluetooth™ capable devices (such as the cell phone preparation/hands-free set).
- On the cell phone, select "Audi UHV" and confirm.
- Enter the PIN "1234" on the cell phone.



Memory cards

Loading:

- Press the  button to open the display.
- Guide the memory card into the card reader slot as shown in the illustration and press on the card until it clicks into place.

Removing:

- Press the  button to open the display.
- Press on the memory card. The card is released and can be removed from the card reader slot.

Indicator lights

	Malfunction Indicator Lamp (USA) ¹⁾
	Malfunction Indicator Lamp (CAN) ¹⁾
AIR BAG	Airbag-System (USA) ¹⁾
	Tire pressure too low (check immediately)
CRUISE	Cruise control activated (USA)
	Cruise control activated (CAN)
ABS	Anti-lock brake system (USA) ¹⁾
	Anti-lock brake system (CAN) ¹⁾

	Safety belt
	Power top
	Turn signals/ Emergency flasher
	Electronic Stabilization Program (ESP)
	Generator ¹⁾
	High beam
EPC	Electronic power control ¹⁾

¹⁾ If this illuminates while driving, contact your authorized Audi dealer immediately.

Warning symbols

BRAKE	Brake malfunction (USA)
	Brake malfunction (CAN)
	Cooling system malfunction
	Engine oil pressure too low

If one of these red symbols appears in the display while driving, pull over immediately, stop the engine and check the owner's manual.

© 2008 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. All rights are expressly reserved by Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH. Printed in Germany.

www.audi.com

**Audi A4 Cabriolet • S4 Cabriolet
Kurzanleitung
Nordamerika
englisch 5.08
291.562.684.21**