

Telephone:
Fax:
VAT Registration No.:

Name:	Manufacturer:	Audi
Address:	Model:	
	Year:	1997
	Registration:	
Tel - Private:	Mileage:	
Tel - Business:	Job number:	
Tel - Mobile	Date	

A16	ABS control module
S241	ABS fluid pressure switch
H29	ABS warning lamp
A137	Airbag control module
H98	Airbag warning lamp
H107	Alarm system warning lamp
G1	Alternator
H1	Alternator warning lamp
A1	Audio unit
A39	Auxiliary warning module
31	Battery -
30	Battery +
H18	Brake fluid level warning lamp
S33	Brake fluid level warning lamp switch
B12	Brake pad wear sensor, left front
B13	Brake pad wear sensor, right front
H28	Brake pad wear warning lamp
A40	Bulb failure warning module
S6	Combination switch
X1	Data link connector (DLC)
S226	Door contact switch, driver
EP1	Earth point location 1
EP2	Earth point location 2
EP6	Earth point location 6
A35	Engine control module (ECM)
S47	Engine coolant 'hot' warning lamp/buzzer switch
H36	Engine coolant 'low' warning lamp
S50	Engine coolant 'low' warning lamp switch
P4	Engine coolant temperature gauge
H5	Engine oil pressure warning lamp
S25	Engine oil pressure warning lamp switch
P5	Engine oil temperature gauge
B156	Engine oil temperature sensor
X96	Fascia illumination connector
P3	Fuel gauge

B3	Fuel gauge tank sensor
H15	Fuel 'low' warning lamp
F	Fuse
H17	Handbrake ON warning lamp
S35	Handbrake warning lamp switch
K6	Hazard warning lamps relay
H2	Headlamp high beam warning lamp
H55	Headlamp low beam ON warning lamp
S1	Ignition switch
15	Ignition switch - ignition ON
A162	Immobilizer control module
S5	Indicator switch
H6	Indicator warning lamp, left or single
H7	Indicator warning lamp, right
R4	Instrument illumination rheostat
A75	Instrumentation control module
H47	Stop lamp failure warning lamp
P7	Tachometer
H99	Traction control warning lamp
H24	Trailer warning lamp
B33	Vehicle speed sensor (VSS)
X91	Vehicle speed sensor (VSS) connector
P9	Vehicle speedometer
P1	Voltmeter
H33	Windscreen washer fluid 'low' warning lamp
S136	Windscreen washer fluid 'low' warning lamp switch

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

