

2017 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Door Component Views - Impala

DOOR COMPONENT VIEWS

DRIVER DOOR COMPONENTS




Fig. 1: Driver Door Components

Courtesy of GENERAL MOTORS COMPANY

Items
1: A24D Door Handle Assembly - Driver Exterior (ATH) <u>A24D Door Handle Assembly - Driver Exterior</u>
2: A9A Outside Rearview Mirror - Driver
3: E17D Outside Rearview Mirror Glass - Driver <u>E17D Outside Rearview Mirror Glass - Driver X1 E17D Outside Rearview Mirror Glass - Driver X2 E17D Outside Rearview Mirror Glass - Driver X3 (UFG or UFT) E17D Outside Rearview Mirror Glass - Driver X4</u>
4: M74D Window Motor - Driver <u>M74D Window Motor - Driver</u>
5: P19AG Speaker - Left Front Door <u>P19AG Speaker - Left Front Door (UQG) P19AG Speaker - Left Front Door (UQS)</u>
6: B63LF Side Impact Sensor - Left Front <u>B63LF Side Impact Sensor - Left Front</u>
7: A23D Door Latch Assembly - Driver <u>A23D Door Latch Assembly - Driver</u>
8: B27D Door Handle Switch - Driver Exterior (ATH)

DRIVER DOOR TRIM COMPONENTS




Fig. 2: Driver Door Trim Components
Courtesy of GENERAL MOTORS COMPANY

Items
1: S79D Window Switch - Driver <u>S79D Window Switch - Driver</u>
2: E1D Accent Lamp - Driver Door (C9B) <u>E1D Accent Lamp - Driver Door X1 E1D Accent Lamp - Driver Door</u>
3: S47D Seat Memory Switch - Driver (A45) <u>S47D Seat Memory Switch - Driver</u>
4: S13D Door Lock Switch - Driver <u>S13D Door Lock Switch - Driver</u>
5: E63D Flood Lamp - Driver Door Handle <u>E63D Flood Lamp - Driver Door Handle</u>
6: S52 Outside Rearview Mirror Switch <u>S52 Outside Rearview Mirror Switch</u>
7: E55D Flood Lamp - Driver Door Pocket <u>E55D Flood Lamp - Driver Door Pocket</u>

PASSENGER DOOR COMPONENTS




Fig. 3: Passenger Door Components

Courtesy of GENERAL MOTORS COMPANY

Items
1: A9B Outside Rearview Mirror - Passenger
2: E17P Outside Rearview Mirror Glass - Passenger <u>E17D Outside Rearview Mirror Glass - Passenger X1 E17D Outside Rearview Mirror Glass - Passenger X2 E17P Outside Rearview Mirror Glass - Passenger X3 (UFG or UFT)</u>
3: A24P Door Handle Assembly - Passenger Exterior (ATH) <u>A24P Door Handle Assembly - Passenger Exterior</u>
4: B27P Door Handle Switch - Passenger Exterior (ATH)
5: A23P Door Latch Assembly - Passenger <u>A23P Door Latch Assembly - Passenger</u>
6: B63RF Side Impact Sensor - Right Front <u>B63RF Side Impact Sensor - Right Front</u>
7: M74P Window Motor - Passenger <u>M74P Window Motor - Passenger</u>
8: P19AH Speaker - Right Front Door <u>P19AH Speaker - Right Front Door (UQG) P19AH Speaker - Right Front Door (UQS)</u>

PASSENGER DOOR TRIM COMPONENTS




Fig. 4: Passenger Door Trim Components
Courtesy of GENERAL MOTORS COMPANY

Items	
1: E1P Accent Lamp - Passenger Door (C9B)	<u>E1P Accent Lamp - Passenger Door X1 E1P Accent Lamp - Passenger Door X2</u>
2: S79P Window Switch - Passenger	<u>S79P Window Switch - Passenger X1 S79P Window Switch - Passenger X2</u>
3: E55P Flood Lamp - Passenger Door Pocket	<u>E55P Flood Lamp - Passenger Door Pocket</u>
4: E63P Flood Lamp - Passenger Door Handle	<u>E63P Flood Lamp - Passenger Door Handle</u>
5: S13P Door Lock Switch - Passenger	<u>S13P Door Lock Switch - Passenger</u>

LEFT REAR DOOR COMPONENTS




Fig. 5: Left Rear Door Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: A24LR Door Handle Assembly - Left Rear Exterior (ATH) [A24LR Door Handle Assembly - Left Rear Exterior](#)
- 2: A23LR Door Latch Assembly - Left Rear [A23LR Door Latch Assembly - Left Rear](#)
- 3: M74LR Window Motor - Left Rear [M74LR Window Motor - Left Rear](#)
- 4: P19AL Speaker - Left Rear Door [P19AL Speaker - Left Rear Door \(UQG\)](#) [P19AL Speaker - Left Rear Door \(UQS\)](#)
- 5: B27LR Door Handle Switch - Left Rear Exterior (ATH)

LEFT REAR DOOR TRIM COMPONENTS




Fig. 6: Left Rear Door Trim Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: S79LR Window Switch - Left Rear **S79LR Window Switch - Left Rear**
- 2: E1LR Accent Lamp - Left Rear Door
- 3: E63LR Flood Lamp - Left Rear Door Handle

RIGHT REAR DOOR COMPONENTS




Fig. 7: Right Rear Door Components
 Courtesy of GENERAL MOTORS COMPANY

Items
1: P19AM Speaker - Right Rear Door <u>P19AM Speaker - Right Rear Door (UQG) P19AM Speaker - Right Rear Door (UQS)</u>
2: A24RR Door Handle Assembly - Right Rear Exterior (ATH) <u>A24RR Door Handle Assembly - Right Rear Exterior</u>
3: B27RR Door Handle Switch - Right Rear Exterior (ATH)
4: A23RR Door Latch Assembly - Right Rear <u>A23RR Door Latch Assembly - Right Rear</u>
5: M74RR Window Motor - Right Rear <u>M74RR Window Motor - Right Rear</u>

RIGHT REAR DOOR TRIM COMPONENTS




Fig. 8: Right Rear Door Trim Components
Courtesy of GENERAL MOTORS COMPANY

Items

- 1: E1RR Accent Lamp - Right Rear Door
- 2: S79RR Window Switch - Right Rear **S79RR Window Switch - Right Rear**
- 3: E63RR Flood Lamp - Right Rear Door Handle