




[Engine Compartment]



[Instrument Panel]
(LHD)




(RHD)




F RELAY LOCATIONS


[Body]
(5-Door)



(3-Door)




① : Engine Room R/B Engine Compartment Left (See Page 76)




F RELAY LOCATIONS

○ : Engine Room J/B Engine Compartment Left (See Page 76)




[Engine Room J/B Inner Circuit]




F RELAY LOCATIONS

○ : Driver Side J/B Lower Finish Panel (See Page 77)




F




F RELAY LOCATIONS

[Driver Side J/B Inner Circuit]




Cont. next page

Cont'd



 : Passenger Side J/B Behind the Glove Box (See Page 77)



[Passenger Side J/B Inner Circuit]

