



Quick Reference Guide

2014 Audi A5 Cabriolet | S5 Cabriolet
2014 Audi RS 5 Cabriolet

Vorsprung durch Technik **Audi** 

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

Cockpit

1 Steering wheel position adjuster

⚠ WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

2 Hood release

3 Data Link Connector for On Board Diagnostics (OBD II)

4 Power windows

⚠ WARNING

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

5 Adjusting the exterior mirrors

Adjust the knob:



Left exterior mirror



Heating the exterior mirror



Right exterior mirror

The mirror glass moves in the direction that the knob is pressed.

6 Door handle and central locking switch



locked





unlocked

7 Memory seat buttons

8 Light switch and instrument lighting

9 Cruise control or adaptive cruise control






- 10 Multifunction steering wheel controls
- 11 Turn signal and high beam lever
- 12 Side assist
- 13 Instruments and indicator lights

- 14 Windshield wiper controls and trip computer buttons
- 15 Ignition lock
- 16 Sound system/MMI display
- 17  Emergency flashers
 PASSENGER AIR BAG OFF indicator light

- 18 Radio or MMI drives
- 19  Drive select
 Parking system
 Electronic Stabilization Control (ESC)
On vehicles equipped with a sound system, buttons 19 are located on the shift gate.
- 20 Climate control
- 21 Shift lever for automatic transmission
- 22 Electromechanical parking brake
- 23 START ENGINE STOP button
- 24 MMI control console
- 25 Power top
- 26 Central power window switch

MMI Functions



Driver assistance systems

Use the button **CAR** to adjust or operate many driver assistance systems in your Audi.

For detailed information on this, please see your vehicle Owner's Manual.

Pairing Cell Phone to Bluetooth System

Depending on your cell phone you can pair your phone using **Secure Simple Pairing** or **standard pairing**.

Secure Simple Pairing (SSP)

- Vehicle must be stationary with ignition on. Bluetooth system will be visible for 5 minutes.
- Press the **TEL** button on the MMI.
- Select the **Search for new cell phone** menu item and confirm.
- Select your Bluetooth cell phone in the display and confirm.
- Select the **Handsfree** menu item and confirm your selection.
- Select **Yes** to confirm the 6 digit PIN matching the cell phone display.
- Select **PAIR** on the phone to complete pairing.

Standard pairing

- Follow steps 1-5 from above.
- Select **Yes** to confirm the 4-digit PIN.
- Enter the same 4-digit PIN into your cell phone.
- Select **PAIR** on the phone to complete pairing.

Various phones required that a confirmation be accepted for automatic future connections between the phone and MMI system as well as acknowledging the synchronization of the address book between the phone and MMI.

Advanced key

Opening and closing the vehicle

With advanced key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

Unlocking the vehicle:


Grasp one of the door handles or the handle recess on the luggage compartment lid.

Locking the vehicle:

Place the selector lever in the P position. Touch the sensor **1** on one of the door handles.

Closing the rear lid:

Pull the rear lid down at the grip on the inside and allow it to drop gently to close it.



WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

WARNING

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

Starting the engine

Advanced key:

You can switch on the ignition and start/stop the engine using the START ENGINE STOP button without having the key inserted in the ignition lock.

Switching the ignition on and off:

Insert the key into the ignition lock.

Do **not** depress the brake pedal. Press on the key.

The key can only be removed when the ignition is switched off.



Starting the engine:

Insert the key into the ignition lock.

Depress the brake pedal and move the selector lever into P or N.

Briefly press on the key.

Stopping the engine when the vehicle is standing:

Move the selector lever into P or N.

Briefly press on the key.

Automatic transmission

Selector lever positions

P Park

R Reverse

N Neutral (Idle)


D/S Drive/Sport

Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever. Place the selector lever in the

D/S position to drive forward. When switching from D to S or from S to D, you must move the selector lever back briefly.

tiptronic: To shift manually, move the selector lever to the right out of the D/S position. The driver information system displays the gears.

Shifting up/down: Press the selector lever forward/back.



Adjusting the seats

1 Adjusting the lumbar support:

Press on the respective area of the switch.

2 Adjusting seat height and forward/back position:

- Front of the seat cushion up/down
- Back of the seat cushion up/down
- Seat up/down
- Seat forward/back

3 Seatback adjustment and head restraint:

- Backrest forward/back
- Head restraint up/down

4 Entry assistance:

Pull the lever up and tilt the backrest forward or back.



Adjusting the headrests

Adjust the head restraint so the upper edge is as even as possible with the top of your head.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

Power top

Opening the power top

Switch the ignition on:
Pull and hold the  switch until the power top opens and the covers close completely.

Closing the power top

Switch the ignition on:
Press and hold the  switch until the top has closed completely.



Variable power top compartment

Raise the power top compartment to increase the size of the luggage compartment.

The power top must be closed.

Raising: Press the tray in the direction of the arrow.



Wind deflector


Installing: Remove the wind deflector from the bag and fold it apart **once**.

Open the rear window on the passenger's side and insert both retaining pins **1** in the mounts in the side trim panel on the driver's side.

Pull the handle **2** in driving direction and lift the center of the wind deflector slightly. Insert both retaining pins **3** in the mounts on the passenger's side.

Press the center of the wind deflector down slightly until the handle locks in place. Straighten the wind deflector frame until it stops.

Removing: Perform the same steps used when installing, but in reverse order.



Fuel cap

Tighten fuel cap clockwise as far as it will go. The Malfunction Indicator Light will illuminate, if your fuel cap is not properly sealed. The label on the inside of the fuel filler door indicates the correct fuel type.



Fuel filler door

Opening: Unlocking the vehicle and press the left side of the fuel filler door.
Closing: Press the fuel filler door in until it latches.



Engine oil

For the applicable oil specifications, refer to the Owner's Manual.

Tire pressure monitoring system

The TPMS must be reset via Radio/MMI if the tire pressure is adjusted or wheels are changed.



Tire pressures

The label with the correct tire pressures is located on the driver's door pillar.

Multi Media Interface/ Sound system

Components

1 Driver information system

2 Multifunction steering wheel

Roll the **left thumbwheel** to select a menu item. Press the thumbwheel to confirm the selection.

Press the **MODE** button to switch between the active radio source, navigation system and telephone.

Press the **NAV** button to repeat the last navigation announcement.

Roll the **right thumbwheel** to adjust the volume. Press the thumbwheel to mute the MMI.

3 Sound system/MMI display

4 On/Off button

Switching on/off: Press briefly/press and hold.

Adjusting the volume: Turn.

Mute: Press briefly.

Select previous/next radio station, track:

Press right/left briefly (MMI only).

Fast forward/rewind:

Press and hold right/left (MMI only).





! WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!

5 Buttons for direct access to the menus

Call up main functions such as **MEDIA**.

6 Control knob

To select a menu item: Turn the knob.

To confirm your selection: Press the knob.

7 Control buttons

Activate the functions currently shown in the corners of the MMI display.

8 Button RETURN or BACK


Cancel the selection/go back to the function above.

9 Joystick

To move the crosshairs in a map view (navigation) or to control the DVD menu.

Operating concept

All functions are controlled using the same operating concept.




A Selecting: Turn the knob.

B Confirming: Press the knob.


C Calling up menus in the display corners: Press the appropriate button.

Placing a phone call



Dialing a phone number from a call list:

- Press the **TEL** button.
- Turn the control knob to select **Dialed numbers**, **Missed calls** or **Received calls** and press to confirm. The phone numbers from the selected list appear in the MMI display.
- Turn the control knob to select the desired number and press to confirm or press the **Dial** control button.



Accessing directory contacts:

- Press the **TEL** button.
- Turn the control knob to select **Directory** and press to confirm.
- Turn the control knob to select the desired contact and press to confirm.
- Turn the control knob to select the desired number and press to confirm or press the **Call** control button.

Setting the clock



Select in the MMI: **MENU** button > **Time** control button > **Time source** > **manual** or **GPS**.


Manual: All menu items displayed are set manually.

GPS: Time and date are set by GPS depending on the manually selected Time zone. Therefore, when traveling into another time zone you must manually update the time zone in order for the time clock to update to the correct time.


Storing a radio station



- 1 Press the **RADIO** button.
- 2 Turn the control knob and select the desired station.



- 3 Press and hold the control knob.




- 4 Press the control knob to store in the next free memory preset or
- 5 Turn the control knob to store in a specific location. Then press the control knob to set.



- 1 Press the **NAV** button.
- 2 Press the **Destination** control button.



- 3 Turn/press the control knob to select/confirm the **Address** menu.



- 4 Turn/press the control knob to select/confirm the **City/Zip code** menu item.



- 5 Turn the control knob to select the first letter of the destination.
- 6 Press the control knob to confirm. Enter the remaining letters of the destination using the same procedure until the desired location name is displayed.





- 7 Press/hold the control knob longer when the city appears in the list.
- 8 Turn/press to select the city and enter detailed destination information if necessary.



- 9 Select the menu item **Start route guidance**.
- 10 Press the control knob to confirm. The route is calculated.

For additional information on indicator lights, refer to your vehicle Owner's Manual.

BRAKE	Brake system (USA)		Steering column lock	AIR BAG	Safety systems (USA)		Engine oil sensor		Rear fog light(s)		Transmission
	Brake system (CAN)		Ignition lock		Safety systems (CAN)		Battery		Headlight range control		Turn signals
PARK BRAKE	Electromechanical parking brake (USA)		Speed warning system (USA)		Worn brake pads		Tank system		Adaptive light	CRUISE	Cruise control (USA)
	Electromechanical parking brake (CAN)		Speed warning system (CAN)		Electromechanical parking brake		Warm up engine		Light-/rain sensor		Cruise control (CAN)
	Safety belts		Adaptive cruise control		Tire pressure monitoring system		Windshield washer fluid level		Adaptive dampers		Adaptive cruise control
	Electromechanical steering		Power top operation	TPMS	Tire pressure monitoring system		Windshield wipers		Sport differential		Adaptive cruise control
	Battery		Electronic Stabilization Control (ESC)	EPC	Electronic power control		Remote control key		Ignition lock		High beam
	Engine oil pressure	ESC OFF	Electronic Stabilization Control (ESC)		Malfunction indicator Lamp (MIL)		Battery in remote control key		Steering column lock		
	Engine oil level	ABS	Anti-lock braking system (ABS) defective (USA)		Engine speed limitation		Defective light bulb warning		Electromechanical steering, dynamic steering		
	Engine cooling system		Anti-lock braking system (ABS) defective (CAN)		Engine oil level		Fog lights		Transmission		

Indicator lights

www.audi.com

**Kurzanleitung
Audi A5 Cabriolet
Audi S5 Cabriolet
Audi RS 5 Cabriolet
Nordamerika
Englisch 05.2013
141.562.8F0.21**



1415628F021

© 2013 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH.