



2012 Audi A7 Sportback

Quick Reference Guide

Audi Vorsprung durch Technik 

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

Cockpit

1 Rear lid

2 Power windows

⚠ WARNING

Be careful when closing the windows and luggage compartment. Check to see that no one is in the way, or serious personal injury could result.

3 Adjusting the exterior mirrors

4 Hood release

5 Data link Connector for On Board Diagnostics (OBD II)

6 Door handle

7 Central locking switch

8 Memory seat buttons

9  All-weather lights

 Night vision assistant

 Rear fog lights

10 Light switch

11 Instrument illumination


12 Head-up Display

13 Steering wheel adjustment

⚠ WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

14 Cruise control or Adaptive cruise control





- 15 Multifunction steering wheel controls
- 16 Turn signal, high beam lever
- 17 Shift paddles

- 18 Audi side assist
- 19 Instruments and indicator lights
- 20 Head-up Display
- 21 Windshield wiper controls

- 22  Folding the MMI display in or out
-  Resetting the trip odometer
- 23 MMI display
- 24 Emergency flashers
- 25 MMI drives
- 26  Parking system
-  PASSENGER AIR BAG OFF indicator light
-  Rear spoiler
-  Electronic Stabilization Program (ESP)
- 27 Climate control
- 28 Selector lever
- 29 Storage compartment or ashtray with cigarette lighter
- 30 START ENGINE STOP button
- 31 MMI control console
- 32 Electromechanical parking brake

Convenience key

Opening and closing the vehicle

With convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.


Unlocking the vehicle:

Take hold one of the door handles.

Locking the vehicle:

Select the **P** selector lever position.

Touch and hold the locking sensor **1** until the vehicle locks.



Opening the rear lid:

Press and hold the  button on the remote control master key for at least one second or pull the button  in the driver's door or press the handle in the rear lid.

Closing the rear lid:

Press the  button in the rear lid or pull and hold the  button in the driver's door or pull down the rear lid lightly using the handle.

WARNING

When you leave the vehicle, always take the ignition key with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

Switching the ignition on/ starting and stopping the engine

Use the START ENGINE STOP button to switch the ignition on and start the engine. The master key must be inside the vehicle.

Switching the ignition on/off:


Do not press the brake pedal and press the START ENGINE STOP button.

Starting the engine:

Press the brake pedal and press the START ENGINE STOP button.

Stopping the engine:

Stop the vehicle, move the selector lever into **P** or **N** and press the START ENGINE STOP button.



Automatic transmission

Selector lever positions


- P** Park
- R** Reverse
- N** Neutral (Idle)
- D/S** Drive/Sport

Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever.

Place the selector lever in the **D/S** position to drive forward.

When switching from **D** to **S** or from **S** to **D**, you must move the selector lever back.

tiptronic: To shift manually, move the selector lever to the right out of the **D/S** position. The driver information system displays the gears.



Shifting up/down:

Press the selector lever forward/back.

Adjusting the seats

1 Adjusting the lumbar support:

Press on the respective area of the switch.

2 Adjusting seat height and forward/back position:

-  Front of the seat cushion up/down
-  Back of the seat cushion up/down
-  Seat up/down
-  Seat forward/back

3 Adjusting the backrest:

-  Backrest forward/back



Adjusting the headrests

Press the knob on the side

4 to slide it down.

Adjust the head restraint so the upper edge is as even as possible with the top of your head.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.



⚠ WARNING

Night vision assistant has limits and cannot always detect pedestrians. Always pay close attention to traffic and the area around your vehicle even when night vision assistant is switched on.

Night vision assistant

The night vision assistant shows the area in front of the vehicle in the instrument cluster display when it is dark outside. The system highlights pedestrians that it detects in yellow. Detected pedestrians are marked in red if they are within a critical distance.

Switching on or off: Switch the ignition and the headlights on. Press the  button located near the light switch.

All-weather lights

Reduces the glare from your own headlights when visibility is poor, for example on wet roads.

Switching on or off:
Press the  button.



Head-up Display

The Head-up Display projects warnings, information from assistance systems and/or navigation information on the windshield.

Switching on/off: Press the  knob.

Adjusting the projection height:
Turn the  knob.

Adaptive cruise control

The adaptive cruise control is a combined cruise control and distance regulation system.



Switching on/off: Pull/press the lever (3).

Storing the speed: Press the button (1).

Changing the stored speed: Press the lever (3) up (faster) or down (slower).

Increasing/decreasing the distance: Slide the switch (2) to the right/left.

⚠ WARNING

Improper use of the adaptive cruise control can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Climate control



Left switch – driver's side

Right switch – passenger's side

Rotary switch: Adjusts the temperature, blower speed and air distribution

- | | | | |
|--|--|--|---------------------------|
| | Heated seats | | Fan speed |
| | Ventilated seats | | Air distribution |
| | Automatic mode | | Recirculation mode |
| | Defrost the windshield/ side windows | | |
| | Switch the air conditioning system on/off | | |
| | Switching on/off | | |
| | Rear window defroster | | |
| | Synchronizing the driver's and front passenger's settings | | |

Fuel


The label on the inside of the fuel filler flap indicates the correct fuel type.



Fuel filler flap

Opening: Press the left side of the fuel filler flap.

Closing: Press the fuel filler flap in until it latches.



Engine oil

For the applicable oil specifications, refer to the Owner's Manual.



Tire pressures

The label with the correct tire pressures is located on the driver's door pillar.

Multi Media Interface

MMI components

1 Driver information system

2 Multifunction steering wheel

Press the **rocker switch**  to the left or right to select the menu tabs in the driver information display.

Press the  **button** to call up the submenu in an activated tab.

Roll the **left thumbwheel** to mark a menu item.

Press the thumbwheel to confirm the selection.

Roll the **right thumbwheel** to adjust the volume.

Press the thumbwheel to mute the MMI.

Press the  **button** to access a stored function.

Press the  **button** to repeat the last navigation announcement.

Press the  **button** briefly to activate the voice recognition system.

After the <Beep>, you can say the desired commands.

To deactivate, press and hold the  **button** until you hear the message <Cancel>.

3 Button for opening/closing the MMI display

4 MMI display

5 MMI drives

WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!





6 On/Off button

Switching on/off: Press briefly/press and hold.

Adjusting the volume: Turn.

Mute: Press briefly.

7 Arrow buttons

Press briefly: Previous/next radio station, select track.

Press and hold: Fast forward/rewind.

8 MMI touch control panel

You can enter individual letters, numbers and symbols or control selected MMI functions with your finger.

9 Function buttons

Call up main functions such as **RADIO**.

10 Control buttons

Activate the functions currently shown in the corners of the MMI display.


11 Control knob

To mark a menu item: Turn the knob.

To confirm your selection: Press the knob.


12 Button **BACK**

Cancel the selection/go back to the function above.



MMI operation

The MMI is operated the same way in all functions.



A Calling up menus in the display corners: Press the appropriate button.

B Marking: Rotate the knob.


C Confirming: Press the knob.

MMI touch

1 Entering numbers, letters and symbols

“Write” each character one at a time on the MMI touch control panel using your finger. When the system recognizes a character, it shows it in the MMI display **A** and reads it aloud.


To select a different character **B**, turn the control knob. The selected symbol appears in the input field **C**. Drag your finger from left to right over the touch control panel to enter a blank space. Move your finger from right to left over the touch control panel to erase a symbol. Touch the control panel briefly to end the input.



2 Selecting/storing radio stations

To select a stored station directly, tap a number on the control panel briefly.


To store the current station, press and hold the desired number on the control panel until you hear a signal.




3 Moving the map

Press the control knob to show the crosshairs in the map. To move the crosshairs, move your finger across the control panel in the desired direction as illustrated.






- 1 Press the NAV function button.
- 2 Press the "Destination" control button.



- 3 Turn/press the control knob to mark/confirm the "Address" menu.



- 4 Turn/press the control knob to mark/confirm the "City/Zip code" menu item.



- 5 "Write" the destination on the MMI touch control panel one letter at a time until the desired destination name is displayed.
- 6 To end the input and go to the list of found destinations, tap the control panel briefly.




- 7 Rotate and press to select the city and enter detailed destination information if necessary.



- 8 Mark the menu item "Start route guidance".
- 9 Press the control knob to confirm. The route is calculated.

MMI Functions



Driver assistance systems

Use the button **CAR** to adjust or operate many driver assistance systems in your Audi.

For detailed information on this, please see your vehicle Owner's Manual.

Establishing a Bluetooth™ Connection for Cell Phones and Bluetooth™ audio players

Requirements: The vehicle must be stationary. The ignition, MMI and cell phone/Bluetooth audio player must be switched on. Switch on the "Bluetooth" and "Bluetooth audio player" menus in the MMI Bluetooth settings. Activate "Bluetooth" and "Visible mode" on the cell phone/Bluetooth audio player.

Pairing a cell phone:



- Press the **TEL** function button on the MMI.
- Select the "Search for new cell phone" menu item and confirm.
- Select your Bluetooth cell phone in the display and confirm.
- Select the "Handsfree" menu item and confirm your selection.
- Confirm the PIN displayed with "Yes" and enter the PIN in your cell phone.
- Confirm the connection in your cell phone too when requested.

Pairing an Bluetooth audio player:

- Press the **MEDIA** function button on the MMI.
- Press the "Source" control button.
- Select the "Bluetooth audio player" menu item and confirm your selection. A message appears indicating that no players are paired with the MMI.
- Press the control knob to begin the search.
- Select your Bluetooth audio player in the display and confirm your selection.
- Press the control knob to confirm the Bluetooth audio player profile.
- Confirm the PIN displayed with "Yes" and enter the PIN in your Bluetooth audio player.
- Confirm the connection in your Bluetooth audio player too when requested.




For additional information on indicator lights, refer to your vehicle Owner's Manual.

 Brake malfunction (USA)	 Engine start system	 Worn brake pads	 Windshield washer fluid level	 Electronic steering column lock	 Cruise control (CAN)
 Brake malfunction (CAN)	 Speed warning system	 Parking brake	 Windshield wipers	 Engine start system	 Adaptive cruise control
 Parking brake (USA)	 Adaptive cruise control	 Tire pressure monitoring system	 Remote control key	 Electromechanical steering	 Adaptive cruise control
 Parking brake (CAN)	 Pedestrian warning	 Tire pressure monitoring system	 Remote control key	 Rear spoiler	 Adaptive cruise control
 Engine cooling system	 Rear spoiler	 Electronic power control	 Battery in remote control key	 Turn signals	 High beam
 Engine oil pressure	 Safety systems (USA)	 Malfunction indicator Lamp	 Defective light bulb	 Cruise control (USA)	
 Engine oil level	 Safety systems (CAN)	 Engine speed limitation	 Rear fog lights		
 Generator	 Electronic Stabilization Program (ESP)	 Engine oil level	 Headlight range control		
 Safety belt	 Electronic Stabilization Program (ESP)	 Engine oil sensor	 Adaptive light		
 Electromechanical steering	 Anti-lock brake system (USA)	 Generator	 Light-/rain sensor		
 Steering column lock	 Anti-lock brake system (CAN)	 Tank system	 Transmission		

© 2011 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH.

Audi A7 Sportback
Kurzanleitung
Nordamerika
Englisch 05.2011
121.562.4G8.21



1215624G821

www.audi.com