




Workshop Manual

chassis SUPPLEMENT

PAJERO PININ '01



PAJERO PININ

WORKSHOP MANUAL SUPPLEMENT

FOREWORD

This manual outlines changes in servicing procedures related to the chassis including vehicle inspections, adjustments and improvements in the newly added models.

Please read this manual carefully so that it will be of assistance for your service activities.

Please note that the following service manuals are also available and should be used in conjunction with this manual.

TECHNICAL INFORMATION MANUAL

IKRE00E1

WORKSHOP MANUAL

CHASSIS

CKRE00E1

CKRX00E1CD(CD-ROM)

ELECTRICAL WIRING

EKRE00E1

EKRE00E1-A

BODY REPAIR MANUAL

BKRE00E1

BKRE00E1-A

ENGINE GROUP

PWEE9502-E

PARTS CATALOGUE

I603F509D□

General	00
Engine	11
Engine Lubrication	12
Fuel	13
Intake and Exhaust	15
Engine Electrical	16
Engine and Emission Control	17
Automatic Transmission	23
Propeller Shaft	25
Front Axle	26
Rear Axle	27
Wheel and Tyre	31
Power Plant Mount	32
Front Suspension	33
Rear Suspension	34
Service Brakes	35
Body	42
Exterior	51
Interior and Supplemental Restraint System (SRS)	52
Chassis Electrical	54

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.



MITSUBISHI MOTOR SALES

Europe B.V.

"GDI" is a trade mark of Mitsubishi Motors Corporation.

WARNING REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLE

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).**
- (2) The SRS components should not be subjected to temperature of 93°C or more. So, remove the SRS-ECU, driver's and front passenger's air bag modules, clock spring, side impact sensors and front seat assemblies (side air bag modules) before drying or baking the vehicle after painting.**
- (3) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.**
- (4) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS), before beginning any service or maintenance of any SRS component or any SRS-related component.**

NOTE

Section titles with asterisks (*) in the table of contents in each group indicate operations requiring warnings.