

Item	Description
1	Crankshaft Wear Ring
2	Crankshaft Rear Wear Ring Remover
3	Forc:ng Screw
4	Remover Tube
5	Crankshaft Rear Wear Ring Remover Sleeve