
APPLY 1/8" BEAD OF SEALANT
APPLY 1/4" BEAD OF SEALANT
APPLY 1/4" BEAD OF SEALANT
FRONT OF ENGINE