


| HIGH CURRENT FUSE VALUE AMPS | COLOR CODE |
|---|---|
| 20A PLUG-IN | YELLOW |
| 30A PLUG-IN | GREEN |
| 40A PLUG-IN | ORANGE |
| 50A PLUG-IN | RED |

| Mini-Fuses | Amps | Circuits Protected |
|---|---|---|
| 1 | 25 | Auxiliary Power Socket |
| 2 | 30 | PCM Power Relay |
| 3 | 30 | Main Light Switch, Headlamp Relay, Multifunction Switch |
| 4 | 15 | Air Suspension |
| 5 | 20 | Trailer Tow Running Lamp Relay, Trailer Tow Reversing Lamp Relay |
| 6 | 15 | Main Light Switch, Park Lamp Relay |
| 7 | 20 | Horn Relay |
| 8 | 15 | Lock Relays |
| 9 | 15 | Daytime Running Lamps (DRL) Module, Fog Lamp Relay |
| 10 | 20 | Fuel Pump Relay |
| 11 | 20 | Charging System |
| 12 | - | NOT USED |
| 13 | - | NOT USED |
| 14 | - | NOT USED |
| 15 | - | NOT USED |
| 16 | - | NOT USED |
| 17 | - | NOT USED |
| 18 | 15 | Fuel Injectors, PCM, Fuel Pump Relay, MAF Sensor |
| 19 | 10 | Trailer/Camper Adapter (Right Stop and Right Turn Lamp) |
| 20 | 10 | Trailer/Camper Adapter (Left Stop and Left Turn Lamp) |
| 21 | - | NOT USED |
| 22 | - | NOT USED |
| 23 | 15 | Heated Oxygen Sensors |
| 24 | 15 | Transmission |

| Maxi-Fuses | Amps | Circuits Protected |
|---|---|---|
| 101 | 30 | Trailer Tow Battery Charge Relay |
| 102 | 50 | 4WABS Module |
| 102 | 20 | Ignition Switch, RABS Module |
| 103 | 50 | Fuse Junction Panel |
| 104 | 30 | Transfer Case Shift Relay Module, Transfer Case Electric Clutch Relay (Electronic) |
| 105 | 40 | Blower Relay |
| 106 | 20 | Charge Air Cooler Pump Relay |
| 107 | - | NOT USED |
| 108 | 30 | Trailer Electronic Brake Control |
| 109 | 50 | Air Suspension Compressor Relay |
| 110 | 30 | Acc Delay Relay |
| 111 | 50 | Ignition Switch |
| 112 | 30 | Power Seat Control Switch |
| 113 | 50 | Ignition Switch |
| 114 | - | NOT USED |
| 115 | - | NOT USED |
| 116 | - | NOT USED |
| 117 | - | NOT USED |
| 118 | - | NOT USED |
| 601 C.B. | - | NOT USED |
| 601 C.B. | - | NOT USED |