
CENTER
SUPPORT
FRONT YOKE
COUPLING SHAFT
U-JOINT SLIP YOKE
DRIVESHAFT
SHAFTS MUST BE ASSEMBLED WITH THESE
YOKES IN (PHASE) LINE AS SHOWN.