REAR LEAF SPRING SUSPENSION COMPONENTS

1. Rear leaf spring shackle-to-body mounting
2. Leaf spring
3. Front leaf spring shackle-to-body mounting
4. Spring plate and U-bolts
5. Shock absorbers
6. Axle assembly