





Item	Description
1	Instrument Panel
2	Steering Column Opening Cover
3	Screw(s) 2.0-3.0 N•m (19.0-26.0 In-Lb)
4	Screw(s) 2.0-2.4 N•m (18.0-21.0 In-Lb)

Item	Description
5	Cowl Side Panel (LH)
6	Nut Insert (4 Req'd)
7	U-Nut
8	Cowl Side Panel (RH)
9	Screw(s) 2.0-2.4 N•m (18.0-21.0 In-Lb)