

GROUP 23**AUTOMATIC TRANSMISSION****GENERAL****OUTLINE OF CHANGE**

- Troubleshooting section has been reviewed to correspond to the abolition of the A/T-ECU idle switch input terminal.

TROUBLESHOOTING <A/T>

Due to the abolition of the A/T-ECU idle switch input terminal, the following descriptions have been deleted. The other descriptions are the same as before.

- (1) Idle position switch listed as No.5 in "ROAD TEST" section.
- (2) Idle position switch listed in "INSPECTION CHART FOR TROUBLE SYMPTOMS"
- (3) No.17 Inspection procedure
- (4) Item No.64 listed in "SERVICE DATA REFERENCE TABLE"
- (5) Idle switch in the row "Check requirement" listed in "ACTUATOR TEST JUDGEMENT VALUE"
- (6) Terminal No.36 in "CHECK AT A/T-ECU TERMINALS"

NOTES