

1998-99 Trooper Master Index[Air conditioner](#)[Blower controls](#)[Compressor controls](#)[Alarm and relay controls](#)[Anti-lock brake system \(ABS\)](#)[Anti-theft system](#)[A/T shift indicator](#)[Automatic transmission controls](#)[Back-up lights](#)[Brake lights](#)[Brake warning system](#)[Charging system](#)[Cigarette lighter](#)[Console lights](#)[Cornering lights](#)[Courtesy lights \(S-Models\)](#)[Courtesy lights](#)[\(Performance & Luxury Models\)](#)[Cruise control](#)[Dash fuse box](#)[Dash lights](#)[Defoggers](#)[Door mirror](#)[Rear window](#)[Digital clock](#)[Dome light \(S-Models\)](#)[Dome light](#)[\(Performance & Luxury Models\)](#)[Engine coolant temperature gauge](#)[Engine controls](#)[Fog lights](#)[Front park lights](#)[Front side marker lights](#)[Fuel gauge](#)[Fuel level indication system](#)[Ground distribution](#)[Hazard lights](#)[Headlights](#)[Heater](#)[Horns](#)[Ignition system](#)[Indicators](#)[Key-in ignition warning system](#)[Keyless entry system](#)[License plate light](#)[Lighting switch details](#)[Lights-on warning system](#)[Luggage room light \(S-Models\)](#)[Luggage room light](#)[\(Performance & Luxury Models\)](#)[Map lights](#)[Meter Assembly](#)[Oil pressure gauge](#)[Oil pressure warning system](#)[Power distribution](#)[Power door locks](#)[Power mirrors](#)[Power mirrors folding](#)[Power seats](#)[Power sunroof](#)[Power windows](#)[Rear defogger](#)[Rear park lights](#)[Seat belt warning system](#)[Seat heater](#)[Shift interlock system](#)[Shift-on-the-fly](#)[Sound system](#)[Speedometer](#)[Starting system](#)[Automatic transmission](#)[Manual transmission](#)[Supplemental restraint system \(SRS\)](#)[Tachometer](#)[Torque-on-demand system](#)[Trailer adapter](#)[Turn lights](#)[Vehicle speed sensor](#)[Voltmeter](#)[Wiper/washer](#)[Rear](#)[Windshield \(S-Models\)](#)[Windshield](#)[\(Performance & Luxury Models\)](#)