

## 2014 GMC Acadia Denali


2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse

### 2014 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse

## PASSENGER COMPARTMENT/ROOF COMPONENT VIEWS

### ROOF PANEL



**Fig. 1: Roof Panel**


Courtesy of GENERAL MOTORS COMPANY

| Callout | Component Name               |
|---------|------------------------------|
| 1       | Sunroof Control Module (C3U) |

### ROOF RAIL AIR BAGS

## 2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse



**Fig. 2: View Of Roof Rail Air Bags**

Courtesy of GENERAL MOTORS COMPANY

### Items


**1: F105R Roof Rail Air Bag - Right** **F105R Roof Rail Air Bag - Right**

**2: F105L Roof Rail Air Bag - Left** **F105L Roof Rail Air Bag - Left**

### DRIVER SEAT COMPONENTS (A45)

## 2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse



**Fig. 3: Driver Seat (A45)**

Courtesy of GENERAL MOTORS COMPANY


| Callout | Component Name                                                     |
|---------|--------------------------------------------------------------------|
| 1       | Seat Front Vertical Motor - Driver                                 |
| 2       | Seat Front Vertical Motor Position Sensor                          |
| 3       | Seat Rear Vertical Motor Position Sensor - Driver                  |
| 4       | Seat Rear Vertical Motor - Driver                                  |
| 5       | Heated Seat Element - Driver Back                                  |
| 6       | Inflatable Restraint Side Impact Module - Left                     |
| 7       | Seat Adjuster Switch - Driver                                      |
| 8       | Seat Lumbar Switch - Driver                                        |
| 9       | Seat Belt Pretensioner - Driver                                    |
| 10      | Seat Horizontal Motor - Driver                                     |
| 11      | Seat Horizontal Motor Position Sensor - Driver                     |
| 12      | Seat Cushion Ventilation Heating and Cooling Module - Driver (KB6) |

## 2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse

|    |                                                                 |
|----|-----------------------------------------------------------------|
| 13 | Memory Seat Module (MSM)                                        |
| 14 | Seat Back Ventilation Heating and Cooling Module - Driver (KB6) |
| 15 | Inflatable Restraint Seat Side Air Bag - Driver InBoard         |
| 16 | Heated Seat Element - Driver Cushion                            |
| 17 | Seat Belt Buckle - Driver                                       |
| 18 | Seat Recline Position Sensor - Driver                           |
| 19 | Seat Recline Motor - Driver                                     |
| 20 | Seat Lumbar Horizontal Motor - Driver                           |

### PASSENGER SEAT COMPONENTS



**Fig. 4: Identifying Passenger Seat Components**

Courtesy of GENERAL MOTORS COMPANY

#### Items


1: B153P Seat Belt Buckle - Passenger **B153P Seat Belt Buckle - Passenger**

## 2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse

- 2:** E14D Seat Heating Element - Passenger Cushion ((KA1 or KB6 or SPO Accessory)) **E14D Seat Heating Element - Passenger Cushion (KA1)** **E14D Seat Heating Element - Passenger Cushion (KB6)** **E14D Seat Heating Element - Passenger Cushion (SPO Accessory)**
- 3:** F106D Seat Side Air Bag - Driver **F106D Seat Side Air Bag - Driver**
- 4:** K85 Passenger Presence Module **K85 Passenger Presence Module**
- 5:** M56P Seat Recline Motor - Passenger ((AAQ)) **M56P Seat Recline Motor - Passenger (AH8)**
- 6:** M52P Seat Lumbar Support Horizontal Motor - Passenger ((AAQ)) **M52P Seat Lumbar Support Horizontal Motor - Passenger (AH8)**
- 7:** K53P Seat Blower Assembly - Passenger Back ((KB6)) **K53P Seat Blower Assembly - Passenger Back (KB6)**
- 8:** M51P Seat Horizontal Motor - Passenger ((AAQ or AG2)) **M51P Seat Horizontal Motor - Passenger (AG2 or AH8)**
- 9:** K55P Seat Blower Assembly - Passenger Cushion ((KB6)) **K55P Seat Blower Assembly - Passenger Cushion (KB6)**
- 10:** F113P Seat Belt Anchor Pretensioner - Passenger **F113P Seat Belt Anchor Pretensioner - Passenger**
- 11:** S65P Seat Lumbar Support Switch - Passenger ((AAQ)) **S65P Seat Lumbar Support Switch - Passenger (AH8)**
- 12:** E14C Seat Heating Element - Passenger Back ((KA1 or KB6 or SPO Accessory)) **E14C Seat Heating Element - Passenger Back (KA1)** **E14C Seat Heating Element - Passenger Back (KB6)** **E14C Seat Heating Element - Passenger Back (SPO Accessory)**
- 13:** S64P Seat Adjuster Switch - Passenger ((AAQ or AG2)) **S64P Seat Adjuster Switch - Passenger (AG2)** **S64P Seat Adjuster Switch - Passenger (AH8)**

### DRIVER SEAT (EXCEPT A45)



**Fig. 5: Driver Seat (A45)**


Courtesy of GENERAL MOTORS COMPANY

**Items**

- 1: F106D Seat Side Air Bag - Driver F106D Seat Side Air Bag - Driver**
- 2: M56D Seat Recline Motor - Driver ((AG3 or AH5)) M56D Seat Recline Motor - Driver (AG3 or AH5)**
- 3: M52D Seat Lumbar Support Horizontal Motor - Driver ((AG3 or AH5)) M52D Seat Lumbar Support Horizontal Motor - Driver (AG3 or AH5)**
- 4: M51D Seat Horizontal Motor - Driver ((AG1 or AG3 or AH5)) M51D Seat Horizontal Motor - Driver (AG1 or AH5 or AG3)**
- 5: S65D Seat Lumbar Support Switch - Driver ((AG3 or AH5)) S65D Seat Lumbar Support Switch - Driver (AG3 or AH5)**
- 6: S64D Seat Adjuster Switch - Driver ((AG1 or AG3 or AH5)) S64D Seat Adjuster Switch - Driver (AG1) S64D Seat Adjuster Switch - Driver (AG3) S64D Seat Adjuster Switch - Driver (AH5)**
- 7: M55D Seat Rear Vertical Motor - Driver ((AG1 or AG3 or AH5)) M55D Seat Rear Vertical Motor - Driver (AG1 or AH5 or AG3)**

- 8: K29D Seat Heating Control Module - Driver ((KA1 without A45 or SPO Accessory)) K29D Seat Heating Control Module - Driver X1 (KA1 without A45) K29D Seat Heating Control Module - Driver X2 (KA1 without A45) K29D Seat Heating Control Module - Driver X3 (KA1 without A45) K29D Seat Heating Control Module - Driver X4 (KA1 without A45)
- 9: M50D Seat Front Vertical Motor - Driver ((AG1 or AG3 or AH5)) M50D Seat Front Vertical Motor - Driver (AG1 or AH5 or AG3)
- 10: B153D Seat Belt Buckle - Driver B153D Seat Belt Buckle - Driver
- 11: E14B Seat Heating Element - Driver Cushion ((KA1 or KB6 or SPO Accessory)) E14B Seat Heating Element - Driver Cushion (KA1) E14B Seat Heating Element - Driver Cushion (KB6) E14B Seat Heating Element - Driver Cushion (SPO Accessory)
- 12: E14A Seat Heating Element - Driver Back ((KA1 or KB6 or SPO Accessory)) E14A Seat Heating Element - Driver Back (KA1) E14A Seat Heating Element - Driver Back (KB6) E14A Seat Heating Element - Driver Back (SPO Accessory)

## HEADLINER COMPONENTS



**Fig. 6: Headliner**

**2014 GMC Acadia Denali**

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse


**Courtesy of GENERAL MOTORS COMPANY**

| <b>Callout</b> | <b>Component Name</b>                              |
|----------------|----------------------------------------------------|
| 1              | Courtesy/Reading Lamps - 3rd Row                   |
| 2              | Infrared Transmitter (U42 with C3U)                |
| 3              | Courtesy/Reading Lamps - 2nd Row (U42 with C3U)    |
| 4              | Digital Video Disc (DVD) Display (U42 with C3U)    |
| 5              | Sunroof Switch (C3U)                               |
| 6              | Overhead Console Courtesy/Reading Lamps - Front    |
| 7              | Console Flood Lamp                                 |
| 8              | Garage Door Opener (GDO) (UG1)                     |
| 9              | Sunshade - Right                                   |
| 10             | Inside Rearview Mirror (ISRVM)                     |
| 11             | Sunshade - Left                                    |
| 12             | Cellular Telephone Microphone (UE1)                |
| 13             | Digital Video Disc (DVD) Display (U42 without C3U) |
| 14             | Courtesy/Reading Lamps - 2nd Row (without C3U)     |
| 15             | Infrared Transmitter (U42 without C3U)             |
| 16             | Electronic Compass Module (U80)                    |
| 17             | Remote Control Door Lock Receiver (RCDLR)          |

**SECOND ROW SEAT AREA FLOOR**

## 2014 GMC Acadia Denali


2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof  
Component Views - Acadia, Enclave And Traverse



**Fig. 7: Second Row Seat Area Floor**  
Courtesy of GENERAL MOTORS COMPANY

| Callout | Component Name                            |
|---------|-------------------------------------------|
| 1       | Battery Current Sensor                    |
| 2       | Fuse Holder - OnStar (UE1)                |
| 3       | Fuse Holder - Engine Control Module (ECM) |

**NEAR THE PASSENGER SEAT**



**Fig. 8: Near the Passenger Seat**

Courtesy of GENERAL MOTORS COMPANY

**Items**


**1: B18 Battery Current Sensor** **B18 Battery Current Sensor**

**2: C1 Battery**

**3: K36 Inflatable Restraint Sensing and Diagnostic Module** **K36 Inflatable Restraint Sensing and Diagnostic Module (SDM) X1** **K36 Inflatable Restraint Sensing and Diagnostic Module (SDM) X2**

**4: B119 Multi-axis Acceleration Sensor** **B119 Multi-axis Acceleration Sensor**

**DRIVER SIDE FOOTWELL AND DOOR SILL (B8K)**




**Fig. 9: Driver Side Footwell and Door Sill (B8K)**  
Courtesy of GENERAL MOTORS COMPANY

**Items**

- 1: E8A Door Sill Plate Lamp - Driver ((B8K))** **E8A Door Sill Plate Lamp - Driver (B8K)**  
**2: E8J Instrument Panel Courtesy Lamp - Left ((B8K))** **E8J Instrument Panel Courtesy Lamp - Left (B8K)**

**PASSENGER SIDE FOOTWELL AND DOOR SILL (B8K)**



**Fig. 10: Passenger Side Footwell and Door Sill (B8K)**  
Courtesy of GENERAL MOTORS COMPANY

**Items**

- 1: E8B Door Sill Plate Lamp - Passenger ((B8K)) E8B Door Sill Plate Lamp - Passenger (B8K)**  
**2: E8K Instrument Panel Courtesy Lamp - Right ((B8K)) E8K Instrument Panel Courtesy Lamp - Right (B8K)**