

1 Parts with prefix A to D



◆ ⇒ ["1.1 Front drive battery module A3 ", page 1](#)

◆ ⇒ ["1.2 Starter B ", page 1](#)

◆ ⇒ ["1.3 Alternator C ", page 2](#)

◆ ⇒ ["1.4 Ignition/ starter switch D ", page 2](#)

◆ ⇒ ["1.5 Immobiliser reader coil D2 ", page 3](#)


◆ ⇒ ["1.6 Electronic ignition lock D9 ", page 3](#)

1.1 Front drive battery module -A34)-

◆ ⇒ ["1.1.1 Connector T2gi ", page 1](#)

1.1.1 Connector -T2gi-

Connector -T2gi-




1.2 Starter -B-

◆ ⇒ ["1.2.1 Connector T1jz ", page 2](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T1jz-

Connector -T1jz-




1.3 Alternator -C-

♦ ⇒ ["1.3.1 Connector T2m", page 2](#)

1.3.1 Connector -T2m-

Connector -T2m-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.4 Ignition/starter switch -D-

♦ ⇒ ["1.4.1 Connector T6f", page 3](#)

1.4.1 Connector -T6f-

Connector -T6f-



1.5 Immobiliser reader coil -D2-


♦ ⇒ ["1.5.1 Connector T2o", page 3](#)

1.5.1 Connector -T2o-

Connector -T2o-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.6 Electronic ignition lock -D9-

♦ ⇒ ["1.6.1 Connector T2p", page 4](#)

1.6.1 Connector -T2p-**Connector -T2p-**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix E

- ◆
- ◆ ⇒ ["1.1 Light switch E1 ", page 1](#)
- ◆ ⇒ ["1.2 Starter inhibitor and reversing lights switch E17 ", page 2](#)
- ◆ ⇒ ["1.3 Driver side belt switch E24 ", page 3](#)
- ◆ ⇒ ["1.4 Front passenger side belt switch E25 ", page 4](#)
- ◆ ⇒ ["1.5 Glove compartment light switch E26 ", page 5](#)
- ◆ ⇒ ["1.6 Driver side volume regulator E67 ", page 5](#)
- ◆ ⇒ ["1.7 Key operated switch to deactivate front passenger side airbag E224 ", page 6](#)
- ◆ ⇒ ["1.8 Rear lid handle release button E234 ", page 7](#)
- ◆ ⇒ ["1.9 Driver's side rear belt switch E258 ", page 7](#)
- ◆ ⇒ ["1.10 Passenger side rear belt switch E259 ", page 8](#)
- ◆ ⇒ ["1.11 Driver side interior locking button for central locking system E308 ", page 8](#)
- ◆ ⇒ ["1.12 Selector lever E313 ", page 9](#)
- ◆ ⇒ ["1.13 Multimedia system operating unit E380 ", page 9](#)
- ◆ ⇒ ["1.14 Entry and start authorisation button E408 ", page 10](#)
- ◆ ⇒ ["1.15 Rear driver side window regulator button E711 ", page 10](#)
- ◆ ⇒ ["1.16 Rear passenger side window regulator button E713 ", page 11](#)
- ◆ ⇒ ["1.17 Interior mirror EX5 ", page 11](#)
- ◆ ⇒ ["1.18 Exterior mirror adjuster EX11 ", page 12](#)
- ◆ ⇒ ["1.19 Heater and air conditioning controls EX21 ", page 12](#)
- ◆ ⇒ ["1.20 Centre switch module in dash panel EX22 ", page 14](#)
- ◆ ⇒ ["1.21 Window regulator switch, front passenger door EX27 ", page 15](#)
- ◆ ⇒ ["1.22 Operating unit for window regulator in driver door EX36 ", page 15](#)


1.1 Light switch -E1-

- ◆ ⇒ ["1.1.1 Connector T4I ", page 2](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.1.1 Connector -T4l-

Connector -T4l-



8K0_973_754_B


1.2 Starter inhibitor and reversing lights switch -E17-

♦ ⇒ ["1.2.1 Connector T2q", page 2](#)

♦ ⇒ ["1.2.2 Connector T2r", page 3](#)

1.2.1 Connector -T2q-

Connector -T2q-




8K0_973_702



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.2 Connector -T2r-

Connector -T2r-




1.3 Driver side belt switch -E24-

♦ ⇒ ["1.3.1 Connector T2ht", page 3](#)

♦ ⇒ ["1.3.2 Connector T2s", page 4](#)

1.3.1 Connector -T2ht-


Connector -T2ht-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.3.2 Connector -T2s-

Connector -T2s-




1.4 Front passenger side belt switch -E25-

♦ ⇒ ["1.4.1 Connector T2gx", page 4](#)

♦ ⇒ ["1.4.2 Connector T2ho", page 5](#)


1.4.1 Connector -T2gx-

Connector -T2gx-



1.4.2 Connector -T2ho-

Connector -T2ho-




1.5 Glove compartment light switch -E26-

♦ ⇒ ["1.5.1 Connector T3e", page 5](#)

1.5.1 Connector -T3e-

Connector -T3e-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.6 Driver side volume regulator -E67-


♦ ⇒ ["1.6.1 Connector T6j", page 6](#)

1.6.1 Connector -T6j-

Connector -T6j-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.7 Key operated switch to deactivate front passenger side airbag -E224-

♦ ⇒ ["1.7.1 Connector T6au", page 6](#)

♦ ⇒ ["1.7.2 Connector T6g", page 7](#)


1.7.1 Connector -T6au-

Connector -T6au-



1.7.2 Connector -T6g-

Connector -T6g-




1.8 Rear lid handle release button -E234-

♦ ⇒ ["1.8.1 Connector T2y", page 7](#)

1.8.1 Connector -T2y-

Connector -T2y-



1.9 Driver's side rear belt switch -E258-

♦ ⇒ ["1.9.1 Connector T2hb", page 8](#)


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.9.1 Connector -T2hb-

Connector -T2hb-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1J0_973_119

1.10 Passenger side rear belt switch -E259-

♦ ⇒ ["1.10.1 Connector T2t", page 8](#)

1.10.1 Connector -T2t-

Connector -T2t-




1J0_973_119

1.11 Driver side interior locking button for central locking system -E308-

♦ ⇒ ["1.11.1 Connector T4n", page 9](#)

1.11.1 Connector -T4n-

Connector -T4n-




1.12 Selector lever -E313-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the prior written consent of AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

◆ ⇒ ["1.12.1 Connector -T10f-", page 9](#)

1.12.1 Connector -T10f-

Connector -T10f-




1.13 Multimedia system operating unit -E380-

◆ ⇒ ["1.13.1 Connector T9a ", page 10](#)

1.13.1 Connector -T9a-

Connector -T9a-



1.14 Entry and start authorisation button -E408-


♦ ⇒ ["1.14.1 Connector T6h", page 10](#)

1.14.1 Connector -T6h-

Connector -T6h-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.15 Rear driver side window regulator button -E711-

♦ ⇒ ["1.15.1 Connector T4p", page 11](#)

1.15.1 Connector -T4p-

Connector -T4p-




1.16 Rear passenger side window regulator button -E713-

♦ ⇒ ["1.16.1 Connector T4bl", page 11](#)

1.16.1 Connector -T4bl-

Connector -T4bl-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.17 Interior mirror -EX5-


♦ ⇒ ["1.17.1 Connector T8ad", page 12](#)

1.17.1 Connector -T8ad-

Connector -T8ad-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.18 Exterior mirror adjuster -EX11-

◆ ⇒ [“1.18.1 Connector T6i”, page 12](#)

1.18.1 Connector -T6i-

Connector -T6i-



1.19 Heater and air conditioning controls -EX21-

◆ ⇒ [“1.19.1 Connector T16d”, page 13](#)


◆ ⇒ [“1.19.2 Connector T16e”, page 13](#)

◆ ⇒ [“1.19.3 Connector T16f”, page 14](#)

◆ ⇒ [“1.19.4 Connector T20c”, page 14](#)


1.19.1 Connector -T16d-

Connector -T16d-



1.19.2 Connector -T16e-

Connector -T16e-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.3 Connector -T16f-

Connector -T16f-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.19.4 Connector -T20c-

Connector -T20c-




1.20 Centre switch module in dash panel -EX22-

♦ ⇒ ["1.20.1 Connector T20d ", page 15](#)

1.20.1 Connector -T20d-

Connector -T20d-



8W0_972_420

1.21 Window regulator switch in front passenger door -EX27-


♦ ⇒ ["1.21.1 Connector T4m", page 15](#)

1.21.1 Connector -T4m-

Connector -T4m-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1K0_972_704_C

1.22 Operating unit for driver door window regulator -EX36-

♦ ⇒ ["1.22.1 Connector T10e", page 16](#)

1.22.1 Connector -T10e-**Connector -T10e-**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix F



- ◆ ⇒ [“1.1 Brake light switch F”, page 1](#)
- ◆ ⇒ [„1.2 Handbrake warning switch F9“, page 2](#)
- ◆ ⇒ [“1.3 Oil pressure switch F22”, page 2](#)
- ◆ ⇒ [“1.4 Brake fluid level warning contact F34”, page 3](#)
- ◆ ⇒ [“1.5 Driver vanity mirror contact switch F147”, page 3](#)
- ◆ ⇒ [“1.6 Front passenger vanity mirror contact switch F148”, page 4](#)
- ◆ ⇒ [“1.7 Bonnet contact switch F266”, page 4](#)
- ◆ ⇒ [“1.8 Bonnet contact switch 2 F329”, page 5](#)
- ◆ ⇒ [“1.9 Actuator 1 for camshaft adjustment F366”, page 5](#)
- ◆ ⇒ [“1.10 Actuator 2 for camshaft adjustment F367”, page 6](#)
- ◆ ⇒ [“1.11 Actuator 3 for camshaft adjustment F368”, page 6](#)
- ◆ ⇒ [“1.12 Actuator 4 for camshaft adjustment F369”, page 7](#)
- ◆ ⇒ [“1.13 Actuator 5 for camshaft adjustment F370”, page 7](#)
- ◆ ⇒ [“1.14 Actuator 6 for camshaft adjustment F371”, page 8](#)
- ◆ ⇒ [“1.15 Actuator 7 for camshaft adjustment F372”, page 8](#)
- ◆ ⇒ [“1.16 Actuator 8 for camshaft adjustment F373”, page 9](#)
- ◆ ⇒ [“1.17 Oil pressure switch for reduced oil pressure F378”, page 9](#)
- ◆ ⇒ [“1.18 Stage 3 oil pressure switch F447”, page 10](#)
- ◆ ⇒ [“1.19 Twin belt buckle FX4”, page 10](#)

1.1 Brake light switch -F-


- ◆ ⇒ [“1.1.1 Connector T4r”, page 2](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.1.1 Connector -T4r-

Connector -T4r-




1.2 Handbrake warning switch -F9-

♦ ⇒ ["1.2.1 Connector T2at", page 2](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T2at-

Connector -T2at-




1.3 Oil pressure switch -F22-

♦ ⇒ ["1.3.1 Connector T1ka", page 3](#)

1.3.1 Connector -T1ka-

Connector -T1ka-




1.4 Brake fluid level warning contact -F34-

♦ ⇒ ["1.4.1 Connector T2ab ", page 3](#)

1.4.1 Connector -T2ab-

Connector -T2ab-



1.5 Driver side vanity mirror contact switch -F147-


♦ ⇒ ["1.5.1 Connector T2u ", page 4](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.5.1 Connector -T2u-

Connector -T2u-




1.6 Front passenger side vanity mirror contact switch -F148-

♦ ⇒ ["1.6.1 Connector T2v ", page 4](#)

1.6.1 Connector -T2v-

Connector -T2v-




1.7 Bonnet contact switch -F266-

♦ ⇒ ["1.7.1 Connector T2z ", page 5](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.7.1 Connector -T2z-

Connector -T2z-




1.8 Bonnet contact switch 2 -F329-

♦ ⇒ ["1.8.1 Connector T2aa ", page 5](#)

1.8.1 Connector -T2aa-

Connector -T2aa-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.9 Actuator 1 for camshaft adjustment -F366-

♦ ⇒ ["1.9.1 Connector T2ac ", page 6](#)

1.9.1 Connector -T2ac-

Connector -T2ac-




1.10 Actuator 2 for camshaft adjustment -F367-

♦ ⇒ ["1.10.1 Connector T2ae ", page 6](#)

1.10.1 Connector -T2ae-

Connector -T2ae-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.11 Actuator 3 for camshaft adjustment -F368-

♦ ⇒ ["1.11.1 Connector T2ag ", page 7](#)

1.11.1 Connector -T2ag-

Connector -T2ag-



1.12 Actuator 4 for camshaft adjustment -F369-


♦ ⇒ ["1.12.1 Connector T2ai", page 7](#)

1.12.1 Connector -T2ai-

Connector -T2ai-



Protected by copyright. Copying for private or commercial purposes, in part or in whole is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.13 Actuator 5 for camshaft adjustment -F370-


♦ ⇒ ["1.13.1 Connector T2ak", page 8](#)

1.13.1 Connector -T2ak-

Connector -T2ak-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.14 Actuator 6 for camshaft adjustment -F371-

♦ ⇒ ["1.14.1 Connector T2am", page 8](#)

1.14.1 Connector -T2am-

Connector -T2am-




1.15 Actuator 7 for camshaft adjustment -F372-

♦ ⇒ ["1.15.1 Connector T2ao", page 9](#)

1.15.1 Connector -T2ao-

Connector -T2ao-




1.16 Actuator 8 for camshaft adjustment -F373-

♦ ⇒ ["1.16.1 Connector T2aq", page 9](#)

1.16.1 Connector -T2aq-

Connector -T2aq-



1.17 Oil pressure switch for reduced oil pressure -F378-

♦ ⇒ ["1.17.1 Connector T1kb", page 10](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.17.1 Connector -T1kb- Connector -T1kb-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.18 Oil pressure switch, stage 3 -F447-

♦ ⇒ [“1.18.1 Connector T2x”, page 10](#)

1.18.1 Connector -T2x- Connector -T2x-



1.19 Twin belt buckle -FX4-

♦ ⇒ [“1.19.1 Connector T4bu”, page 11](#)

♦ ⇒ [“1.19.2 Connector T4o”, page 11](#)

1.19.1 Connector -T4bu-



Connector -T4bu-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.2 Connector -T4o-

Connector -T4o-



1 Parts with prefix G



- ◆ ⇒ ["1.1 Oil pressure sender G10 ", page 3](#)
- ◆ ⇒ ["1.2 Ambient temperature sensor G17 ", page 3](#)
- ◆ ⇒ ["1.3 Engine speed sender G28 ", page 4](#)
- ◆ ⇒ ["1.4 Coolant shortage indicator sender G32 ", page 4](#)
- ◆ ⇒ ["1.5 Windscreen washer fluid level sender G33 ", page 5](#)
- ◆ ⇒ ["1.6 Hall sender G40 ", page 5](#)
- ◆ ⇒ ["1.7 Rear right speed sensor G44 ", page 6](#)
- ◆ ⇒ ["1.8 Front right speed sensor G45 ", page 7](#)
- ◆ ⇒ ["1.9 Rear left speed sensor G46 ", page 7](#)
- ◆ ⇒ ["1.10 Front left speed sensor G47 ", page 8](#)
- ◆ ⇒ ["1.11 Knock sensor 1 G61 ", page 8](#)
- ◆ ⇒ ["1.12 Coolant temperature sender G62 ", page 9](#)
- ◆ ⇒ ["1.13 Air mass meter G70 ", page 10](#)
- ◆ ⇒ ["1.14 Rear right vehicle level sender G77 ", page 11](#)
- ◆ ⇒ ["1.15 Engine outlet coolant temperature sender G82 ", page 11](#)
- ◆ ⇒ ["1.16 Radiator outlet coolant temperature sender G83 ", page 12](#)
- ◆ ⇒ ["1.17 Seat occupied sensor, front passenger side G128 ", page 12](#)
- ◆ ⇒ ["1.18 Left vent temperature sender G150 ", page 13](#)
- ◆ ⇒ ["1.19 Right vent temperature sender G151 ", page 14](#)
- ◆ ⇒ ["1.20 Rear seat occupied sensor, driver side G177 ", page 14](#)
- ◆ ⇒ ["1.21 Rear seat occupied sensor, front passenger side G178 ", page 15](#)
- ◆ ⇒ ["1.22 Side airbag crash sensor on driver side G179 ", page 16](#)
- ◆ ⇒ ["1.23 Side airbag crash sensor on front passenger side G180 ", page 17](#)
- ◆ ⇒ ["1.24 Crash sensor for front airbag G190 ", page 18](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- ◆ ⇒ ["1.25 Footwell vent temperature sender G192 ", page 19](#)
- ◆ ⇒ ["1.26 Rear left parking aid sender G203 ", page 20](#)
- ◆ ⇒ ["1.27 Fuel pressure sender G247 ", page 20](#)
- ◆ ⇒ ["1.28 Front right parking aid sender G252 ", page 21](#)
- ◆ ⇒ ["1.29 Front left parking aid sender G255 ", page 22](#)
- ◆ ⇒ ["1.30 Rear side airbag crash sensor on driver side G256 ", page 22](#)
- ◆ ⇒ ["1.31 Rear side airbag crash sensor on passenger side G257 ", page 23](#)
- ◆ ⇒ ["1.32 Evaporator output temperature sensor G263 ", page 24](#)
- ◆ ⇒ ["1.33 Oil level and oil temperature sender G266 ", page 25](#)
- ◆ ⇒ ["1.34 Hall sender 3 G300 ", page 26](#)
- ◆ ⇒ ["1.35 Intake manifold flap potentiometer G336 ", page 27](#)
- ◆ ⇒ ["1.36 Rain and light sensor G397 ", page 27](#)
- ◆ ⇒ ["1.37 Fuel pressure sender for low pressure G410 ", page 28](#)
- ◆ ⇒ ["1.38 Exterior door handle contact sensor, driver side G415 ", page 28](#)
- ◆ ⇒ ["1.39 Exterior door handle contact sensor, front passenger side G416 ", page 29](#)
- ◆ ⇒ ["1.40 Exhaust gas pressure sensor 1 G450 ", page 29](#)
- ◆ ⇒ ["1.41 Clutch position sender G476 ", page 30](#)
- ◆ ⇒ ["1.42 Exhaust gas temperature sender 3 G495 ", page 31](#)
- ◆ ⇒ ["1.43 Front left sender for park assist steering on left side of vehicle G568 ", page 31](#)
- ◆ ⇒ ["1.44 Front right sender for park assist steering on right side of vehicle G569 ", page 32](#)
- ◆ ⇒ ["1.45 Anti-theft alarm sensor G578 ", page 32](#)
- ◆ ⇒ ["1.46 Vacuum sender G608 ", page 33](#)
- ◆ ⇒ ["1.47 Exhaust gas temperature sender 4 G648 ", page 33](#)
- ◆ ⇒ ["1.48 Gearbox neutral position sender G701 ", page 34](#)
- ◆ ⇒ ["1.49 Rear left park assist steering sender G716 ", page 34](#)
- ◆ ⇒ ["1.50 Rear right park assist steering sender G717 ", page 35](#)


- ◆ ⇒ ["1.51 Pressure sender for refrigerant circuit G805 ", page 35](#)
- ◆ ⇒ ["1.52 Rear centre seat occupied sensor G1010 ", page 36](#)
- ◆ ⇒ ["1.53 Fuel delivery unit GX1 ", page 37](#)
- ◆ ⇒ ["1.54 Accelerator pedal module GX2 ", page 37](#)
- ◆ ⇒ ["1.55 Throttle valve module GX3 ", page 38](#)
- ◆ ⇒ ["1.56 Lambda probe 1 after catalytic converter GX7 ", page 39](#)
- ◆ ⇒ ["1.57 Intake manifold sender GX9 ", page 39](#)
- ◆ ⇒ ["1.58 Lambda probe 1 before catalytic converter GX10 ", page 41](#)
- ◆ ⇒ ["1.59 Charge pressure sender GX26 ", page 42](#)

1.1 Oil pressure sender -G10-

- ◆ ⇒ ["1.1.1 Connector T3f ", page 3](#)

1.1.1 Connector -T3f-

Connector -T3f-



1.2 Ambient temperature sensor -G17-


- ◆ ⇒ ["1.2.1 Connector T2ay ", page 4](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T2ay- Connector -T2ay-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.3 Engine speed sender -G28-

♦ ⇒ ["1.3.1 Connector T3u", page 4](#)

1.3.1 Connector -T3u- Connector -T3u-




1.4 Coolant shortage indicator sender -G32-

♦ ⇒ ["1.4.1 Connector T2bg", page 5](#)

1.4.1 Connector -T2bg-

Connector -T2bg-



1.5 Windscreen washer fluid level sender -G33-


♦ ⇒ ["1.5.1 Connector T2bh", page 5](#)

1.5.1 Connector -T2bh-

Connector -T2bh-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG



1.6 Hall sender -G40-

♦ ⇒ ["1.6.1 Connector T3ad", page 6](#)


♦ ⇒ ["1.6.2 Connector T3ae", page 6](#)

1.6.1 Connector -T3ad-

Connector -T3ad-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.6.2 Connector -T3ae-

Connector -T3ae-



1.7 Rear right speed sensor -G44-


♦ ⇒ ["1.7.1 Connector T2bi", page 7](#)

1.7.1 Connector -T2bi-

Connector -T2bi-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.8 Front right speed sensor -G45-

♦ ⇒ ["1.8.1 Connector T2bj", page 7](#)

1.8.1 Connector -T2bj-

Connector -T2bj-




1.9 Rear left speed sensor -G46-

♦ ⇒ ["1.9.1 Connector T2bk", page 8](#)

1.9.1 Connector -T2bk-

Connector -T2bk-




1.10 Front left speed sensor -G47-

◆ ⇒ ["1.10.1 Connector T2bl", page 8](#)

1.10.1 Connector -T2bl-

Connector -T2bl-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.11 Knock sensor 1 -G61-

◆ ⇒ ["1.11.1 Connector T2bo", page 9](#)

◆ ⇒ ["1.11.2 Connector T2bp", page 9](#)

1.11.1 Connector -T2bo-

Connector -T2bo-




1.11.2 Connector -T2bp-

Connector -T2bp-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.12 Coolant temperature sender -G62-

◆ ⇒ ["1.12.1 Connector T2br", page 10](#)

◆ ⇒ ["1.12.2 Connector T2bs", page 10](#)

1.12.1 Connector -T2br-


Connector -T2br-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.12.2 Connector -T2bs-

Connector -T2bs-




1.13 Air mass meter -G70-

♦ ⇒ ["1.13.1 Connector T4w", page 11](#)

1.13.1 Connector -T4w-

Connector -T4w-




1.14 Rear right vehicle inclination sender -G77-

♦ ⇒ ["1.14.1 Connector T3ap ", page 11](#)

1.14.1 Connector -T3ap-

Connector -T3ap-




1.15 Engine outlet coolant temperature sender -G82-

♦ ⇒ ["1.15.1 Connector T2bv ", page 12](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.15.1 Connector -T2bv-

Connector -T2bv-




1.16 Radiator outlet coolant temperature sender -G83-

♦ ⇒ ["1.16.1 Connector T2bw", page 12](#)

1.16.1 Connector -T2bw-

Connector -T2bw-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.17 Seat occupied sensor, front passenger side -G128-

♦ ⇒ ["1.17.1 Connector T2av", page 13](#)

♦ ⇒ ["1.17.2 Connector T2hp", page 13](#)

1.17.1 Connector -T2av-


Connector -T2av-



1.17.2 Connector -T2hp-

Connector -T2hp-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.18 Left vent temperature sender -G150-

♦ ⇒ ["1.18.1 Connector T2aw ", page 14](#)

1.18.1 Connector -T2aw-

Connector -T2aw-




1.19 Right vent temperature sender -G151-

♦ ⇒ ["1.19.1 Connector T2ax ", page 14](#)

1.19.1 Connector -T2ax-

Connector -T2ax-



1.20 Rear seat occupied sensor, driver side -G177-


♦ ⇒ ["1.20.1 Connector T2az ", page 15](#)

♦ ⇒ ["1.20.2 Connector T2hs ", page 15](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.20.1 Connector -T2az-

Connector -T2az-




1.20.2 Connector -T2hs-

Connector -T2hs-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.21 Rear seat occupied sensor, passenger side -G178-

♦ ⇒ ["1.21.1 Connector T2ba ", page 16](#)

♦ ⇒ ["1.21.2 Connector T2hq ", page 16](#)


1.21.1 Connector -T2ba-

Connector -T2ba-



1.21.2 Connector -T2hq-

Connector -T2hq-



1.22 Side airbag crash sensor on driver side -G179-


♦ ⇒ ["1.22.1 Connector T2bt", page 17](#)

♦ ⇒ ["1.22.2 Connector T2hm", page 17](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.22.1 Connector -T2bt-

Connector -T2bt-




1.22.2 Connector -T2hm-

Connector -T2hm-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.23 Side airbag crash sensor on front passenger side -G180-

♦ ⇒ ["1.23.1 Connector T2bu ", page 18](#)

♦ ⇒ ["1.23.2 Connector T2hn ", page 18](#)


1.23.1 Connector -T2bu-

Connector -T2bu-



1.23.2 Connector -T2hn-

Connector -T2hn-



1.24 Crash sensor for front airbag -G190-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not


- ◆ ⇒ ["1.24.1. Connector T2bb ", page 19](#)
- ◆ ⇒ ["1.24.2. Connector T2hc ", page 19](#)

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this document. Copyright by AUDI AG.


1.24.1 Connector -T2bb-

Connector -T2bb-



1.24.2 Connector -T2hc-

Connector -T2hc-




1.25 Footwell vent temperature sender -G192-

◆ ⇒ ["1.25.1 Connector T2bc", page 20](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.25.1 Connector -T2bc-

Connector -T2bc-




5Q0_973_115

1.26 Rear left parking aid sender -G203-

♦ ⇒ ["1.26.1 Connector T3z", page 20](#)

1.26.1 Connector -T3z-

Connector -T3z-



4F0_973_703

1.27 Fuel pressure sender -G247-


♦ ⇒ ["1.27.1 Connector T3l", page 21](#)

♦ ⇒ ["1.27.2 Connector T3m", page 21](#)

Prohibited from being copied, reproduced, disseminated or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.27.1 Connector -T3l-

Connector -T3l-



1.27.2 Connector -T3m-

Connector -T3m-



1.28 Front right parking aid sender -G252-


♦ ⇒ ["1.28.1 Connector T3y ", page 22](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.28.1 Connector -T3y-

Connector -T3y-




1.29 Front left parking aid sender -G255-

♦ ⇒ ["1.29.1 Connector T3x ", page 22](#)

1.29.1 Connector -T3x-

Connector -T3x-



1.30 Rear side airbag crash sensor on driver side -G256-


♦ ⇒ ["1.30.1 Connector T2bd ", page 23](#)

♦ ⇒ ["1.30.2 Connector T2hd ", page 23](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.30.1 Connector -T2bd-

Connector -T2bd-




1.30.2 Connector -T2hd-

Connector -T2hd-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.31 Rear side airbag crash sensor on front passenger side -G257-

♦ ⇒ ["1.31.1 Connector T2be ", page 24](#)

♦ ⇒ ["1.31.2 Connector T2he ", page 24](#)

1.31.1 Connector -T2be-


Connector -T2be-



1.31.2 Connector -T2he-

Connector -T2he-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.32 Evaporator output temperature sender -G263-

♦ ⇒ ["1.32.1 Connector T2bf", page 25](#)


♦ ⇒ ["1.32.2 Connector T2go", page 25](#)

1.32.1 Connector -T2bf-

Connector -T2bf-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.32.2 Connector -T2go-

Connector -T2go-



1.33 Oil level and oil temperature sender -G266-

- ◆ ⇒ ["1.33.1 Connector T3s ", page 26](#)
- ◆ ⇒ ["1.33.2 Connector T3t ", page 26](#)

1.33.1 Connector -T3s-



Connector -T3s-



1.33.2 Connector -T3t-

Connector -T3t-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.34 Hall sender 3 -G300-

◆ ⇒ ["1.34.1 Connector T3g", page 27](#)

1.34.1 Connector -T3g-

Connector -T3g-



1.35 Intake manifold flap potentiometer -G336-


♦ ⇒ ["1.35.1 Connector T3ab ", page 27](#)

1.35.1 Connector -T3ab-

Connector -T3ab-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG




1.36 Rain and light sensor -G397-

♦ ⇒ ["1.36.1 Connector T3ac ", page 28](#)

1.36.1 Connector -T3ac-

Connector -T3ac-



1.37 Fuel pressure sender for low-pressure -G410-


♦ ⇒ ["1.37.1 Connector T3af", page 28](#)

1.37.1 Connector -T3af-

Connector -T3af-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.38 Driver door exterior handle contact sensor -G415-

♦ ⇒ ["1.38.1 Connector T2bm", page 29](#)

1.38.1 Connector -T2bm-

Connector -T2bm-




4F0_973_702

1.39 Front passenger door exterior handle contact sensor -G416-

♦ ⇒ ["1.39.1 Connector T2bn", page 29](#)

1.39.1 Connector -T2bn-

Connector -T2bn-



4F0_973_702



1.40 Exhaust gas pressure sensor 1 -G450-


♦ ⇒ ["1.40.1 Connector T3ag", page 30](#)

♦ ⇒ ["1.40.2 Connector T3ah", page 30](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.40.1 Connector -T3ag-

Connector -T3ag-




1.40.2 Connector -T3ah-

Connector -T3ah-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.41 Clutch position sender -G476-

◆ ⇒ ["1.41.1 Connector T5d", page 31](#)

1.41.1 Connector -T5d-

Connector -T5d-




1.42 Exhaust gas temperature sender 3 -G495-

♦ ⇒ ["1.42.1 Connector T3aj", page 31](#)

1.42.1 Connector -T3aj-

Connector -T3aj-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.43 Front left sender for park assist steering on left side of vehicle -G568-

♦ ⇒ ["1.43.1 Connector T3r", page 32](#)

1.43.1 Connector -T3r-

Connector -T3r-




1.44 Front right sender for park assist steering on right side of vehicle -G569-

♦ ⇒ ["1.44.1 Connector T3o ", page 32](#)

1.44.1 Connector -T3o-

Connector -T3o-




1.45 Anti-theft alarm sensor -G578-

♦ ⇒ ["1.45.1 Connector T4t ", page 33](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.45.1 Connector -T4t-

Connector -T4t-




1.46 Vacuum sender -G608-

♦ ⇒ ["1.46.1 Connector T3ai", page 33](#)

1.46.1 Connector -T3ai-

Connector -T3ai-




1.47 Exhaust gas temperature sender 4 -G648-

♦ ⇒ ["1.47.1 Connector T3ak", page 34](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.47.1 Connector -T3ak-

Connector -T3ak-




1.48 Gearbox neutral position sender -G701-

♦ ⇒ ["1.48.1 Connector T3am", page 34](#)

1.48.1 Connector -T3am-

Connector -T3am-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.49 Rear left park assist steering sender -G716-

♦ ⇒ ["1.49.1 Connector T3h", page 35](#)

1.49.1 Connector -T3h-

Connector -T3h-



1.50 Rear right park assist steering sender -G717-


♦ ⇒ ["1.50.1 Connector T3k ", page 35](#)

1.50.1 Connector -T3k-

Connector -T3k-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.51 Pressure sender for refrigerant circuit -G805-

♦ ⇒ ["1.51.1 Connector T3aq ", page 36](#)

1.51.1 Connector -T3aq-

Connector -T3aq-



1.52 Rear centre seat occupied sensor -G1010-


♦ ⇒ ["1.52.1 Connector T2au", page 36](#)

♦ ⇒ ["1.52.2 Connector T2hr", page 37](#)

1.52.1 Connector -T2au-


Connector -T2au-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.52.2 Connector -T2hr-

Connector -T2hr-




1.53 Fuel delivery unit -GX1-

♦ ⇒ ["1.53.1 Connector T5e ", page 37](#)

1.53.1 Connector -T5e-

Connector -T5e-



1.54 Accelerator pedal module -GX2-


♦ ⇒ ["1.54.1 Connector T6I ", page 38](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.54.1 Connector -T6l-

Connector -T6l-




1.55 Throttle valve module -GX3-

- ♦ ⇒ ["1.55.1 Connector T6m", page 38](#)
 - ♦ ⇒ ["1.55.2 Connector T6n", page 39](#)
- with respect to the correctness of information in this document. Copyright by AUDI AG.

1.55.1 Connector -T6m-

Connector -T6m-




1.55.2 Connector -T6n-

Connector -T6n-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.56 Lambda probe 1 after catalytic converter -GX7-

♦ ⇒ [“1.56.1 Connector T4z”, page 39](#)

1.56.1 Connector -T4z-

Connector -T4z-



1.57 Intake manifold sender -GX9-


♦ ⇒ [“1.57.1 Connector T3ao”, page 40](#)

♦ ⇒ [“1.57.2 Connector T4aa”, page 40](#)

♦ ⇒ [“1.57.3 Connector T4x”, page 41](#)


1.57.1 Connector -T3ao-

Connector -T3ao-



1.57.2 Connector -T4aa-

Connector -T4aa-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.57.3 Connector -T4x-

Connector -T4x-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.58 Lambda probe 1 before catalytic converter -GX10-


◆ ⇒ [“1.58.1 Connector T4y”, page 41](#)

◆ ⇒ [“1.58.2 Connector T5f”, page 42](#)

◆ ⇒ [“1.58.3 Connector T6k”, page 42](#)


1.58.1 Connector -T4y-

Connector -T4y-




1.58.2 Connector -T5f-

Connector -T5f-



1.58.3 Connector -T6k-

Connector -T6k-




1.59 Charge pressure sender -GX26-

- ◆ ⇒ ["1.59.1 Connector T3w ", page 43](#)
- ◆ ⇒ ["1.59.2 Connector T4u ", page 43](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.59.1 Connector -T3w-


Connector -T3w-



1.59.2 Connector -T4u-

Connector -T4u-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1 Parts with prefix H to I

⇒ [“1.1 Treble horn H2”, page 1](#)

⇒ [“1.2 Bass horn H7”, page 1](#)

⇒ [“1.3 Alarm horn H12”, page 2](#)




1.1 Treble horn -H2-

◆ ⇒ [“1.1.1 Connector T2bx”, page 1](#)

1.1.1 Connector -T2bx-

Connector -T2bx-




1.2 Bass horn -H7-

◆ ⇒ [“1.2.1 Connector T2by”, page 2](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T2by-

Connector -T2by-



1.3 Alarm horn -H12-


♦ ⇒ ["1.3.1 Connector T3ar", page 2](#)

1.3.1 Connector -T3ar-

Connector -T3ar-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1 Parts with prefix J

- ◆
- ◆ ⇒ ["1.1 ABS control unit J104 ", page 2](#)
- ◆ ⇒ ["1.2 Fresh air blower control unit J126 ", page 2](#)
- ◆ ⇒ ["1.3 Airbag control unit J234 ", page 3](#)
- ◆ ⇒ ["1.4 Electronically controlled damping control unit J250 ", page 4](#)
- ◆ ⇒ ["1.5 Control unit in dash panel insert J285 ", page 5](#)
- ◆ ⇒ ["1.6 Battery monitor control unit J367 ", page 6](#)
- ◆ ⇒ ["1.7 Driver door control unit J386 ", page 6](#)
- ◆ ⇒ ["1.8 Front passenger door control unit J387 ", page 8](#)
- ◆ ⇒ ["1.9 Adaptive cruise control unit J428 ", page 10](#)
- ◆ ⇒ ["1.10 Parking aid control unit J446 ", page 11](#)
- ◆ ⇒ ["1.11 Power steering control unit J500 ", page 12](#)
- ◆ ⇒ ["1.12 Entry and start authorisation control unit J518 ", page 13](#)
- ◆ ⇒ ["1.13 Onboard supply control unit J519 ", page 13](#)
- ◆ ⇒ ["1.14 Digital sound package control unit J525 ", page 15](#)
- ◆ ⇒ ["1.15 Steering column electronics control unit J527 ", page 16](#)
- ◆ ⇒ ["1.16 Data bus diagnostic interface J533 ", page 17](#)
- ◆ ⇒ ["1.17 Fuel pump control unit J538 ", page 17](#)
- ◆ ⇒ ["1.18 Engine control unit J623 ", page 18](#)
- ◆ ⇒ ["1.19 Chip card reader control unit J676 ", page 19](#)
- ◆ ⇒ ["1.20 Mechatronic unit for dual clutch gearbox J743 ", page 21](#)
- ◆ ⇒ ["1.21 Control unit for cornering light and headlight range control J745 ", page 22](#)
- ◆ ⇒ ["1.22 Control unit for electronic steering column lock J764 ", page 22](#)
- ◆ ⇒ ["1.23 Reversing camera system control unit J772 ", page 23](#)
- ◆ ⇒ ["1.24 Control unit 1 for information electronics J794 ", page 24](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- ◆ ⇒ ["1.25 Control unit for structure-borne sound J869", page 33](#)
- ◆ ⇒ ["1.26 Exhaust flap control unit J883", page 33](#)
- ◆ ⇒ ["1.27 Emergency call module control unit and communication unit J949", page 34](#)
- ◆ ⇒ ["1.28 Control unit with rear driver side window regulator motor J1016", page 36](#)
- ◆ ⇒ ["1.29 Control unit with rear passenger side window regulator motor J1017", page 37](#)
- ◆ ⇒ ["1.30 Blind Spot Monitor control unit J1086", page 38](#)
- ◆ ⇒ ["1.31 Blind Spot Monitor control unit 2 J1087", page 39](#)
- ◆ ⇒ ["1.32 Charger 1 for mobile devices J1146", page 39](#)

1.1 ABS control unit -J104-

- ◆ ⇒ ["1.1.1 Connector T38a", page 2](#)

1.1.1 Connector -T38a-

Connector -T38a-




1.2 Fresh air blower control unit -J126-

- ◆ ⇒ ["1.2.1 Connector T4q", page 3](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T4q-

Connector -T4q-



1.3 Airbag control unit -J234-

♦ ⇒ ["1.3.1 Connector T90a ", page 3](#)

♦ ⇒ ["1.3.2 Connector T90b ", page 4](#)


♦ ⇒ ["1.3.3 Connector T90c ", page 4](#)

1.3.1 Connector -T90a-

Connector -T90a-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.3.2 Connector -T90b-

Connector -T90b-



1.3.3 Connector -T90c-

Connector -T90c-




1.4 Electronically controlled damping control unit -J250-

◆ ⇒ ["1.4.1 Connector T18b", page 5](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.4.1 Connector -T18b-

Connector -T18b-




1.5 Control unit in dash panel insert -J285-

- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
- ◆ ⇒ ["1.5.1 Connector T18a", page 5](#)
 - ◆ ⇒ ["1.5.2 Connector T2gb", page 6](#)


1.5.1 Connector -T18a-

Connector -T18a-



1.5.2 Connector -T2gb-

Connector -T2gb-




1.6 Battery monitor control unit -J367-

♦ ⇒ ["1.6.1 Connector T2gh", page 6](#)

1.6.1 Connector -T2gh-

Connector -T2gh-



1.7 Driver door control unit -J386-

♦ ⇒ ["1.7.1 Connector T16g", page 7](#)


♦ ⇒ ["1.7.2 Connector T20h", page 7](#)

♦ ⇒ ["1.7.3 Connector T32a", page 8](#)

♦ ⇒ ["1.7.4 Connector T6o", page 8](#)


1.7.1 Connector -T16g-

Connector -T16g-



1.7.2 Connector -T20h-


Connector -T20h-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.7.3 Connector -T32a-

Connector -T32a-




1.7.4 Connector -T6o-

Connector -T6o-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.8 Front passenger door control unit -J387-


- ◆ ⇒ ["1.8.1 Connector T16h ", page 9](#)
- ◆ ⇒ ["1.8.2 Connector T20i ", page 9](#)
- ◆ ⇒ ["1.8.3 Connector T32b ", page 10](#)
- ◆ ⇒ ["1.8.4 Connector T6p ", page 10](#)

1.8.1 Connector -T16h-

Connector -T16h-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.8.2 Connector -T20i-

Connector -T20i-



1.8.3 Connector -T32b-

Connector -T32b-




1.8.4 Connector -T6p-

Connector -T6p-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability




1.9 Adaptive cruise control unit -J428-

♦ ⇒ ["1.9.1 Connector T7a", page 11](#)

1.9.1 Connector -T7a-

Connector -T7a-



1.10 Parking aid control unit -J446-

♦ ⇒ ["1.10.1 Connector T18c", page 11](#)


♦ ⇒ ["1.10.2 Connector T26b", page 12](#)

1.10.1 Connector -T18c-

Connector -T18c-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.10.2 Connector -T26b-

Connector -T26b-



1.11 Power steering control unit -J500-

♦ ⇒ ["1.11.1 Connector T2ee ", page 12](#)


♦ ⇒ ["1.11.2 Connector T3be ", page 13](#)

1.11.1 Connector -T2ee-

Connector -T2ee-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.11.2 Connector -T3be-

Connector -T3be-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.12 Entry and start authorisation control unit -J518-

♦ ⇒ ["1.12.1 Connector T40a ", page 13](#)

1.12.1 Connector -T40a-

Connector -T40a-



1.13 Onboard supply control unit -J519-


♦ ⇒ ["1.13.1 Connector T46a ", page 14](#)

♦ ⇒ ["1.13.2 Connector T73a ", page 14](#)

♦ ⇒ ["1.13.3 Connector T73b ", page 15](#)


1.13.1 Connector -T46a-

Connector -T46a-



1.13.2 Connector -T73a-


Connector -T73a-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.13.3 Connector -T73b-

Connector -T73b-




1.14 Digital sound package control unit -J525-

♦ ⇒ ["1.14.1 Connector T2gd ", page 15](#)

♦ ⇒ ["1.14.2 Connector T38b ", page 16](#)

1.14.1 Connector -T2gd-


Connector -T2gd-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.14.2 Connector -T38b-

Connector -T38b-



1.15 Steering column electronics control unit -J527-


♦ ⇒ ["1.15.1 Connector T12e", page 16](#)

♦ ⇒ ["1.15.2 Connector T16a", page 17](#)

1.15.1 Connector -T12e-


Connector -T12e-

Copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.15.2 Connector -T16a-

Connector -T16a-




1.16 Data bus diagnostic interface -J533-

♦ ⇒ ["1.16.1 Connector T20f", page 17](#)

1.16.1 Connector -T20f-

Connector -T20f-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.17 Fuel pump control unit -J538-

♦ ⇒ ["1.17.1 Connector T5g", page 18](#)

1.17.1 Connector -T5g-

Connector -T5g-



1.18 Engine control unit -J623-


◆ ⇒ ["1.18.1 Connector T60b", page 18](#)

◆ ⇒ ["1.18.2 Connector T91a", page 19](#)

◆ ⇒ ["1.18.3 Connector T94a", page 19](#)


1.18.1 Connector -T60b-

Connector -T60b-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Connector -T91a-



Connector -T94a-



1.19 Chip card reader control unit -J676-


- ◆ ⇒ [“1.19.1 Connector T10n”, page 20](#)
- ◆ ⇒ [“1.19.2 Connector T2hv”, page 20](#)
- ◆ ⇒ [“1.19.3 Connector T5af”, page 21](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.19.1 Connector -T10n-

Connector -T10n-



1.19.2 Connector -T2hv-


Connector -T2hv-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.3 Connector -T5af-

Connector -T5af-



1.20 Mechatronic unit for dual clutch gearbox -J743-

♦ ⇒ ["1.20.1 Connector T20g ", page 21](#)


♦ ⇒ ["1.20.2 Connector T25a ", page 22](#)

1.20.1 Connector -T20g-

Connector -T20g-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.20.2 Connector -T25a-

Connector -T25a-




1.21 Control unit for cornering light and headlight range control -J745-

♦ ⇒ ["1.21.1 Connector T20e", page 22](#)

1.21.1 Connector -T20e-

Connector -T20e-




1.22 Control unit for electronic steering column lock -J764-

♦ ⇒ ["1.22.1 Connector T4ac", page 23](#)

1.22.1 Connector -T4ac-

Connector -T4ac-




1.23 Reversing camera system control unit -J772-

♦ ⇒ ["1.23.1 Connector T2gc ", page 23](#)

♦ ⇒ ["1.23.2 Connector T8y ", page 24](#)

1.23.1 Connector -T2gc-


Connector -T2gc-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.23.2 Connector -T8y-

Connector -T8y-



1.24 Control unit 1 for information electronics -J794-


- ◆ ⇒ ["1.24.1 Connector T12b ", page 25](#)
- ◆ ⇒ ["1.24.2 Connector T12c ", page 25](#)
- ◆ ⇒ ["1.24.3 Connector T12d ", page 26](#)
- ◆ ⇒ ["1.24.4 Connector T2gk ", page 26](#)
- ◆ ⇒ ["1.24.5 Connector T2gl ", page 27](#)
- ◆ ⇒ ["1.24.6 Connector T2gm ", page 27](#)
- ◆ ⇒ ["1.24.7 Connector T2gn ", page 28](#)
- ◆ ⇒ ["1.24.8 Connector T4bh ", page 28](#)
- ◆ ⇒ ["1.24.9 Connector T4bi ", page 29](#)
- ◆ ⇒ ["1.24.10 Connector T4bv ", page 29](#)
- ◆ ⇒ ["1.24.11 Connector T5ag ", page 30](#)
- ◆ ⇒ ["1.24.12 Connector T5o ", page 30](#)
- ◆ ⇒ ["1.24.13 Connector T5p ", page 31](#)
- ◆ ⇒ ["1.24.14 Connector T5q ", page 31](#)
- ◆ ⇒ ["1.24.15 Connector T5r ", page 32](#)
- ◆ ⇒ ["1.24.16 Connector T8ae ", page 32](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

♦ ⇒ ["1.24.17 Connector T8z ", page 33](#)


1.24.1 Connector -T12b-

Connector -T12b-



1.24.2 Connector -T12c-

Connector -T12c-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.24.3 Connector -T12d-

Connector -T12d-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.24.4 Connector -T2gk-

Connector -T2gk-




1.24.5 Connector -T2gl-

Connector -T2gl-



1.24.6 Connector -T2gm-


Connector -T2gm-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.24.7 Connector -T2gn-

Connector -T2gn-




1.24.8 Connector -T4bh-

Connector -T4bh-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.24.9 Connector -T4bi-

Connector -T4bi-



1.24.10 Connector -T4bv-


Connector -T4bv-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.24.11 Connector -T5ag-

Connector -T5ag-




1.24.12 Connector -T5o-

Connector -T5o-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.24.13 Connector -T5p-

Connector -T5p-




1.24.14 Connector -T5q-

Connector -T5q-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.24.15 Connector -T5r-

Connector -T5r-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.24.16 Connector -T8ae-

Connector -T8ae-



1.24.17 Connector -T8z-

Connector -T8z-




1.25 Control unit for structure-borne sound -J869-

♦ ⇒ ["1.25.1 Connector T6q", page 33](#)

1.25.1 Connector -T6q-

Connector -T6q-



1.26 Exhaust flap control unit -J883-

♦ ⇒ ["1.26.1 Connector T3as", page 34](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.26.1 Connector -T3as-

Connector -T3as-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.27 Emergency call module control unit and communication unit -J949-

- ◆ ⇒ ["1.27.1 Connector T36a ", page 34](#)
- ◆ ⇒ ["1.27.2 Connector T26a ", page 35](#)
- ◆ ⇒ ["1.27.3 Connector T4bf ", page 35](#)
- ◆ ⇒ ["1.27.4 Connector T4ce ", page 36](#)
- ◆ ⇒ ["1.27.5 Connector T4cf ", page 36](#)


1.27.1 Connector -T36a-

Connector -T36a-



1.27.2 Connector -T26a-

Connector -T26a-




1.27.3 Connector -T4bf-

Connector -T4bf-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.27.4 Connector -T4ce-



Connector -T4ce-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.27.5 Connector -T4cf-

Connector -T4cf-




1.28 Control unit with rear driver side window regulator motor -J1016-

- ◆ ⇒ ["1.28.1 Connector T10i", page 37](#)
- ◆ ⇒ ["1.28.2 Connector T10o", page 37](#)

1.28.1 Connector -T10i-


Connector -T10i-



1.28.2 Connector -T10o-

Connector -T10o-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.29 Control unit with rear passenger side window regulator motor -J1017-

- ◆ ⇒ ["1.29.1 Connector T10j", page 38](#)
- ◆ ⇒ ["1.29.2 Connector T10p", page 38](#)

1.29.1 Connector -T10j-

Connector -T10j-




1.29.2 Connector -T10p-

Connector -T10p-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.30 Blind Spot Monitor control unit -J1086-

♦ ⇒ ["1.30.1 Connector T8ai", page 39](#)

1.30.1 Connector -T8ai-

Connector -T8ai-




1.31 Blind Spot Monitor control unit 2 -J1087-

♦ ⇒ ["1.31.1 Connector T8aj", page 39](#)

1.31.1 Connector -T8aj-

Connector -T8aj-



1.32 Charger 1 for mobile devices -J1146-


♦ ⇒ ["1.32.1 Connector T2gf", page 40](#)

♦ ⇒ ["1.32.2 Connector T6x", page 40](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.32.1 Connector -T2gf-


Connector -T2gf-




6Q0_035_674_C

1.32.2 Connector -T6x-

Connector -T6x-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



4B0_971_978_B

1 Parts with prefix K to M



- ◆ ⇒ ["1.1 Central locking SAFELOCK function warning lamp K133 ", page 1](#)
- ◆ ⇒ ["1.2 Storage compartment illumination bulb L120 ", page 2](#)
- ◆ ⇒ ["1.3 Light 1 for rear left door ambient lighting L201 ", page 2](#)
- ◆ ⇒ ["1.4 Light 1 for rear right door ambient lighting L202 ", page 3](#)
- ◆ ⇒ ["1.5 Light for driver side interior door handle illumination L219 ", page 3](#)
- ◆ ⇒ ["1.6 Light for passenger side interior door handle illumination L220 ", page 4](#)
- ◆ ⇒ ["1.7 Light 1 for dashboard ambient lighting L292 ", page 4](#)
- ◆ ⇒ ["1.8 Light 2 for dashboard ambient lighting L293 ", page 5](#)
- ◆ ⇒ ["1.9 High-level brake light bulb M25 ", page 5](#)
- ◆ ⇒ ["1.10 Front left headlight MX1 ", page 6](#)
- ◆ ⇒ ["1.11 Front right headlight MX2 ", page 7](#)
- ◆ ⇒ ["1.12 Left tail light cluster MX3 ", page 8](#)
- ◆ ⇒ ["1.13 Right tail light MX4 ", page 9](#)
- ◆ ⇒ ["1.14 Left tail light 2 MX5 ", page 10](#)
- ◆ ⇒ ["1.15 Right tail light 2 MX6 ", page 11](#)

1.1 Central locking SAFELOCK function warning lamp -K133-

- ◆ ⇒ ["1.1.1 Connector T2bz ", page 2](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.1.1 Connector -T2bz-

Connector -T2bz-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.2 Storage compartment illumination bulb -L120-

♦ ⇒ ["1.2.1 Connector T4ad", page 2](#)

1.2.1 Connector -T4ad-

Connector -T4ad-




1.3 Light 1 for rear left door ambient lighting -L201-

♦ ⇒ ["1.3.1 Connector T2cc", page 3](#)

1.3.1 Connector -T2cc-

Connector -T2cc-



1.4 Light 1 for rear right door ambient lighting -L202-


♦ ⇒ ["1.4.1 Connector T2cd ", page 3](#)

1.4.1 Connector -T2cd-

Connector -T2cd-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.5 Light for driver side interior door handle illumination -L219-

♦ ⇒ ["1.5.1 Connector T2ce ", page 4](#)

1.5.1 Connector -T2ce-

Connector -T2ce-



1.6 Light for front passenger side interior door handle illumination -L220-


♦ ⇒ ["1.6.1 Connector T2cf", page 4](#)

1.6.1 Connector -T2cf-

Connector -T2cf-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.7 Light 1 for dashboard ambient lighting -L292-

♦ ⇒ ["1.7.1 Connector T4ai", page 5](#)

1.7.1 Connector -T4ai-

Connector -T4ai-




1.8 Light 2 for dashboard ambient lighting -L293-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorized by AUDI AG. AUDI AG does not guarantee or accept any liability

♦ ⇒ ["1.8.1 Connector T4aj", page 5](#) with respect to the correctness of information in this document. Copyright by AUDI AG.

1.8.1 Connector -T4aj-

Connector -T4aj-




1.9 High-level brake light bulb -M25-

♦ ⇒ ["1.9.1 Connector T2h", page 6](#)

1.9.1 Connector -T2h-

Connector -T2h-



1.10 Front left headlight -MX1-

♦ ⇒ ["1.10.1 Connector T10g", page 6](#)


♦ ⇒ ["1.10.2 Connector T8aa", page 7](#)

1.10.1 Connector -T10g-

Connector -T10g-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.10.2 Connector -T8aa-

Connector -T8aa-




1.11 Front right headlight -MX2-

♦ ⇒ ["1.11.1 Connector T10h", page 7](#)

♦ ⇒ ["1.11.2 Connector T8ab", page 8](#)

1.11.1 Connector -T10h-


Connector -T10h-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.11.2 Connector -T8ab-

Connector -T8ab-



1.12 Left tail light -MX3-

♦ ⇒ ["1.12.1 Connector T4ak", page 8](#)


♦ ⇒ ["1.12.2 Connector T6r", page 9](#)

1.12.1 Connector -T4ak-

Connector -T4ak-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee the accuracy of the information with respect to the correctness of information in this document. Copyright © AUDI AG.



1.12.2 Connector -T6r-

Connector -T6r-



1.13 Right tail light -MX4-

♦ ⇒ ["1.13.1 Connector T4al", page 9](#)


♦ ⇒ ["1.13.2 Connector T6s", page 10](#)

1.13.1 Connector -T4al-

Connector -T4al-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.13.2 Connector -T6s-

Connector -T6s-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.14 Left tail light 2 -MX5-


◆ ⇒ ["1.14.1 Connector T4am", page 10](#)

◆ ⇒ ["1.14.2 Connector T4an", page 11](#)

◆ ⇒ ["1.14.3 Connector T6u", page 11](#)


1.14.1 Connector -T4am-

Connector -T4am-




1.14.2 Connector -T4an-

Connector -T4an-



1.14.3 Connector -T6u-

Connector -T6u-




1.15 Right tail light 2 -MX6-

- ◆ ⇒ ["1.15.1 Connector T4ao ", page 12](#)
- ◆ ⇒ ["1.15.2 Connector T4ap ", page 12](#)
- ◆ ⇒ ["1.15.3 Connector T6w ", page 13](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.15.1 Connector -T4ao-

Connector -T4ao-




1.15.2 Connector -T4ap-

Connector -T4ap-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.15.3 Connector -T6w-

Connector -T6w-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix N




- ◆ ⇒ [“1.1 Injector, cylinder 1 N30 ”, page 2](#)
- ◆ ⇒ [“1.2 Injector, cylinder 2 N31 ”, page 4](#)
- ◆ ⇒ [“1.3 Injector, cylinder 3 N32 ”, page 5](#)
- ◆ ⇒ [“1.4 Injector, cylinder 4 N33 ”, page 7](#)
- ◆ ⇒ [“1.5 Ignition coil 1 with output stage N70 ”, page 8](#)
- ◆ ⇒ [“1.6 Activated charcoal filter solenoid valve 1 N80 ”, page 8](#)
- ◆ ⇒ [“1.7 Coolant shut-off valve N82 ”, page 10](#)
- ◆ ⇒ [“1.8 Driver side airbag igniter N95 ”, page 10](#)
- ◆ ⇒ [“1.9 Ignition coil 2 with output stage N127 ”, page 11](#)
- ◆ ⇒ [“1.10 Front passenger side airbag igniter 1 N131 ”, page 11](#)
- ◆ ⇒ [“1.11 Rear belt tensioner igniter on driver side N196 ”, page 12](#)
- ◆ ⇒ [“1.12 Rear belt tensioner igniter on passenger side N197 ”, page 13](#)
- ◆ ⇒ [“1.13 Side airbag igniter on driver side N199 ”, page 14](#)
- ◆ ⇒ [“1.14 Side airbag igniter on front passenger side N200 ”, page 15](#)
- ◆ ⇒ [“1.15 Camshaft control valve 1 N205 ”, page 16](#)
- ◆ ⇒ [“1.16 Turbocharger air recirculation valve N249 ”, page 18](#)
- ◆ ⇒ [“1.17 Driver side curtain airbag igniter N251 ”, page 18](#)
- ◆ ⇒ [“1.18 Front passenger side curtain airbag igniter N252 ”, page 19](#)
- ◆ ⇒ [“1.19 Air conditioner compressor regulating valve N280 ”, page 20](#)
- ◆ ⇒ [“1.20 Fuel metering valve N290 ”, page 21](#)
- ◆ ⇒ [“1.21 Ignition coil 3 with output stage N291 ”, page 21](#)
- ◆ ⇒ [“1.22 Ignition coil 4 with output stage N292 ”, page 22](#)
- ◆ ⇒ [“1.23 Intake manifold flap valve N316 ”, page 22](#)
- ◆ ⇒ [“1.24 Exhaust camshaft control valve 1 N318 ”, page 23](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- ◆ ⇒ ["1.25 Front left shock absorber damping adjustment valve N336 ", page 23](#)
- ◆ ⇒ ["1.26 Front right shock absorber damping adjustment valve N337 ", page 24](#)
- ◆ ⇒ ["1.27 Rear left shock absorber damping adjustment valve N338 ", page 24](#)
- ◆ ⇒ ["1.28 Rear right shock absorber damping adjustment valve N339 ", page 25](#)
- ◆ ⇒ ["1.29 Ignition key withdrawal lock solenoid N376 ", page 25](#)
- ◆ ⇒ ["1.30 Valve for oil pressure control N428 ", page 26](#)
- ◆ ⇒ ["1.31 Coolant valve for gearbox N488 ", page 27](#)
- ◆ ⇒ ["1.32 Actuator for engine temperature regulation N493 ", page 28](#)
- ◆ ⇒ ["1.33 Piston cooling jet control valve N522 ", page 29](#)
- ◆ ⇒ ["1.34 Injector 2, cylinder 1 N532 ", page 29](#)
- ◆ ⇒ ["1.35 Injector 2, cylinder 2 N533 ", page 30](#)
- ◆ ⇒ ["1.36 Injector 2, cylinder 3 N534 ", page 30](#)
- ◆ ⇒ ["1.37 Injector 2, cylinder 4 N535 ", page 31](#)
- ◆ ⇒ ["1.38 Cylinder 2 inlet cam actuator N583 ", page 31](#)
- ◆ ⇒ ["1.39 Cylinder 2 exhaust cam actuator N587 ", page 32](#)
- ◆ ⇒ ["1.40 Cylinder 3 inlet cam actuator N591 ", page 32](#)
- ◆ ⇒ ["1.41 Cylinder 3 exhaust cam actuator N595 ", page 33](#)
- ◆ ⇒ ["1.42 Front left seat belt NX10 ", page 33](#)
- ◆ ⇒ ["1.43 Front right seat belt NX11 ", page 36](#)

1.1 Injector, cylinder 1 -N30-


- ◆ ⇒ ["1.1.1 Connector T2da ", page 3](#)
- ◆ ⇒ ["1.1.2 Connector T2db ", page 3](#)
- ◆ ⇒ ["1.1.3 Connector T2dc ", page 4](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.1.1 Connector -T2da-


Connector -T2da-



04E_973_702

1.1.2 Connector -T2db-

Connector -T2db-




4F0_973_702



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.1.3 Connector -T2dc- Connector -T2dc-



1.2 Injector, cylinder 2 -N31-


- ◆ ⇒ ["1.2.1 Connector T2dd ", page 4](#)
- ◆ ⇒ ["1.2.2 Connector T2de ", page 5](#)
- ◆ ⇒ ["1.2.3 Connector T2df ", page 5](#)

1.2.1 Connector -T2dd- Connector -T2dd-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.2 Connector -T2de- Connector -T2de-



1.2.3 Connector -T2df- Connector -T2df-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the express written consent of AUDI AG. AUDI AG does not guarantee or accept any liability

1.3 Injector, cylinder 3 -N32-

- ◆ ⇒ ["1.3.1 Connector T2dj", page 6](#)
- ◆ ⇒ ["1.3.2 Connector T2dk", page 6](#)
- ◆ ⇒ ["1.3.3 Connector T2dl", page 7](#)

1.3.1 Connector -T2dj-


Connector -T2dj-



04E_973_702

1.3.2 Connector -T2dk-

Connector -T2dk-




4F0_973_702



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.3.3 Connector -T2dl-

Connector -T2dl-



1.4 Injector, cylinder 4 -N33-


♦ ⇒ ["1.4.1 Connector T2dm", page 7](#)

♦ ⇒ ["1.4.2 Connector T2dn", page 8](#)

1.4.1 Connector -T2dm-

Connector -T2dm-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.4.2 Connector -T2dn-

Connector -T2dn-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.5 Ignition coil 1 with output stage -N70-

♦ ⇒ ["1.5.1 Connector T4at", page 8](#)

1.5.1 Connector -T4at-

Connector -T4at-



1.6 Activated charcoal filter solenoid valve 1 -N80-


♦ ⇒ ["1.6.1 Connector T2ec", page 9](#)

♦ ⇒ ["1.6.2 Connector T2ed", page 9](#)

♦ ⇒ ["1.6.3 Connector T2ig", page 10](#)


1.6.1 Connector -T2ec-

Connector -T2ec-



1.6.2 Connector -T2ed-


Connector -T2ed-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.6.3 Connector -T2ig-

Connector -T2ig-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.7 Coolant shut-off valve -N82-

♦ ⇒ ["1.7.1 Connector T2w", page 10](#)

1.7.1 Connector -T2w-

Connector -T2w-




1.8 Driver side airbag igniter -N95-

♦ ⇒ ["1.8.1 Connector T2gy", page 11](#)

1.8.1 Connector -T2gy-

Connector -T2gy-



1.9 Ignition coil 2 with output stage -N127-


♦ ⇒ ["1.9.1 Connector T4aq", page 11](#)

1.9.1 Connector -T4aq-

Connector -T4aq-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.10 Front passenger side airbag igniter 1 -N131-

♦ ⇒ ["1.10.1 Connector T3at", page 12](#)

♦ ⇒ ["1.10.2 Connector T3br", page 12](#)

1.10.1 Connector -T3at-

Connector -T3at-




1.10.2 Connector -T3br-

Connector -T3br-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.11 Rear belt tensioner igniter on driver side -N196-

- ◆ ⇒ ["1.11.1 Connector T2cp ", page 13](#)
- ◆ ⇒ ["1.11.2 Connector T2hh ", page 13](#)

1.11.1 Connector -T2cp-

Connector -T2cp-




1.11.2 Connector -T2hh-

Connector -T2hh-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.12 Rear belt tensioner igniter on front passenger side -N197-

- ◆ ⇒ ["1.12.1 Connector T2cq ", page 14](#)
- ◆ ⇒ ["1.12.2 Connector T2hi ", page 14](#)


1.12.1 Connector -T2cq-

Connector -T2cq-



1.12.2 Connector -T2hi-

Connector -T2hi-




1.13 Side airbag igniter on driver side -N199-

- ◆ ⇒ ["1.13.1 Connector T3au ", page 15](#)
- ◆ ⇒ ["1.13.2 Connector T3bt ", page 15](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.13.1 Connector -T3au-

Connector -T3au-



1.13.2 Connector -T3bt-

Connector -T3bt-



1.14 Side airbag igniter on front passenger side -N200-


- ◆ ⇒ ["1.14.1 Connector T3bk ", page 16](#)

- ◆ ⇒ ["1.14.2 Connector T3bs ", page 16](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.14.1 Connector -T3bk-

Connector -T3bk-



1.14.2 Connector -T3bs-

Connector -T3bs-



1.15 Camshaft control valve 1 -N205-

- ◆ ⇒ ["1.15.1 Connector T2cr ", page 17](#)
- ◆ ⇒ ["1.15.2 Connector T2cs ", page 17](#)
- ◆ ⇒ ["1.15.3 Connector T2cu ", page 18](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.15.1 Connector -T2cr-

Connector -T2cr-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.15.2 Connector -T2cs-

Connector -T2cs-



1.15.3 Connector -T2cu-

Connector -T2cu-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.16 Turbocharger air recirculation valve -N249-

♦ ⇒ ["1.16.1 Connector T2cv", page 18](#)

1.16.1 Connector -T2cv-

Connector -T2cv-




1.17 Driver side curtain airbag igniter -N251-

♦ ⇒ ["1.17.1 Connector T2cw", page 19](#)

♦ ⇒ ["1.17.2 Connector T2hj", page 19](#)

1.17.1 Connector -T2cw-

Connector -T2cw-




1.17.2 Connector -T2hj-

Connector -T2hj-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.18 Front passenger side curtain airbag igniter -N252-

- ◆ ⇒ ["1.18.1 Connector T2cx ", page 20](#)
- ◆ ⇒ ["1.18.2 Connector T2hk ", page 20](#)


1.18.1 Connector -T2cx-

Connector -T2cx-



1.18.2 Connector -T2hk-

Connector -T2hk-



1.19 Air conditioner compressor regulating valve -N280-


♦ ⇒ ["1.19.1 Connector T2fn ", page 21](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.1 Connector -T2fn-

Connector -T2fn-



1.20 Fuel metering valve -N290-


♦ ⇒ ["1.20.1 Connector T2cz ", page 21](#)

1.20.1 Connector -T2cz-

Connector -T2cz-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.21 Ignition coil 3 with output stage -N291-

♦ ⇒ ["1.21.1 Connector T4ar ", page 22](#)

1.21.1 Connector -T4ar-

Connector -T4ar-




1.22 Ignition coil 4 with output stage -N292-

♦ ⇒ ["1.22.1 Connector T4as ", page 22](#)

1.22.1 Connector -T4as-

Connector -T4as-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.23 Intake manifold flap valve -N316-


♦ ⇒ ["1.23.1 Connector T2dg ", page 23](#)

1.23.1 Connector -T2dg-

Connector -T2dg-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.24 Exhaust camshaft control valve 1 -N318-

♦ ⇒ ["1.24.1 Connector T2dh ", page 23](#)

1.24.1 Connector -T2dh-

Connector -T2dh-




1.25 Front left shock absorber damping adjustment valve -N336-

♦ ⇒ ["1.25.1 Connector T2ch ", page 24](#)

1.25.1 Connector -T2ch- Connector -T2ch-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright © AUDI AG.



1.26 Front right shock absorber damping adjustment valve -N337-

♦ ⇒ [“1.26.1 Connector T2ci”, page 24](#)

1.26.1 Connector -T2ci- Connector -T2ci-



1.27 Rear left shock absorber damping adjustment valve -N338-


♦ ⇒ [“1.27.1 Connector T2cj”, page 25](#)

1.27.1 Connector -T2cj-

Connector -T2cj-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.28 Rear right shock absorber damping adjustment valve -N339-

♦ ⇒ ["1.28.1 Connector T2ck ", page 25](#)

1.28.1 Connector -T2ck-

Connector -T2ck-




1.29 Ignition key withdrawal lock solenoid -N376-

♦ ⇒ ["1.29.1 Connector T2ds ", page 26](#)

1.29.1 Connector -T2ds-

Connector -T2ds-



1.30 Oil pressure control valve -N428-

◆ ⇒ [“1.30.1 Connector T2dt”, page 26](#)

◆ ⇒ [“1.30.2 Connector T2du”, page 27](#)


◆ ⇒ [“1.30.3 Connector T2dv”, page 27](#)

1.30.1 Connector -T2dt-

Connector -T2dt-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.30.2 Connector -T2du-

Connector -T2du-



1.30.3 Connector -T2dv-

Connector -T2dv-



1.31 Coolant valve for gearbox -N488-


♦ ⇒ ["1.31.1 Connector T2dw", page 28](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.31.1 Connector -T2dw-

Connector -T2dw-



1.32 Actuator for engine temperature regulation -N493-

♦ ⇒ ["1.32.1 Connector T5h ", page 28](#)


♦ ⇒ ["1.32.2 Connector T5i ", page 29](#)

1.32.1 Connector -T5h-

Connector -T5h-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.32.2 Connector -T5i-

Connector -T5i-




1.33 Piston cooling jet control valve -N522-

♦ ⇒ ["1.33.1 Connector T2dx", page 29](#)

1.33.1 Connector -T2dx-

Connector -T2dx-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.34 Injector 2, cylinder 1 -N532-

♦ ⇒ ["1.34.1 Connector T2dy", page 30](#)

1.34.1 Connector -T2dy-

Connector -T2dy-




1.35 Injector 2, cylinder 2 -N533-

♦ ⇒ ["1.35.1 Connector T2dz ", page 30](#)

1.35.1 Connector -T2dz-

Connector -T2dz-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.36 Injector 2, cylinder 3 -N534-

♦ ⇒ ["1.36.1 Connector T2ea ", page 31](#)

1.36.1 Connector -T2ea-

Connector -T2ea-



1.37 Injector 2, cylinder 4 -N535-


♦ ⇒ ["1.37.1 Connector T2eb ", page 31](#)

1.37.1 Connector -T2eb-

Connector -T2eb-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.38 Inlet cam actuator for cylinder 2 -N583-

♦ ⇒ ["1.38.1 Connector T3av ", page 32](#)

1.38.1 Connector -T3av-

Connector -T3av-




1.39 Exhaust cam actuator for cylinder 2 -N587-

♦ ⇒ ["1.39.1 Connector T3aw", page 32](#)

1.39.1 Connector -T3aw-

Connector -T3aw-




1.40 Inlet cam actuator for cylinder 3 -N591-

♦ ⇒ ["1.40.1 Connector T3ax", page 33](#)

1.40.1 Connector -T3ax-

Connector -T3ax-



1.41 Exhaust cam actuator for cylinder 3 -N595-


◆ ⇒ ["1.41.1 Connector T3ay ", page 33](#)

1.41.1 Connector -T3ay-

Connector -T3ay-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.42 Front left seat belt -NX10-

◆ ⇒ ["1.42.1 Connector T2cl ", page 34](#)

◆ ⇒ ["1.42.2 Connector T2cm ", page 34](#)


◆ ⇒ ["1.42.3 Connector T2hg ", page 35](#)

◆ ⇒ ["1.42.4 Connector T5ae ", page 35](#)

◆ ⇒ ["1.42.5 Connector T5m ", page 36](#)


1.42.1 Connector -T2cl-

Connector -T2cl-



1.42.2 Connector -T2cm-


Connector -T2cm-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.42.3 Connector -T2hg-


Connector -T2hg-



1.42.4 Connector -T5ae-


Connector -T5ae-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.42.5 Connector -T5m-

Connector -T5m-



4M0_972_705

1.43 Front right seat belt -NX11-


- ◆ ⇒ ["1.43.1 Connector T2cn ", page 36](#)
- ◆ ⇒ ["1.43.2 Connector T2co ", page 37](#)
- ◆ ⇒ ["1.43.3 Connector T2hf ", page 37](#)
- ◆ ⇒ ["1.43.4 Connector T5ad ", page 38](#)
- ◆ ⇒ ["1.43.5 Connector T5n ", page 38](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.43.1 Connector -T2cn-

Connector -T2cn-




4M1_972_562

1.43.2 Connector -T2co-


Connector -T2co-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.43.3 Connector -T2hf-

Connector -T2hf-




1.43.4 Connector -T5ad-

Connector -T5ad-



1.43.5 Connector -T5n-

Connector -T5n-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefixes O to Q



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix R

- ◆
- ◆ ⇒ [“1.1 Front left treble loudspeaker R20 ”, page 2](#)
- ◆ ⇒ [“1.2 Front left bass loudspeaker R21 ”, page 2](#)
- ◆ ⇒ [“1.3 Front right treble loudspeaker R22 ”, page 3](#)
- ◆ ⇒ [“1.4 Front right bass loudspeaker R23 ”, page 3](#)
- ◆ ⇒ [“1.5 Aerial amplifier R24 ”, page 4](#)
- ◆ ⇒ [“1.6 Telephone microphone R38 ”, page 5](#)
- ◆ ⇒ [“1.7 Interior microphone R74 ”, page 6](#)
- ◆ ⇒ [“1.8 TV tuner R78 ”, page 6](#)
- ◆ ⇒ [“1.9 Aerial amplifier 2 for TV R83 ”, page 8](#)
- ◆ ⇒ [“1.10 Aerial amplifier for mobile telephone R86 ”, page 9](#)
- ◆ ⇒ [“1.11 Front left mid-range loudspeaker R103 ”, page 11](#)
- ◆ ⇒ [“1.12 Front right mid-range loudspeaker R104 ”, page 12](#)
- ◆ ⇒ [“1.13 Aerial amplifier 2 R111 ”, page 12](#)
- ◆ ⇒ [“1.14 Driver's side aerial for entry and start system R134 ”, page 14](#)
- ◆ ⇒ [“1.15 Passenger side aerial for entry and start system R135 ”, page 15](#)
- ◆ ⇒ [“1.16 Rear bumper aerial for entry and start system R136 ”, page 15](#)
- ◆ ⇒ [“1.17 Interior aerial 1 for entry and start system R138 ”, page 16](#)
- ◆ ⇒ [“1.18 Interior aerial 2 for entry and start system R139 ”, page 16](#)
- ◆ ⇒ [“1.19 Centre loudspeaker R208 ”, page 17](#)
- ◆ ⇒ [“1.20 Left effect loudspeaker R209 ”, page 17](#)
- ◆ ⇒ [“1.21 Right effect loudspeaker R210 ”, page 18](#)
- ◆ ⇒ [“1.22 Subwoofer R211 ”, page 19](#)
- ◆ ⇒ [“1.23 Actuator for structure-borne sound R214 ”, page 20](#)
- ◆ ⇒ [“1.24 Roof aerial R216 ”, page 20](#)


- ◆ ⇒ ["1.25 Centre loudspeaker 2 R219 ", page 21](#)
- ◆ ⇒ ["1.26 Front camera for driver assist systems R242 ", page 22](#)
- ◆ ⇒ ["1.27 USB hub R293 ", page 23](#)
- ◆ ⇒ ["1.28 LTE aerial 1 R297 ", page 24](#)
- ◆ ⇒ ["1.29 LTE aerial 2 R306 ", page 25](#)
- ◆ ⇒ ["1.30 Microphone for emergency call module R321 ", page 26](#)
- ◆ ⇒ ["1.31 LTE aerial 3 R330 ", page 26](#)
- ◆ ⇒ ["1.32 Loudspeaker for emergency call module R335 ", page 27](#)
- ◆ ⇒ ["1.33 Aerial for in-vehicle communication R364 ", page 27](#)

1.1 Front left treble loudspeaker -R20-

- ◆ ⇒ ["1.1.1 Connector T2ev ", page 2](#)

1.1.1 Connector -T2ev-

Connector -T2ev-



8W0_971_832



1.2 Front left bass loudspeaker -R21-

- ◆ ⇒ ["1.2.1 Connector T2ef ", page 3](#)


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2.1 Connector -T2ef-

Connector -T2ef-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept responsibility with respect to the correctness of information in this document. Copyright by AUDI AG.




1.3 Front right treble loudspeaker -R22-

♦ ⇒ ["1.3.1 Connector T2fc", page 3](#)

1.3.1 Connector -T2fc-

Connector -T2fc-




1.4 Front right bass loudspeaker -R23-

♦ ⇒ ["1.4.1 Connector T2eg", page 4](#)

1.4.1 Connector -T2eg-

Connector -T2eg-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.5 Aerial amplifier -R24-

- ◆ ⇒ ["1.5.1 Connector T2el ", page 4](#)
- ◆ ⇒ ["1.5.2 Connector T2if ", page 5](#)
- ◆ ⇒ ["1.5.3 Connector T4ca ", page 5](#)


1.5.1 Connector -T2el-

Connector -T2el-



1.5.2 Connector -T2if-

Connector -T2if-




1.5.3 Connector -T4ca-

Connector -T4ca-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.6 Telephone microphone -R38-

◆ ⇒ ["1.6.1 Connector T4av", page 6](#)

1.6.1 Connector -T4av-

Connector -T4av-



1.7 Internal microphone -R74-


◆ ⇒ [“1.7.1 Connector T4ax”, page 6](#)

1.7.1 Connector -T4ax-

Connector -T4ax-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.8 TV tuner -R78-

◆ ⇒ [“1.8.1 Connector T12f”, page 7](#)


◆ ⇒ [“1.8.2 Connector T2gz”, page 7](#)

◆ ⇒ [“1.8.3 Connector T2ia”, page 8](#)

◆ ⇒ [“1.8.4 Connector T4bx”, page 8](#)

1.8.1 Connector -T12f-

Connector -T12f-




1.8.2 Connector -T2gz-

Connector -T2gz-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.8.3 Connector -T2ia-

Connector -T2ia-



1.8.4 Connector -T4bx-

Connector -T4bx-



1.9 Aerial amplifier 2 for TV -R83-


♦ ⇒ ["1.9.1 Connector T2id", page 9](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.9.1 Connector -T2id-

Connector -T2id-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted. Audi reserves all rights. Audi AG does not warrant or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.10 Aerial amplifier for mobile telephone -R86-

- ◆ ⇒ ["1.10.1 Connector T2fe", page 9](#)
- ◆ ⇒ ["1.10.2 Connector T2ff", page 10](#)
- ◆ ⇒ ["1.10.3 Connector T2fg", page 10](#)
- ◆ ⇒ ["1.10.4 Connector T2gg", page 11](#)
- ◆ ⇒ ["1.10.5 Connector T4bg", page 11](#)

1.10.1 Connector -T2fe-

Connector -T2fe-



1.10.2 Connector -T2ff-



Connector -T2ff-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.10.3 Connector -T2fg-

Connector -T2fg-



1.10.4 Connector -T2gg-

Connector -T2gg-




1.10.5 Connector -T4bg-

Connector -T4bg-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.11 Front left mid-range loudspeaker -R103-


♦ ⇒ ["1.11.1 Connector T2eh", page 12](#)

1.11.1 Connector -T2eh-

Connector -T2eh-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.12 Front right mid-range loudspeaker -R104-

♦ ⇒ [“1.12.1 Connector T2ei”, page 12](#)

1.12.1 Connector -T2ei-

Connector -T2ei-



1.13 Aerial amplifier 2 -R111-

♦ ⇒ [“1.13.1 Connector T2em”, page 13](#)


♦ ⇒ [“1.13.2 Connector T2ic”, page 13](#)

♦ ⇒ [“1.13.3 Connector T4au”, page 14](#)

♦ ⇒ [“1.13.4 Connector T4by”, page 14](#)

1.13.1 Connector -T2em-

Connector -T2em-




1.13.2 Connector -T2ic-

Connector -T2ic-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.13.3 Connector -T4au-

Connector -T4au-




1.13.4 Connector -T4by-

Connector -T4by-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.14 Driver's side aerial for entry and start system -R134-

◆ ⇒ ["1.14.1 Connector T2en", page 15](#)

1.14.1 Connector -T2en-

Connector -T2en-




1.15 Passenger side aerial for entry and start system -R135-

♦ ⇒ ["1.15.1 Connector T2eo ", page 15](#)

1.15.1 Connector -T2eo-

Connector -T2eo-




1.16 Rear bumper aerial for entry and start system -R136-

♦ ⇒ ["1.16.1 Connector T2ep ", page 16](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.16.1 Connector -T2ep-

Connector -T2ep-




1.17 Interior aerial 1 for entry and start system -R138-

◆ ⇒ ["1.17.1 Connector T2er", page 16](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.17.1 Connector -T2er-

Connector -T2er-




1.18 Interior aerial 2 for entry and start system -R139-

◆ ⇒ ["1.18.1 Connector T2eq", page 17](#)

1.18.1 Connector -T2eq-

Connector -T2eq-



1.19 Centre loudspeaker -R208-


♦ ⇒ ["1.19.1 Connector T2ew", page 17](#)

1.19.1 Connector -T2ew-

Connector -T2ew-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.20 Left effect loudspeaker -R209-

♦ ⇒ ["1.20.1 Connector T2es", page 18](#)

♦ ⇒ ["1.20.2 Connector T2ex", page 18](#)


1.20.1 Connector -T2es-

Connector -T2es-




1.20.2 Connector -T2ex-

Connector -T2ex-



1.21 Right effect loudspeaker -R210-

- ◆ ⇒ ["1.21.1 Connector T2et ", page 19](#)
- ◆ ⇒ ["1.21.2 Connector T2ey ", page 19](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.21.1 Connector -T2et-

Connector -T2et-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.21.2 Connector -T2ey-

Connector -T2ey-



1.22 Subwoofer -R211-


♦ ⇒ ["1.22.1 Connector T4aw", page 20](#)

1.22.1 Connector -T4aw-

Connector -T4aw-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.23 Actuator for structure-borne sound -R214-

♦ ⇒ ["1.23.1 Connector T2ez ", page 20](#)

1.23.1 Connector -T2ez-

Connector -T2ez-




1.24 Roof aerial -R216-

♦ ⇒ ["1.24.1 Connector T2fa ", page 21](#)

♦ ⇒ ["1.24.2 Connector T2ge ", page 21](#)

1.24.1 Connector -T2fa-

Connector -T2fa-




1.24.2 Connector -T2ge-

Connector -T2ge-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.25 Centre loudspeaker 2 -R219-

♦ ⇒ ["1.25.1 Connector T2fb", page 22](#)

1.25.1 Connector -T2fb-

Connector -T2fb-



1.26 Front camera for driver assist systems -R242-


♦ ⇒ ["1.26.1 Connector T12a ", page 22](#)

♦ ⇒ ["1.26.2 Connector T12g ", page 23](#)

1.26.1 Connector -T12a-


Connector -T12a-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.26.2 Connector -T12g-

Connector -T12g-




1.27 USB hub -R293-

- ◆ ⇒ [“1.27.1 Connector T5j”, page 23](#)
- ◆ ⇒ [“1.27.2 Connector T6al”, page 24](#)
- ◆ ⇒ [“1.27.3 Connector T6y”, page 24](#)


1.27.1 Connector -T5j-

Connector -T5j- is protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.27.2 Connector -T6al-


Connector -T6al-



1.27.3 Connector -T6y-

Connector -T6y-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.28 LTE aerial 1 -R297-


♦ ⇒ ["1.28.1 Connector T2ek ", page 25](#)

1.28.1 Connector -T2ek-

Connector -T2ek-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.29 LTE aerial 2 -R306-

♦ ⇒ ["1.29.1 Connector T2ej", page 25](#)

♦ ⇒ ["1.29.2 Connector T2jd", page 26](#)

1.29.1 Connector -T2ej-

Connector -T2ej-




1.29.2 Connector -T2jd-

Connector -T2jd-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.30 Microphone for emergency call module -R321-

♦ ⇒ ["1.30.1 Connector T4ch ", page 26](#)

1.30.1 Connector -T4ch-

Connector -T4ch-



1.31 LTE aerial 3 -R330-


♦ ⇒ ["1.31.1 Connector T2g ", page 27](#)

1.31.1 Connector -T2g-

Connector -T2g-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.32 Emergency call module loudspeaker -R335-

♦ ⇒ ["1.32.1 Connector T2fh", page 27](#)


1.32.1 Connector -T2fh-

Connector -T2fh-



1.33 Aerial for in-vehicle communication -R364-

♦ ⇒ ["1.33.1 Connector T2fd", page 28](#)

1.33.1 Connector -T2fd-**Connector -T2fd-**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix S to U

- ◆
- ◆ ⇒ ["1.1 Fuse holder C SC ", page 1](#)
- ◆ ⇒ ["1.2 Fuse holder G SG ", page 2](#)
- ◆ ⇒ ["1.3 Coupling point 1 for alternator TGEN1 ", page 2](#)
- ◆ ⇒ ["1.4 Coupling point in interior TI ", page 4](#)
- ◆ ⇒ ["1.5 Coupling point 1 for engine prewiring harness, adapter wire TMOAD1 ", page 5](#)
- ◆ ⇒ ["1.6 Coupling point 2 for engine prewiring harness, adapter wire TMOAD2 ", page 7](#)
- ◆ ⇒ ["1.7 Coupling point 1 for engine prewiring harness TMOVO1 ", page 8](#)
- ◆ ⇒ ["1.8 Coupling point 2 for engine prewiring harness TMOVO2 ", page 9](#)
- ◆ ⇒ ["1.9 Coupling point on front left bumper TSFVL ", page 11](#)
- ◆ ⇒ ["1.10 Coupling point for centre rear seat TSHM ", page 12](#)
- ◆ ⇒ ["1.11 Coupling point for front left seat TSVL ", page 14](#)
- ◆ ⇒ ["1.12 Coupling point for front right seat TSVR ", page 19](#)
- ◆ ⇒ ["1.13 Coupling point for rear left door TTHL ", page 24](#)
- ◆ ⇒ ["1.14 Coupling point for rear right door TTHR ", page 25](#)
- ◆ ⇒ ["1.15 Coupling point in rear left door TTIHL ", page 26](#)
- ◆ ⇒ ["1.16 Coupling point in rear right door TTIHR ", page 27](#)
- ◆ ⇒ ["1.17 Coupling point in front left door TTIVL ", page 28](#)
- ◆ ⇒ ["1.18 Coupling point in front right door TTIVR ", page 29](#)
- ◆ ⇒ ["1.19 Coupling point for front left door TTVL ", page 30](#)
- ◆ ⇒ ["1.20 Coupling point for front right door TTVR ", page 31](#)
- ◆ ⇒ ["1.21 12 V socket U5 ", page 32](#)
- ◆ ⇒ ["1.22 Diagnostic connection U31 ", page 33](#)


1.1 Fuse holder C -SC-

- ◆ ⇒ ["1.1.1 Connector T2fi ", page 2](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the prior written permission of AUDI AG. AUDI AG does not guarantee or accept any liability for the correctness of information in this document. Copyright by AUDI AG.

1.1.1 Connector -T2fi-

Connector -T2fi-




1.2 Fuse holder G -SG-

♦ ⇒ ["1.2.1 Connector T2gj", page 2](#)

1.2.1 Connector -T2gj-

Connector -T2gj-



1.3 Coupling point 1 for alternator -TGEN1-

♦ ⇒ ["1.3.1 Connector T4b", page 3](#)

♦ ⇒ ["1.3.2 Connector T4g", page 3](#)

♦ ⇒ ["1.3.3 Connector T8a", page 4](#)


♦ ⇒ ["1.3.4 Connector T8c", page 4](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.3.1 Connector -T4b-

Connector -T4b-



1.3.2 Connector -T4g-

Connector -T4g-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.3.3 Connector -T8a-

Connector -T8a-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.3.4 Connector -T8c-

Connector -T8c-




1.4 Coupling point in interior -TI-

◆ ⇒ ["1.4.1 Connector T4bs", page 5](#)

1.4.1 Connector -T4bs-

Connector -T4bs-




1.5 Coupling point 1 for engine prewiring harness, adapter wire -TMOAD1-

- ◆ ⇒ ["1.5.1 Connector T14k ", page 5](#)
- ◆ ⇒ ["1.5.2 Connector T14m ", page 6](#)
- ◆ ⇒ ["1.5.3 Connector T8g ", page 6](#)
- ◆ ⇒ ["1.5.4 Connector T8i ", page 7](#)

1.5.1 Connector -T14k-


Connector -T14k-

Copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.5.2 Connector -T14m-

Connector -T14m-




4H0_973_717

1.5.3 Connector -T8g-

Connector -T8g-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1J0_973_814

1.5.4 Connector -T8i-

Connector -T8i-




1.6 Coupling point 2 for engine prewiring harness, adapter wire -TMOAD2-

♦ ⇒ ["1.6.1 Connector T8d", page 7](#)

♦ ⇒ ["1.6.2 Connector T8j", page 8](#)

1.6.1 Connector -T8d-


Connector -T8d-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.6.2 Connector -T8j-

Connector -T8j-



1.7 Coupling point 1 for engine prewiring harness -TMOVO1-


♦ ⇒ ["1.7.1 Connector T14d ", page 8](#)

♦ ⇒ ["1.7.2 Connector T14o ", page 9](#)

♦ ⇒ ["1.7.3 Connector T14q ", page 9](#)

1.7.1 Connector -T14d-


Connector -T14d-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.7.2 Connector -T14o-

Connector -T14o-




1.7.3 Connector -T14q-

Connector -T14q-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.8 Coupling point 2 for engine prewiring harness -TMOVO2-

- ◆ ⇒ ["1.8.1 Connector T10a ", page 10](#)
- ◆ ⇒ ["1.8.2 Connector T10d ", page 10](#)
- ◆ ⇒ ["1.8.3 Connector T4cc ", page 11](#)
- ◆ ⇒ ["1.8.4 Connector T4cd ", page 11](#)

1.8.1 Connector -T10a-

Connector -T10a-




1.8.2 Connector -T10d-

Connector -T10d-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.8.3 Connector -T4cc-


Connector -T4cc-



1.8.4 Connector -T4cd-

Connector -T4cd-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.9 Coupling point on front left bumper -TSFVL-

◆ ⇒ ["1.9.1 Connector T6a", page 12](#)

◆ ⇒ ["1.9.2 Connector T6b", page 12](#)


1.9.1 Connector -T6a-

Connector -T6a-



1.9.2 Connector -T6b-

Connector -T6b-




1.10 Coupling point for centre rear seat -TSHM-

- ◆ ⇒ ["1.10.1 Connector T6av ", page 13](#)
- ◆ ⇒ ["1.10.2 Connector T6aw ", page 13](#)
- ◆ ⇒ ["1.10.3 Connector T6c ", page 14](#)
- ◆ ⇒ ["1.10.4 Connector T6d ", page 14](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.10.1 Connector -T6av-

Connector -T6av-



1.10.2 Connector -T6aw-

Connector -T6aw-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.10.3 Connector -T6c-

Connector -T6c-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.10.4 Connector -T6d-

Connector -T6d-




1.11 Coupling point for front left seat -TSVL-

- ◆ ⇒ ["1.11.1 Connector T3bf", page 15](#)
- ◆ ⇒ ["1.11.2 Connector T3bp", page 15](#)
- ◆ ⇒ ["1.11.3 Connector T3bq", page 16](#)
- ◆ ⇒ ["1.11.4 Connector T3c", page 16](#)
- ◆ ⇒ ["1.11.5 Connector T5ab", page 17](#)
- ◆ ⇒ ["1.11.6 Connector T5ac", page 17](#)
- ◆ ⇒ ["1.11.7 Connector T5c", page 18](#)

- ◆ ⇒ [“1.11.8 Connector T5k ”, page 18](#)
- ◆ ⇒ [“1.11.9 Connector T6an ”, page 19](#)
- ◆ ⇒ [“1.11.10 Connector T6e ”, page 19](#)


1.11.1 Connector -T3bf-

Connector -T3bf-



1.11.2 Connector -T3bp-


Connector -T3bp-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.11.3 Connector -T3bq-

Connector -T3bq-



1.11.4 Connector -T3c-


Connector -T3c-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.11.5 Connector -T5ab-

Connector -T5ab-




1.11.6 Connector -T5ac-

Connector -T5ac-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.11.7 Connector -T5c-

Connector -T5c-



1.11.8 Connector -T5k-


Connector -T5k-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.11.9 Connector -T6an-

Connector -T6an-




1.11.10 Connector -T6e-

Connector -T6e-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.12 Coupling point for front right seat -TSVR-


- ◆ ⇒ ["1.12.1 Connector T3bg ", page 20](#)
- ◆ ⇒ ["1.12.2 Connector T3bj ", page 20](#)
- ◆ ⇒ ["1.12.3 Connector T3bu ", page 21](#)
- ◆ ⇒ ["1.12.4 Connector T3bv ", page 21](#)
- ◆ ⇒ ["1.12.5 Connector T5ah ", page 22](#)
- ◆ ⇒ ["1.12.6 Connector T5l ", page 22](#)
- ◆ ⇒ ["1.12.7 Connector T5y ", page 23](#)

- ◆ ⇒ [“1.12.8 Connector T5z”, page 23](#)
- ◆ ⇒ [“1.12.9 Connector T6ao”, page 24](#)
- ◆ ⇒ [“1.12.10 Connector T6at”, page 24](#)

1.12.1 Connector -T3bg-


Connector -T3bg-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.12.2 Connector -T3bj-

Connector -T3bj-



1.12.3 Connector -T3bu-



Connector -T3bu-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

1.12.4 Connector -T3bv-

Connector -T3bv-




1.12.5 Connector -T5ah-

Connector -T5ah-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.12.6 Connector -T5l-

Connector -T5l-



1.12.7 Connector -T5y-

Connector -T5y-




1.12.8 Connector -T5z-

Connector -T5z-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.12.9 Connector -T6ao-

Connector -T6ao-




1.12.10 Connector -T6at-

Connector -T6at-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright © Audi AG




1.13 Coupling point for rear left door -TTHL-

- ◆ ⇒ ["1.13.1 Connector T19a ", page 25](#)
- ◆ ⇒ ["1.13.2 Connector T19b ", page 25](#)


1.13.1 Connector -T19a-

Connector -T19a-



1.13.2 Connector -T19b-

Connector -T19b-



1.14 Coupling point for rear right door -TTHR-


◆ ⇒ ["1.14.1 Connector T19c", page 26](#)

◆ ⇒ ["1.14.2 Connector T19d", page 26](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.14.1 Connector -T19c-


Connector -T19c-



1.14.2 Connector -T19d-

Connector -T19d-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.15 Coupling point in rear left door -TTIHL-

- ◆ ⇒ ["1.15.1 Connector T8q ", page 27](#)
- ◆ ⇒ ["1.15.2 Connector T8s ", page 27](#)

1.15.1 Connector -T8q-

Connector -T8q-




1.15.2 Connector -T8s-

Connector -T8s-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.16 Coupling point in rear right door -TTIHR-

- ◆ ⇒ ["1.16.1 Connector T8ah ", page 28](#)
- ◆ ⇒ ["1.16.2 Connector T8r ", page 28](#)

1.16.1 Connector -T8ah-

Connector -T8ah-




1.16.2 Connector -T8r-

Connector -T8r-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability



1.17 Coupling point in front left door -TTIVL-

♦ ⇒ ["1.17.1 Connector T4h", page 29](#)


♦ ⇒ ["1.17.2 Connector T4i", page 29](#)

1.17.1 Connector -T4h-

Connector -T4h-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.17.2 Connector -T4i-

Connector -T4i-




1.18 Coupling point in front right door -TTIVR-

- ◆ ⇒ ["1.18.1 Connector T4j", page 30](#)
- ◆ ⇒ ["1.18.2 Connector T4k", page 30](#)


1.18.1 Connector -T4j-

Connector -T4j-



1.18.2 Connector -T4k-

Connector -T4k-



1.19 Coupling point for front left door -TTVL-


- ◆ ⇒ ["1.19.1 Connector T27a ", page 31](#)
- ◆ ⇒ ["1.19.2 Connector T27b ", page 31](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.1 Connector -T27a-

Connector -T27a-




1.19.2 Connector -T27b-

Connector -T27b-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.20 Coupling point for front right door -TTVR-

- ◆ ⇒ ["1.20.1 Connector T27c ", page 32](#)
- ◆ ⇒ ["1.20.2 Connector T27d ", page 32](#)


1.20.1 Connector -T27c-

Connector -T27c-



1.20.2 Connector -T27d-

Connector -T27d-



1.21 12 V socket -U5-


♦ ⇒ ["1.21.1 Connector T3az ", page 33](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.21.1 Connector -T3az-

Connector -T3az-




1.22 Diagnostic connection -U31-

♦ ⇒ ["1.22.1 Connector T16c", page 33](#)

1.22.1 Connector -T16c-

Connector -T16c-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix V


- ◆
- ◆ ⇒ ["1.1 Windscreen wiper motor V ", page 2](#)
- ◆ ⇒ ["1.2 Headlight washer system pump V11 ", page 2](#)
- ◆ ⇒ ["1.3 Rear window wiper motor V12 ", page 2](#)
- ◆ ⇒ ["1.4 Continued coolant circulation pump V51 ", page 3](#)
- ◆ ⇒ ["1.5 Windscreen and rear window washer pump V59 ", page 4](#)
- ◆ ⇒ ["1.6 Air recirculation flap control motor V113 ", page 5](#)
- ◆ ⇒ ["1.7 Driver side window regulator motor V147 ", page 5](#)
- ◆ ⇒ ["1.8 Front passenger side window regulator motor V148 ", page 6](#)
- ◆ ⇒ ["1.9 Tank filler flap locking motor V155 ", page 6](#)
- ◆ ⇒ ["1.10 Charge air cooling pump V188 ", page 7](#)
- ◆ ⇒ ["1.11 Brake vacuum pump V192 ", page 7](#)
- ◆ ⇒ ["1.12 Charge pressure positioner V465 ", page 8](#)
- ◆ ⇒ ["1.13 Driver door lock unit VX21 ", page 10](#)
- ◆ ⇒ ["1.14 Front passenger door lock unit VX22 ", page 10](#)
- ◆ ⇒ ["1.15 Rear left door lock unit VX23 ", page 11](#)
- ◆ ⇒ ["1.16 Rear right door lock unit VX24 ", page 11](#)
- ◆ ⇒ ["1.17 Rear lid lock unit VX25 ", page 12](#)
- ◆ ⇒ ["1.18 Air distribution flap VX33 ", page 12](#)
- ◆ ⇒ ["1.19 Front left temperature flap VX34 ", page 13](#)
- ◆ ⇒ ["1.20 Front right temperature flap VX35 ", page 14](#)
- ◆ ⇒ ["1.21 Defroster flap VX47 ", page 15](#)
- ◆ ⇒ ["1.22 Air recirculation flap VX52 ", page 15](#)
- ◆ ⇒ ["1.23 Radiator fan VX57 ", page 16](#)

1.1 Windscreen wiper motor -V-

♦ ⇒ ["1.1.1 Connector T4az", page 2](#)

1.1.1 Connector -T4az-

Connector -T4az-




1.2 Headlight washer system pump -V11-

♦ ⇒ ["1.2.1 Connector T2fj", page 2](#)

1.2.1 Connector -T2fj-

Connector -T2fj-




1.3 Rear window wiper motor -V12-

♦ ⇒ ["1.3.1 Connector T4ba", page 3](#)

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.3.1 Connector -T4ba-

Connector -T4ba-



1.4 Continued coolant circulation pump -V51-

◆ ⇒ ["1.4.1 Connector T3bd", page 3](#)


◆ ⇒ ["1.4.2 Connector T3bw", page 4](#)

◆ ⇒ ["1.4.3 Connector T3by", page 4](#)

1.4.1 Connector -T3bd-


Connector -T3bd-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.4.2 Connector -T3bw-

Connector -T3bw-




1.4.3 Connector -T3by-

Connector -T3by-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.5 Windscreen and rear window washer pump -V59-

◆ ⇒ ["1.5.1 Connector T2fo", page 5](#)

1.5.1 Connector -T2fo-

Connector -T2fo-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted without the prior written permission of AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.6 Air recirculation flap control motor -V113-

♦ ⇒ ["1.6.1 Connector T6aq", page 5](#)

1.6.1 Connector -T6aq-

Connector -T6aq-



1.7 Driver side window regulator motor -V147-


♦ ⇒ ["1.7.1 Connector T3ba", page 6](#)

1.7.1 Connector -T3ba-

Connector -T3ba-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.8 Front passenger side window regulator motor -V148-

♦ ⇒ ["1.8.1 Connector T3bb", page 6](#)

1.8.1 Connector -T3bb-

Connector -T3bb-




1.9 Tank filler flap locking motor -V155-

♦ ⇒ ["1.9.1 Connector T2fk", page 7](#)

1.9.1 Connector -T2fk-

Connector -T2fk-




1.10 Charge air cooling pump -V188-

♦ ⇒ ["1.10.1 Connector T3bc", page 7](#)

1.10.1 Connector -T3bc-

Connector -T3bc-



1.11 Vacuum pump for brakes -V192-


♦ ⇒ ["1.11.1 Connector T2fl", page 8](#)

♦ ⇒ ["1.11.2 Connector T6ad", page 8](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.11.1 Connector -T2fl-

Connector -T2fl-



1.11.2 Connector -T6ad-

Connector -T6ad-



1.12 Charge pressure positioner -V465-

◆ ⇒ ["1.12.1 Connector T6ag ", page 9](#)

◆ ⇒ ["1.12.2 Connector T6ah ", page 9](#)

◆ ⇒ ["1.12.3 Connector T6ax ", page 10](#)


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.12.1 Connector -T6ag-

Connector -T6ag-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.12.2 Connector -T6ah-

Connector -T6ah-



1.12.3 Connector -T6ax-

Connector -T6ax-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.13 Driver door lock unit -VX21-

♦ ⇒ ["1.13.1 Connector T8t", page 10](#)

1.13.1 Connector -T8t-

Connector -T8t-




1.14 Front passenger door lock unit -VX22-

♦ ⇒ ["1.14.1 Connector T8u", page 11](#)

1.14.1 Connector -T8u-

Connector -T8u-




1.15 Rear left door lock unit -VX23-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorized by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

◆ ⇒ ["1.15.1 Connector T8v", page 11](#)

1.15.1 Connector -T8v-

Connector -T8v-




1.16 Rear right door lock unit -VX24-

◆ ⇒ ["1.16.1 Connector T8w", page 12](#)

1.16.1 Connector -T8w-

Connector -T8w-




1.17 Rear lid lock unit -VX25-

♦ ⇒ [“1.17.1 Connector T4s”, page 12](#)

1.17.1 Connector -T4s-

Connector -T4s-



1.18 Air distribution flap -VX33-


♦ ⇒ [“1.18.1 Connector T6aa”, page 13](#)

♦ ⇒ [“1.18.2 Connector T6as”, page 13](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.18.1 Connector -T6aa-

Connector -T6aa-



1.18.2 Connector -T6as-

Connector -T6as-



1.19 Front left temperature flap -VX34-

♦ ⇒ ["1.19.1 Connector T6ab ", page 14](#)

♦ ⇒ ["1.19.2 Connector T6ar ", page 14](#)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.19.1 Connector -T6ab-

Connector -T6ab-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.19.2 Connector -T6ar-

Connector -T6ar-




1.20 Front right temperature flap -VX35-

♦ ⇒ ["1.20.1 Connector T6ac", page 15](#)

1.20.1 Connector -T6ac-

Connector -T6ac-



1.21 Defroster flap -VX47-


♦ ⇒ ["1.21.1 Connector T6z ", page 15](#)

1.21.1 Connector -T6z-

Connector -T6z-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.22 Air recirculation flap -VX52-

♦ ⇒ ["1.22.1 Connector T6ae ", page 16](#)

1.22.1 Connector -T6ae-

Connector -T6ae-




1.23 Radiator fan -VX57-

♦ ⇒ ["1.23.1 Connector T4bb ", page 16](#)

1.23.1 Connector -T4bb-

Connector -T4bb-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 Parts with prefix W to Z



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- ◆ ⇒ ["1.1 Luggage compartment light W3 ", page 1](#)
- ◆ ⇒ ["1.2 Glove compartment light W6 ", page 2](#)
- ◆ ⇒ ["1.3 Left footwell light W9 ", page 2](#)
- ◆ ⇒ ["1.4 Right footwell light W10 ", page 3](#)
- ◆ ⇒ ["1.5 Front passenger side illuminated vanity mirror W14 ", page 3](#)
- ◆ ⇒ ["1.6 Driver side illuminated vanity mirror W20 ", page 4](#)
- ◆ ⇒ ["1.7 Light for driver door ambient lighting W86 ", page 4](#)
- ◆ ⇒ ["1.8 Light for passenger door ambient lighting W87 ", page 5](#)
- ◆ ⇒ ["1.9 Light 2 for driver's door background lighting W97 ", page 5](#)
- ◆ ⇒ ["1.10 Light 2 for passenger door background lighting W98 ", page 6](#)
- ◆ ⇒ ["1.11 Rear interior light WX2 ", page 6](#)
- ◆ ⇒ ["1.12 Front roof module WX3 ", page 7](#)
- ◆ ⇒ ["1.13 Left number plate light X4 ", page 10](#)
- ◆ ⇒ ["1.14 Right number plate light X5 ", page 11](#)
- ◆ ⇒ ["1.15 Multimedia system display unit 1 Y22 ", page 11](#)
- ◆ ⇒ ["1.16 Heated rear window Z1 ", page 12](#)
- ◆ ⇒ ["1.17 Left washer jet heater element Z20 ", page 13](#)
- ◆ ⇒ ["1.18 Right washer jet heater element Z21 ", page 13](#)
- ◆ ⇒ ["1.19 Windscreen heater for front sensors Z113 ", page 14](#)
- ◆ ⇒ ["1.20 Front left seat heating ZX11 ", page 14](#)
- ◆ ⇒ ["1.21 Front right seat heating ZX13 ", page 15](#)

1.1 Luggage compartment light -W3-

- ◆ ⇒ ["1.1.1 Connector T2fr ", page 2](#)

1.1.1 Connector -T2fr-

Connector -T2fr-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2 Glove compartment light -W6-

♦ ⇒ ["1.2.1 Connector T2fs", page 2](#)

1.2.1 Connector -T2fs-

Connector -T2fs-




1.3 Left footwell light -W9-

♦ ⇒ ["1.3.1 Connector T2ca", page 3](#)

1.3.1 Connector -T2ca-

Connector -T2ca-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.4 Right footwell light -W10-

♦ ⇒ ["1.4.1 Connector T2cb", page 3](#)

1.4.1 Connector -T2cb-

Connector -T2cb-




1.5 Front passenger side illuminated vanity mirror -W14-

♦ ⇒ ["1.5.1 Connector T2fp", page 4](#)

1.5.1 Connector -T2fp-

Connector -T2fp-




1.6 Driver side illuminated vanity mirror -W20-

♦ ⇒ ["1.6.1 Connector T2fq", page 4](#)

1.6.1 Connector -T2fq-

Connector -T2fq-



1.7 Light for driver door ambient lighting -W86-


♦ ⇒ ["1.7.1 Connector T4ag", page 5](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.7.1 Connector -T4ag-

Connector -T4ag-




1.8 Light for passenger door ambient lighting -W87-

♦ ⇒ ["1.8.1 Connector T4ah ", page 5](#)

1.8.1 Connector -T4ah-

Connector -T4ah-




1.9 Light 2 for driver door ambient lighting -W97-

♦ ⇒ ["1.9.1 Connector T4ae ", page 6](#)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.9.1 Connector -T4ae-

Connector -T4ae-



1.10 Light 2 for front passenger door ambient lighting -W98-


♦ ⇒ ["1.10.1 Connector T4af", page 6](#)

1.10.1 Connector -T4af-

Connector -T4af-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




1.11 Rear interior light -WX2-

♦ ⇒ ["1.11.1 Connector T4bc", page 7](#)

♦ ⇒ ["1.11.2 Connector T6ai", page 7](#)


1.11.1 Connector -T4bc-

Connector -T4bc-



1.11.2 Connector -T6ai-

Connector -T6ai-




1.12 Front roof module -WX3-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- ◆ ⇒ ["1.12.1 Connector T16b", page 8](#)
- ◆ ⇒ ["1.12.2 Connector T4be", page 8](#)
- ◆ ⇒ ["1.12.3 Connector T6ak", page 9](#)
- ◆ ⇒ ["1.12.4 Connector T6am", page 9](#)
- ◆ ⇒ ["1.12.5 Connector T6ap", page 10](#)
- ◆ ⇒ ["1.12.6 Connector T8x", page 10](#)


1.12.1 Connector -T16b-

Connector -T16b-





1.12.2 Connector -T4be-

Connector -T4be-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.12.3 Connector -T6ak-**Connector -T6ak-****1.12.4 Connector -T6am-****Connector -T6am-**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.12.5 Connector -T6ap-

Connector -T6ap-



1.12.6 Connector -T8x-

Connector -T8x-



1.13 Left number plate light -X4-


♦ ⇒ ["1.13.1 Connector T2ft", page 11](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.13.1 Connector -T2ft-

Connector -T2ft-




1.14 Right number plate light -X5-

♦ ⇒ ["1.14.1 Connector T2fu", page 11](#)

1.14.1 Connector -T2fu-

Connector -T2fu-



1.15 Multimedia system display unit 1 -Y22-


♦ ⇒ ["1.15.1 Connector T9b", page 12](#)



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.15.1 Connector -T9b-

Connector -T9b-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


1.16 Heated rear window -Z1-

♦ ⇒ ["1.16.1 Connector T1le", page 12](#)

♦ ⇒ ["1.16.2 Connector T1ll", page 13](#)


1.16.1 Connector -T1le-

Connector -T1le-



1.16.2 Connector -T1II-

Connector -T1II-




1.17 Left washer jet heater element -Z20-

♦ ⇒ ["1.17.1 Connector T2fz", page 13](#)

1.17.1 Connector -T2fz-

Connector -T2fz-




1.18 Right washer jet heater element -Z21-

♦ ⇒ ["1.18.1 Connector T2ga", page 14](#)

1.18.1 Connector -T2ga-

Connector -T2ga-



1.19 Windscreen heater for front sensors -Z113-


♦ ⇒ ["1.19.1 Connector T2fy", page 14](#)

1.19.1 Connector -T2fy-

Connector -T2fy-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.20 Front left seat heating -ZX11-


♦ ⇒ ["1.20.1 Connector T4bd", page 15](#)

1.20.1 Connector -T4bd-

Connector -T4bd-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1.21 Front right seat heating -ZX13-

♦ ⇒ ["1.21.1 Connector T4bm", page 15](#)

1.21.1 Connector -T4bm-

Connector -T4bm-

