

2013 SUSPENSION

CHEVROLET WHEEL ALIGNMENT SPECIFICATIONS

WHEEL ALIGNMENT SPECIFICATIONS

CAMARO

CAMARO FE2, ROA with WRS Tire Size - Front and Rear P245/50ZR19

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.15	-0.4	0.35
Right Rear Camber (°)	-1.15	-0.4	0.35
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE2, ROA without WRS Tire Size - Front and Rear P245/50ZR19

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.75	0
Right Rear Camber (°)	-1.5	-0.75	0
Rear Toe (°)	0	0.2	0.4

Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE2, ROB with WRS Tire Size - Front and Rear P245/55R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.15	-0.4	0.35
Right Rear Camber (°)	-1.15	-0.4	0.35
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE2, ROB without WRS Tire Size - Front and Rear P245/55R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	-1.5	-0.75	0
Right Rear Camber (°)	-1.5	-0.75	0
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE2, ROC with WRS Tire Size - Front and Rear P245/45ZR20 and P275/40ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.15	-0.4	0.35
Right Rear Camber (°)	-1.15	-0.4	0.35
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE2, ROC without WRS Tire Size - Front and Rear P245/45ZR20 and P275/40ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55

Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.75	0
Right Rear Camber (°)	-1.5	-0.75	0
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE3 / FE4, ROC Tire Size - Front and Rear P245/45ZR20 and P275/40ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65
Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-1.55	-0.8	-0.05
Right Front Camber (°)	-1.55	-0.8	-0.05
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.15	-0.4	0.35
Right Rear Camber (°)	-1.15	-0.4	0.35
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE4, RKC Tire Size - Front and Rear P285/35ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	5.15	5.9	6.65

Right Front Caster (°)	5.15	5.9	6.65
Left Front Camber (°)	-1.55	-0.8	-0.05
Right Front Camber (°)	-1.55	-0.8	-0.05
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.15	-0.4	0.35
Right Rear Camber (°)	-1.15	-0.4	0.35
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE5, RPG Tire Size - Front and Rear P285/35ZR20 and P305/35ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.85	5.6	6.35
Right Front Caster (°)	4.85	5.6	6.35
Left Front Camber (°)	-1.75	-1	-0.25
Right Front Camber (°)	-1.75	-1	-0.25
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.75	0
Right Rear Camber (°)	-1.5	-0.75	0
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAMARO FE6, RKC Tire Size - Front and Rear P285/35ZR20

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.85	5.6	6.35
Right Front Caster (°)	4.85	5.6	6.35
Left Front Camber (°)	-1.75	-1	-0.25
Right Front Camber (°)	-1.75	-1	-0.25
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.75	0
Right Rear Camber (°)	-1.5	-0.75	0
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPRICE**CAPRICE PPV**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	4.75	6	7.25
Right Front Caster (°)	4.75	6	7.25
Left Front Camber (°)	-0.43	-0.1	0.23
Right Front Camber (°)	-0.43	-0.1	0.23
Front Toe (°)	0	0.17	0.34
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-0.95	-0.5	-0.05
Right Rear Camber (°)	-0.95	-0.5	-0.05
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA

CAPTIVA All Models except Sport

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.43	2.18	2.93
Right Front Caster (°)	1.43	2.18	2.93
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.1	-0.35	0.4
Right Rear Camber (°)	-1.1	-0.35	0.4
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LEA ZLF26 AWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.4	3.2
Right Front Caster (°)	1.6	2.4	3.2
Left Front Camber (°)	-1.6	-0.8	0
Right Front Camber (°)	-1.6	-0.8	0
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0

Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LEA ZLF26 FWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.4	3.2
Right Front Caster (°)	1.6	2.4	3.2
Left Front Camber (°)	-1.6	-0.8	0
Right Front Camber (°)	-1.6	-0.8	0
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LFW and F46 ZLF26 AWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-1.4	-0.6	0.2
Right Front Camber (°)	-1.4	-0.6	0.2
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4

Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LFW and F46 ZLF26 FWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.7	3.5
Right Front Caster (°)	1.9	2.7	3.5
Left Front Camber (°)	-1.4	-0.6	0.2
Right Front Camber (°)	-1.4	-0.6	0.2
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LFW ZLF26 AWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.4	3.2
Right Front Caster (°)	1.6	2.4	3.2
Left Front Camber (°)	-1.5	-0.7	0.1
Right Front Camber (°)	-1.5	-0.7	0.1
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0

Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CAPTIVA Sport RPO LFW ZLF26 FWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.4	3.2
Right Front Caster (°)	1.6	2.4	3.2
Left Front Camber (°)	-1.5	-0.7	0.1
Right Front Camber (°)	-1.5	-0.7	0.1
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	0	0.2	0.4
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

COBALT

COBALT G1LC All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.65	4.4	5.15
Right Front Caster (°)	3.65	4.4	5.15

Left Front Camber (°)	-1.48	-0.73	0.02
Right Front Camber (°)	-1.48	-0.73	0.02
Front Toe (°)	-0.16	0.04	0.24
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.83	-1.33	-0.83
Right Rear Camber (°)	-1.83	-1.33	-0.83
Rear Toe (°)	-0.17	0.33	0.83
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

COBALT G1NC All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.61	4.36	5.11
Right Front Caster (°)	3.61	4.36	5.11
Left Front Camber (°)	-1.39	-0.64	0.11
Right Front Camber (°)	-1.39	-0.64	0.11
Front Toe (°)	-0.15	0.05	0.25
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.84	-1.34	-0.84
Right Rear Camber (°)	-1.84	-1.34	-0.84
Rear Toe (°)	-0.21	0.29	0.79
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE

CORVETTE FE1, FE2 Suspension

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	6.9	7.5	8.1
Right Front Caster (°)	6.9	7.5	8.1
Left Front Camber (°)	-1.05	-0.45	0.15
Right Front Camber (°)	-1.05	-0.45	0.15
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.05	-0.45	0.15
Right Rear Camber (°)	-1.05	-0.45	0.015
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE3 with XFA

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7	7.6	8.2
Right Front Caster (°)	7	7.6	8.2
Left Front Camber (°)	-1.55	-0.95	-0.35
Right Front Camber (°)	-1.55	-0.95	-0.35
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.8	-1.2	-0.6
Right Rear Camber (°)	-1.8	-1.2	-0.6
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.1	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE3 with XFG

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7	7.6	8.2
Right Front Caster (°)	7	7.6	8.2
Left Front Camber (°)	-1.55	-0.95	-0.35
Right Front Camber (°)	-1.55	-0.95	-0.35
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.8	-1.2	-0.6
Right Rear Camber (°)	-1.8	-1.2	-0.6
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE3 with XND

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	6.9	7.5	8.1
Right Front Caster (°)	6.9	7.5	8.1
Left Front Camber (°)	-1.05	-0.45	0.15
Right Front Camber (°)	-1.05	-0.45	0.15
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.05	-0.45	0.15
Right Rear Camber (°)	-1.05	-0.45	0.015
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE4 with XFA

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7	7.6	8.2
Right Front Caster (°)	7	7.6	8.2
Left Front Camber (°)	-1.55	-0.95	-0.35
Right Front Camber (°)	-1.55	-0.95	-0.35
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.8	-1.2	-0.6
Right Rear Camber (°)	-1.8	-1.2	-0.6
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.1	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE4 with XFG

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7	7.6	8.2
Right Front Caster (°)	7	7.6	8.2
Left Front Camber (°)	-1.55	-0.95	-0.35
Right Front Camber (°)	-1.55	-0.95	-0.35
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.8	-1.2	-0.6
Right Rear Camber (°)	-1.8	-1.2	-0.6
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.1	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE4 with XFH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	6.6	7.2	7.8
Right Front Caster (°)	6.6	7.2	7.8
Left Front Camber (°)	-1.9	-1.3	-0.7
Right Front Camber (°)	-1.9	-1.3	-0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.9	-1.3	-0.7
Right Rear Camber (°)	-1.9	-1.3	-0.7
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE5 with XFG

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	7.1	7.7	8.3
Right Front Caster (°)	7.1	7.7	8.3
Left Front Camber (°)	-1.55	-0.95	-0.35
Right Front Camber (°)	-1.55	-0.95	-0.35
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.8	-1.2	-0.6

Right Rear Camber (°)	-1.8	-1.2	-0.6
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CORVETTE FE5 with XFH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	6.6	7.2	7.8
Right Front Caster (°)	6.6	7.2	7.8
Left Front Camber (°)	-1.9	-1.3	-0.7
Right Front Camber (°)	-1.9	-1.3	-0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.9	-1.3	-0.7
Right Rear Camber (°)	-1.9	-1.3	-0.7
Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE

CRUZE except XJ2 and IK9 RPO codes QOI P225/45R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.25	-0.5	0.25
Right Front Camber (°)	-1.25	-0.5	0.25

Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE except XJ2 and IK9 RPO codes QYF P225/50R17

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.25	-0.5	0.25
Right Front Camber (°)	-1.25	-0.5	0.25
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE except XJ2 and IK9 RPO codes QYW P215/60R16

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25

Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.25	-0.5	0.25
Right Front Camber (°)	-1.25	-0.5	0.25
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE IK9 RPO Restriction QOI P225/45R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.12	0.08	0.28
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE IK9 RPO Restriction QYF P225/50R17

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.12	0.08	0.28
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE IK9 RPO Restriction QYW P215/60R16

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.12	0.08	0.28
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE XJ2 RPO Restriction QOI P225/45R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.25	-0.5	0.25
Right Front Camber (°)	-1.25	-0.5	0.25
Front Toe (°)	-0.12	0.08	0.28
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

CRUZE XJ2 RPO Restriction QYF P225/50R17

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.25	-0.5	0.25
Right Front Camber (°)	-1.25	-0.5	0.25
Front Toe (°)	-0.12	0.08	0.28
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.45	-0.7
Right Rear Camber (°)	-2.2	-1.45	-0.7
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

IMPALA

IMPALA Limited RPO 9C1

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3	3.8
Right Front Caster (°)	2.2	3	3.8
Left Front Camber (°)	-1.4	-0.6	0.2
Right Front Camber (°)	-1.4	-0.6	0.2
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.7	0.1
Right Rear Camber (°)	-1.5	-0.7	0.1
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

IMPALA Limited RPO 9C3

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3	3.8
Right Front Caster (°)	2.2	3	3.8
Left Front Camber (°)	-1.4	-0.6	0.2
Right Front Camber (°)	-1.4	-0.6	0.2
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.7	0.1
Right Rear Camber (°)	-1.5	-0.7	0.1
Rear Toe (°)	-0.1	0.1	0.3

Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

IMPALA Limited RPO FE1 (LS)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	2.9	3.7
Right Front Caster (°)	2.1	2.9	3.7
Left Front Camber (°)	-1.6	-0.8	0
Right Front Camber (°)	-1.6	-0.8	0
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-0.7	0.1
Right Rear Camber (°)	-1.5	-0.7	0.1
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

IMPALA Limited RPO FE2 (LT)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	2.9	3.7
Right Front Caster (°)	2.1	2.9	3.7
Left Front Camber (°)	-1.6	-0.8	0
Right Front Camber (°)	-1.6	-0.8	0
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	-1.5	-0.7	0.1
Right Rear Camber (°)	-1.5	-0.7	0.1
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.2	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

IMPALA Limited RPO FE3 (LTZ)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.4	3.2	4
Right Front Caster (°)	2.4	3.2	4
Left Front Camber (°)	-1.5	-0.7	0.1
Right Front Camber (°)	-1.5	-0.7	0.1
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.7	-0.9	-0.1
Right Rear Camber (°)	-1.7	-0.9	-0.1
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU

MALIBU RPO 1ZH69, 1ZK69 P225/50R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4

Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU RPO QGK P235/50R18

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU RPO QPE P205/60R16

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU RPO RA8 P215/60R16

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU RPO RA9 P225/55R17

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

MALIBU RPO RP2 P245/40R19

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	3.9	4.7
Right Front Caster (°)	3.1	3.9	4.7
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.6	-0.8	0
Right Rear Camber (°)	-1.6	-0.8	0
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

ORLANDO

ORLANDO All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.65	4.4	5.15
Right Front Caster (°)	3.65	4.4	5.15
Left Front Camber (°)	-1.05	-0.3	0.45
Right Front Camber (°)	-1.05	-0.3	0.45
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.9	-1.4	-0.9
Right Rear Camber (°)	-1.9	-1.35	-0.9
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SONIC

SONIC ECO Suspension

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.8	4.55	5.3
Right Front Caster (°)	3.8	4.55	5.3
Left Front Camber (°)	-1.7	-0.95	-0.2
Right Front Camber (°)	-1.7	-0.95	-0.2
Front Toe (°)	-0.16	0.04	0.24
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-1	-0.5
Right Rear Camber (°)	-1.5	-1	-0.5
Rear Toe (°)	-0.09	0.41	0.91
Thrust Angle	0.4	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SONIC FE1 Suspension

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.65	4.4	5.15
Right Front Caster (°)	3.65	4.4	5.15
Left Front Camber (°)	-1.55	-0.8	-0.05
Right Front Camber (°)	-1.55	-0.8	-0.05
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-1	-0.5
Right Rear Camber (°)	-1.5	-1	-0.5
Rear Toe (°)	-0.1	0.4	0.9
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SONIC FE3 Suspension

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.8	4.55	5.3
Right Front Caster (°)	3.8	4.55	5.3
Left Front Camber (°)	-1.7	-0.95	-0.2
Right Front Camber (°)	-1.7	-0.95	-0.2
Front Toe (°)	-0.16	0.04	0.24
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-1	-0.5

Right Rear Camber (°)	-1.5	-1	-0.5
Rear Toe (°)	-0.09	0.41	0.91
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SONIC FE4 Suspension

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.6	4.35	5.1
Right Front Caster (°)	3.6	4.35	5.1
Left Front Camber (°)	-1.45	-0.7	0.05
Right Front Camber (°)	-1.45	-0.7	0.05
Front Toe (°)	-0.07	0.13	0.33
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.5	-1	-0.5
Right Rear Camber (°)	-1.5	-1	-0.5
Rear Toe (°)	-0.12	0.38	0.88
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SPARK

SPARK Classic

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.8	3.8	4.8
Right Front Caster (°)	2.8	3.8	4.8
Left Front Camber (°)	-0.25	0.5	1.25
Right Front Camber (°)	-0.25	0.5	1.25

Front Toe (°)	0	0.17	0.34
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2	-1.5	-1
Right Rear Camber (°)	-2	-1.5	-1
Rear Toe (°)	-0.08	0.25	0.58
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SPARK M300 Diesel

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.69	3.44	4.19
Right Front Caster (°)	2.69	3.44	4.19
Left Front Camber (°)	-0.7	0.05	0.8
Right Front Camber (°)	-0.7	0.05	0.8
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.45	-0.95
Right Rear Camber (°)	-1.95	-1.45	-0.95
Rear Toe (°)	-0.19	0.16	0.51
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SPARK M300 F

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.9	3.65	4.4

Right Front Caster (°)	2.9	3.65	4.4
Left Front Camber (°)	-1.17	-0.42	0.33
Right Front Camber (°)	-1.17	-0.42	0.33
Front Toe (°)	-0.16	0.04	0.24
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.45	-0.95
Right Rear Camber (°)	-1.95	-1.45	-0.95
Rear Toe (°)	-0.05	0.3	0.65
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SPARK M300 Gasoline

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.8	3.55	4.3
Right Front Caster (°)	2.8	3.55	4.3
Left Front Camber (°)	-0.95	-0.2	0.55
Right Front Camber (°)	-0.95	-0.2	0.55
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.95	-1.45	-0.95
Right Rear Camber (°)	-1.95	-1.45	-0.95
Rear Toe (°)	-0.11	0.24	0.59
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAX

TRAX LS/LT/LTZ (AWD) P 205/70R16 (Canada)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.75	-1	-0.25
Right Rear Camber (°)	-1.75	-1	-0.25
Rear Toe (°)	-0.2	0.2	0.6
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAX LS/LT/LTZ (AWD) P 215/55R18 (Canada)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.75	-1	-0.25
Right Rear Camber (°)	-1.75	-1	-0.25
Rear Toe (°)	-0.2	0.2	0.6
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAX LS/LT/LTZ (FWD) P 205/70R16 (Canada)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.75	-1	-0.25
Right Rear Camber (°)	-1.75	-1	-0.25
Rear Toe (°)	-0.2	0.2	0.6
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAX LS/LT/LTZ (FWD) P 215/55R18 (Canada)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.75	4.5	5.25
Right Front Caster (°)	3.75	4.5	5.25
Left Front Camber (°)	-1.35	-0.6	0.15
Right Front Camber (°)	-1.35	-0.6	0.15
Front Toe (°)	-0.04	0.16	0.36
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.75	-1	-0.25
Right Rear Camber (°)	-1.75	-1	-0.25
Rear Toe (°)	-0.2	0.2	0.6
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

UTILITY

UTILITY All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	0.91	1.66	2.41
Right Front Caster (°)	0.91	1.66	2.41
Left Front Camber (°)	-1.58	-0.83	-0.08
Right Front Camber (°)	-1.58	-0.83	-0.08
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-2.2	-1.6	-1
Right Rear Camber (°)	-2.2	-1.6	-1
Rear Toe (°)	0.09	0.29	0.49
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

VOLT

VOLT All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.6	4.4	5.2
Right Front Caster (°)	3.6	4.4	5.2
Left Front Camber (°)	-1.2	-0.4	0.4
Right Front Camber (°)	-1.2	-0.4	0.4
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	-2.2	-1.4	-0.6
Right Rear Camber (°)	-2.2	-1.4	-0.6
Rear Toe (°)	-0.25	0.15	0.55
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

AVALANCHE

AVALANCHE C/K 1500 w/ 17" Tires w/ QAS, QAN and R4Y

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	2.2	3.2	4.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

AVALANCHE C/K 1500 w/ 17" Tires w/ QGI

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2.5	3.5	4.5
Left Front Camber (°)	-0.9	-0.1	0.7

Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

AVALANCHE C/K 1500 w/ 17" Tires w/ QJP, QJM, QAN and R5C

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

AVALANCHE C/K 1500 w/ 18" Tires w/ QXK and Y91

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	2	3	4
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

AVALANCHE C/K 1500 w/ 20" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

COLORADO

COLORADO with RPO F88

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.83	3.58	4.33
Right Front Caster (°)	2.83	3.58	4.33
Left Front Camber (°)	-0.5	0	0.5
Right Front Camber (°)	-0.5	0	0.5
Front Toe (°)	-0.13	0	0.13
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

COLORADO with RPO F89

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.58	3.33	4.08
Right Front Caster (°)	2.58	3.33	4.08
Left Front Camber (°)	-0.5	0	0.5
Right Front Camber (°)	-0.5	0	0.5
Front Toe (°)	-0.13	0	0.13
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EQUINOX

EQUINOX All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.7	3.5
Right Front Caster (°)	1.9	2.7	3.5
Left Front Camber (°)	-1.3	-0.5	0.3
Right Front Camber (°)	-1.3	-0.5	0.3
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.2	-0.4	0.4
Right Rear Camber (°)	-1.2	-0.4	0.4
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS

EXPRESS AWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.9	3.9	4.9
Right Front Caster (°)	3.3	4.3	5.3
Left Front Camber (°)	-0.45	0.15	0.75
Right Front Camber (°)	-0.45	0.15	0.75
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS CARGO AWD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.9	3.9	4.9
Right Front Caster (°)	3.3	4.3	5.3
Left Front Camber (°)	-0.45	0.15	0.75
Right Front Camber (°)	-0.45	0.15	0.75
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS CARGO G10/G20 LD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3	4	5
Right Front Caster (°)	3.3	4.3	5.3
Left Front Camber (°)	-0.45	0.15	0.75
Right Front Camber (°)	-0.45	0.15	0.75
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS CARGO G20 HD/G30/G40

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.3	4.3	5.3
Right Front Caster (°)	3.7	4.7	5.7
Left Front Camber (°)	-0.35	0.25	0.85
Right Front Camber (°)	-0.35	0.25	0.85
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS G10/G20 LD

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3	4	5
Right Front Caster (°)	3.3	4.3	5.3
Left Front Camber (°)	-0.45	0.15	0.75
Right Front Camber (°)	-0.45	0.15	0.75

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

EXPRESS G20 HD/G30/G40

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.3	4.3	5.3
Right Front Caster (°)	3.7	4.7	5.7
Left Front Camber (°)	-0.35	0.25	0.85
Right Front Camber (°)	-0.35	0.25	0.85
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8") W/ QXR

Measurement	Minimum	Preferred	Maximum
-------------	---------	-----------	---------

Left Front Caster (°)	2	3	4
Right Front Caster (°)	2.2	3.2	4.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3.2	4.2
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8")
w/QNM,QPR,QPO,QBL,QJP,QJM,QXK,QU1

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8")
w/QVL,QVM,QXN,QXQ,QST,QSS,QGI,RBX

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8") w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.6	3.6	4.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Crew Cab) and Denali (1500 Crew Cab) Short Box (5' 8") w/RHG

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	4.1	5.1
Right Front Caster (°)	3.1	4.1	5.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Long Box (8' 0") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Long Box (8' 0") w/QPR,QNM,QPO,QU1

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3.2	4.2
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0

Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Long Box (8' 0") w/QST

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Long Box (8' 0") w/QXN,QVL,QVM,QXR,QGI,QSS,RBX

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3

Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Long Box (8' 0")
w/QXQ,QJP,QJM,QBL,QXK,QSS**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6' 6") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3.2	4.2

Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6' 6")
w/QNM,QPR,QPO,QBL,QJP,QJM,QXK,QU1**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6' 6")
w/QVL,QVM,QXN,QXQ,QST,QSS,QGI,RBX**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6' 6") w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.6	3.6	4.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6' 6") w/RHG

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.1	4.1	5.1
Right Front Caster (°)	3.1	4.1	5.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Regular Box (6'6") W/ QXR

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2.2	3.2	4.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Short Box (5' 8")
w/QBL,QXK,QJP,QJM,QPR,QPO,QNM,QU1**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Short Box (5' 8") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3.2	4.2
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0

Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Extended Cab) and Denali (1500 Extended Cab) Short Box (5' 8") w/QXR, QGI

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Long Box (8' 0") w/QBL,QXK,QJP,QJM,QPR,QPO,QNM,QU1

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3

Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Long Box (8' 0") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.2	3.2	4.2
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Long Box (8' 0")
w/QXQ,QVM,QXN,QVL,QSS,QST,RBX**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1

Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Long Box (8' 0") w/QXR, QGI

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Long Box (8' 0") w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.6	3.6	4.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Regular Box (6' 6") w/QMG, QMH

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1	2	3
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Regular Box (6' 6") w/QNM, QPR, QPO, QBL, QU1

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Regular Box (6' 6") w/QST

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Regular Box (6' 6")
w/QVL,QVM,QXK,QJP,QJM,QSS**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (1500 Regular Cab) and Denali (1500 Regular Cab) Regular Box (6' 6")
w/QXR,QXN,QXQ,RBX,QGI**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0

Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3

Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6

Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 2500 Regular Box (6' 6") SRW w/QXT

--	--	--	--

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Cab Chassis Wheel Base 4356.1mm (171.5in)
DRW All**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) CK 3500 Regular Box (6' 6") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3

Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Cab Chassis Wheel Base 4356.1mm (171.5in) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Diesel) Denali CK 3500 Regular Box (6' 6") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 2500 Regular Box (6'6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7

Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

**SILVERADO (2500 and 3500 Crew Cab - Gas) CK 3500 Cab Chassis Wheel Base 4356.1mm (171.5in)
DRW**

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) CK 3500 Regular Box (6' 6") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 2500 Regular Box (6'6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 3500 Cab Chassis Wheel Base 4356.1mm (171.5in) DRW

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Crew Cab - Gas) Denali CK 3500 Regular Box (6' 6") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.2	2.2	3.2
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Regular Box (6' 6") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Regular Box (6' 6") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0

Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3

Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.2	2.2	3.2
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0

Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Regular Box (6' 6") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0

Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Regular Box (6' 6") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) DRW All

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0

Right Max Turn, Outward (°)	0	-	-
-----------------------------	---	---	---

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Diesel) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0

Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0

Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Regular Box (6' 6") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Regular Box (6' 6") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6

Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 3500 Long Box (8' 0") (Box Delete) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0

Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Regular Box (6' 6") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3

Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Regular Box (6' 6") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Regular Box (6' 6") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5

Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 2500 Regular Box (6' 6") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 3500 Long Box (8' 0") (Box Off) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.7	2.7	3.7
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Extended Cab - Gas) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1	2	3
Right Front Caster (°)	0.9	1.9	2.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.1	2.1	3.1
Right Front Caster (°)	0.8	1.8	2.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Cab Chassis Wheelbase 3492.5 mm (137.5 in) DRW

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Cab Chassis Wheelbase 4124.96 mm (162.4 in) DRW

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3

Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Long Box (8' 0") DRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1	2	3
Right Front Caster (°)	0.9	1.9	2.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.1	2.1	3.1
Right Front Caster (°)	0.8	1.8	2.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0

Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Cab Chassis Wheel Base 137.5in (3492.5mm) DRW

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0

Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Cab Chassis Wheel Base 162.4 in (4125 mm) DRW

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Long Box (8' 0") DRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8

Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Diesel) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1	2	3
Right Front Caster (°)	0.9	1.9	2.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 2500 Long Box (8' 0") (Box Delete) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.1	2.1	3.1
Right Front Caster (°)	0.8	1.8	2.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0

Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Cab Chassis Wheelbase 3492.5 mm (137.5 in) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Cab Chassis Wheelbase 4124.96 mm (162.4 in) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0

Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Long Box (8' 0") (Box Delete) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Long Box (8' 0") (Box Delete) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0

Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3

Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1	2	3
Right Front Caster (°)	0.9	1.9	2.9
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 2500 Long Box (8' 0") (Box Off) SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.1	2.1	3.1
Right Front Caster (°)	0.8	1.8	2.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW W/O QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.3	2.3	3.3
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0

Right Max Turn, Outward (°)	0	-	-
-----------------------------	---	---	---

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 2500 Long Box (8' 0") SRW w/QXT

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.5	2.5	3.5
Right Front Caster (°)	1.2	2.2	3.2
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Cab Chassis Wheel Base 137.5in (3492.5mm) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.4	2.4	3.4
Right Front Caster (°)	1.4	2.4	3.4
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Cab Chassis Wheel Base 162.4 in (4125 mm) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.7	2.7	3.7
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Long Box (8' 0") (Box Off) DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.6	2.6	3.6
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0

Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Long Box (8' 0") (Box Off) SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.3	2.3	3.3
Right Front Caster (°)	1.1	2.1	3.1
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Long Box (8' 0") DRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	1.8	2.8	3.8
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SILVERADO (2500 and 3500 Regular Cab - Gas) Denali CK 3500 Long Box (8' 0") SRW All

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.6	2.6	3.6
Right Front Caster (°)	1.5	2.5	3.5
Left Front Camber (°)	-0.3	0.5	1.3
Right Front Camber (°)	-0.3	0.5	1.3
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN

SUBURBAN C/K 1500 w/ 17" Tires w/ QAS, QAN and R4Y

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	2.2	3.2	4.2
Left Front Camber (°)	-0.9	-0.1	0.7

Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 17" Tires w/ QGI

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2.5	3.5	4.5
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 17" Tires w/ QJP, QJM, QAN and R5C

Measurement	Minimum	Preferred	Maximum

Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 18" Tires Two Mode Hybrid All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 18" Tires w/ PPV (QAR)

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.85	-0.1	0.65
Right Front Camber (°)	-0.85	-0.1	0.65
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 18" Tires w/ QXK and Y91

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 20" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 22" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0

Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 1500 w/ 22" Tires Two Mode Hybrid All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

SUBURBAN C/K 2500 w/ 16" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2.3	3.3	4.3
Left Front Camber (°)	-0.6	0.2	1
Right Front Camber (°)	-0.6	0.2	1
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0

Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE

TAHOE C/K 1500 w/ 17" Tires PPV w/ QAR

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 17" Tires w/ QAS, QAN and R4Y

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.8	2.8	3.8
Right Front Caster (°)	2.2	3.2	4.2
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0

Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 17" Tires w/ QGI

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.3	3.3	4.3
Right Front Caster (°)	2.5	3.5	4.5
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 17" Tires w/ QJP, QJM, QAN and R5C

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2	3	4
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7

Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 18" Tires Two Mode Hybrid All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4
Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 18" Tires w/ QXK and Y91

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2	3	4

Right Front Caster (°)	1.9	2.9	3.9
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 20" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.1	3.1	4.1
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 22" Tires All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	-0.1	0.1	0.3
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TAHOE C/K 1500 w/ 22" Tires Two Mode Hybrid All Models

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	1.9	2.9	3.9
Right Front Caster (°)	2.1	3.1	4.1
Left Front Camber (°)	-0.9	-0.1	0.7
Right Front Camber (°)	-0.9	-0.1	0.7
Front Toe (°)	0	0.2	0.4
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0.4	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0

Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAILBLAZER

TRAILBLAZER with RPO F88

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.83	3.58	4.33
Right Front Caster (°)	2.83	3.58	4.33
Left Front Camber (°)	-0.5	0	0.5
Right Front Camber (°)	-0.5	0	0.5
Front Toe (°)	-0.13	0	0.13
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAILBLAZER with RPO F89

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	2.58	3.33	4.08
Right Front Caster (°)	2.58	3.33	4.08
Left Front Camber (°)	-0.5	0	0.5
Right Front Camber (°)	-0.5	0	0.5
Front Toe (°)	-0.13	0	0.13
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	0	0	0
Right Rear Camber (°)	0	0	0
Rear Toe (°)	0	0	0
Thrust Angle	0	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0

Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAVERSE

TRAVERSE All Models except QPR

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.9	4.7	5.5
Right Front Caster (°)	3.9	4.7	5.5
Left Front Camber (°)	-1.7	-0.9	-0.1
Right Front Camber (°)	-1.7	-0.9	-0.1
Front Toe (°)	-0.2	0	0.2
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.7	-0.9	-0.1
Right Rear Camber (°)	-1.7	-0.9	-0.1
Rear Toe (°)	-0.1	0.1	0.3
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-

TRAVERSE All Models With QPR

Measurement	Minimum	Preferred	Maximum
Left Front Caster (°)	3.9	4.7	5.5
Right Front Caster (°)	3.9	4.7	5.5
Left Front Camber (°)	-1.7	-0.9	-0.1
Right Front Camber (°)	-1.7	-0.9	-0.1
Front Toe (°)	-0.2	0	0.2
Left SAI (°)	0	0	0
Right SAI (°)	0	0	0
Left Rear Camber (°)	-1.7	-0.9	-0.1
Right Rear Camber (°)	-1.7	-0.9	-0.1

Rear Toe (°)	-0.2	0	0.2
Thrust Angle	0.3	0	0
Left Toe Out, Inward (°)	0	0	0
Right Toe Out, Inward (°)	0	0	0
Left Toe Out, Outward (°)	0	0	0
Right Toe Out, Outward (°)	0	0	0
Left Max Turn, Inward (°)	0	0	0
Right Max Turn, Inward (°)	0	0	0
Left Max Turn, Outward (°)	0	0	0
Right Max Turn, Outward (°)	0	-	-