

A

Accessories and Modifications	184
Accessories.....	184
Additional Safety Precautions..	185
Modifications	185
ACCESSORY (Ignition Key Position).....	78
Accessory Power Socket	108
Additives, Engine Oil.....	228
Airbag (SRS)	9, 43, 45
Air Cleaner Element.....	241
Air Conditioning Filter.....	252
Air Conditioning System.....	114
Maintenance.....	251
Usage	116, 121
Air Outlets (Vents).....	114
Air Pressure, Tires	253
Alarm, Anti-theft.....	156
Alcohol in Gasoline.....	316
Aluminum Wheels, Cleaning.....	275
Antifreeze	231
Anti-lock Brakes (ABS) Indicator.....	56, 199
Operation	199
Anti-theft, Audio System.....	156

Anti-theft Steering Column

Lock.....	77
Anti-theft System.....	157
Appearance Care	273
Armrest.....	89
Ashtrays.....	110
Audio Controls, Remote.....	155
Audio System	128
Automatic Climate Control System.....	114
Automatic Lighting.....	64
Automatic Seat Belt Tensioners.....	41
Automatic Speed Control.....	158
Automatic Transmission.....	192
Capacity, Fluid	312
Checking Fluid Level.....	238
Shifting.....	192
Shift Lever Position Indicator ..	192
Shift Lever Positions	192
Shift Lock Release.....	195

B

Battery	
Charging System	
Indicator.....	54, 296
Jump Starting	290
Maintenance.....	246
Specifications	313
Before Driving	177
Belts, Seat	8, 40
Beverage Holder.....	104
Body Repair.....	280
Brakes	
Anti-lock System (ABS).....	198
Break-in, New Linings	178
Bulb Replacement	266
Fluid	239
Parking.....	102
System Indicator.....	54, 299
Wear Indicators	197
Braking System.....	197
Break-in, New Car	198
Brightness Control, Instruments...	66
Brights, Headlights	63

CONTINUED



Index

Bulb Replacement	
Back-up Lights	266
Brake Lights.....	266
Ceiling Lights.....	269
Courtesy Lights	269
Fog Lights	263
Front Side Marker Lights.....	265
Headlights	262
High-mount Brake Light	267
License Plate Lights.....	268
Specifications	313
Trunk Light	270
Turn Signal Lights.....	265
Bulbs, Halogen.....	262

C

Cancel Button.....	75
Capacities Chart.....	312
Carbon Monoxide Hazard	49
Carrying, Cargo	186
Cassette Player	
Care	148
Operation.....	133, 145
CAUTION, Explanation of	ii
CD Changer	136, 149, 151

Ceiling Lights	111
Certification Label.....	310
Chains	259
Changing Oil	
How to	229
When to.....	218
Changing a Flat Tire	283
Changing Engine Coolant.....	233
Charging System Indicator ...	54, 297
Checklist, Before Driving.....	190
Child Safety	20
Child Seats.....	24
Tether Anchorage Point	39
Childproof Door Locks	82
Cigarette Lighter	109
Cleaner, Air	241
Cleaning	
Aluminum Wheels	275
Carpeting	276
Exterior	274
Fabric	276
Interior	276
Leather.....	276
Seat Belts	276
Vinyl	276
Windows	277

Wood Trim	277
Climate Control System.....	114
Clock, Setting the	102
Code, Audio System	136
CO in the Exhaust	318
Coin Box	106
Cold Weather, Starting in	191
Compact Spare	282
Console Compartment	106
Consumer Information*	324
Controls, Instruments and.....	51
Coolant	
Adding.....	231
Checking.....	182
Proper Solution	231
Replacing	233
Temperature Gauge	60
Corrosion Protection	279
Courtesy Lights	117
Crankcase Emissions Control	
System.....	318
Cruise Control Operation	158
Customer Relations Office	324

D

DANGER, Explanation of	ii
Dashboard	2, 52
Daytime Running Lights.....	65
Defects, Reporting Safety.....	327
Defogger, Rear Window	71
Defrosting the Windows.....	120, 124
Differential Oil	239
Dimensions	312
Dimming the Headlights	63
Dipstick	
Automatic Transmission.....	238
Engine Oil	181
Directional Signals.....	66
Disc Brake Wear Indicators.....	197
Disposal of Used Oil.....	230
Doors	
Locking and Unlocking.....	78
Lockout Prevention	79
Monitor Light.....	57
Power Door Locks	78
DOT Tire Quality Grading	314
Drive Belts.....	252
Driver and Passenger Safety.....	5

Driving	189
Economy	183
In Bad Weather	204
In Foreign Countries	317
Driving Position Memory	
System.....	97

E

Economy, Fuel	183
Emergencies on the Road.....	281
Battery, Jump Starting	290
Brake System Indicator	299
Changing a Flat Tire	283
Charging System Indicator	296
Checking the Fuses.....	302
Low Oil Pressure Indicator	295
Malfunction Indicator Lamp	297
Manually Closing Moonroof	300
Overheated Engine	293
Emergency Brake.....	102
Emergency Flashers	70
Emergency Towing	306
Emissions Controls.....	318
Emissions Testing,State	321

Engine	
Belts.....	252
Coolant Temperature Gauge	60
Malfunction Indicator	
Lamp	55, 297
Oil Pressure Indicator	54, 295
Oil, What Kind to Use	227
Overheating.....	293
Specifications	313
Speed Limiter	194
Starting.....	191
Engine Speed Limiter.....	194
Ethanol in Gasoline	316
Evaporative Emissions Controls..	318
Exhaust Fumes	49
Exhaust Gas Recirculation	
System.....	319
Expectant Mothers, Use of Seat	
Belts by	18
Exterior, Cleaning the	274

F

Fabric, Cleaning.....	276
-----------------------	-----

CONTINUED



Index

Fan, Interior 118, 123
 Features, Comfort and
 Convenience 113
 Filling the Fuel Tank 179
 Filters
 Air Cleaner 241
 Air Conditioning 252
 Oil 229
 Flashers, Hazard Warning 70
 Flat Tire, Changing a 283
 Fluids
 Automatic Transmission 238
 Brake 239
 Differential 239
 Power Steering 240
 Windshield Washer 237
 FM Stereo Radio
 Reception 129, 139
 Fog Lights 67
 Foreign Countries, Driving in 317
 Four-way Flashers 70
 Front Airbags 9, 43
 Fuel 178
 Fill Door and Cap 179
 Gauge 60
 Octane Requirement 178

Oxygenated 316
 Reserve Indicator 57
 Tank, Filling the 179
 Fuel Mileage, Improving 183
 Fuses, Checking the 302

G

Gasohol 316
 Gasoline 178
 Fuel Reserve Indicator 57
 Gauge 60
 Octane Requirement 178
 Tank, Filling the 179
 Gas Station Procedures 179
 Gauges 58
 Engine Coolant Temperature ... 60
 Fuel 60
 Speedometer 58
 Tachometer 58
 GAWR (Gross Axle Weight
 Rating) 207
 Gearshift Lever Positions 192
 Glass Cleaning 278
 Glove Box 88

GVWR (Gross Vehicle Weight
 Rating) 207

H

Halogen Headlight Bulbs 262
 Hazard Warning Flashers 70
 Headlights
 Automatic Lighting 64
 Daytime Running Lights 65
 High Beam Indicator 57
 Lights On Indicator 55
 Reminder Chime 63
 Replacing Halogen Bulbs 262
 Turning on 63
 Head Restraints 88
 Heating and Cooling 114
 High Altitude, Starting at 191
 High-Low Beam Switch 63
 High-mount Brake Light 267
 HomeLink Universal
 Transmitter 162
 Hood Latch 241
 Hood, Opening the 180
 Horn 62
 Hydroplaning 205

I

Identification Number, Vehicle....	310
Ignition	
Keys.....	74
Switch.....	77
Timing Control System.....	319
Immobilizer System.....	75
Important Safety Precautions	6
Indicators, Instrument	
Panel.....	53
Infant Restraint	28
Infant Seats.....	28
Tether Anchorage Points	39
Inflation, Proper Tire	253
Inside Mirror	91
Inspection, Tire	255
Instrument Panel	53
Instrument Panel Brightness	66
Interior Cleaning.....	277
Introduction	i

J

Jacking up the Car	284
Jack, Tire	284

Jump Starting	290
---------------------	-----

K

Keys.....	74
-----------	----

L

Label, Certification	310
Lane Change, Signaling	66
Lap/Shoulder Belt.....	40
Learning Key.....	75
Leather, Cleaning	276
Lights On Indicator	55
Lighter, Cigarette	109
Lights	
Bulb Replacement	262
Ceiling	111
Courtesy.....	112
Indicator.....	53
Parking.....	63
Turn Signal	66
Load Limit	187
LOCK (Ignition Key Position)	77
Locks	
Anti-theft Steering Column	77

Childproof Door.....	82
Fuel Fill Door	179
Glove Box	85
Power Door	78
Trunk	83
Trunk Pass-through Cover.....	90
Low Coolant Level.....	182
Low Fuel Indicator	57
Low Oil Pressure Indicator ...	54, 295
Lubricant Specifications	
Chart	312
Luggage	186

M

Maintenance	213
Owner Maintenance Checks....	225
Record.....	223-224
Required Indicator.....	61
Safety.....	214
Schedule	218-222
Malfunction Indicator Lamp ..	55, 297
Memory, Driving Position	93
Meters, Gauges.....	58

CONTINUED



Index

Methanol in Gasoline	316
Mirrors, Adjusting	91
Moonroof	100
Closing Manually	300
Operation	100

N

Neutral Gear Position.....	193
New Vehicle Break-in	178
NOTICE, Explanation of.....	i
Numbers, Identification	310

O

Octane Requirement, Gasoline	178
Odometer.....	59
Odometer, Trip	59
Oil	
Change, How to	229
Change, When to	218
Checking Engine	181
Pressure Indicator	54, 295
Selecting Proper Viscosity	
Chart	228
ON (Ignition Key Position)	80

Onboard Refueling Vapor	
Recovery	310
OnStar	167
Opening the Trunk	83
Operation in Foreign Countries..	317
Outside Mirrors	91
Outside Temperature Indicator	59
Overheating, Engine	293
Owner Maintenance Checks.....	225
Oxygenated Fuels.....	316

P

Paint Touch-up	275
Panel Brightness Control	66
Park Gear Position.....	193
Parking	196
Parking Brake	106
Parking Brake and Brake	
System Indicator	54, 299
Parking Lights.....	63
Parking Over Things that Burn...	320
PGM-FI System.....	319
Polishing and Waxing	275
Pre-Drive Safety Checklist	11
Pregnancy, Using Seat Belts	18

Protecting Adults.....	12
Additional Safety Precautions....	19
Advice for Pregnant Women.....	18
Protecting Children	20
Protecting Infants	28
Protecting Larger Children	35
Protecting Small Children	32
Using Child Seats with	
Tethers.....	39

R

Radiator Overheating.....	293
Radio/Cassette Sound System	128
Readiness Codes.....	298
Rear Lights, Bulb Replacement ..	264
Rear Seat Armrest	90
Rear Ventilation	126
Rear View Mirror.....	91
Rear Window Defogger	71
Reclining the Seat Backs	87
Reminder Lights	53
Remote Transmitter	79
Replacement Information	
Air Cleaner Element.....	241
Air Conditioning Filter.....	252



Engine Coolant.....	233
Engine Oil and Filter	229
Fuses	302
Light Bulbs	262
Schedule	216
Spark Plugs.....	243
Tires	257
Wiper Blades	249
Replacing Seat Belts After a Crash	42
Reserve Tank, Engine Coolant	182
Reverse Gear Position.....	193
Rotation, Tire	256

S

Safety Belts.....	8
Safety Defects, Reporting*	327
Safety Features	7
Airbags.....	9
Door Locks	10
Head Restraints	10
Seat Belts	8
Seats & Seat-Backs.....	10
Safety Labels, Location of	50
Safety Messages	ii

Seat Belts	8, 40
Additional Information.....	40
Advice for Pregnant Women.....	18
Automatic Seat Belt Tensioner..	41
Child Seat Anchor Plate.....	39
Cleaning.....	277
Lap/Shoulder Belt.....	40
Maintenance	42
Reminder Light and Beeper.....	40, 54
Replacement.....	42
System Components.....	40
Use During Pregnancy.....	18
Wearing a Lap/Shoulder Belt....	15
Seat Heaters	95
Seat Position Memory	93
Seats, Adjusting the.....	86
Security Alarm System	157
Serial Number	310
Service Intervals	218
Service Manual*	329
Service Station Procedures	179
Setting the Clock	102
Shifting the Automatic Transmission.....	192
Shift Lever Position Indicator	192

Shift Lock Release.....	195
Side Airbags	45
How The Side Airbag Indicator Light Works	47
How Your Side Airbags Work....	45
Side Marker Lights, Bulb Replacement in	265
Signaling Turns	66
Ski Sleeve	96
Snow Tires.....	259
Solvent-type Cleaners.....	274
Sound System.....	128
Spare Tire Inflating.....	282
Specifications	313
Spark Plugs, Replacing	243
Specifications Charts.....	312
Speed Control.....	158
Speedometer	58
Spotlights	111

CONTINUED



Index

SRS, Additional Information..... 43
 Additional Safety Precautions.... 48
 Automatic Seat Belt
 Tensioners 41
 How the SRS Indicator Works ... 46
 How Your Airbags Work 43, 45
 SRS Components 43
 SRS Service..... 48
 SRS Indicator..... 46, 55
 START (Ignition Key Position) 77
 Starting the Engine..... 191
 In Cold Weather at High
 Altitude 191
 With a Dead Battery 290
 State Emissions Testing 322
 Steam Coming from Engine..... 293
 Steering Wheel
 Adjustments 71
 Anti-theft Column Lock 77
 Position Memory 93
 Stereo Sound System 128
 Storing Your Car..... 271
 Sun Visor..... 107
 Sunglasses Holder 107

Supplemental Restraint
 System..... 9, 43, 45
 Service Precautions 48
 Servicing 48
 SRS Indicator..... 46, 55
 System Components..... 43
 Tensioners, Seat Belts 41
 Synthetic Oil..... 228

T

Tachometer 58
 Taillights, Changing Bulbs in..... 266
 Taking Care of the Unexpected .. 281
 Tape Player 133, 148
 Technical Descriptions
 DOT Tire Quality Grading 314
 Emissions Control Systems..... 318
 Oxygenated Fuels..... 316
 Three Way Catalytic
 Converter..... 320
 Temperature Gauge 60
 Tensioners, Seat Belts 41
 Tether Anchorage Points 39
 Theft Deterrent System..... 157
 Theft Protection..... 156

Three Way Catalytic Converter... 320
 Time, Setting the 102
 Timing Belt..... 253
 Tire Chains 259
 Tire, How to Change a Flat 283
 Tires 253
 Air Pressure 254
 Balancing 256
 Checking Wear 255
 Compact Spare..... 282
 DOT Tire Quality Grading..... 314
 Inflation..... 253
 Inspection 255
 Maintenance..... 256
 Replacing 257
 Rotating..... 256
 Snow 259
 Specifications 313
 Tools, Tire Changing 283
 Torn Seat Belts 42
 Towing
 A Trailer..... 206
 By Emergency Wrecker 306
 Transmission
 Checking Fluid Level,
 Automatic 238

Fluid Selection.....	238
Identification Number.....	311
Shifting the Automatic.....	192
Treadwear	314
Trip Meter	59
Trunk.....	83
Emergency Trunk Opener	84
Opening the	83
Open Monitor Light	57
Turn Signals	66

U

Underside, Cleaning	279
Unexpected, Taking Care of the	281
Uniform Tire Quality Grading	314
Unleaded Gasoline.....	178
Upholstery Cleaning.....	277
Used Oil, How to Dispose of	230

V

Vanity Mirror	107
Vehicle Capacity Load	187
Vehicle Dimensions.....	312

Vehicle Identification Number.....	310
Vehicle Stability Assist (VSA) System.....	201
VSA System Indicator	56, 202
VSA Activation Indicator ...	56, 201
VSA Off Switch	202
Vehicle Storage	271
Ventilation	116
VIN	310
Vinyl Cleaning.....	277
Viscosity, Oil.....	228

W

WARNING, Explanation of	ii
Warning Labels, Location of	50
Warranty Coverages*	326
Washer, Windshield Checking the Fluid Level	237
Operation	70
Washing	274
Waxing and Polishing	275
Wheels Adjusting the Steering	71
Alignment and Balance	256
Cleaning Aluminum Alloys.....	275

Compact Spare	282
Wrench	284
Windows Cleaning	277
Operating the Power	98
Rear, Defogger	71
Windshield Cleaning	68
Defroster	120, 125
Washers	70
Wipers, Windshield Changing Blades.....	249
Operation	68
Wood Trim	277
Worn Tires	255
Wrecker, Emergency Towing.....	306

* U.S. and Canada only