



System Start-up

When you turn the ignition switch to ON (II), it takes several seconds before the Navigation System turns on the display.

The first display is the Acura Navigation System Logo. This remains for several seconds, then changes to display the disclaimer shown on the right. Read this disclaimer carefully so you understand it.

To use the system, either push in on the Joystick, or touch the "OK" box on the screen. The Main Menu will come on the display.

If you do not press the joystick or touch "OK", the screen will go dark after 30 seconds. If you are not planning to use the Navigation System at this time, touch the SHUT DOWN box on the display. To return to the disclaimer, press any button.

This system provides route information to help you reach your destination.

Due to road conditions some recommendations may not be appropriate.

Always obey all traffic laws and exercise your own good judgement.

For safety, program the system while the car is stopped.

See your Owner's Manual for complete instructions.

OK Setup 1 : 00

Touching the time display while the screen is dark enlarges the time display. Touch the time display again to return it to its normal size.

If you leave the ignition switch in Accessory (I) or ON (II) without starting the engine, and do not perform any operations on the system, it will automatically turn off after five minutes.

If you are entering information into the system, it will not turn off in five minutes. This allows you to enter in a destination before starting the engine and driving away.